Generalized Interpolation Material Point (GIMP) Method

John Nairn

May 20, 2016

1 Introduction

These notes provide a detailed derivation of the GIMP method for MPM, which was first described by Bardenhagen and Kober. The notes pay attention to large deformation and give extensions to axisymmetry. Finally, GIMP methods for implementing transport equations are derived.

2 Virtual Work or Power

Let δu be a virtual displacement. Virtual work (or power) gives the following starting equation:

$$\int_{V} \rho \, \boldsymbol{b} \cdot \delta \boldsymbol{u} \, dV + \int_{S_{T}} \boldsymbol{T} \cdot \delta \boldsymbol{u} \, dS + \sum_{p} \boldsymbol{F_{p}} \cdot \delta \boldsymbol{u} = \int_{V} \rho \, \boldsymbol{a} \cdot \delta \boldsymbol{u} \, dV + \int_{V} \boldsymbol{\sigma} \cdot \nabla \delta \boldsymbol{u} \, dV$$
 (1)

where b is specific body force (e.g., gravity), T is traction applied on the surface S_T , F_p is a force applied directly to a particle (an extra turn added for MPM modeling), a is acceleration, ρ is density, and σ is the Cauchy stress.

3 Particle Basis Expansion

First, we expand ρb , ρa , and σ in a particle basis, where any function of x is written as:

$$f(\mathbf{x}) = \sum_{p} f_p \chi_p(\mathbf{x}) \tag{2}$$

where f_p is the value of the function on particle p and $\chi_p(x)$ is a particle basis function. The function integrates to total particle volume:

$$V_p = \int_V \chi_p(\mathbf{x}) \, dV \tag{3}$$

The most common function is for $\chi_p(x) = 1$ inside the particle domain and 0 outside the domain, but any other function could be used (hence the using of the term "Generalized"). The main particle property expansions are:

$$\rho \mathbf{b} = \sum_{p} \rho_{p} \mathbf{b}_{p} \chi_{p}(\mathbf{x}) = \sum_{p} \frac{m_{p}}{V_{p}} \mathbf{b}_{p} \chi_{p}(\mathbf{x})$$
 (4)

$$\rho a = \sum_{p} \frac{m_p}{V_p} \frac{dv_p}{dt} \chi_p(x) = \sum_{p} \frac{\dot{p}_p}{V_p} \chi_p(x)$$
 (5)

$$\sigma = \sum_{p} \sigma_{p} \chi_{p}(x) \tag{6}$$

where m_p is particle mass, V_p is current particle volume, v_p is particle velocity, p_p is particle momentum, and σ_p is particle stress.

To fit better in the analysis, the external work caused by particle forces can be expanded as work per unit volume spread out over the particle using

$$F_{p} \cdot \delta u = \int_{V} \frac{F_{p} \cdot \delta u}{V_{p}} \chi_{F}(x) dV$$
 (7)

where $\chi_F(x)$ is another particle function. It need not be the same as $\chi_p(x)$, but must also integrate to particle volume, V_p

The new virtual work equation becomes:

$$\sum_{p} \int_{V} \frac{m_{p}}{V_{p}} \chi_{p}(\mathbf{x}) \mathbf{b}_{p} \cdot \delta \mathbf{u} \, dV + \int_{S_{T}} \mathbf{T} \cdot \delta \mathbf{u} \, dS + \sum_{p} \frac{\mathbf{F}_{p}}{V_{p}} \int_{V} \chi_{F}(\mathbf{x}) \cdot \delta \mathbf{u} \, dV$$
 (8)

$$= \sum_{p} \int_{V} \frac{\dot{p}_{p}}{V_{p}} \chi_{p}(\mathbf{x}) \cdot \delta \mathbf{u} \, dV + \sum_{p} \int_{V} \boldsymbol{\sigma}_{p} \chi_{p}(\mathbf{x}) \cdot \nabla \delta \mathbf{u} \, dV$$
 (9)

4 Grid Expansion

Next, we expand the virtual displacements in grid-based shape functions using:

$$\delta u = \sum_{i} \delta u_{i} N_{i}(x) \tag{10}$$

where the sum is over nodes (*i*), δu_i is the virtual displacement on node *i*, and $N_i(x)$ are the nodal shape functions (standard finite element shape functions). Each term is revised as follows:

$$\sum_{i} \sum_{p} \int_{V} \frac{m_{p}}{V_{p}} \chi_{p}(\mathbf{x}) \mathbf{b}_{p} \cdot \delta \mathbf{u}_{i} N_{i}(\mathbf{x}) dV = \sum_{i} \sum_{p} S_{ip} m_{p} \mathbf{b}_{p} \cdot \delta \mathbf{u}_{i}$$
(11)

$$\int_{S_T} T \cdot \delta u = \sum_i \delta u_i \cdot \int_{S_T} N_i(x) T \, dS \tag{12}$$

$$\sum_{i} \sum_{p} \frac{F_{p}}{V_{p}} \int_{V} \chi_{F}(\mathbf{x}) \cdot \delta \mathbf{u}_{i} N_{i}(\mathbf{x}) dV = \sum_{i} \sum_{p} F_{ip} F_{p} \cdot \delta \mathbf{u}_{i}$$
 (13)

$$\sum_{i} \sum_{p} \int_{V} \frac{\dot{p}_{p}}{V_{p}} \chi_{p}(\mathbf{x}) \cdot \delta \mathbf{u}_{i} N_{i}(\mathbf{x}) dV = \sum_{i} \sum_{p} S_{ip} \dot{p}_{p} \cdot \delta \mathbf{u}_{i}$$
(14)

$$\sum_{i} \sum_{p} \int_{V} \boldsymbol{\sigma}_{p} \chi_{p}(\boldsymbol{x}) \cdot \delta \boldsymbol{u}_{i} \nabla N_{i}(\boldsymbol{x}) dV = \sum_{i} \sum_{p} (V_{p} \boldsymbol{\sigma}_{p} \boldsymbol{G}_{ip}) \cdot \delta \boldsymbol{u}_{i}$$
 (15)

where the GIMP shape functions are:

$$S_{ip} = \frac{1}{V_p} \int_V \chi_p(\mathbf{x}) N_i(\mathbf{x}) dV$$
 (16)

$$F_{ip} = \frac{1}{V_p} \int_V \chi_F(\mathbf{x}) N_i(\mathbf{x}) \, dV \tag{17}$$

$$G_{ip} = \frac{1}{V_p} \int_{V} \chi_p(\mathbf{x}) \nabla N_i(\mathbf{x}) dV$$
 (18)

Two logical choices for $\chi_F(x)$ are $\chi_F(x) = \chi_p(x)$, which leads to $F_{ip} = S_{ip}$ (and is the choice used below), or $\chi_F(x) = V_p \delta(x - x_p)$, which leads to $F_{ip} = N_i(x_p)$

The particle stress term can be revised to use particle mass as follows:

$$V_p \sigma_p = m_p \frac{\sigma_p}{\rho_p} = m_p \frac{\sigma_p}{\rho_p} \frac{\rho_0}{\rho_0} = m_p \frac{J\sigma_p}{\rho_0} = m_p \frac{\tau}{\rho_0}$$
(19)

Here $J=V_p/V_0=\rho_0/\rho_p$ is the relative volume and τ is the Kirchhoff stress. In this form the stress term depends most naturally on Kirchhoff stresses normalized to initial density (and this approach avoids the need to find current particle density or volume when calculating that term on each time step). For this reason, NairnMPM always tracks stress as τ/ρ_0 (and all material models are expected to calculate this stress). When archiving stress, NairnMPM writes Cauchy stress using $\sigma_p=(\rho_0/J)*(\tau/\rho_0)$. Note that when doing energy calculations that $\tau \cdot \mathrm{du}$, where du is incremental deformation gradient, is energy per unit initial volume and therefore the energy calculated in code using $(\tau/\rho_0) \cdot \mathrm{du}$ is energy per unit mass or $dU/(\rho_0 V_0)$.

5 MPM Equations

Making use of the fact that δu_i is arbitrary, the summand of all terms can be equated to arrive at the controlling MPM equation on the background grid of:

$$\sum_{p} S_{ip}^{(n)} \frac{dp_{p}^{(n)}}{dt} = \frac{dp_{i}^{(n)}}{dt} = f_{i}^{(n)} + f_{i,T}^{(n)}$$
(20)

where

$$f_{i}^{(n)} = \sum_{p} \left(-m_{p} \frac{\tau_{p}^{(n)} \cdot G_{ip}^{(n)}}{\rho_{0}} + m_{p} S_{ip}^{(n)} \boldsymbol{b}_{p} + \boldsymbol{F}_{p}^{(n)} S_{ip}^{(n)} \right)$$
(21)

$$f_{i,T}^{(n)} = \int_{S_T} N_i(\mathbf{x}) T \, dS \tag{22}$$

where superscript (n) has been added to mean terms calculated from the state of all particles at the start of time step n. Commonly the body force, \boldsymbol{b}_p , will be independent of the particle state (e.g., gravity, which is a constant, or a general body force that depends only on nodal position and time and not on particle state). When that holds, it can be removed from the sum. The total internal force then becomes

$$f_{i}^{(n)} = \sum_{p} \left(-m_{p} \frac{\tau_{p}^{(n)} \cdot G_{ip}^{(n)}}{\rho_{0}} + F_{p}^{(n)} S_{ip}^{(n)} \right) + m_{i}^{(n)} b(x_{i}, t)$$
(23)

where $b(x_i, t)$ is body force at the nodal location and

$$m_i^{(n)} = \sum_p m_p S_{ip}^{(n)} \tag{24}$$

is total nodal mass.

Once the forces are found, the momentum can be updated on the grid using

$$\mathbf{p}_{i}^{(n+1)} = \mathbf{p}_{i}^{(n)} + (\mathbf{f}_{i}^{(n)} + \mathbf{f}_{i,T}^{(n)})\Delta t$$
 (25)

where Δt is the time step and:

$$\mathbf{p}_{i}^{(n)} = \sum_{p} \mathbf{p}_{p}^{(n)} S_{ip}^{(n)} \tag{26}$$

5.1 Velocity Approach to Strain and Particle Updates

5.1.1 Incremental Displacement Gradient

For particle stress and strain updates, the algorithm needs to evaluate the spatial velocity gradient, $\nabla v(x,t)$, and use that to find the incremental deformation gradient, dF, defined by

$$dF^{(n)} = \exp(\nabla \nu \Delta t) \tag{27}$$

which assumes ∇v is constant over the time step. The gradient is found by extrapolating spatial velocity on the grid:

$$\nabla \mathbf{v} = \sum_{i} \mathbf{v}_{i}^{(n)} \otimes \mathbf{G}_{ip} \tag{28}$$

and the spatial velocity is found from

$$v_i^{(n)} = \frac{p_i^{(n)}}{m_i^{(n)}} \tag{29}$$

This velocity gradient is used to update stresses and strains on the particles. It can be done at the beginning of the time step (using $v_i^{(n)}$) or at the end of the time step using the updated grid velocity $(v_i^{(n+1)})$. NairnMPM allows either of the options and adds a third option to update both at the beginning and at the end. This later method (which is default method called USAVG) is analogous to a midpoint rule integration. Although it is less efficient (due to two updates), it may provide improved convergence as a function of time step size.

5.1.2 Particle Updates with Damping

In each time step, the Eulerian update on the grid is used to update the Lagrangian velocities and positions on the particles, and it is useful to include damping options in both the grid and particle updates. Two global damping strategies are to add damping terms proportional to either the grid velocity or the particle velocity. In most cases, these two approaches to damping should have similar results. By including them both, however, it is possible to propose several different types of damping schemes. The fact that MPM has two velocities (grid and particle velocity), is the reason MPM has some interesting damping options.

If damping is based on grid velocity, then the nodal momentum update changes to a damped acceleration or:

$$p_i^{*(n+1)} = p_i^{(n)} + m_i^{(n)} (\boldsymbol{a}_i^{(n)} - \alpha_g(t) \boldsymbol{v}_i^{(n)}) \Delta t = p_i^{(n)} + m_i^{(n)} \boldsymbol{a}_i^{*(n)} \Delta t$$
(30)

where "*" indicates a term that is revised to include damping, where $\alpha_g(t)$ is the grid damping constant (with units 1/sec) that applies to all nodes (i.e., independent of x_i), but may evolve in time (such as a kinetic energy thermostat). See below for how to deal with position-dependent damping.

Particle methods have historically tried two methods for updating particle velocity — a FLIP update that increments particle velocity using accelerations extrapolated to the grid and a PIC update that extrapolates velocity directly to the particle. Combining the grid damping above with a second particle damping constant, $\alpha_n(t)$, these two updates become:

$$\mathbf{v}_{p,FLIP}^{(n+1)} = \mathbf{v}_{p}^{(n)} + \mathbf{a}_{g \to p}^{**(n)} \Delta t
\mathbf{v}_{p,PIC}^{(n+1)} = \mathbf{v}_{g \to p}^{(n)} + \mathbf{a}_{g \to p}^{**(n)} \Delta t = \mathbf{v}_{g \to p}^{*(n+1)} - \alpha_{p}(t) \mathbf{v}_{p}^{(n)} \Delta t$$
(31)

$$\mathbf{v}_{p,PIC}^{(n+1)} = \mathbf{v}_{g\to p}^{(n)} + \mathbf{a}_{g\to p}^{**(n)} \Delta t = \mathbf{v}_{g\to p}^{*(n+1)} - \alpha_p(t) \mathbf{v}_p^{(n)} \Delta t$$
 (32)

where $a_{g \to p}^{**(n)}$ is a doubly-damped acceleration extrapolated to the particle (i.e., subscript $g \to p$ means extrapolation from the grid to the particles):

$$a_{g \to p}^{**(n)} = a_{g \to p}^{*(n)} - \alpha_p(t) v_p^{(n)} = a_{g \to p}^{(n)} - \alpha_g(t) v_{g \to p}^{(n)} - \alpha_p(t) v_p^{(n)}$$
(33)

and the needed extrapolations to the particle are:

$$a_{g \to p}^{*(n)} = \sum_{i} a_{i}^{*(n)} S_{ip}^{(n)}, \quad a_{g \to p}^{(n)} = \sum_{i} \frac{f_{i}^{(n)} + f_{i,T}^{(n)}}{m_{i}^{(n)}} S_{ip}^{(n)}, \quad \text{and} \quad v_{g \to p}^{(n)} = \sum_{i} v_{i}^{(n)} S_{ip}^{(n)}$$
 (34)

The extrapolated velocities are

$$\mathbf{v}_{g\to p}^{*(n+1)} = \sum_{i} \frac{\mathbf{p}_{i}^{*(n+1)}}{m_{i}^{(n)}} S_{ip}^{(n)} = \mathbf{v}_{g\to p}^{(n+1)} - \alpha_{g}(t) \mathbf{v}_{g\to p}^{(n)} \Delta t = \mathbf{v}_{g\to p}^{(n)} + \mathbf{a}_{g\to p}^{*(n)} \Delta t$$
(35)

$$\mathbf{v}_{g \to p}^{(n+1)} = \sum_{i} \left(\frac{\mathbf{p}_{i}^{(n)}}{m_{i}^{(n)}} + \frac{\mathbf{f}_{i}^{(n)} + \mathbf{f}_{i,T}^{(n)}}{m_{i}^{(n)}} \Delta t \right) S_{ip}^{(n)} = \mathbf{v}_{g \to p}^{(n)} + \mathbf{a}_{g \to p}^{(n)} \Delta t$$
(36)

Both damping strategies can be done entirely within the particle update. The two methods can be used individually or combined. Because grid and particle velocities should be similar, the total damping constant is $\alpha(t) = \alpha_g(t) + \alpha_p(t)$. In the absence of damping $(\alpha(t) = \alpha_g(t) = 0)$, the FLIP and PIC updates and the simpler form often presented in the literature:

$$\mathbf{v}_{p,FLIP}^{(n+1)} = \mathbf{v}_{p}^{(n)} + \mathbf{a}_{g \to p}^{(n)} \Delta t
\mathbf{v}_{p,PIC}^{(n+1)} = \mathbf{v}_{g \to p}^{(n+1)}$$
(37)

$$v_{p,PIC}^{(n+1)} = v_{g \to p}^{(n+1)} \tag{38}$$

The results above extend these updates for two types of damping (grid or particle damping).

Next, the MPM position update with damping is found by integrating the extrapolated velocity over the time step. This integration is done on the grid and therefore should use the PIC form of velocity (i.e., the grid velocity). Integrating using the midpoint rule:

$$\mathbf{x}_{p}^{(n+1)} = \mathbf{x}_{p}^{(n)} + \int_{0}^{\Delta t} \mathbf{v}_{p,PIC}^{(n+1)}(\Delta t = t) dt \approx \mathbf{x}_{p}^{(n)} + \frac{1}{2} \left(\mathbf{v}_{g \to p}^{(n)} + \mathbf{v}_{p,PIC}^{(n+1)} \right) \Delta t$$
 (39)

$$= x_p^{(n)} + v_{g \to p}^{(n)} \Delta t + \frac{1}{2} a_{g \to p}^{**(n)} (\Delta t)^2$$
(40)

This update along with the FLIP velocity update (which is usually recommended due to its conservation of momentum properties) can be written using terms convenient for coding (i.e., $v_{g\to p}^{*(n+1)}$ and $a_{g\to p}^{*(n)}$) as:

$$\mathbf{x}_{p}^{(n+1)} = \mathbf{x}_{p}^{(n)} + \mathbf{v}_{g \to p}^{*(n+1)} \Delta t - \frac{1}{2} (\mathbf{a}_{g \to p}^{*(n)} + \alpha_{p}(t) \mathbf{v}_{p}^{(n)}) (\Delta t)^{2}$$
(41)

$$\mathbf{v}_{p}^{(n+1)} = \mathbf{v}_{p}^{(n)} + \left(\mathbf{a}_{g \to p}^{*(n)} - \alpha_{p}(t)\mathbf{v}_{p}^{(n)}\right) \Delta t \tag{42}$$

These are the updates always used by NairnMPM.

It is interesting to redefine the grid and particle damping terms using:

$$\alpha_g(t) \to -\frac{1-\beta}{\Delta t} + \alpha_g' \quad \text{and} \quad \alpha_p(t) \to \frac{1-\beta}{\Delta t} + \alpha_p'$$
 (43)

The time dependence of primed damping terms have been dropped, but they can all still depend on time. By unraveling all effective terms, the net updates become

$$\boldsymbol{x}_{p}^{(n+1)} = \boldsymbol{x}_{p}^{(n)} + \boldsymbol{v}_{g \to p}^{(n+1)} \Delta t - \frac{1}{2} (\boldsymbol{a}_{g \to p}^{(n)} + \alpha_{PIC}(\beta) (\boldsymbol{v}_{p}^{(n)} - \boldsymbol{v}_{g \to p}^{(n)}) + \alpha_{g}' \boldsymbol{v}_{g \to p}^{(n)} + \alpha_{p}' \boldsymbol{v}_{p}^{(n)}) (\Delta t)^{2}$$
(44)

$$\mathbf{v}_{p}^{(n+1)} = \mathbf{v}_{p}^{(n)} + \left(\mathbf{a}_{g \to p}^{(n)} - \alpha_{PIC}(\beta) \left(\mathbf{v}_{p}^{(n)} - \mathbf{v}_{g \to p}^{(n)}\right) - \alpha_{g}' \mathbf{v}_{g \to p}^{(n)} - \alpha_{p}' \mathbf{v}_{p}^{(n)}\right) \Delta t \tag{45}$$

where the new "PIC Damping" term is

$$\alpha_{PIC}(\beta) = \frac{1 - \beta}{\Delta t} \tag{46}$$

It is called PIC damping, because in the absence of other damping terms ($\alpha_g' = \alpha_p' = 0$), the still-damped position and velocity updates become:

$$\mathbf{x}_{p}^{(n+1)} = \mathbf{x}_{p}^{(n)} + \left(\mathbf{v}_{g \to p}^{(n+1)} - \frac{1-\beta}{2} \left(\mathbf{v}_{p}^{(n)} - \mathbf{v}_{g \to p}^{(n)}\right)\right) \Delta t - \frac{1}{2} \mathbf{a}_{g \to p}^{(n)} (\Delta t)^{2}$$
(47)

$$\mathbf{v}_{p}^{(n+1)} = \mathbf{v}_{p}^{(n)} - (1 - \beta) \left(\mathbf{v}_{p}^{(n)} - \mathbf{v}_{g \to p}^{(n)} \right) + \mathbf{a}_{g \to p}^{(n)} \Delta t$$
 (48)

If $\beta = 1$, the update is an undamped FLIP update. If $\beta = 0$, the update is an undamped, PIC update. Thus β can be interpreted as the fraction FLIP in the velocity update. But the above analysis was formally all a FLIP analysis. A better interpretation is that β adds an new form of artificial damping that is proportional to the inversion error between the particle velocity and the grid velocity extrapolated to the particle $(v_p^{(n)} - v_{g \to p}^{(n)})$. The net damping effect will be to damp out this error.

5.1.3 **Some Implementation Details**

There are two approaches to coding updates with damping. First, it can be done entirely within the particle update task. The input to this task from the nodes will be $p_i^{(n+1)}$ (which will have replaced $p_i^{(n)}$ in the momentum update), $f_i^{(n)} + f_{i,T}^{(n)}$, and $m_i^{(n)}$. We can define two new effective terms

$$a_{g \to p}^{(n)'} = a_{g \to p}^{(n)} - \alpha_{PIC}(\beta) (\mathbf{v}_{p}^{(n)} - \mathbf{v}_{g \to p}^{(n)}) - \alpha_{g}' \mathbf{v}_{g \to p}^{(n)} - \alpha_{p}' \mathbf{v}_{p}^{(n)}$$

$$= a_{g \to p}^{(n)} - \alpha_{g}(t) \mathbf{v}_{g \to p}^{(n)} - \alpha_{p}(t) \mathbf{v}_{p}^{(n)}$$
(50)

$$= a_{g \to p}^{(n)} - \alpha_g(t) v_{g \to p}^{(n)} - \alpha_p(t) v_p^{(n)}$$
(50)

$$\mathbf{v}_{g \to p}^{(n+1)'} = \mathbf{v}_{g \to p}^{(n+1)} - \left(\alpha_{PIC}(\beta) \left(\mathbf{v}_{p}^{(n)} - \mathbf{v}_{g \to p}^{(n)}\right) + \alpha_{g}' \mathbf{v}_{g \to p}^{(n)} + \alpha_{p}' \mathbf{v}_{p}^{(n)}\right) \Delta t$$
 (51)

$$= v_{g \to p}^{(n+1)} - \left(\alpha_g(t)v_{g \to p}^{(n)} + \alpha_p(t)v_p^{(n)}\right) \Delta t$$
 (52)

where $v_{g\to p}^{(n)}$ is found from available input properties using

$$\mathbf{v}_{g \to p}^{(n)} = \mathbf{v}_{g \to p}^{(n+1)} - \mathbf{a}_{g \to p}^{(n)} \Delta t \tag{53}$$

The final updates become

$$\mathbf{x}_{p}^{(n+1)} = \mathbf{x}_{p}^{(n)} + \mathbf{v}_{g \to p}^{(n+1)'} \Delta t - \frac{1}{2} \mathbf{a}_{g \to p}^{(n)'} (\Delta t)^{2}$$
 (54)

$$\mathbf{v}_{p}^{(n+1)} = \mathbf{v}_{p}^{(n)} + \mathbf{a}_{g \to p}^{(n)'} \Delta t$$
 (55)

which are standard position and velocity updates to second order in position. Notice that it was important to keep the second order term on the position update in order to end up with consistent definitions for extrapolated velocity and acceleration.

In NairnMPM, the grid damping is added in the update particles task, but the particle damping is not added until calling the material point class. Separating them out gives

$$\mathbf{x}_{p}^{(n+1)} = \mathbf{x}_{p}^{(n)} + (\mathbf{v}_{*} - \alpha_{p}(t)\mathbf{v}_{p}^{(n)}\Delta t)\Delta t - \frac{1}{2}(\mathbf{a}_{*} - \alpha_{p}(t)\mathbf{v}_{p}^{(n)})(\Delta t)^{2}$$
 (56)

$$= x_p^{(n)} + \Delta t \left(v_* - \frac{\Delta t}{2} \left(a_* + \alpha_p(t) v_p^{(n)} \right) \right)$$
 (57)

$$\mathbf{v}_{p}^{(n+1)} = \mathbf{v}_{p}^{(n)} + \left(\mathbf{a}_{*} - \alpha_{p}(t)\mathbf{v}_{p}^{(n)}\right)\Delta t = \mathbf{v}_{p}^{(n)}\left(1 - \alpha_{p}(t)\Delta t\right) + \mathbf{a}_{*}\Delta t \tag{58}$$

where

$$\mathbf{v}_{*} = \mathbf{v}_{g \to p}^{(n+1)} - \alpha_{g}(t) \mathbf{v}_{g \to p}^{(n)} \Delta t$$
 (59)

$$a_* = a_{g \to p}^{(n)} - \alpha_g(t) v_{g \to p}^{(n)}$$
 (60)

The position update must be called first, because it needs $v_p^{(n)}$, which is changed in the velocity update.

5.1.4 Applying Damping to Force Calculations

When all damping is done in the particle updates (as is possible from above equations), it is possible that damping will affect other sections of the code that use nodal momentum or force, such as contact, differently. To avoid these effects (if they matter), a second approach would be to apply the grid damping to the force calculation. But, when PIC damping is used, this could cause very unrealistic forces (because that term can be large when Δt is small). A potential solution is to apply only α_g' to force calculations and then apply PIC damping during the particle updates. At the time of the particle update, the nodal input values would be

$$f_i^{**(n)} = f_i^{(n)} + f_{i,T}^{(n)} - \alpha_g' p_i^{(n)}$$
(61)

$$p_i^{**(n+1)} = p_i^{(n)} + m_i^{(n)} a_i^{**(n)} \Delta t$$
 (62)

$$a_i^{**(n)} = \frac{f_i^{(n)} + f_{i,T}^{(n)}}{m_i^{(n)}} - \alpha_g' v_i^{(n)}$$
(63)

The effective terms become

$$a_{g \to p}^{(n)'} = a_{g \to p}^{**(n)} - \alpha_{PIC}(\beta) (v_p^{(n)} - v_{g \to p}^{(n)}) - \alpha_p' v_p^{(n)}$$
(64)

$$v_{g\to p}^{(n+1)'} = v_{g\to p}^{**(n+1)} - \left(\alpha_{PIC}(\beta) \left(v_p^{(n)} - v_{g\to p}^{(n)}\right) + \alpha_p' v_p^{(n)}\right) \Delta t$$
 (65)

where $v_{g \to p}^{(n)}$ is found from available input properties using

$$\mathbf{v}_{g\to p}^{(n)} = \mathbf{v}_{g\to p}^{**(n+1)} - \mathbf{a}_{g\to p}^{**(n)} \Delta t \tag{66}$$

The final updates are the same as above except when coding

$$\nu_* = \nu_{g \to p}^{**(n+1)} + \alpha_{PIC} \nu_{g \to p}^{(n)} \Delta t$$
 (67)

$$a_* = a_{g \to p}^{**(n)} + \alpha_{PIC} \nu_{g \to p}^{(n)}$$
 (68)

5.1.5 Position Dependent Damping Strategies

Potentially it might be useful to damp certain regions differently than other regions. For example, damping could be used in a crack plane to absorb released energy. This section considers changes when the damping terms depend on position. For damping based on grid velocity, the nodal momentum update changes to:

$$p_i^{*(n+1)} = p_i^{(n)} + \left(a_i^{*(n)} - \alpha_g(t, \mathbf{x}_i) \mathbf{v}_i^{(n)} \right) \Delta t = p_i^{(n)} + a_i^{*(n)} \Delta t$$
 (69)

where "*" indicates a term that is revised to including position-dependent damping term where x_i is the nodal position. The particle velocity update would be:

$$\mathbf{v}_{p,FLIP}^{(n+1)} = \mathbf{v}_{p}^{(n)} + \left(\mathbf{a}_{g\to p}^{(n)} - \left(\sum_{i} \alpha_{g}(t, \mathbf{x}_{i}) \mathbf{v}_{i}^{(n)} S_{ip}\right) - \alpha_{p}(t, \mathbf{x}_{p}) \mathbf{v}_{p}^{(n)}\right) \Delta t$$
(70)

The summation terms causes some problems. First, it is inefficient because it needs another extrapolation and likely repeated calculation of $\alpha_g(t, \mathbf{x}_i)$. Second, it loses connection to simple velocity terms. The situation can be improved by replacing $\alpha_g(t, \mathbf{x}_i)$ with $\alpha_g(t, \mathbf{x}_p)$, which is constant for the sum and can be removed from the sum to give

$$\mathbf{v}_{p,FLIP}^{(n+1)} = \mathbf{v}_{p}^{(n)} + \left(\mathbf{a}_{g\to p}^{(n)} - \alpha_{g}(t, \mathbf{x}_{p})\mathbf{v}_{g\to p}^{(n)} - \alpha_{p}(t, \mathbf{x}_{p})\mathbf{v}_{p}^{(n)}\right) \Delta t \tag{71}$$

The remainder of the update analysis can be followed as above. The only difference in code is that $\alpha_g(t, \mathbf{x}_p)$ and $\alpha_p(t, \mathbf{x}_p)$ need to be calculated for each particle in the update loop while for time dependence only, they only need to be calculated once in the entire particle update task. In this approach, the damping could be implemented as a particle property rather then as a function of Eulerian grid coordinates.

6 GIMP Derivation Comments

The nodal force f_i is sometimes interpreted as a sum of internal force, body force, and external force (for the three terms, respectively), but there is no need to separate them during calculations; they all add to the nodal force. The force $f_{i,T}$ is a force due to tractions and needs extra work to integrate the tractions over traction-loaded surfaces in the extent of the grid shape function for node i.

Note that Eq. (20) is diagonal in the nodal system. Thus unlike other derivations of MPM, which get to here with a non-diagonal mass matrix, there is no need to invoke lumping of that mass matrix to make the problem tractable. The GIMP derivation naturally results in a lumped mass matrix.

Within this generalized framework, the various style of MPM are characterized by how they calculate S_{ip} and G_{ip} . Given particle functions, $\chi_p(x)$, the above equations give an "exact" result that is sometimes called "finite GIMP." In general, exact integration of arbitrary particle domains is difficult and is therefore not done. Instead various schemes have developed to approximate the integrals. The NairnMPM wiki page as one approach to classify the MPM family tree of methods.

7 Axisymmetric GIMP

In axisymmetric GIMP, the virtual work integrals are converted to cylindrical integrals:

$$\int_{A} \rho \, \boldsymbol{b} \cdot \delta \boldsymbol{u} \, r dA + \int_{L_{T}} \boldsymbol{T} \cdot \delta \boldsymbol{u} \, r dL + \sum_{p} \boldsymbol{F_{p}} \cdot \delta \boldsymbol{u} = \int_{A} \rho \, \boldsymbol{a} \cdot \delta \boldsymbol{u} \, r dA + \int_{A} \boldsymbol{\sigma} \cdot \nabla \delta \boldsymbol{u} \, r dA \tag{72}$$

where A is the area of integration in the r-z plane, dA = dr dz, L_T is the path for surfaces having traction loads, and T and F_p have been redefined to be traction and force per radian. The result after expansion in the particle basis changes to:

$$\sum_{p} \int_{A} \frac{m_{p}}{A_{p} \langle r_{p} \rangle} \chi_{p}(\mathbf{x}) \mathbf{b}_{p} \cdot \delta \mathbf{u} \, r dA + \int_{L_{T}} \mathbf{T} \cdot \delta \mathbf{u} \, dL + \sum_{p} \frac{\mathbf{F}_{p}}{A_{p} \langle r_{p} \rangle} \int_{A} \chi_{p}(\mathbf{x}) \cdot \delta \mathbf{u} \, r dA \qquad (73)$$

$$= \sum_{p} \int_{A} \frac{\dot{p}_{p}}{A_{p} \langle r_{p} \rangle} \chi_{p}(\mathbf{x}) \cdot \delta \mathbf{u} \, r dA + \sum_{p} \int_{A} \boldsymbol{\sigma}_{p} \chi_{p}(\mathbf{x}) \cdot \nabla \delta \mathbf{u} \, r dA$$
 (74)

where A_p is the particle area in the r-z plane, $\langle r_p \rangle$ is the average radial position of the particle, and particle mass has been redefined to be the mass per radian or $m_p = \rho_p A_p \langle r_p \rangle$. The particle basis functions have the new normalization of

$$A_p \langle r_p \rangle = \int_A \chi_p(\mathbf{x}) r dA$$
 where $\langle r_p \rangle = \frac{1}{A_p} \int_{A_p} r dA$ (75)

The first four results above after expansion in the grid-based shape functions are identical except that definition of S_{ip} changes to

$$S_{ip} = \frac{1}{A_p \langle r_p \rangle} \int_A \chi_p(\mathbf{x}) N_i(\mathbf{x}) \, r \, dA \tag{76}$$

The stress term needs some extra work by evaluating $\nabla \delta u$ in cylindrical coordinates, which is:

$$\nabla \delta \boldsymbol{u} = \begin{pmatrix} \frac{\partial \delta u_r}{\partial r} & \frac{\partial \delta u_r}{\partial z} & 0\\ \frac{\partial \delta u_z}{\partial r} & \frac{\partial \delta u_z}{\partial z} & 0\\ 0 & 0 & \frac{\delta u_r}{r} \end{pmatrix}$$
(77)

The stress term evaluates to

$$\sum_{i} \sum_{p} \int_{A} \boldsymbol{\sigma}_{p} \chi_{p}(\boldsymbol{x}) \cdot \delta \boldsymbol{u}_{i} \nabla N_{i}(\boldsymbol{x}) r dA = \sum_{i} \sum_{p} A_{p} \langle r_{p} \rangle \begin{pmatrix} \sigma_{rr} & \sigma_{rz} \\ \sigma_{rz} & \sigma_{zz} \end{pmatrix} \boldsymbol{G}_{ip} \cdot \left(\delta u_{i,z}, \delta u_{i,z} \right) \\
+ \sum_{i} \sum_{p} A_{p} \langle r_{p} \rangle \left(\sigma_{\theta\theta}, 0 \right) T_{ip} \cdot \left(\delta u_{i,z}, \delta u_{i,z} \right) \tag{78}$$

where G_{ip} is redefined and T_{ip} is a new shape function:

$$G_{ip} = \frac{1}{A_p \langle r_p \rangle} \int_A \chi_p(\mathbf{x}) \nabla N_i(\mathbf{x}) r dA$$
 (79)

$$T_{ip} = \frac{1}{A_p \langle r_p \rangle} \int_A \chi_p(\mathbf{x}) N_i(\mathbf{x}) dA$$
 (80)

For the particle stress term, we can revise to use particle mass as follows:

$$A_p \langle r_p \rangle \boldsymbol{\sigma}_p = m_p \frac{\boldsymbol{\sigma}_p}{\rho_p} = m_p \frac{\boldsymbol{\sigma}_p}{\rho_p} \frac{\rho_0}{\rho_0} = m_p \frac{J \boldsymbol{\sigma}_p}{\rho_0} = m_p \frac{\tau}{\rho_0}$$
 (82)

Making use of the fact that δu_i is arbitrary, the summands of all terms can be equated to arrive at the controlling MPM equation on the background grid in axisymmetric calculations:

$$\frac{d\mathbf{p}_i}{dt} = \mathbf{f}_i + \mathbf{f}_{i,T} \tag{83}$$

where

$$f_{i} = \sum_{p} \left(-\frac{m_{p}}{\rho_{0}} \begin{pmatrix} \tau_{rr} & \tau_{rz} \\ \tau_{rz} & \tau_{zz} \end{pmatrix} \cdot \boldsymbol{G}_{ip} - \frac{m_{p}}{\rho_{0}} (\tau_{\theta\theta}, 0) T_{ip} + m_{p} S_{ip} \boldsymbol{b}_{p} + S_{ip} \boldsymbol{F}_{p} \right)$$
(84)

$$f_{i,T} = \int_{S_T} N_i(x) T \, dS \tag{85}$$

This final result is very similar to MPM in Cartesian coordinates except it uses revised shape functions, m_p , F_p , and T are redefined to be quantities per radian, and there is an extra stress term in f_i .

8 GIMP Analysis for Conduction

The heat conduction equation is

$$\rho C_V \frac{\partial T}{\partial t} + \nabla \cdot \mathbf{q} = q_s(\mathbf{x}) \tag{86}$$

where ρ is density, C_V is heat capacity (per unit mass), T is temperature, \mathbf{q} is heat flux (per unit area), and $q_s(\mathbf{x})$ is heat source (per unit volume). For heat conduction, the heat flux is $\mathbf{q} = -\mathsf{k}\nabla T$ where k is the thermal conductivity tensor and T is temperature. Solving this equation in the MPM weak form gives

$$\int_{V} \left(\rho C_{V} \frac{\partial T}{\partial t} + \nabla \cdot \mathbf{q} - q_{s}(\mathbf{x}) \right) w(\mathbf{x}) dV = 0$$
(87)

where w(x) is an arbitrary weighting function. Using the vector identity:

$$(\nabla \cdot q) w(x) = \nabla \cdot (w(x)q) - (\nabla w(x)) \cdot q \tag{88}$$

and the divergence theorem, the weak form equation becomes:

$$\int_{V} \left(\rho C_{V} w(\mathbf{x}) \frac{\partial T}{\partial t} - \nabla w(\mathbf{x}) \cdot \mathbf{q} - q_{s}(\mathbf{x}) w(\mathbf{x}) \right) dV + \int_{\delta V} (w(\mathbf{x}) \mathbf{q}) \cdot \hat{n} dS = 0$$
 (89)

where δV is the border of V and \hat{n} is a surface normal vector.

As in GIMP for the momentum equation, we expand the particle quantities in the particle basis to get:

$$\rho C_V \frac{\partial T}{\partial t} = \sum_p \rho_p C_{V,p} \frac{\partial T_p}{\partial t} \chi_p(\mathbf{x})$$
 (90)

$$q_s(\mathbf{x}) = \sum_p q_{s,p} \chi_p(\mathbf{x}) \tag{91}$$

$$q = \sum_{p} q_{p} \chi_{p}(\mathbf{x}) \tag{92}$$

where subscript p denotes a particle property and $\chi_p(x)$ is the particle basis function for particle p (which is typically 1 within the deformed particle domain and zero elsewhere). Next expand weight function and its gradient in the grid shape functions:

$$w(\mathbf{x}) = \sum_{i} w_i N_i(\mathbf{x})$$
 and $\nabla w(\mathbf{x}) = \sum_{i} w_i \nabla N_i(\mathbf{x})$ (93)

After substituting all expansions, the weak form equation becomes

$$-\sum_{i} \int_{\delta V} (w_{i} N_{i}(\mathbf{x}) \mathbf{q}) \cdot \hat{n} \, dS = \int_{V} \left\{ -\sum_{i} \sum_{p} \left[\left(w_{i} \nabla N_{i}(\mathbf{x}) \right) \cdot \mathbf{q}_{p} \chi_{p}(\mathbf{x}) \right] \right\}$$
(94)

$$-\sum_{i}\sum_{p}q_{s,p}\chi_{p}(\mathbf{x})w_{i}N_{i}(\mathbf{x}) + \sum_{i}\sum_{p}\rho_{p}C_{V,p}\chi_{p}(\mathbf{x})w_{i}N_{i}(\mathbf{x})\frac{\partial T_{p}}{\partial t} dV$$
 (95)

Using Eqs. (16) and (18) for GIMP shape functions and arbitrary nature of w(x), this equation transforms to an equation for each node:

$$\sum_{p} m_{p} C_{V,p} \frac{\partial T_{p}}{\partial t} S_{ip} = \sum_{p} V_{p} \boldsymbol{q}_{p} \cdot \boldsymbol{G}_{ip} + \sum_{p} V_{p} q_{s,p} S_{ip} - \int_{\delta V} (N_{i}(\boldsymbol{x}) \boldsymbol{q}) \cdot \hat{\boldsymbol{n}} \, dS$$
 (96)

where $m_p = \rho_p V_p = \rho_0 V_0$ is particle mass. This equation works for large deformation provided V_P is the current particle volume and Eqs. (16) and (18) use finite GIMP methods. If Eqs. (16) and (18) are replaced by uniform GIMP (or CPDI), it still approximately accounts for large deformation by using current particle volume (V_p) in the sums.

8.1 MPM Equation

Defining $m_{Tp}^{(n)} = m_p C_{V,p}$ as a thermal mass on the particle in step n (with units E/K, where E is energy, which is nJ/K in mmgs units when C_V is heat capacity per unit mass — E/(K-M) or nJ/(K-g)), a thermal momentum on the node can be defined as

$$p_{Ti}^{(n)} = \sum_{p} m_{Tp}^{(n)} T_{p}^{(n)} S_{ip}^{(n)}$$
(97)

The units for thermal momentum are E or F-L (which are nJ (Joules) or μ N-mm in mmgs units). In the momentum analog, temperature is replaced by velocity, thermal mass is replaced by actual mass, and the sum gives momentum with units F-T (or μ N-sec in mmgs units). A thermal momentum equation, as scalar analog of the momentum equation, can be written as

$$\frac{dp_{Ti}^{(n)}}{dt} = Q_i^{(n)} + Q_{i,q}^{(n)} + Q_{i,c}^{(n)}$$
(98)

where

$$Q_{i}^{(n)} = \sum_{p} V_{p}^{(n)} \left(\boldsymbol{q}_{p}^{(n)} \cdot \boldsymbol{G}_{ip}^{(n)} + q_{s,p}^{(n)} S_{ip}^{(n)} \right) = \sum_{p} m_{p} \left(\frac{J \boldsymbol{q}_{p}^{(n)}}{\rho_{0}} \cdot \boldsymbol{G}_{ip}^{(n)} + \bar{q}_{s,p}^{(n)} S_{ip}^{(n)} \right)$$
(99)

$$Q_{i,q}^{(n)} = -\int_{\delta V} (N_i(\boldsymbol{x})\boldsymbol{q}^{(n)}) \cdot \hat{n} \, dS \tag{100}$$

are total thermal flows (or thermal forces) with units of E/T or Pwr (for power) and nJ/sec or nWatts in mmgs units. The first heat flow is internal heat flow while the second is heat flow at the boundaries due to flux boundary conditions. The $q_p^{(n)}$ term is flux with units Pwr/L² (or nW/mm² in mmgs units) and $\bar{q}_{s,p}^{(n)}$ is particle heat source per unit mass with units Pwr/M (or nW/g in mmgs units). The particle heat flux is analogous to particle stress in the momentum equation (using units F/L^2), but rather then track and update $q_p^{(n)}$ on the particle (as done for stress), it is calculated on each time step using

$$\frac{q_p^{(n)}}{\rho_0} = -\frac{k_p^{(n)}}{\rho_0} \nabla T_p^{(n)} = -\frac{k_p^{(n)}}{\rho_0} \sum_i T_i^{(n)} G_{ip}^{(n)}$$
(101)

where nodal temperature is defined by

$$T_i^{(n)} = \frac{p_{Ti}^{(n)}}{m_{Ti}^{(n)}}$$
 where $m_{Ti}^{(n)} = \sum_p m_{Tp}^{(n)} S_{ip}^{(n)}$ (102)

Note that conductivity has units Pwr/(L-K) (or nW/(mm-K) in mmgs units) and $q_{s,p}^{(n)}$ has units Pwr/L³ (or nW/mm³ in mmgs units).

The last term the thermal momentum equation is for crack tip heating. Because that heating is implemented on massless crack particles, an alternative extrapolation is needed:

$$Q_{i,c}^{(n)} = \sum_{c} V_c^{(n)} q_{s,c}^{(n)} S_{ic}^{(n)*} = \sum_{c} f_H G_c t_c \frac{\Delta a}{n \Delta t} S_{ic}^{(n)*}$$
(103)

where c means crack particle, G_c is the total energy release per unit area, and $t_c \Delta a$ is the total area (with t_c being crack thickness). This energy is released over n steps or total time $n\Delta t$ giving the total heating rate of $V_c^{(n)}q_{s,c}^{(n)}=f_HG_ct_p\Delta a/(n\Delta t)$. The shape function spreads this heat over nearby nodes with partition of unity, but because crack particles may interact with inactive nodes, the shape functions are renormalized to be partition of unity by dividing by their sum over active nodes only (as indicated by the \ast on the shape function). The parameter f_H is an option to allow only a fraction of the energy to be converted into heat.

Momentum and Particle Updates

The thermal momentum update on the node is

$$p_{T_i}^{(n+1)} = p_{T_i}^{(n)} + \left(Q_i^{(n)} + Q_{i,q}^{(n)}\right) \Delta t = p_{T_i}^{(n)} + m_{T_i}^{(n)} a_{T_i}^{(n)} \Delta t$$
(104)

where the nodal thermal acceleration is

$$a_{Ti}^{(n)} = \frac{p_{Ti}^{(n+1)} - p_{Ti}^{(n)}}{m_{Ti}^{(n)} \Delta t} = \frac{Q_i^{(n)} + Q_{i,q}^{(n)}}{m_{Ti}^{(n)}}$$
(105)

As done for velocity, we can write two updates for the particles — a FLIP update that increments particle temperature using thermal accelerations extrapolated to the grid and a PIC update that extrapolates temperature directly to the particle:

$$T_{p,FLIP}^{(n+1)} = T_p^{(n)} + a_{T,g\to p}^{(n)} \Delta t$$
 (106)

$$T_{p,FLIP}^{(n+1)} = T_p^{(n)} + a_{T,g\to p}^{(n)} \Delta t$$

$$T_{p,PIC}^{(n+1)} = T_{g\to p}^{(n+1)}$$
(106)

where

$$a_{T,g\to p}^{(n)} = \sum_{i} a_{Ti}^{(n)} S_{ip}^{(n)}$$
(108)

$$T_{g\to p}^{(n+1)} = \sum_{i} \left(T_i^{(n)} + a_{Ti}^{(n)} \Delta t \right) S_{ip}^{(n)} = T_{g\to p}^{(n)} + a_{T,g\to p}^{(n)} \Delta t$$
 (109)

$$T_{g \to p}^{(n)} = \sum_{i} T_{i}^{(n)} S_{ip}^{(n)} \tag{110}$$

Unlike like particle velocity and position update, the addition of PIC character to temperature updates leads to thermal conduction, even if the conductivity of the material is set to zero. Thus, the particle temperature update is always done using FLIP. Like particle stresses, particle temperatures can develop variations within a cell. Because of these variations, particle temperature does not give the best measure of the local temperature when implementing features such as particle properties that depend on temperature. To implement temperature-dependent features on time step n, it is better to assume the temperature at the particle is equal to $T_{g \to p}^{(n)}$. In other words, the particle temperature evolves as described above, but whenever some other feature of the code needs to know the temperature at the particle, it should use the grid-based temperature and not the evolving particle temperature.

9 GIMP Analysis for Diffusion

We can derive GIMP diffusion analysis from the GIMP conduction analysis by replacing temperature with concentration potential μ (where μ is a dimensionless potential approximated as $\mu = c/c_{sat}$; *i.e.* from 0 to 1), and then by setting $\rho = 1$, and $C_V = 1$, and k = D, where D is the diffusion tensor. Defining $V_p^{(n)}$ as a solvent "mass" on the particle in step n (with SI units m³), a solvent momentum on the node can be defined as

$$p_{Di}^{(n)} = \sum_{p} V_p^{(n)} \mu_p^{(n)} S_{ip}^{(n)}$$
(111)

The mgs units for solvent momentum are $mm^3-\mu$. A solvent momentum equation, as scalar analog of the momentum equation, can be written as

$$\frac{dp_{Di}^{(n)}}{dt} = S_i^{(n)} + S_{i,q}^{(n)}$$
(112)

where

$$S_{Di}^{(n)} = \sum_{p} V_{p}^{(n)} \left(s_{p}^{(n)} \cdot G_{ip}^{(n)} + s_{s,p}^{(n)} S_{ip}^{(n)} \right)$$
 (113)

$$S_{Di,q}^{(n)} = -\int_{\delta V} (N_i(\boldsymbol{x})\boldsymbol{s}^{(n)}) \cdot \hat{n} \, dS$$
 (114)

are total solvent flow (or solvent forces) with mgs units mm³- μ /sec. The first flow is internal flow while the second is flow across the surfaces due to flux boundary conditions. The $s_p^{(n)}$ term is flux with mgs units mm- μ /sec (or (solvent force)/mm²). It is analogous to stress term in the momentum equation (also with units of (force)/mm²), but rather then track and update $s_p^{(n)}$ on the particle, it is calculated on each time step using

$$\mathbf{s}_{p}^{(n)} = -D_{p}^{(n)} \nabla \mu_{p}^{(n)} = -D_{p}^{(n)} \sum_{i} \mu_{i}^{(n)} \mathbf{G}_{ip}^{(n)}$$
(115)

where nodal concentration potential is defined by

$$\mu_i^{(n)} = \frac{p_{Di}^{(n)}}{V_i^{(n)}}$$
 where $V_i^{(n)} = \sum_p V_p^{(n)} S_{ip}^{(n)}$ (116)

Note that diffusion tensor has mgs units of $\mathrm{mm}^2/\mathrm{sec}$ and $s_{s,p}^{(n)}$ (which is solvent source term) has mgs units μ /sec.

The nodal update becomes

$$p_{Di}^{(n+1)} = p_{Di}^{(n)} + \left(S_i^{(n)} + S_{i,q}^{(n)}\right) \Delta t = p_{Di}^{(n)} + V_i^{(n)} a_{Di}^{(n)} \Delta t \quad \text{where} \quad a_{Di}^{(n)} = \frac{S_i^{(n)} + S_{i,q}^{(n)}}{V_i^{(n)}}$$
(117)

The FLIP particle update becomes

$$\mu_{p,FLIP}^{(n+1)} = \mu_p^{(n)} + a_{D,g\to p}^{(n)} \Delta t \tag{118}$$

$$\mu_{p,FLIP}^{(n+1)} = \mu_p^{(n)} + a_{D,g \to p}^{(n)} \Delta t$$

$$a_{D,g \to p}^{(n)} = \sum_{i} a_{Di}^{(n)} S_{ip}^{(n)}$$
(118)

(120)

10 **Consistent Units**

internally, both NairnMPM and OSParticulas use mm-g-sec units system. Despite this internal use, the input of properties are not always based on these units. The two ways to enter properties are using "Legacy Units" or picking and using you own "Consistent Units" system. Currently scripts interpreted by NairnFEAMPM or NairnFEAMPMViz myst use Legacy units, but input files created directly in XML can pick a different set by adding the <ConsistentUnits> command. Some MPM units options are given in Tables 1 and 2. The units including "Alt" means their treatment in Legacy units is not consistent. Refer to documentation to see how to input properties that need those units and to see how quantities with those units are output.

11 Consistent Units in Static FEA

In static FEA, the only units needed are for length and force. The legacy units for NairnFEA are close to consistent using length in mm and force in N, which leads to stress and moduli in MPa = N/m^2 and interface parameters in MPa/mm. Boundary conditions are set using mm, N, and MPa for displacements, loads, and tractions, respectively. The only inconsistency is that the output energies re in J while the energy consistent with mm and N should be mJ = N-mm. The consistent units options are in Table 3.

Table 1: Consistent units for the momentum equation

Quantity	Legacy	SI (m-kg-sec)	mm-g-sec	
Length	mm	m	mm	
Mass	g	kg	g	
Time	sec	sec	sec	
Alt Time	msec	sec	sec	
Density	$\frac{g}{\text{cm}^3}$	$\frac{kg}{m^3}$	$\frac{g}{\text{mm}^3}$	
Velocity	mm sec	m sec	mm sec	
Alt Velocity	m sec	m sec	mm sec	
Force	N	$N = \frac{kg \cdot m}{sec^2}$	$\mu N = \frac{g \cdot mm}{sec^2}$	
Pressure	MPa	$Pa = \frac{N}{m^2}$	$Pa = \frac{\mu N}{mm^2}$	
Alt Strain	%	none	none	
Energy	J	$J = N \cdot m$	$nJ = \mu N \cdot mm$	
ERR	$\frac{J}{m^2}$	$\frac{J}{m^2}$	$\frac{\text{nJ}}{\text{mm}^2}$	
Stress Int.	MPa√m	Pa√m	Pa√mm	
Viscosity	cР	kg m·sec	g mm·sec	

Table 2: Consistent units for conduction and diffusion equation

Quantity	Legacy	SI (m-kg-sec)	mm-g-sec
Heat Capacity	J/(kg-K)	J/(kg-K)	nJ/(g-K)
Conductivity	W/(m-K)	W/(m-K)	nW/(mm-K)
Heat Flux	W/m ²	W/m ²	nW/mm ²
Diffusion	m ² /sec	m ² /sec	mm ² /sec
Solvent Flux	kg/(m²·sec)	kg/(m²⋅sec)	g/(mm²·sec)

Table 3: Consistent units for FEA

Units	Length	Force	Stress	Energy
Legacy	mm	N	MPa	J
SI	m	N	Pa	J
mm-g-sec	mm	μ N	Pa	nJ
cm-g-sec	cm	$10^{-5}N = dyne$	$10^{-1} Pa = Ba$	10^{-7} J = erg
mm-g-msec	mm	N	MPa	mJ