

Advanced Logic Design DSP Hardware Design Methodologies

Mingoo Seok Columbia University

Readings: Parhi Sec. 2 and 3

Acknowledgement: Prof. Z. Zhang (UMich),

VLSI Digital Signal Processing Systems: Design and Implementation by Prof. K. K. Parhi (UMinn

Representing DSP Algorithms

Example: 3-tap FIR filter

$$y(n) = ax(n) + bx(n-1) + cx(n-2)$$


- non-terminating, i.e., $n = 1...\infty$
- Definitions:
 - Iteration: execution of all the computations in the algorithm once
 - Iteration period: the time required for one iteration
 - Sampling rate (or throughput): number of samples processed per second
 - Critical path: the longest path (computation time) between inputs and outputs (in combinational circuits), or the longest path between any two sequential elements (in sequential circuits)
 - Minimum clock period: determined by the critical path
 - Latency: the difference between the time an output is generated and the time at which its corresponding input was received by the system
 - Combinational circuit: latency is in terms of absolute time units
 - Sequential circuit: latency is in terms of number of clock cycles

(1) Block Diagram

Example: 3-tap FIR filter

$$y(n) = ax(n) + bx(n-1) + cx(n-2)$$

– non-terminating, i.e., $n=1...\infty$




- Consists of functional blocks connected with directed edges
- Represents data flow from its input to output
- Critical path is the longest path among paths that do not contain delay elements
- 4 types of paths: input-delay, delay-output, input-output, delay-delay
- Clock period is lower bounded by the critical path computation time

(2) Signal-Flow Graph (SFG)

Example: 3-tap FIR filter

$$y(n) = ax(n) + bx(n-1) + cx(n-2)$$

– non-terminating, i.e., $n=1...\infty$




- Represent additions and multiplications
- Nodes represent variables for a computation
- A directed edge denotes multiplication or delay
- Multiple incoming edges and one outgoing edge denotes addition
- Only used for linear systems; cannot be used to describe multirate DSP systems

(3) Data-Flow Graph (DFG)

Example: 3-tap FIR filter


$$y(n) = ax(n) + bx(n-1) + cx(n-2)$$

– non-terminating, i.e., $n=1...\infty$




- Nodes represent computations. Each has an execution time in absolute time units. i.e.,
 numbers in the parenthesis
- Directed edges represent data paths. It may have a delay in clock cycles.
- Any node can fire when all inputs are available, and many nodes can fire concurrently
- Intra-iteration precedence: every edge that has zero delay
- Inter-iteration precedence: every edge that has non-zero delay
- DFG is used to derive concurrent implementations onto parallel hardware

Loops




- Loop: directed path that begins and ends at the same node
- Loop bound: "loop computation time" divided by "loop delay"

Iteration Bound



- Three loops: L1, L2, L3.
- Loop bound of the l-th loop: t_l/w_l where t_l is the loop computation time, and w_l is the number of delays in the loop
 - Loop bound of L1: 12n/1D = 12
 - L2: 10n/2D = 5
 - L3: 15n/2D = 7.5
- Critical loop: loop with the maximum loop bound
 - L1
- Iteration bound: the loop bound of the critical loop
 - 12ns (= L1)
- Iteration bound is the *lower bound* on the iteration or sample period of the system (given speed of arithmetic operation and unlimited number of processing units). In other word, an implementation of the DSP program *can never achieve* an iteration period less than the iteration bound

Compute Iteration Bound




- Enumerate loops and count loop bounds
 - Three loops: $(1 \rightarrow 4 \rightarrow 2 \rightarrow 1; 1 \rightarrow 5 \rightarrow 3 \rightarrow 2 \rightarrow 1; 1 \rightarrow 6 \rightarrow 3 \rightarrow 2 \rightarrow 1)$
- Iteration bound is the maximum loop bound
 - Max(4/2, 5/3, 5/4) = 2

Pipelining and Parallel Processing

Pipelining


Continue sending water without waiting for the water in the pipe to be drained




- Shortens the critical path
- Allows an increased clock speed, sampling rate (throughput) or reduced power consumption at the same throughput
- Parallel processing
 - Multiple outputs are computed in parallel in a clock period
 - The effective sampling speed is increased by the level of parallelism
 - Allows an increased sampling rate (throughput) or reduced power consumption at the same throughput

Pipelining Digital Filters

Direct-form 3-tap FIR filter





Pipelined filter: reduces critical path, increases latency and register use



Pipeline Register Placement


- Start with DFG
- Cut: separate the vertices of a graph into two disjoint subsets
- Cutset: the set of edges whose end points are in different subsets
- Feed-forward cutset: data move in the forward direction on all the edges of the cutset
- Place registers across any feedforward cutset of the graph






Fine-Grain Pipelining

Break functional units for a better balance and shorten critical path




Data-Broadcast Structure

- Transposed SFG
 - Reverse the direction of all the edges in the SFG and interchange the input and output preserves the functionality of the system



- Data-broadcast structure
 - Reduced critical path delay



Parallel Processing


- Parallel processing is the dual of pipelining
 - Exploit concurrency in different ways:
 - Pipelining: break computation hardware into sets to improve utilization by concurrently operating on different samples
 - Parallel processing: duplicate computation hardware to operate on different samples
 - Example: y(n) = ax(n) + bx(n-1) + cx(n-2)
 - 3× parallel processing: k denotes clock cycle

$$y(3k) = ax(3k) + bx(3k-1) + cx(3k-2)$$
$$y(3k+1) = ax(3k+1) + bx(3k) + cx(3k-1)$$
$$y(3k+2) = ax(3k+2) + bx(3k+1) + cx(3k)$$

- 3× sampling rate and 3× throughput at the same clock frequency
- To maintain the same sampling rate, clock frequency can be reduced by 3×
- Clock rate ≠ sampling rate


Parallel Processing

3× parallel direct-form FIR




The computing core design is unchanged


Complete Parallel System



Serial to parallel



Parallel to serial



Communication Bound

- Why only pipelining is used?
- Pipelining can be used only to the extent, until the critical path computation time is limited by the communication or I/O
 - Pipelining can no longer increase the speed once the bound is reached
 - Use parallel processing to further increase the speed

