I/O and Disks

Thierry Sans



I/O management



- I/O devices vary greatly and new types of I/O devices appear frequently
- Various methods to control them and to manage their performances
- → Ports, buses, device controllers connect to various devices

I/O Device Interfaces


Port - connection point for device (e.g. serial port)

Bus - daisy chain or shared direct access e.g. Peripheral Component Interconnect Bus (PCI) e.g Universal Serial Bus (USB)

Controller (host adapter) - electronics that operate port, bus, device (e.g Northbridge, Southbridge, graphics controller, DMA, NIC, ...)

- Can be integrated or separated (host adapter)
- · Contains processor, microcode, private memory, bus controller, etc

I/O architecture



How the OS communicates with the device?

→ Each device has three types of registers and the OS controls the device by reading or writing these registers

status register
See the current status of the device

command register (also called control register)
Tell the device to perform a certain task

data register
Pass data to the device, or get data from the device

Two ways to read/write those registers

I/O ports

in and out instructions on x86 to read and write devices registers

Memory-mapped I/O

Device registers are available as if they were memory locations and the OS can load (to read) or store (to write) to the device

I/O Ports on PC

I/O address range (hexadecimal)	device
000-00F	DMA controller
020–021	interrupt controller
040–043	timer
200-20F	game controller
2F8–2FF	serial port (secondary)
320-32F	hard-disk controller
378–37F	parallel port
3D0-3DF	graphics controller
3F0-3F7	diskette-drive controller
3F8–3FF	serial port (primary)

Reading/Writing to I/O ports

Pintos threads/io.h

```
static inline uint8_t inb (uint16_t port)
{
   uint8_t data;
   asm volatile ("inb %w1, %b0" : "=a" (data) : "Nd" (port));
   return data;
}


static inline void outb (uint16_t port, uint8_t data)
{
   asm volatile ("outb %b0, %w1" : : "a" (data), "Nd" (port));
}
```

Device driver

```
while (STATUS == BUSY)
; //wait until device is not busy
write data to data register
write command to command register
Doing so starts the device and executes the command
while (STATUS == BUSY)
; //wait until device is done with your request
```


Example: parallel port (LPTI)

Three registers



 Every bits (except IRQ) corresponds to a pin on 25-pin connector





Parallel Port Driver


```
D_3
D_7
       D_6
              D_5
                     D_4
                                  D_2
                                               D_0
        read/write data register (port 0x378)
             PAP
                  OFON ERR
BSY
      ACK
       read-only status register (port 0x379)
                    IRQ
                           DSL
                                        ALF
                                               STR
```

read/write control register (port 0x37a)

```
void
sendbyte(uint8_t byte)
 /* Wait until \overline{BSY} bit is 1. */
 while ((inb (0x379) & 0x80) == 0)
   delay ();
 /* Put the byte we wish to send on pins D7-0. */
 outb (0x378, byte);
  /* Pulse STR (strobe) line to inform the printer
  * that a byte is available */
 uint8_t ctrlval = inb (0x37a);
  outb (0x37a, ctrlval \mid 0x01);
 delay ();
 outb (0x37a, ctrlval);
```


Polling

- → OS waits until the device is ready by repeatedly reading the status register
- ✓ Simple and working
- Wastes CPU time just waiting for the device



Interrupts

- 1. Put the I/O request process to sleep and switch context
- 2. When the device is finished, send an interrupt to wake the process waiting for the I/O
- √ CPU is properly utilized



Polling vs Interrupts

→ Interrupts is not always the best solution


If, device performs very quickly, interrupt will slow down the system

E.g. high network packet arrival rate

- Packets can arrive faster than OS can process them
- Interrupts are very expensive (context switch)
- Interrupt handlers have high priority
- In worst case, can spend 100% of time in interrupt handler and never make any progress a.k.a receive livelock
- ✓ Best adaptive switching between interrupts and polling


One More Problem: Data Copying

 CPU wastes a lot of time in copying a large chunk of data from memory to the device




DMA (Direct Memory Access)

- Only use CPU to transfer control requests, not data, by passing buffer locations in memory
 - Device reads list and accesses buffers through DMA
 - Descriptions sometimes allow for scatter/gather I/O




DMA (Direct Memory Access)

- I. OS writes DMA command block into memory
- 2. DMA bypasses CPU to transfer data directly between I/O device and memory
- 3. When completed, DMA raises an interrupt



Example: IDE disk read with DMA




I/O instruction using DMA

Pintos threads/io.h

Example: IDE Disk Driver

```
void IDE_ReadSector(int disk, int off, void *buf)
{
 outb(0x1F6, disk == 0 ? 0xE0 : 0xF0); // Select Drive
 IDEWait();
 outb(0x1F2, 1); // Read length (1 sector = 512 B)
 outb(0x1F3, off); // LBA low
 outb(0x1F4, off >> 8); // LBA mid
 outb(0x1F5, off >> 16); // LBA high
 outb(0x1F7, 0x20); // Read command
 insw(0x1F0, buf, 256); // Read 256 words
void IDEWait()
 // Discard status 4 times
 inb(0x1F7); inb(0x1F7);
 inb(0x1F7); inb(0x1F7);
 // Wait for status BUSY flag to clear
 while ((inb(0x1F7) \& 0x80) != 0)
```

Example: Network Interface Card




- Link interface talks to wire/fiber/antenna
- FIFOs on card provide small amount of buffering
- Bus interface logic uses DMA to move packets to and from buffers in main memory

Variety is a challenge

- Problem: there are many devices and each has its own protocol
 - Some devices are accessed by I/O ports or memory mapping or both
 - Some devices can interact by polling or interrupt or both
 - Some device can transfer data by programmed I/O or DMA or both
- ✓ Solution : abstraction
 - Build a common interface
 - Write device driver for each device
- → Drivers are 70% of Linux source code

File System Abstraction

File system specifics of which disk class it is using
 It issues block read and write request to the generic block layer



Disks

Hard Disk Drive (HDD)

Platter (aluminum coated with a thin magnetic layer)

- A circular hard surface
- Data is stored persistently by inducing magnetic changes to it
- Each platter has 2 sides, each of which is called a surface

Spindle


- Spindle is connected to a motor that spins the platters around
- The rate of rotations is measured in RPM (Rotations Per Minute)
 Typical modern values: 7,200 RPM to 15,000 RPM

Track

- Concentric circles of sectors
- Data is encoded on each surface in a track
- A single surface contains many thousands and thousands of tracks


Cylinder

- A stack of tracks of fixed radius
- Heads record and sense data along cylinders
- · Generally only one head active at a time




Read and Write Head (Each disk platter has its own head)

Inside Hard Disk



HDD Interface



- → Disk interface presents linear array of sectors
 - Historically 5 I 2 Bytes but 4 KiB in "advanced format" disks
 - Written atomically (even if there is a power failure)
- ✓ Disk maps logical sector #s to physical sectors
- ✓ OS doesn't know logical to physical sector mapping

Seek, Rotate, Transfer

Seek - move head to above specific track

- 1. speedup accelerate arm to max speed
- 2. coast at max speed (for long seeks)
- 3. slowdown stops arm near destination
- 4. settle adjusts head to actual desired track

Seeks is slow

- settling alone can take 0.5 to 2ms
- entire seek often takes 4 10 ms

Seek, Rotate, Transfer

Rotate disk until the head is above the right sector

- → Depends on rotations per minute (RPM)
 With typical 7200 RPM it takes 8.3 ms / rotation
- Average rotation is slow (4.15 ms)

Seek, Rotate, Transfer

Data is either read from or written to the surface.

- → Depends on RPM and sector density
 With typical 100+ MB/s it takes 5µs / sector (512 bytes)
- ✓ Pretty Fast

Workload

So ...

- · seeks are slow
- rotations are slow
- transfers are fast

What kind of workload is fastest for disks?

- Sequential: access sectors in order (transfer dominated)
- Random: access sectors arbitrarily (seek+rotation dominated)
- → Disk Scheduler decides which I/O request to schedule next
 - First Come First Served (FCFS)
 - Shortest Seek Time First (SSTF)
 - Elevator Scheduling (SCAN) commonly used on Unix

Solid State Drive (SSD)

- → Completely solid state (no moving parts), remembers data by storing charge (like RAM)
- ✓ Same interface as HDD (linear array of sectors)
- √ No mechanical seek and rotation times to worry about (SSD are way faster than HDD)
- ✓ Lower power consumption and heat (better for mobile devices)
- More expensive than HDD yet (but getting cheaper)
- Limited durability as charge wears out over time (but improving)
- Limited # overwrites possible
 - Blocks wear out after 10,000 (MLC) 100,000 (SLC) erases
 - Requires Flash Translation Layer (FTL) to provide wear levelling, so repeated writes to logical block don't wear out physical block
 - FTL can seriously impact performance

Acknowledgments

Some of the course materials and projects are from

- Ryan Huang teaching CS 318 at John Hopkins University
- David Mazière teaching CS 140 at Stanford