# I/O and Disks

Thierry Sans



## I/O management



- I/O devices vary greatly and new types of I/O devices appear frequently
- Various methods to control them and to manage their performances
- Ports, buses, device controllers connect to various devices

#### I/O Device Interfaces


Port - connection point for device (e.g. serial port)

**Bus** - daisy chain or shared direct access e.g. Peripheral Component Interconnect Bus (PCI) e.g Universal Serial Bus (USB)

**Controller** (host adapter) - electronics that operate port, bus, device (e.g Northbridge, Southbridge, graphics controller, DMA, NIC, ...)

- Can be integrated or separated (host adapter)
- · Contains processor, microcode, private memory, bus controller, etc

#### I/O architecture



#### How the OS communicates with the device?

→ Each device has three types of registers and the OS controls the device by reading or writing these registers

**status** register
See the current status of the device

**command** register

Tell the device to perform a certain task

data register
Pass data to the device, or get data from the device

## Two ways to read/write those registers

#### I/O ports

in and out instructions on x86 to read and write devices registers

#### Memory-mapped I/O

Device registers are available as if they were memory locations and the OS can load (to read) or store (to write) to the device

#### I/O Ports on PC

I/O address range (hexadecimal)	device
000-00F	DMA controller
020–021	interrupt controller
040–043	timer
200-20F	game controller
2F8–2FF	serial port (secondary)
320-32F	hard-disk controller
378–37F	parallel port
3D0-3DF	graphics controller
3F0-3F7	diskette-drive controller
3F8–3FF	serial port (primary)

### Reading/Writing to I/O ports

Pintos threads/io.h

```
static inline uint8_t inb (uint16_t port)
{
   uint8_t data;
   asm volatile ("inb %w1, %b0" : "=a" (data) : "Nd" (port));
   return data;
}


static inline void outb (uint16_t port, uint8_t data)
{
   asm volatile ("outb %b0, %w1" : : "a" (data), "Nd" (port));
}
```

#### Device driver

```
while (STATUS == BUSY)
; //wait until device is not busy
write data to data register
write command to command register
Doing so starts the device and executes the command
while (STATUS == BUSY)
; //wait until device is done with your request
```


## Example: parallel port (LPTI)

Three controllers



 Every bits (except IRQ) corresponds to a pin on 25-pin connector






#### Parallel Port Driver

```
void
sendbyte(uint8_t byte)
 /* Wait until \overline{BSY} bit is 1. */
 while ((inb (0x379) & 0x80) == 0)
   delay ();
 /* Put the byte we wish to send on pins D7-0. */
 outb (0x378, byte);
  /* Pulse STR (strobe) line to inform the printer
  * that a byte is available */
 uint8_t ctrlval = inb (0x37a);
 outb (0x37a, ctrlval \mid 0x01);
 delay ();
 outb (0x37a, ctrlval);
```


## Polling

- → OS waits until the device is ready by repeatedly reading the status register
- ✓ Simple and working
- Wastes CPU time just waiting for the device



#### Interrupts

- 1. Put the I/O request process to sleep and switch context
- 2. When the device is finished, send an interrupt to wake the process waiting for the I/O
- √ CPU is properly utilized



## Polling vs Interrupts

#### → Interrupts is not always the best solution


If, device performs very quickly, interrupt will slow down the system

E.g., high network packet arrival rate

- Packets can arrive faster than OS can process them
- Interrupts are very expensive (context switch)
- Interrupt handlers have high priority
- In worst case, can spend 100% of time in interrupt handler and never make any progress a.k.a receive livelock
- ✓ Best adaptive switching between interrupts and polling


## One More Problem: Data Copying

 CPU wastes a lot of time in copying a large chunk of data from memory to the device




## DMA (Direct Memory Access)

- Only use CPU to transfer control requests, not data, by passing buffer locations in memory
  - Device reads list and accesses buffers through DMA
  - Descriptions sometimes allow for scatter/gather I/O




## DMA (Direct Memory Access)

- I. OS writes DMA command block into memory
- 2. DMA bypasses CPU to transfer data directly between I/O device and memory
- 3. When completed, DMA raises an interrupt



#### Example: IDE disk read with DMA




## I/O instruction using DMA

Pintos threads/io.h

#### Example: IDE Disk Driver

```
void IDE_ReadSector(int disk, int off, void *buf)
{
 outb(0x1F6, disk == 0 ? 0xE0 : 0xF0); // Select Drive
 IDEWait();
 outb(0x1F2, 1); // Read length (1 sector = 512 B)
 outb(0x1F3, off); // LBA low
 outb(0x1F4, off >> 8); // LBA mid
 outb(0x1F5, off >> 16); // LBA high
 outb(0x1F7, 0x20); // Read command
 insw(0x1F0, buf, 256); // Read 256 words
void IDEWait()
 // Discard status 4 times
 inb(0x1F7); inb(0x1F7);
 inb(0x1F7); inb(0x1F7);
 // Wait for status BUSY flag to clear
 while ((inb(0x1F7) \& 0x80) != 0)
```

#### Example: Network Interface Card




- · Link interface talks to wire/fiber/antenna
- FIFOs on card provide small amount of buffering
- Bus interface logic uses DMA to move packets to and from buffers in main memory

## Variety is a challenge

- Problem: there are many devices and each has its own protocol
  - Some devices are accessed by I/O ports or memory mapping or both
  - Some devices can interact by polling or interrupt or both
  - Some device can transfer data by programmed I/O or DMA or both
- ✓ Solution : abstraction
  - Build a common interface
  - Write device driver for each device
- → Drivers are 70% of Linux source code

## File System Abstraction

File system specifics of which disk class it is using
 It issues block read and write request to the generic block layer



# Disks

## Hard Disk Drive (HDD)

**Platter** (aluminum coated with a thin magnetic layer)

- A circular hard surface
- Data is stored persistently by inducing magnetic changes to it
- Each platter has 2 sides, each of which is called a surface

#### **Spindle**


- Spindle is connected to a motor that spins the platters around
- The rate of rotations is measured in RPM (Rotations Per Minute)
   Typical modern values: 7,200 RPM to 15,000 RPM

#### **Track**

- Concentric circles of sectors
- Data is encoded on each surface in a track
- A single surface contains many thousands and thousands of tracks


#### **Cylinder**

- A stack of tracks of fixed radius
- Heads record and sense data along cylinders
- Generally only one head active at a time




Read and Write Head (Each disk platter has its own head)

#### Inside Hard Disk



#### HDD Interface



- → Disk interface presents linear array of sectors
  - Historically 5 I 2 Bytes but 4 KiB in "advanced format" disks
  - Written atomically (even if there is a power failure)
- ✓ Disk maps logical sector #s to physical sectors
- ✓ OS doesn't know logical to physical sector mapping

#### Seek, Rotate, Transfer

Seek - move head to above specific track

- 1. speedup accelerate arm to max speed
- 2. coast at max speed (for long seeks)
- 3. slowdown stops arm near destination
- 4. settle adjusts head to actual desired track

#### Seeks is slow

- settling alone can take 0.5 to 2ms
- entire seek often takes 4 10 ms

#### Seek, Rotate, Transfer

Rotate disk until the head is above the right sector

- → Depends on rotations per minute (RPM)
  With typical 7200 RPM it takes 8.3 ms / rotation
- Average rotation is slow (4.15 ms)

#### Seek, Rotate, Transfer

Data is either read from or written to the surface.

- → Depends on RPM and sector density
  With typical 100+ MB/s it takes 5µs / sector (512 bytes)
- ✓ Pretty Fast

#### Workload

#### So ...

- · seeks are slow
- rotations are slow
- transfers are fast

#### What kind of workload is fastest for disks?

- Sequential: access sectors in order (transfer dominated)
- Random: access sectors arbitrarily (seek+rotation dominated)
- → Disk Scheduler decides which I/O request to schedule next
  - First Come First Served (FCFS)
  - Shortest Seek Time First (SSTF)
  - Elevator Scheduling (SCAN) commonly used on Unix

## Solid State Drive (SSD)

- → Completely solid state (no moving parts), remembers data by storing charge (like RAM)
- √ Same interface as HDD (linear array of sectors)
- √ No mechanical seek and rotation times to worry about (SSD are way faster than HDD)
- ✓ Lower power consumption and heat (better for mobile devices)
- More expensive than HDD yet (but getting cheaper)
- Limited durability as charge wears out over time (but improving)
- Limited # overwrites possible
  - Blocks wear out after 10,000 (MLC) 100,000 (SLC) erases
  - Requires Flash Translation Layer (FTL) to provide wear levelling, so repeated writes to logical block don't wear out physical block
  - FTL can seriously impact performance

### Acknowledgments

Some of the course materials and projects are from

- · Ryan Huang teaching CS 318 at John Hopkins University
- David Mazière teaching CS 140 at Stanford