The trials and tribulations of building a phase-sensitive detector with an Arduino microcontroller

K. D. Schultz

Department of Physics Hartwick College

MAS-APS, 2014





Original Goals

- Use Arduino as a tool for teaching about phase-sensitive detection, like.....
- To do so with only the Arduino, a computer for display purposes, and passive external components (resistors and capacitors)





Why PSD?

- Phase Sensitive Detection (PSD) is the basis of many techniques in physics and engineering
 - Homodyne detection
 - Interferometry
 - Lock-in amplifiers
- Black boxes are useful for application work, but not so much for pedagogical purposes
- Software PSD allows students to peek into the black box.





Why Arduino?

- Cheap
- Popular
 - Lots of support
- Simple programming environment
 - Perhaps too simple, IDE has very poor debugging tools.
- Works well with Processing, which is a free and powerful language for visualization




Arduino picture from Sparkfun CC-BY-2.0





PSD Basics



Mathematics of PSD

$$\begin{aligned} V_{\textit{mix}} &= V_{\textit{s}} V_{\textit{r}} \left[\left(\cos \left(\omega_{\textit{s}} - \omega_{\textit{r}} \right) t - \left(\phi_{\textit{s}} - \phi_{\textit{r}} \right) \right] \\ V_{\textit{o}} &= A \frac{V_{\textit{s}} V_{\textit{r}}}{2} \left[\cos (\phi_{\textit{s}} - \phi_{\textit{r}}) \right] \end{aligned}$$


Restrictions

- \bullet $\omega_r = \omega_s$
- V_s and V_r have no DC offset






Flowchart







Phase Manipulation



- Need to be able to shift phase to maximize signal
- All-pass phase shifters work, but require a bit more hardware external to Ardunio
- Software solutions difficult to implement
- Use two phase detection.

•
$$V_I = V_s \times \cos(\theta), V_Q = V_s \times \sin(\theta)$$


$$\bullet R = \sqrt{V_I^2 + V_Q^2}$$

$$\bullet \ \phi = \tan^{-1}(V_Q/V_I)$$





Creating a Reference Signal




Timers and Interrupts Part I

- The ratio of PWM on to off determines an average "DC" signal
- When register TCNT1 reaches OCR1A PWM goes low
- When TCNT1 overflows PWM goes high again





Creating a Reference Signal





Timers and Interrupts Part II

- Need fast timer2 and regular timer1, which outputs PWM
- When timer2 reaches OCR2A:
 - Update OCR1A from wavetable
 - read signal at AnalogIn
- When timer1 counts up to OCR1A, PWM goes low
- When timer1 overflows PWM goes high again







Signal Input














Signal Input

- Arduino can only have positive voltages at its inputs or outputs
 - Integer overflow when mixing
 - Necessary DC offsets makes phase indefinite
- Need to run ADC as fast as we can so as to to interfere with reference generation.
 - Setting pre-scalars and registers can get sampling rates of 50k samples/sec. Not bad for a 30 board!
 - ADC has 10 bit resolution with adjustable V_{ref}, so resolution on the order of a millivolt is possible






Display



In-phase channel as phase is changed







What we accomplished

- Built and tested a working two-channel phase-sensitive detector
- Learned techniques that can be used for other micro-processor based instruments
- Published on github under GPL v3 license

Still to do

- Characterize detector (noise, internal phase shift, etc...)
- Clean up display
- Explore other memory options on Arduino
- Use in an application





For Further Reading I



https://github.com/HartwickChaosLab/ Arduino-Phase-Sensitive-Detector

Arduino

http://www.arduino.cc

Processing

http://processing.org

Moding the Arduino ADC

https://sites.google.com/site/measuringstuff/
the-arduino

J. Thompson

"Advanced Arduino Sound Synthesis"

Make Vol. 35



