

# **Parameter Passing**

**Computer Engineering 1** 

### **Motivation**



```
#include <stdio.h>
int32 t doubleTheValue(int32 t b);
int32 t main(void)
   int32 t a = 5;
   a = doubleTheValue(a);
  printf("%d\n", a);
int32 t doubleTheValue(int32 t b)
  int32 t c = b + b;
   return c;
```

- How does main() pass the value of a to the function?
- Where is the local variable c stored?
- How is the value of c returned to main()?

## Agenda



- Parameter Passing
- Passing through Registers
- Passing through Global Variables
- Reentrancy
- ARM Procedure Call Standard
- Functions Stack Frame
- Calling Assembly Subroutines from C

## Learning Objectives



At the end of this lesson you will be able

- to explain and classify the different possibilities to pass data between different parts of the program
- to outline what an Application Binary Interface is
- to name the roles of the different registers in the ARM Procedure Call Standard
- to enumerate and describe the operations of the caller of a subroutine
- to summarize the structure of a subroutine and describe what happens in the prolog and epilog respectively
- to explain, interpret and discuss stack frames
- to access elements of a stack frame in assembly
- to understand the build-up and tear-down of stack-frames
- to call an assembly subroutine from a C program

## Parameter Passing



#### ■ Where?

- Register
  - Caller and Callee<sup>1)</sup> use the same register
- Global variables
  - Shared variables in data area (section)
- Stack
  - Caller → PUSH parameter on stack
  - Callee → access parameter through LDR <Rt>, [SP, #<imm>]

#### ■ How?

- pass by value
  - Handover the value
- pass by reference
  - Handover the address to a value

<sup>1)</sup> Caller: the routine that calls the subroutine; Callee: the subroutine being called

## Passing through Registers



### Register / "pass by value"

```
AREA exData, DATA, . . .
        AREA exCode, CODE, ...
                  R1, #0x03
          MOVS
                  double
          BL
  caller
           MOVS
                  ...,R0
        double
callee
                  R0,R1,#1
           LSLS
function
          BX
                  LR
double
```

6

#### Values in agreed registers, e.g.

- R1 Parameter:
   Caller → function
- R0 Return value of function
- Efficient and simple
- Limited number of registers
  - How do we pass tables and structs?

## Passing through Registers



#### Register / "pass by reference"

```
TLENGTH
                     16
            EQU
AREA exData, DATA, . . .
plTable SPACE TLENGTH
AREA exCode, CODE, ...
        R0,=p1Table
  LDR
        R1, #TLENGTH
  MOVS
        doubleTableValues
  BL
doubleTableValues
            R2,#0
     MOVS
loop LDRB R4, [R0,R2]
            R4,R4,#1
     LSLS
            R4, [R0, R2]
     STRB
           R2,#1
     ADDS
            R2,R1
     CMP
            loop
     BLO
            LR
     BX
```

- Pass reference (= address) of data structure in register
- Allows passing of larger structures
- Example
  - Function doubleTableValues
    - doubles each value in the table
  - R0 Caller passes address of p1Table
  - R1 Caller passes length of table (pass by value)

caller

callee
function
doubleTableValues

<sup>1)</sup> Filling the table with values is not shown in the code

## Passing through Global Variables



#### **Global Variables**

```
AREA exData, DATA, . . .
param1
         SPACE 1
result.
         SPACE 1
AREA exCode, CODE, ...
  LDR
           R4,=param1
           R5, #0x03
  MOVS
           R5, [R4]
  STRB
           double q
  BL
           R4,=result
  LDR
  LDRB
           ..., [R4]
double g
  LDR
           R4,=param1
           R1, [R4]
  LDRB
           R0,R1,#1
  LSLS
           R4,=result
  LDR
           R0, [R4]
  STRB
  BX
           LR
```

#### Shared variables in data area

- param1 Caller → procedure
- result Return value

#### Overhead to access variable

In Caller and Callee

#### Error-prone, unmaintainable

- No encapsulation,
- Many dependencies
  - Multiple use of the same variable
  - Where is the variable written?
  - Who is allowed to read variable?
- Requires unique variable names
  - Challenge if there is a large number of modules

caller


callee function double\_g

## Reentrancy



#### Recursive Function Calls?

- Registers and global variables are overwritten
- Requires an own set of data for each call
  - Parameters / Local variables



#### Solution

- Combined use of registers and stack for parameter passing
- See ARM Procedure Call Standard



#### Procedure Call Standard for the ARM architecture (AAPCS)

- http://infocenter.arm.com/help/topic/com.arm.doc.ihi0042e/IHI0042E\_aapcs.pdf
- Part of the ABI (Application Binary Interface) for the ARM Architecture
- ABI → Specification to which independently produced relocatable object files must conform to be statically linkable<sup>1)</sup> and executable
  - Function calls
  - Parameter passing
  - Binary formats of information



source: colourbox

"The AAPCS defines how subroutines can be separately written, separately compiled, and separately assembled to work together. It describes a contract between a calling routine (caller) and a called routine (callee)."

→ Enables interaction of code produced by different compilers.



### AAPCS specifies

Most of the items have already been covered in this course

Layout of data	Size, alignment, layout of fundamental data types
Register Usage	What are the registers used for
Memory Sections and Stack	Code, read-only data, read-write data, stack, heap
Stack	• Full-descending, word-aligned,
Subroutine Calls	Mechanism using LR and PC
Result Return	<ul> <li>Returning arguments through r0 (and r1 – r3)</li> </ul>
Parameter Passing	Passing arguments in r0-r3 and on stack



#### Register Usage

12

Register	Synonym	Role
r0	a1	Argument / result / scratch register 1
r1	a2	Argument / result / scratch register 2
r2	a3	Argument / scratch register 3
r3	a4	Argument / scratch register 4
r4	v1	Variable register 1
r5	v2	Variable register 2
r6	v3	Variable register 3
r7	v4	Variable register 4
r8	v5	Variable register 5 Cortex-M0: Registers
r9	v6	Variable register 6 r8 – r11 have limited set of
r10	v7	Variable register 7 instructions. Therefore, they are often not used by
r11	v8	Variable register 8 compilers.
r12	IP	Intra-Procedure-call scratch register <sup>1)</sup>
r13	SP	
r14	LR	
r15	PC	

**Register contents** might be modified by callee

**Callee must** preserve contents of these registers (Callee saved)



#### Scratch Register

- Used to hold an intermediate value during a calculation
- Usually, such values are not named in the program source and have a limited lifetime

#### Variable Register

- A register used to hold the value of a variable, usually one local to a routine, and often named in the source code.
- Cortex-M0 registers R8 R11 (v5 v8) are often unused
  - as they are accessible only by few instructions

#### Argument, Parameter

- Used interchangeably
- Formal parameter of a subroutine



29.07.2020

#### Parameters

14

- Caller copies arguments to R0 to R3
- Caller copies additional parameters to stack

#### Returning fundamental data types

Smaller than word zero or sign extend to word; return in R0

Word return in R0

Double-word return in R0 / R1 <sup>1)</sup>

• 128-bit return in R0 – R3 <sup>1)</sup>

#### ■ Returning composite data types (structs, arrays, ...)

Up to 4 bytes return in R0

Larger than 4 bytes stored in data area; address passed as

extra argument at function call

<sup>1)</sup> Least significant word stored in lowest register



#### Example

```
void caller(void)
{
    uint32_t p = 4;
    uint32_t q = 5;
    uint32_t r = 6;
    uint32_t sum;

sum = callee(p,q,r);
}
```

```
MOVS
      r4,#4
                local variables
      r5,#5
MOVS
                R4 - R6
      r6,#6
MOVS
      r2,r6
MOV
                copy parameters
    r1,r5
MOV
                to R0 - R2
      r0,r4
MOV
BL
      callee
                copy return value
      r7,r0 }
MOV
                to local variable
```


```
callee PROC
ADDS r0,r0,r1 callee uses
ADDS r0,r0,r2 own copies
BX lr of parameters
ENDP
```


PUSH and POP are omitted in the example



#### Subroutine Call – Caller Side

Pattern as used by the compiler. Manually written assembly code may be slightly different.









#### Subroutine Structure – Callee Side

Pattern as used by the compiler. Manually written assembly code may be slightly different.






<sup>1)</sup> only registers modified by the callee are saved and restored. r8 – r11 are often unused by the compiler.




### Summary – Flow of Execution for a Subroutine Call



t









#### Access to Local Variables on Stack

Example using word sized variables



Compiler uses indirect addressing relative to stack pointer (SP)



R0 and R1 used as scratch register



#### Functions in C

- Subroutine with return value (usually in register R0 / R1)
- Function Parameters
  - Always "pass by value"
  - Copy is being passed (not the original)
  - "pass by reference" only possible through use of pointers
    - → Pointer itself passed by value
  - Registers R0 R3
    - → starting with the first argument in R0
  - Stack if more space is required
- Local Variables
  - In registers R4 R7
  - On stack if more space is required or address operator (&) is used



stack


#### Example

```
a[0]
int main(void)
{
                                  MOV r0,...; start
                                                                  a[1]
  uint32 t start = 0x1234;
                                  BL calc
  uint32 t result = 0;
                                                                              stack frame
                                                                  a[6]
                               > PUSH {r4-r7,lr}
  result = calc(start);
                                                                  a[7]
                                  ;allocate a[] on stack
}
                                                                   r4
                                _{\pi} SUB sp,sp,\#0x20
uint32 t calc (uint32 t val)
                                                                   r5
                                _{7} MOVS r6,#0 ;res
                                                                   r6
  uint32 t a[8];
                                  ;access a[0]
                                                                   r7
  uint32 t res = 0;
                                \rightarrow STR r0, [sp, #0x00]
                                                                   1 r
  a[0] = val;
                                → MOV
                                        r0,r6 ;res
                                  ;stack teardown
  return res;
                                  ADD sp,sp,\#0x20
                                  POP {r4-r7,pc}
```



#### Build-up and tear-down of stack frames

```
int32 t main(void)
  int16 t x, y;
  x = func1(...);
  y = func2(...)
int16 t func1(...)
  z = func3(...)
int16 t func2(...) {...}
int16 t func3(...) {...}
```



### Calling Assembly Subroutines from C



```
extern void strcopy(char *d, const char *s);
int main (void)
 const char *srcstr = "First string";
 char dststr[] = "Second string";
 strcopy(dststr, srcstr);
 return (0);
           PRESERVE8
           AREA
                   SCopy, CODE, READONLY
           EXPORT strcopy
           ; R0 points to destination string
           ; R1 points to source string
strcopy
           LDRB R2, [R1] ; Load byte and update address
           ADDS R1, R1, #1
           STRB R2, [R0]
                            ; Store byte and update address
           ADDS R0, R0, #1
           CMP R2, #0
                            : Check for null terminator
           BNE strcopy
                            ; Keep going if not
           BX
                             : Return
                LR
END
```

Example: from ARM Ltd.

#### Conclusions



#### Parameter Passing

- Through registers
- Through global variables
- On the stack (stack frame)

#### Procedure Call Standard

- R0 R3 parameters / scratch → callee may modify these registers
- R4 R7 local variables → callee restores potentially modified registers
- R0 R3 Return

#### Stack Frame

25

- Nesting of subroutines
- Stack frame is constructed at function call
- Stack frame is deconstructed when function terminates (returns)

