# CE218472 - PSoC 6 MCU: Comparing External Voltages Using a Low-Power Comparator

## **Objective**

This example demonstrates the voltage comparison functionality using the LPComp resource in  $PSoC^{\otimes}$  6 MCU, with  $ModusToolbox^{TM}$  IDE.

### Requirements

Tool: ModusToolbox IDE 1.0
Programming Language: C

Associated Parts: All PSoC 6 MCU parts

Related Hardware: PSoC 6 BLE Pioneer Kit, PSoC 6 WiFi-BT Pioneer Kit, PSoC 6 WiFi-Prototyping Kit

#### Overview

This code example demonstrates how to configure the low-power comparator (LPComp) resource for comparing internal reference voltage and external voltage input from a GPIO. The LED is used to indicate the comparison result.

## **Hardware Setup**

This example uses the PSoC 6 BLE Pioneer Kit's default configuration. See the kit guide to ensure the kit is configured correctly.

**Note**: The PSoC 6 BLE Pioneer kit and the PSoC 6 WiFi-BT Pioneer kit ship with KitProg2. ModusToolbox only works with KitProg3. Before using this code example, make sure that the kit is upgraded to KitProg3. See ModusToolbox Help > ModusToolbox IDE Documentation > User Guide; section PSoC 6 MCU KitProg Firmware Loader. If you do not upgrade, you will see an error like "unable to find CMSIS-DAP device" or "KitProg firmware is out of date".

### **Software Setup**

None.

## Operation

Follow the instructions that came with your kit to make sure the kit is connected to your PC.

- 1. Place a potentiometer on P5[6] to change the Vplus input voltage.
- 2. Import the code example into a new workspace. If you are not familiar with this process, see KBA225201.
- Program the PSoC 6 MCU device. In the project explorer, select the mainapp project. In the Quick Panel, scroll to the Launches section and click the Program (KitProg3) configuration.
- 4. Turn the knob of the potentiometer until the Vplus input is higher than Vref.
- 5. Confirm that KIT\_LED2 is OFF.
- 6. Turn the knob of the potentiometer until the Vplus input is lower than Vref.
- 7. Confirm that KIT\_LED2 is ON.

# Debugging

You can debug the example to step through the code. Use the **Debug (KitProg3)** configuration. If you are unfamiliar with how to start a debug session with ModusToolbox IDE, see KBA224621.



# **Design and Implementation**

PSoC 6 MCU is a dual-CPU architecture MCU with Arm® CM0+ and Arm CM4 CPUs. The CM0+ CPU enables the CM4 CPU on device reset. This code example uses one LPComp resource, one status LED, one GPIO used for the input external input voltage, and one potentiometer.

The main function compares the LPComp inputs when an interrupt triggers; it updates the LED state and goes into Deep Sleep to wait for the next interrupt. The status LED shows the voltage comparison result. If the positive terminal input is higher than the negative terminal input, the LED is OFF; otherwise, it is ON.

Note: The internal reference voltage (Vref) can vary; see the device datasheet for the range.

#### **Resources and Settings**

Table 1 lists the ModusToolbox resources used in this example, and how they are used in the design. For pin usage and configuration, open the **Pins** tab of the *design.modus* file.

Table 1. ModusToolbox Resources

Resource	Alias	Purpose
Low-Power Comparator	LPComp	Provide low-power voltage comparison
Digital Output Pin	KIT_LED2	Provide visual feedback
Analog Input Pin	Vplus	Provide user input

Figure 1 to Figure 3 show the non-default configuration settings for the ModusToolbox resources.




Figure 1. LPComp Configuration







Figure 2. GPIO Configuration for Non-Inverting Terminal

Figure 3. GPIO Configuration for LED Pin



# Reusing this Example

This example is designed for the supported kits. To port the design to a different PSoC 6 MCU device, right-click an application project and choose **Change Device**. If changing to a different kit, you may need to reassign pins.



Table 2. Device and Pin Mapping Table across PSoC 6 MCU Kits

Kit Name	Device Used	LED
CY8CKIT-062-WiFi-BT	CY8C6247BZI-D54	P13[7]
CY8CKIT-062-BLE	CY8C6347BZI-BLD53	P13[7]
CY8CPROTO-062-4343W	CY8C624ABZI-D44	P13[7]

In some cases, a resource used by a code example (for example, an IP block) is not supported on another device. In that case the example will not work. If you build the code targeted at such a device, you will get errors. See the device datasheet for information on what a particular device supports.

#### **Related Documents**

For a comprehensive list of PSoC 6 MCU resources, see KBA223067 in the Cypress community.

Application Notes				
AN210781 – Getting Started with PSoC 6 MCU with Bluetooth Low Energy (BLE) Connectivity	Describes PSoC 6 MCU devices with BLE connectivity and how to build your first PSoC Creator™ project and ModusToolbox application			
AN221774 – Getting Started with PSoC 6 MCU	Describes PSoC 6 MCU devices and how to build your first PSoC Creator project and ModusToolbox application			
AN215656 – PSoC 6 MCU: Dual-CPU System Design	Describes the dual-CPU architecture in PSoC 6 MCU devices, and shows how to build simple dual-CPU design			
Code Examples				
CE218129 - PSoC 6 MCU Wake up from Hibernate using a Low-Power Comparator				
Visit the Cypress GitHub site for a comprehensive collection of code examples using ModusToolbox IDE				
Device Documentation				
PSoC 6 MCU: PSoC 63 with BLE Datasheet	PSoC 6 MCU: PSoC 63 with BLE Architecture Technical Reference Manual			
Development Kit Documentation				
CY8CKIT-062-BLE PSoC 6 BLE Pioneer Kit				
CY8CKIT-062-WiFi-BT PSoC 6 WiFi-BT Pioneer Kit				
CY8CPROTO-062-4343W PSoC 6 Wi-Fi BT Prototyping Kit				
Tool Documentation				
ModusToolbox	The Cypress IDE for IoT designers			

# **Cypress Resources**

Cypress provides a wealth of data at www.cypress.com to help you to select the right device, and quickly and effectively integrate the device into your design.

For the PSoC 6 MCU devices, see KBA223067 in the Cypress community for a comprehensive list of PSoC 6 MCU resources.



# **Document History**

Document Title: CE218472 - PSoC 6 MCU: Comparing External Voltages Using a Low-Power Comparator

Document Number: 002-24749

Revision	ECN	Orig. of Change	Submission Date	Description of Change
**	6371312	AJYA	11/13/2018	New code example

5



## **Worldwide Sales and Design Support**

Cypress maintains a worldwide network of offices, solution centers, manufacturers' representatives, and distributors. To find the office closest to you, visit us at Cypress Locations.

#### **Products**

Arm® Cortex® Microcontrollers cypress.com/arm

Automotive cypress.com/automotive

Clocks & Buffers cypress.com/clocks

Interface cypress.com/interface

Internet of Things cypress.com/iot

Memory cypress.com/memory

Microcontrollers cypress.com/mcu

PSoC cypress.com/psoc

Power Management ICs cypress.com/pmic

Touch Sensing cypress.com/touch

USB Controllers cypress.com/usb

Wireless Connectivity cypress.com/wireless

#### **PSoC® Solutions**

PSoC 1 | PSoC 3 | PSoC 4 | PSoC 5LP | PSoC 6 MCU

## **Cypress Developer Community**

Community Forums | Projects | Videos | Blogs | Training | Components

## **Technical Support**

cypress.com/support

PSoC is a registered trademark; PSoC Creator and ModusToolbox are trademarks of Cypress Semiconductor Corporation. All other trademarks or registered trademarks referenced herein are the property of their respective owners.



Cypress Semiconductor 198 Champion Court San Jose, CA 95134-1709

© Cypress Semiconductor Corporation, 2018. This document is the property of Cypress Semiconductor Corporation and its subsidiaries, including Spansion LLC ("Cypress"). This document, including any software or firmware included or referenced in this document ("Software"), is owned by Cypress under the intellectual property laws and treaties of the United States and other countries worldwide. Cypress reserves all rights under such laws and treaties and does not, except as specifically stated in this paragraph, grant any license under its patents, copyrights, trademarks, or other intellectual property rights. If the Software is not accompanied by a license agreement and you do not otherwise have a written agreement with Cypress governing the use of the Software, then Cypress hereby grants you a personal, non-exclusive, nontransferable license (without the right to sublicense) (1) under its copyright rights in the Software (a) for Software provided in source code form, to modify and reproduce the Software solely for use with Cypress hardware products, only internally within your organization, and (b) to distribute the Software in binary code form externally to end users (either directly or indirectly through resellers and distributors), solely for use on Cypress hardware product units, and (2) under those claims of Cypress's patents that are infringed by the Software (as provided by Cypress, unmodified) to make, use, distribute, and import the Software solely for use with Cypress hardware products. Any other use, reproduction, modification, translation, or compilation of the Software is prohibited.

TO THE EXTENT PERMITTED BY APPLICABLE LAW, CYPRESS MAKES NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THIS DOCUMENT OR ANY SOFTWARE OR ACCOMPANYING HARDWARE, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. No computing device can be absolutely secure. Therefore, despite security measures implemented in Cypress hardware or software products, Cypress does not assume any liability arising out of any security breach, such as unauthorized access to or use of a Cypress product. In addition, the products described in these materials may contain design defects or errors known as errata which may cause the product to deviate from published specifications. To the extent permitted by applicable law, Cypress reserves the right to make changes to this document without further notice. Cypress does not assume any liability arising out of the application or use of any product or circuit described in this document. Any information provided in this document, including any sample design information or programming code, is provided only for reference purposes. It is the responsibility of the user of this document to properly design, program, and test the functionality and safety of any application made of this information and any resulting product. Cypress products are not designed, intended, or authorized for use as critical components in systems designed or intended for the operation of weapons, weapons systems, nuclear installations, life-support devices or systems, other medical devices or systems (including resuscitation equipment and surgical implants), pollution control or hazardous substances management, or other uses where the failure of the device or system could cause personal injury, death, or property damage ("Unintended Uses"). A critical component is any component of a device or system whose failure to perform can be reasonably expected to cause the failure of the device or system, or to affect its safety or effectiveness. Cypress is not liable, in whole or in part, and you shall and hereby do release Cypress from any claim, damage, or other liability arising from or related to all Unintended Uses of Cypress products. You shall indemnify and hold Cypress harmless from and against all claims, costs, damages, and other liabilities, including claims for personal injury or death, arising from or related to any Unintended Uses of Cypress products.

Cypress, the Cypress logo, Spansion, the Spansion logo, and combinations thereof, WICED, PSoC, CapSense, EZ-USB, F-RAM, and Traveo are trademarks or registered trademarks of Cypress in the United States and other countries. For a more complete list of Cypress trademarks, visit cypress.com. Other names and brands may be claimed as property of their respective owners.