## **Chapter 4 Connecting Smart Objects**



RFID Systems



Smart Machinery



Digital Signage



Phones and Tablets



Security Systems



Home Automation



Medical Devices

For IoT to produce data that is to be visualized, the sensors and actuators have to be connected using various protocols.

To achieve this connectivity, **characteristics and communications criteria** as well as **The various technologies used** need to be studied

The communication criteria that needs to be expounded include;


 Range, Frequency Bands, Power Consumption, Topology, Constrained Devices, Constrained-Node Networks.

Technologies for connecting smart objects include;

• IEEE 802.15.4, IEEE 802.15.4g and IEEE 802.15.4e, IEEE 1901.2a, IEEE 802.11ah, LoRaWAN, NB-loT and Other LTF Variations.

### 1. Communications Criteria

In connecting things both wired and wireless connections are available or under development.




[Image from Senseware blog on iot-implementations-wireless-vs-wired]

Wireless Connections is more prevalent over wired because it eases deployment and allows smart objects to be mobile, changing location without losing connectivity. But nevertheless, wired connections are used where necessary.

# 1. Range

Range as one of the communication criteria helps us to answer the following questions while evaluating options of wired and wireless access technologies.

- How far does the signal need to be propagated?
- That is, what will be the area of coverage for a selected wireless technology?
- Should indoor versus outdoor deployments be differentiated?



### Short Range:

The classical wired example is a serial cable. Wireless short-range technologies are often considered as an alternative to a serial cable, supporting tens of meters of maximum distance between two devices. Signals are transmitted as low as 10 kbit/s making it not suitable for deployment in most cases.

Examples include Bluetooth and Visible Light Communications

### Medium Range

• This connection spans from 10 to 100 of meters, the maximum distance is generally 1 mile (1600 meters) between two devices.

RF technologies do not have real maximum distances defined, as long as the radio signal is transmitted and received in the scope of the applicable specification.

Medium Range Wireless Technologies

-IEEE 802.11 Wi-Fi,

-IEEE 802.15.4,

-802.15.4g WPAN

Wired Technologies

-IEEE 802.3 Ethernet

-IEEE 1901.2 Narrowband Power Line Communications (PLC)

### Long range

Two devices with distance of 1 mile between themselves require long – range technologies.

Examples include cellular(2G, 3G and 4G and 5G) and outdoor IEEE 802.11 Wi-Fi and Low-Power Wide-Area (LPWA) technologies.

Long range connections are found mainly in Industrial networks, IEEE 802.3 over optical fiber and IEEE 1901 Broadband Power Line Communications.

For wireless deployment, consider;

- Specifications or product descriptions
- A proper radio planning using appropriate tools
- Field radio survey to better understand the actual conditions in a given area such as noise and interference
- Landscape and topology changes in the field such as buildings that may interfere with signal transmission

# 2. Frequency Bands

Frequency bands are ranges of radio wave frequencies used to transmit data in the wireless spectrum, and can further be broken down into WiFi channels. The higher the frequency, the faster the data transmission and shorter the signal range.

Focusing on IoT access technologies, the frequency bands leveraged by wireless communications are split
between licensed and unlicensed bands. Licensed spectrum is generally applicable to IoT long-range access
technologies and allocated to communications infrastructures deployed by services providers, public services (for
example, first responders, military), broadcasters, and utilities.

When deploying large numbers of devices in licensed spectrum, there are platforms such as CISCO Jasper Control Center which make automating the provisioning, deployment, and management of large numbers of devices has become much easier.

### **Licensed vs Unlicensed bands**

Licensed Spectrum is that in which users must subscribe to services when connecting their IoT devices. Licensed spectrum include

Cellular, WiMAX and NarrowBand IoT(NB-IoT) Technologies.

Unlicensed means that no guarantees or protections are offered in the ISM(Industrial, Scientific and Medical) bands for device communications. These bands are not regulated

Examples include; 2.4 GHz band as used by IEEE 802.11b/g/n Wi-Fi, IEEE 802.15.1 Bluetooth, IEEE 802.15.4 WPAN

Regulation of bands mandates device compliance on parameters such as transmit power, duty cycle and dwell time, channel bandwidth, and channel hopping.

Unlicensed spectrum is usually simpler to deploy as it does not require service provider but suffer reliability and performance issues frequently than those implementing licensed spectrum

See ... https://www.iotacommunications.com/blog/licensed-vs-unlicensed-spectrum/

## Sub-GHz range

• Some communications within the ISM bands operate in the sub-GHz range.

Sub-GHz bands are used by protocols such as IEEE 802.15.4, 802.15.4g, and 802.11ah, and LPWA technologies such as LoRa and Sigfox

Advantage of Sub-Ghz bands;

- Sub-GHz bands allow greater distances between devices better than the 2.4 GHz ISM band.
- Low power consumption

Disadvantage of Sub-GHz bands;

Lower rate of data delivery compared to higher frequencies (not a concern for IoT Sensors)

Several sub-GHz ranges have been defined in the ISM band. The most well-known ranges are centered on 169 MHz, 433 MHz, 868 MHz, and 915 MHz. However, most IoT access technologies tend to focus on the two sub-GHz frequency regions around 868 MHz and 915 MHz.

## **Band Regulation parameters**

• Several bands in different countries are not licensed but they are just regulated.


The regulators document parameters such as;

- Channel bandwidth; effective bandwidth multiplied by frequency reuse factor
- Channel Hopping; works by synchronizing the nodes in the network along a sequence of channels. All nodes must know the sequence and all nodes must know where in the sequence they should be.
- Transmit Power; The proportionality of effective range to the access point Higher Transmitting power, the farther the signal travel
- Dwell Time; (or transmit time) is the amount of time needed to transmit on a frequency.
- The UCC in Uganda notes that, the use of wireless devices in the bands 5150-5350 MHz, 5470-5725 MHz and 5725-5825 MHz for Wireless Access Systems including Radio Local Area Networks (WAS/RLAN's) would be used to enhance wireless connection in the country. For more details https://www.ucc.co.ug/files/downloads/Guidelines-for-use-of-5.8-GHz-ISM-band.pdf

# 3. Power Consumption

A powered node has a direct connection to a power source, and communications are usually not limited by power consumption criteria


- IoT wireless access technologies must address the needs of low power consumption and connectivity for battery-powered nodes.
- This need for reduced power consumption has led to Low-Power Wide-Area (LPWA) wireless environment.
- Wired IoT technologies are not exempted from power consumption



# 4. Topology

A topology defines the way various components communicate with each other within an IoT network.

- Star topology-
- Peer-to-peer-
- Mesh topology-



**Figure 4-2** *Star, Peer-to-Peer, and Mesh Topologies* 

## 4. Constrained Devices

- While categorizing the class of IoT nodes, constrained devices can be defined in terms of perilous exercise,
   with computing, memory, storage, power, and networking continuously evolving and improving.
- Constrained nodes have limited resources that impact their networking feature set and capabilities.

Classes of Constrained Nodes, as Defined by RFC 7228

Class 0; This class of nodes is severely constrained, with less than 10 KB of memory and less than 100 KB of Flash processing and storage capability for example a push button.

Class 1; These nodes can implement an optimized stack specifically designed for constrained nodes, such as Constrained Application Protocol (CoAP) example are environmental sensors.

Class 2; These nodes are characterized by running full implementations of an IP stack on embedded devices. Example power meter

## **Constrained-Node Networks**

These are often referred to as low-power and lossy networks (LLNs).

- Low Power refers to the fact that nodes must cope with the requirements from powered and battery-powered constrained nodes
- Lossy networks indicates that network performance may suffer from interference and variability due to harsh radio environments

Characteristics of protocols used in constrained-Node Network.

- Latency and Determinism
- Data Rate and Throughput
- Overhead and Payload

# **IoT Access Technologies**

• This criteria highlights technologies that are seen as having market and/or mind share.

The following topics address the IoT access technology

- Standardization and alliances: The standards bodies that maintain the protocols for a technology
- Physical layer: The wired or wireless methods and relevant frequencies
- MAC layer: Considerations at the Media Access Control (MAC) layer, which bridges the physical layer with data link control
- Topology: The topologies supported by the technology
- Security: Security aspects of the technology
- Competitive technologies: Other technologies that are similar and may be suitable alternatives to the given technology

## **Access Technologies**

- IEEE 802.15.4
- IEEE 802.15.4g and 802.15.4e
- IEEE 1901.2a
- IEEE 802.11ah
- LoRaWAN
- NB-IoT and Other LTE Variations

### **IEEE 802.15.4**

- IEEE 802.15.4 is a wireless access technology for low-cost and low-data-rate devices that are powered or run on batteries. It enables easy installation.
- It can be found in the following deployments

Home and building automation

Automotive networks

Industrial wireless sensor networks

Interactive toys and remote controls

Criticism of IEEE 802.15.4

MAC reliability; Other devices are transmitting so there is back-off(waiting and listening time before transmission)

**Unbound Latency** 

• Multi-path fading; Multipath fading refers to multiple copies of the signal hitting the receiver at different points in time because of different signal paths and reflections, IEEE.802.15.2 lacks a frequency-hopping technique

## Protocols based on IEEE 802.15.4

#### 1. ZigBee;

It defines upper-layer components (network through application) as well as application profiles. These include building automation,
 home automation, and healthcare

#### 2. 6LoWPAN;

 6LoWPAN is an IPv6 adaptation layer defined by the IETF 6LoWPAN working group that describes how to transport IPv6 packets over IEEE 802.15.4 layers

### 3. ZigBee IP;

- It adopts the 6LoWPAN adaptation layer, IPv6 network layer, and RPL routing protocol

#### 4. ISA100.11a;

 ISA100.11a is developed by the International Society of Automation (ISA) as "Wireless Systems for Industrial Automation: Process Control and Related Applications."

other protocols include; WirelessHART and Thread.

# ZigBee

ZigBee solutions are aimed at smart objects and sensors that have low bandwidth and low power needs.
 Furthermore, products that are ZigBee compliant and certified by the ZigBee Alliance should interoperate even though different vendors may manufacture them.

The application support layer in Figure 4-3 interfaces the lower portion of the stack dealing with the networking of ZigBee devices with the higher-layer applications.

**Network and security layer** provides mechanisms for network startup, configuration, routing, and securing communications. and topology.

**MAC Layer**; defines how devices in the same area will share the frequencies allocated.

PHY Layer; this defines how frequencies are modulated

Application/Profiles

Application Support

Application Support

Network and Security Layer

MAC Layer

PHY Layer

Zigbee or Vendor Specific

Zigbee Platform Stack

IEEE 802.15.4

**Figure 4-3** *High-Level ZigBee Protocol Stack* 

ZigBee has not provided interoperability with other IoT solutions that is why ZigBee was developed

# ZigBee IP

• In this IEEE 802.15.4 continues with support of IP and TCP/UDP protocols and various other open standards

ZigBee IP was designed specifically for Smart Energies SE 2.0 but it is not limited to this use case




Figure 4-4 ZigBee IP Protocol Stack

- -ZigBee IP supports 6LoWPAN as an adaptation layer unlike ZigBee.
- -At Network layer ZigBee IP nodes support IPv6, ICMPv6, and 6LoWPAN Neighbor Discovery (ND)

The compelling protocol stack of ZigBee opens up opportunities for ZigBee IP to integrate and interoperate on just about any 802.15.4 network with other solutions built on these open IoT standards

## PHY and MAC layers of IEEE 802.15.4

#### Physical Layer


The 802.15.4 standard supports an extensive number of PHY options that range from 2.4 GHz to sub-GHz frequencies in ISM bands.

The original IEEE 802.15.4-2003 standard specified only three PHY options based on direct sequence spread spectrum (DSSS) modulation, Originally, the transmission layer was as follows;

- 2.4 GHz, 16 channels, with a data rate of 250 kbps
- 915 MHz, 10 channels, with a data rate of 40 kbps
- 868 MHz, 1 channel, with a data rate of 20 kbps
- The following were introduced to support the above three in communication
  - OQPSK PHY: employs offset quadrature phase-shift keying (OQPSK) modulation
  - BPSK PHY: employs binary phase-shift keying (BPSK) modulation
  - ASK PHY: employs amplitude shift keying (ASK) and BPSK modulation

These improvements increase the maximum data rate for both 868 MHz and 915 MHz to 100 kbps and 250 kbps, respectively.

## IEEE 802.15.4 PHY Format



**Figure 4-5** *IEEE 802.15.4 PHY Format* 


The **PHY Header** portion of the PHY frame shown in Figure 4-5 is simply a frame length value. It lets the receiver know how much total data to expect in the PHY service data

Products and solutions implementing PHY must refer to the proper IEEE 802.15.4 specification, frequency band, modulation, and data rate

## MAC Layer of IEEE 802.15.4

- The IEEE 802.15.4 MAC layer manages access to the PHY channel by defining how devices in the same area will share the frequencies allocated.
- Tasks performed at Mac Layer
  - Network beaconing for devices acting as coordinators (New devices use beacons to join an 802.15.4 network)
  - PAN association and disassociation by a device.
  - Device security.
  - Reliable link communications between two peer MAC entities
- These tasks can be achieved using predefined data frame types;
  - Data frame: Handles all transfers of data.
  - Beacon frame: Used in the transmission of beacons from a PAN coordinator
  - Acknowledgement frame: Confirms the successful reception of a frame
  - MAC command frame: Responsible for control communication between devices

## **IEEE 802.15.2 MAC Layer Format**



Frame Control field: defines attributes such as frame type, addressing modes, and other control flags.

Sequence Number field indicates the sequence identifier for the frame

Addressing field specifies the Source and Destination PAN Identifier fields as well as the Source and Destination Address fields

MAC Payload field defines payloads related to beacons and MAC commands

MAC Footer field defines a frame check sequence, calculation of data in the frame

 Table 4-6
 Main Characteristics of Access Technologies Discussed in This Chapter

		and				
Characteristic	IEEE 802.15.4	IEEE 802.15.4e	IEEE 1901.2a	IEEE 802.1 1ah	LoRaWAN	NB-IoT
Wired or wireless	Wireless	Wireless	Wired	Wireless	Wireless	Wireless
Frequency	Unlicensed 2.4 GHz and sub-GHz	Unlicensed 2.4 GHz and sub-GHz	Unlicensed CENELEC A and B, FCC, ARIB	Unlicensed sub-GHz	Unlicensed sub-GHz	Licensed
Topology	Star, mesh	Star, mesh	Mesh	Star	Star	Star
Range	Medium	Medium	Medium	Medium	Long	Long
Data rate	Low	Low	Low	Low-high	Low	Low

## **IEEE 802.15.4 Topology**