
Lecture 29 – Processor design 4


- We will look at the process of instruction fetching and execution
- The processor works autonomously as a continuous fetch-andexecute engine, with no other input than an external clock
- Since instructions as in the machine code are stored in memory, they have to be brought to the processor one by one and executed
- The instruction at address (i + 1) has to be fetched and executed after instruction i, since the instructions of a program are stored consecutively in the memory
- The processor has to do all these by itself

- Processors have a special register inside them that manages the process of instruction fetch by keeping track of the address of the next instruction to be fetched at all times
- This register is called the program counter or the PC
- The processing of an instruction begins with fetching its opcode from the memory word whose address is in the PC
- The contents of the PC are incremented while this happens to hold the address of the next instruction in the sequential order
- The opcode is brought to the processor and appropriate action is performed in the execution phase
- Once this is completed, the next instruction is processed by fetching it from the memory using PC as the address
- This goes on for ever inside the processor until a special STOP instruction is encountered
- Executing this instruction stops all activities of the processor

- So how do we start the process?
- It is clear that once one instruction is done with, the next one is taken up by incrementing the PC
- Thus, once the execution of a program starts, everything goes on as the program indicates
- So how to start a program?
- A program can be started by loading the address of its first instruction into the PC
- However, how does the very first program start when the computer's power is turned on?




- We know Operating System (OS) is the program that controls our computer
- The OS itself is loaded into the processor's memory from the hard disk on boot up prior to taking over the system
- Which program loads the operating system? How does that program get the control at the very beginning?
- Modern PCs have a program called the BIOS (Basic Input Output System), which is the very first one to get control of the processor
- How does the BIOS get control?



- The processor hardware has a special feature to load a value of 0 to the PC when power is turned on or when the reset button of the computer is pressed (*literally* "resets" the "PC")
- Thus, the very first program that gets control is the one that is saved at memory address 0
- Computer manufacturers place a special program at address 0 that has the BIOS program, which knows how to load the operating system from the boot record and proceed accordingly
- Any corruption in the BIOS can be very detrimental to booting the computer


Memory access

- How does the simple processor access the memory?
- We will use a memory interface that supplies the address to the memory along with the signals to indicate if a read or a write is desired
- Data should be presented separately for writes; data supplied by the memory should be used inside the processor for reads
- We assume an external memory interface consisting of address lines, data lines, and two control lines
- The data lines are connected directly to the data lines of the bus, as if the memory is a large register array, but outside of the processor



Memory access

- The address has to be supplied separately, prior to the read or write operation
- We assign a memory address register (MAR) to hold the address
- The MAR is connected to the bus like other registers and can be written to from the bus
- There is usually no need to enable the MAR to the internal bus
- It can be assumed to be enabled always to the external memory interface
- Two control lines RD and WR are sent to the memory to indicate memory read and write respectively




Enhanced enhanced single bus architecture

 With this information, the enhanced single bus architecture is modified to include additional components

 The memory address register to store the next memory address to be accessed

 The program counter to store the current address of the instruction being performed



Two more instructions

- We will introduce two more simple instructions: NOP instruction for no operation and STOP instruction to stop the processor.
- NOP does nothing: when it is executed nothing at all changes in the processor or memory.
- It may seem superfluous, but comes into use when nothing is required from the processor other than spending the required clocks to fetch and execute this instruction.

Assembly Instruction	Machine Code	Action
nop	00	-
stop	07	(Stops fetch)

- The STOP instruction terminates the endless fetch-execute cycle that the processor is engaged in.
- The processor enters a state of complete inaction when the STOP instruction is executed.
- There is no way to come out of this state through a program as the processor has stopped looking at programs!
- Thus, the only way to come out is a hard reset through a reset button or through power cycling.