

CS301 Embedded System and Microcomputer Principle


Lecture 6: Serial Communication - UART

2024 Fall

This PowerPoint is for internal use only at Southern University of Science and Technology. Please do not repost it on other platforms without permission from the instructor.



Recap






Subroutine (cont.)

- What happens during a function call?
 - A new stack frame is created with local variables, parameters, and saved registers.
 - The return address is saved so the program can resume after the function.
 - Parameters are passed through registers or placed in the caller's stack frame.
 - Control transfers to the function, using its frame for local execution.

• When the function finishes, the frame is popped, and execution resumes at the saved return address.





ARM Calling Convention

- Which registers to save?
- Caller save and Calee save
 - r0-r3 are the argument registers; r0-r1 are also the result registers
 - r4-r8 are callee-save registers
 - r9 might be a callee-save register or not
 - r10-r11 are callee-save registers
 - r12-r15 are special registers

https://developer.arm.com/documentation/den0013/d/Application-Binary-Interfaces/Procedure-Call-Standard



ARM Function Call Example

C and corresponding Disassembly code in Cubelde

08000262:

```
main.c ×
66 int sum(int a, int b) {
    int ret = a + b;
    return ret;
69 }
70
71 int main(void) {
    int a = 3;
    int b = 2;
74
75    int res = sum(a, b);
76 }
```

```
main:
                    {r7, lr}
08000242:
            push
                                         sum:
08000244:
            sub
                   sp, #16
                                        08000224:
                                                             {r7}
                                                     push
                  r7, sp, #0
08000246:
            add
                                        08000226:
                                                     sub
                                                             sp, #20
72
                   int a = 3;
                                        08000228:
                                                     add
                                                             r7, sp, #0
08000248:
                    r3, #3
            movs
                                                             r0, [r7, #4]
                                        0800022a:
                                                     str
                   r3, [r7, #12]
0800024a:
            str
                                        0800022c:
                                                     str
                                                             r1, [r7, #0]
                   int b = 2;
73
                                        0800022e:
                                                     ldr
                                                             r2, [r7, #4]
0800024c:
                    r3, #2
            movs
                                                             r3, [r7, #0]
                                        08000230:
                                                     ldr
                    r3, [r7, #8]
0800024e:
            str
                                                     add
                                        08000232:
                                                             r3, r2
75
                  int res = sum(a, b);
                                        08000234:
                                                     str
                                                             r3, [r7, #12]
08000250:
            ldr
                    r1, [r7, #8]
                                                             r3, [r7, #12]
                                                     ldr
                                        08000236:
                    r0, [r7, #12]
08000252:
            ldr
                                        08000238:
                                                             r0, r3
                                                    mov
            b1
                  0x8000224 <sum>
08000254:
                                        0800023a:
                                                     adds
                                                             r7, #20
08000258:
            str
                   r0, [r7, #4]
                                        0800023c:
                                                     mov
                                                             sp, r7
0800025a:
                    r3, #0
            movs
                                        0800023e:
                                                             {r7}
                                                     pop
76
                                        08000240:
                                                             lr
                                                     bx
0800025c:
                    r0, r3
            mov
                    r7, #16
0800025e:
            adds
08000260:
                    sp, r7
            mov
```

baiyh@sustech.edu.ćn pop {r7, pc}

ARM Nested Function Call Example

C and corresponding Disassembly code in Cubelde

```
return ret;
                                                                                         68
                                                                                         69 }
                                                                                         70
                                                                                         71⊖int main(void) {
                                                         int sum(int a, int b) {
                                               66
                                                                                                 int a = 3;
          int main(void) {
                                                                                                 int b = 2;
                                                                                         73
          main:
                                                         sum:
                                                                                         74
                                              08000242:
                                                           push
                                                                   {r7, lr}
08000266:
            push
                     {r7, lr}
                                                                                         75
                                                                                                 int res = sum(a, b);
                                              08000244:
                                                           sub
                                                                   sp, #16
                                                                                         76 }
08000268:
            sub
                     sp, #16
                                              08000246:
                                                           add
                                                                   r7, sp, #0
0800026a:
                     r7, sp, #0
                                                                                               sub:
                                                                   r0, [r7, #4]
                                              08000248:
                                                           str
                      int a = 3;
                                                                                              08000224:
                                                                                                                   {r7}
                                                                                                           push
                                                                   r1, [r7, #0]
                                              0800024a:
                                                           str
0800026c:
                     r3, #3
                                                                                              08000226:
                                                                                                                   sp, #20
            movs
                                                                                                           sub
                                                                  int ret = a + sub(a, b);
                                               67
0800026e:
            str
                     r3, [r7, #12]
                                                                                              08000228:
                                                                                                                   r7, sp, #0
                                                                                                           add
                                                                   r1, [r7, #0]
                                              0800024c:
                                                           ldr
                      int b = 2;
                                                                                              0800022a:
                                                                                                                   r0, [r7, #4]
                                                                                                           str
                                              0800024e:
                                                           ldr
                                                                   r0, [r7, #4]
08000270:
                     r3, #2
                                                                                              0800022c:
                                                                                                                   r1, [r7, #0]
            movs
                                                                                                           str
                                              08000250:
                                                                   0x8000224 <sub>
08000272:
                     r3, [r7, #8]
                                                                                              0800022e:
                                                                                                           ldr
                                                                                                                   r2, [r7, #4]
                                              08000254:
                                                                   r2, r0
                                                           mov
                     int res = sum(a, b);
                                                                                              08000230:
                                                                                                           ldr
                                                                                                                   r3, [r7, #0]
                                              08000256:
                                                           ldr
                                                                   r3, [r7, #4]
08000274:
                     r1, [r7, #8]
            ldr
                                                                                              08000232:
                                                                                                           subs
                                                                                                                   r3, r2, r3
                                              08000258:
                                                           add
                                                                   r3, r2
08000276:
            ldr
                     r0, [r7, #12]
                                                                                              08000234:
                                                                                                                   r3, [r7, #12]
                                                                                                           str
                                              0800025a:
                                                                   r3, [r7, #12]
                                                           str
08000278:
                     0x8000242 <sum>
                                                                                               63
                                                                                                                  return res;
                                               68
                                                                  return ret;
0800027c:
                     r0, [r7, #4]
                                                                                              08000236:
                                                                                                           ldr
                                                                                                                   r3, [r7, #12]
                                              0800025c:
                                                           ldr
                                                                   r3, [r7, #12]
0800027e:
                     r3, #0
            movs
                                                                                               64
                                               69
 76
                                                                                              08000238:
                                                                                                                   r0, r3
                                                                                                           mov
                                              0800025e:
                                                                   r0, r3
08000280:
                     r0, r3
                                                           mov
                                                                                                                   r7, #20
            mov
                                                                                              0800023a:
                                                                                                           adds
                                                                   r7, #16
                                              08000260:
                                                           adds
08000282:
            adds
                     r7, #16
                                                                                              0800023c:
                                                                                                                   sp, r7
                                                                                                           mov
                                              08000262:
                                                                   sp, r7
                                                           mov
08000284:
                                                                                              0800023e:
                     sp, r7
                                                                                                                   {r7}
             mov
                                                                                                           pop
                                              08000264:
08000286:
                     {r7, pc}
                                                                                              08000240:
                                                                                                           bx
                                                                                                                   lr
            pop
```

63

64 } 65

61⊖int sub(int c, int d) { int res = c - d;

return res:

66⊖ int sum(int a, int b) {

int ret = a + sub(a, b)



Communication Interfaces

- Communication interfaces:
 - For exchanging information with external devices
 - Communication protocols

Abbreviation	Full Name
U(S)ART	Universal (synchronous) asynchronous receiver/transmitter
SSI/SPI	Synchronous serial interface/Serial peripheral interface
I ² C	Inter-integrated circuit
USB	Universal serial bus
Ethernet	High-speed network
CAN	Controller area network



Communication Interfaces

Abbreviation		Воц	ındary address		Peripheral	Bus	
Appleviation		0x4001 5	800 - 0x4001 7FFF	Reserved			
U(S)ART		0x4001 54	400 - 0x4001 57FF	TIM11 tim	ner	1	
SSI/SPI		0x4001 50	000 - 0x4001 53FF	TIM10 tim	ner] 1	
331/371		0x4001 4	C00 - 0x4001 4FFF	TIM9 time	er	1 1	
I ² C \		0x4001 4	900 - 0x4001 4BFF	Reserved]	
LICE		0x4001 3	C00 - 0x4001 3FFF	ADC3]	
USB		0x4001 3	800 - 0x4001 3BFF	USART1]	
Ethernet		0x4001 3	400 - 0x4001 37FF	TIM8 time	er] 1	
CAN		0x4001 3	000 - 0x4001 33FF	SPI1	SPI1		
CAN		0x4001 2	C00 - 0x4001 2FFF	TIM1 time	er		
0x4000 6400 - 0x4000 67FF	bxCAN1	0x4001.2	800 - 0x4001 2BFF	ADC2		APB2	
0x4000 6800 - 0x4000 6BFF	bxCAN2				T		
0x4000 6000 ⁽¹⁾ - 0x4000 63FF	Shared USB/CAN SRAM 5	o12 bytes	Boundary add	ress	Peripheral		В
0x4000 5C00 - 0x4000 5FFF	USB device FS registers		0xA000-0000 - 0xA0	00 0FFF	FSMC		
	2C2		0x5000 0000 - 0x500	3 FFFF	USB OTG FS		
0x4000 5400 - 0x4000 57FF	I2C1		0x4003 0000 - 0x4FF	F FFFF	Reserved		1
0x4000 5000 - 0x4000 53FF	UART5		0x4002 8000 - 0x400	2 9FFF	Ethernet		1
0x4000 4C00 - 0x4000 4FFF	UART4		0x4002 3400 - 0x400	2 7FFF	Reserved		1
0x4000 4800 - 0x4000 4BFF	USART3		0x4002 3000 - 0x400)2 33FF	CRC		†
0x4000 4400 - 0x4000 47FF	USART2		0x4002 2000 - 0x400)2 23FF	Flash memory interface		
0x4000 4000 - 0x4000 43FF	Reserved	baiyh@s	usteth.edd.th)O 4FFF	Danaminal		AH
0x4000 3C00 - 0x4000 3FFF	SPI3/I2S		APB1				



Outline


- UART Protocol
- UART in Practice
- USART in STM32




Serial vs. Parallel Communication

Characteristics	Transmission Rate	Anti- Interference Ability	LUSTANCE	I/O Resource Usage	Cost	
Serial Transfer	Low	High	High	Low	Low	
Parallel Transfer	High	Low	Low	High	High	

Serial Transfer



Parallel Transfer









Synchronous vs. Asynchronous Communication

- Synchronous Communication
 - Shares the same clock signal, which is sent along with data;
 - The device that generates the clock is called the *master* and other devices are *slaves*
- Asynchronous Communication
 - no clock transmitted, fewer wires
 - it relies on synchronous signals like start and stop bits within the data signal








Asynchronous



Direction of Communication


- Simplex Communication:
 - Data can only be transmitted in one direction Simplex
- Half-Duplex Communication
 - Data can be transmitted in both directions but need time division
- Full-Duplex Communication
 - Data can be simultaneously transmitted in both directions






UART

- UART (Universal Asynchronous Receiver-Transmitter)
 - a universal serial asynchronous communication bus with two data lines, enables full-duplex transmission and reception, and is commonly used in embedded systems for communication between a host and peripheral devices.
- How to synchronize the transmissions of the two ends which run on independent clocks?
 - Use absolute (real) time
 - Transmit short data (e.g. one byte) at a time, assuming the two clocks run at same rate during that period of time





Frame Format




- Data are sent in short frames, each of which typically contains a single byte
- Data frame
 - One logic-low start bit
 - Data (LSBit first, and size of 5~8 bits)
 - One optional parity bit to make total number of ones in data even or odd
 - One or two logic-high stop bits



Frame Example

• Example: 8-N-1 format: 8-bit data, no parity bit, 1 stop bit



- For each frame transmittion:
- The line is high when no data is sent
- The transmitter sends a 0 bit as a start bit (ST)
- The receiver uses the falling edge to be synched with the sender
- Then data 0x55 is sent (LSBit first)
- The line becomes high for 1 stop bit (SP) to make sure that the next start bit makes a falling edge
- → sequence sent is 0101010101



Transmission Speed

- Receiver must know the transmission rate Baud Rate(波特率)
 - # of signal changes per second, e.g., 9600 baud (bps)
 - In UART, each signal change represents one bit, so baud rate (Baud) and bits per second (bps) are equal
 - 8-N-1 format, Since each 8 bits of data are accompanied by a start and a stop bit, maximum data rate is only 8/10 of baud rate

Example:

- Baud rate is 9600 bps. Each frame has a start bit, 8 data bits, a stop bit, and no parity bit.
- Transmission rate in byte per second of actual data
 - 9600bps/(1 + 8 + 1) = 960 bytes/second
- The start and stop bits are the protocol overhead




Outline

- UART Protocol
- UART in Practice
- USART in STM32



Synchronization of two ends


- Problem: Transmitter and Receiver have their own clocks, and they might be different in phase.
 - The data is sampled at the middle of each clock cycle
 - E.g. 10% Phase difference might lead to transmission error for 8-N-1 format





Synchronization of two ends


- Solution: How close must the two ends run their clocks?
 - The final sample is taken 9.5 bit periods after the initial falling edge and must lie within the stop bit
 - The permissible error is therefore about ± 0.5 bit period in 9.5 periods or $\pm 5\%$
 - There may be errors in both receiver and transmitter, so each should be accurate to within about ±2.5%





Bit Level Reorganization


 Problem: After the cable propagation, the signal may be interfered and has glitches





Bit Level Reorganization


- Solution: Oversampling
 - Receiver sample clock is 16x faster than baud rate
 - 3 samples in the middle from the 16 are picked for voting
 - 2 out of 3 scheme determines the bit level
 - Noise flag is set if 3 selected sample are not identical





Error Detection


- Problem: How to check the data integrity?
- Solution: Parity bit is added to the tail of frame.
 - Even Parity: total number of "1" bits in data and parity is even
 - Odd Parity: total number of "1" bits in data and parity is odd
 - Example: Data = 10101011 (five "1" bits)
 - The parity bit should be 0 for odd parity and 1 for even parity
 - This can detect single-bit data corruption





UART Connection

- Universal
 - UART is programmable.
- Asynchronous
 - Sender provides no clock signal to receivers





UART physical implementation

- Problem of directly using UART
 - UART is a communication mechanism, it only defines the timing sequence, but does not specify the electrical characteristics of the interface.
 - When using UART communication, processors typically use TTL levels. However, there are differences in the voltage levels used by different processors, so UART connections between different processors usually cannot be directly connected.
 - UART does not specify a standard for connectors when different devices are connected
- In practice, we use RS232, which defines the electrical and mechanical characteristics of the interface



RS-232

- RS232 defines the electrical and mechanical characteristics of the interface for serial communication.
 - while UART has everything to do with logic and programming, but RS232 refers to the electronics and hardware needed for serial communications


Standard	Voltage signal	Max distance	Max speed	Number of devices supported per port		
RS-232	logic 1: -15V to -3V, logic 0: +3 to +15 V)	50 feet	20Kbit/s	1 master, 1 receiver		
RS-485	Differential (-7V to +12V)	4000 feet	10Mbit/s	32 masters, 32 receivers		



RS-232 DB9 Connector

• 9 pins


Pin	Description
1	Data carrier detect (DCD)
2	Received data (RxD)
3	Transmitted data (TxD)
4	Data terminal ready
	(DTR)
5	Signal ground (GND)
6	Data set ready (DSR)
7	Request to send (RTS)
8	Clear to send (CTS)
9	Ring indicator (RI)






UART Between Devices

A level converter chips converts UART default TTL voltage level to RS-232 voltage level



USB to UART converter adapts UART port to a standard USB interface






Outline

- UART Protocol
- UART in Practice
- USART in STM32



USART


- USART: Universal synchronous/asynchronous Receiver-transmitter
 - Support both synchronous and asynchronous communications
- An integrated hardware peripheral in STM32
 - capable of generating data frame timing based on a byte of data in the data register, sending it out through the TX pin, and automatically receiving data frame timing from the RX pin, concatenating it into a byte of data stored in the data register
 - It comes with a built-in baud rate generator
 - It can be configured with data bit length, stop bit length, and optional parity bit.





USART Registers

- Control registers
- Transmit and receive register
- Status register
- Baud rate register



Register name	Offset	Description
USARTx_SR	0x0000	Status register
USARTx_DR	0x0004	Data register
USARTx_BRR	0x0008	Baud rate register
USARTx_CR1	0x000C	Control Register 1
USARTx_CR2	0x0010	Control Register 2
USARTx_CR3	0x0014 @sustech.edu.cn	Control Register 3



Baud Rate Registers

- Baud rate register (USART_BRR)
 - USARTDIV is an unsigned fixed point number that is coded on the USART_BRR register. It's used to configure the Tx/Rx Baud rate

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
Reserved															
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	DIV_Mantissa[11:0]								DIV_Fra	ction[3:0]					
rw	rw	rw	rw	rw	rw	rw	rw	rw	rw	rw	rw	rw	rw	rw	rw

Bits 31:16 Reserved, forced by hardware to 0.

Bits 15:4 DIV_Mantissa[11:0]: mantissa of USARTDIV

These 12 bits define the mantissa of the USART Divider (USARTDIV)


Bits 3:0 DIV_Fraction[3:0]: fraction of USARTDIV

These 4 bits define the fraction of the USART Divider (USARTDIV)



Baud Rate Configuration

- Baud rate register (USART_BRR)
 - The baud rate for the receiver and transmitter (Rx and Tx) are both set to the same value as programmed in the Mantissa and Fraction values of USARTDIV(分频系数).





Example

 Example: Configure USART_BRR register values for baud rate = 115200 for USART1, suppose USART input clock is 72MHz

```
USART freq
 baud = -
                               USARTDIV = DIV_Mantissa + (DIV_Fraction / 16)
115200 = 72000000/(16* USARTDIV) → USARTDIV = 39.0625
(39.0625)_{10} = (100111.0001)_2 = 0x27.1 \rightarrow USART_BRR = 0x271
Or you can calculate using:
DIV_Fraction = 16*0.0625 = 1 = 0x1
DIV_Mantissa = mantissa (39.0625) = 39 = 0x27
Then, USART BRR = 0x271
uint16 t mantissa;
uint16 t fraction;
/* USARTDIV = DIV_Mantissa + (DIV_Fraction/16) */
mantissa = 39;
                                            +0.5 is used for rounding
fraction = 0.0625 * 16(+ 0.5) = 0x1;
USART1->BRR = (mantissa << 4) + fraction;
                             baivh@sustech.edu.cn
```



Example

Calculate the value of USART_BRR to program USARTDIV = 50.99

DIV_Fraction = 16*0.99 = 15.84
The nearest real number is 16 = 0x10 => overflow of DIV_frac[3:0] => carry must be added up to the mantissa

DIV_Mantissa = mantissa (50.990 + carry) = 51 = 0x33 Then, USART_BRR = 0x330 to get USARTDIV = 51.000