

#### CS301 Embedded System and Microcomputer Principle

Lecture 4: ARM Assembly

2024 Fall


This PowerPoint is for internal use only at Southern University of Science and Technology. Please do not repost it on other platforms without permission from the instructor.





# Recap

EmbeddedC



lifetime: from declaration till end of process
scope: within function
lifetime: from declaration till end of function
scope: within function
lifetime: from declaration till end of process


value maintains between function invocations

scope: entire project (static global: current



# Compiler


- A high level language (such as C, C++, Fortran, etc.) is converted into either machine code or mnemonics using a computer package called a compiler.
- Most programs are written in a high level language
- But assembly language programming is commonly used for engineering systems which must operate in real time e.g. a mobile phone.
- Nobody writes computer programs using machine code.





#### **Assembler**

- A computer package called an assembler converts an assembly language program into a machine code program.
- E.g.



- In ARM mode, each instruction occupying 4 adjacent memory locations, as each instruction is 32 bits long. Cortex-M is Thumb-2 mode (mix of 16/32bits instructions)
- The machine code can be downloaded to the microprocessor memory.



### **Assembly Language**

#### Mnemonics

- In general nobody remembers all of the machine code for any particular processor (or indeed any).
- Instead we use mnemonics
  - mnemonics are words or phrases which are easy to remember and can replace something which is difficult to remember.
- Assembly language
  - If the mnemonics for every instruction in a computer program were listed in the order that they were executed then the resulting list would be an assembly language program.
- Example:

MOV r6, r14 MOV r7, #0xCB MOV r7, r12 MOV r12, #114



# **Assembly Format**

#### label opcode operand1, operand2, operand3 ; comments

- label
  - Place marker, memory address of the current instruction
  - Used by branch instructions to implement if-then or goto
- opcode
  - The name of the instruction
  - Operation to be performed by processor core
- operands
  - Registers
  - Constants (called immediate values)
- comments
  - Everything after the semicolon (;) is a comment
  - Explain programmers' intentions or assumptions



# **Assembly Instructions**

- Arithmetic and logic
  - Add, Subtract, Multiply, Shift, Rotate
- Data movement
  - Load, Store, Move
- Compare and branch
  - Compare, Branch



#### **Instructions for Arithmetic**

• The ARM7 can add, subtract and multiply numbers (but not

divide).

- Opcode destination, source1, source2
  - Opcodes: ADD, SUB, MUL, etc.
- Examples:
  - ADD R5,R2,R1
    - R5 = R2 + R1
  - SUB R5,R1,#23
    - R5 = R1 23
  - RSB R5,R1,R2
    - R5 = R2 R1, reverse subtraction
  - MUL R5,R2,R1
    - R5 = R2 \* R1
    - If the result is more than 32 bits long, the destination register, R5 only holds the bottom 32 bits of the result and the rest is lost

R0
R1
R2
R3
R4
R5
R6
R7
R8
R9
R10
R11
R12
R13 (SP)
R14 (LR)
R15 (PC)



# **Flags**

```
a = 10000

b = 10000

c = a + b
```

- Are a and b signed or unsigned numbers?
  - CPU does not know the answer at all.
  - Therefore, the hardware sets up both the carry flag and the overflow flag.
  - It is software's (programmers'/compilers') responsibility to interpret the flags.
  - Noted: In computers, numbers are stored in their two's complement representation.



### Condition Flags in Program Status Register


	D31	D30	D29	D28		D7	D6	D5	D4	D3	D2	D1	D0	
PSR:	Ν	Z	С	V	Reserved	- 1	F	Т	M4	М3	M2	M1	MO	

- Condition Flags: NZCV
  - Negative bit
    - N = 1 if most significant bit of result is 1
  - **Zero** bit
    - Z = 1 if all bits of result are 0
  - Carry bit
    - For unsigned addition, C = 1 if carry takes place
    - For unsigned subtraction, C = 0 if borrow takes place (carry = not borrow)
    - For shift/rotation, C = last bit shifted out
  - oVerflow bit
    - V = 1 if adding 2 same-signed numbers produces a result with the opposite sign
      - Positive + Positive = Negative, or
      - Negative + negative = Positive
    - Non-arithmetic operations does not touch V bit, such as MOV, AND, LSL




# Carry

Carry/borrow flag bit for unsigned numbers



- Carry flag = 1, indicating carry has occurred on unsigned addition.
- Carry flag is 1 because the result crosses the boundary between 31 and 0.




- Carry flag = 0, indicating borrow has occurred on unsigned subtraction.
- For subtraction, carry = NOT borrow.



#### **Overflow**

Two's Complement Signed Integer Add/Sub

Overflow occurs if  $sum \ge 2^n$  when adding two positives, i.e. result becomes negative.



overflow occurs if  $sum < -2^n$  when adding two negatives, i.e. result becomes negative

Overflow never occurs when adding two numbers with different signs



#### **Exercise**

Assume a four-bit system unsigned and signed operations

Expression	Result	Carry if unsigned	Overflow if signed
0100 + 0010	0110		
0100 + 0110	1010		
1100 + 1110	1010		
1100 + 1010	0110		



#### **Exercise**

Assume a four-bit system unsigned and signed operations

Expression	Result	Carry if unsigned	Overflow if signed
0100 + 0010	0110	No	No
0100 + 0110	1010	No	Yes
1100 + 1110	1010	Yes	No
1100 + 1010	0110	Yes	Yes



# **Updating NZCV flags in PSR**

- Most instructions update NZCV flags only if 'S' suffix is present
  - ADD r0, r1, r2; r0 = r1 + r2, NZCV flags unchanged
  - ADDS r0, r1, r2; r0 = r1 + r2, NZCV flags updated
- Some instructions update NZCV flags even if no S is specified.
  - CMP: Compare, like SUBS but without destination register
  - CMP r1, r2 vs SUBS r0, r1, r2

Flags not changed		Flags updated
ADD	$\longrightarrow$	ADDS
SUB	$\longrightarrow$	SUBS
MUL	$\longrightarrow$	MULS
AND	$\longrightarrow$	ANDS
ORR	$\longrightarrow$	ORRS
LSL	$\longrightarrow$	LSLS
MOV	$\longrightarrow$	MOVS



- NZCV results:
  - N (Negative) = 0; bit 31 of result is 0
  - Z(Zero) = 1; IsZero(result)
  - C (Carry) = 1; carry, result crosses the boundary of 32 bits
  - V (oVerflow) = 0; adding +ve and -ve values, never overflow



```
MOV R2, #0x7FFFFFFF ; R2 = 0x7fffffff
MOV R3, #0x2 ; R3 = 0x2

ADDS R1, R2, R3 ; R1 = R2 + R3 and update the flags

0x7FFFFFFF
+ 0x00000002
0x80000001

N=1

N=1

V=1
```

- NZCV results:
  - N (Negative) = 1; bit 31 of result is 1
  - Z(Zero) = 0; not zero
  - C (Carry) = 0; carry, result doesn't cross 32 bits boundary
  - V (oVerflow) = 1; overflow, +ve add +ve, result becomes -ve



• Show the status of the C and Z flags after the addition of 0x38 and 0x2F in the following instructions:

```
MOV R6, #0x38 ; R6 = 0x38

MOV R7, #0x2F ; R17 = 0x2F

ADDS R6, R6, R7 ; add R7 to R6
```

• Show the status of the Z flag after the subtraction of 0x23 from 0xA5 in the following instructions:


```
LDR R0,=0xA5

LDR R1,=0x23

SUBS R0,R0,R1 ;subtract R1 from R0
```



# Flags in PSR Register






### Instructions using logic

- AND r0, r1, r2; Bitwise AND, r0 = r1 AND r2
  - clear a specific bit(s) of a byte
- ORR r0, r1, r2; Bitwise OR, r0 = r1 OR r2
  - set a specific bit(s) of a byte
- EOR r0, r1, r2; Bitwise Exclusive OR, r0 = r1 EOR r2
  - toggle a specific bit(s) of a byte
- BIC r0, r1, r2; Bit clear, r0 = r1 AND ~r2

$$ORR \stackrel{0 \times 04}{=} \stackrel{0 \times 30}{=} \stackrel{0 \times 34}{=} \stackrel{0 \times 34}{=}$$




#### Instructions using logic





#### **Data Transfer Instructions**

- MOV r0, r1; Move, r0 = r1
- MVN r0, r1; r0 = 1's Complement of r1
- LDR r0, [r1]; load value from memory location[r1] to r0
- STR r0, [r1]; store value r0 into memory location[r1]






23

#### Load

- Loading Word from Memory
  - LDR r1, [r0]; r1 = memory.word[r0]
  - the data travels from memory to register



Core


Contents **Address** 0x20000007 0x8B 0x20000006 0xAD 0x20000005 0xF0 0x20000004 0x0D 0x20000003 0xDE 0x20000002 0xAD 0xBE 0x20000001 0x20000000 0xEF

Memory




#### Store

- Storing Word to Memory
  - STR r1, [r0]; memory.word[r0] = r1
  - the data travels from register to memory



Core




Memory




#### **Store**

- Storing Word to Memory
  - STR r1, [r0]; memory.word[r0] = r1
  - the data travels from register to memory



Core




Memory



# Little Endian vs Big Endian


- Little-endian
  - LSB of a word is at least memory address
- Big-endian
  - MSB of a word is at least memory address





# Little endian or Big endian

- Microprocessors can be either 'little endian' or 'big endian'
- The ARM7 processor can be configured as either little endian or big endian.
  - Intel (e.g. the Pentium) uses little endian whereas MIPS uses big endian.
  - Cortex M uses little endian by default





# **Addressing Mode**

- Register addressing mode
  - MOV R2, R4
  - ADD R3, R2, R1
- Immediate addressing
  - MOV R1, #0x25
  - ADD R6, R6, #0x40
- Register indirect (indexed)
  - STR R5, [R6]
  - LDR R10, [R3]



# **Immediate Addressing**

- Immediate addressing means that the instruction code contains a value to be used.
- Restrictions
  - The immediate value has to be specified by 12 bits
  - but it does not have to be the least significant byte, and the remaining 4 bits to specify the location of the 8 bits
  - E.g.
  - MOV r4, #0xFF0
    - Will put 0x00000FF0 into r4 (the #0xFF0 is the immediate)
  - ADD r2, r1, #10
    - add 10 to value in r1 and put the sum in r2
  - SUB r8, r8, #99
    - subtract 99 from value in r8



#### **Valid Immediate**

- The instruction code is always 32 bits and it must include information about the type of instruction
  - (e.g. ADD, MOV, EOR, etc.) and the destination register as well as the immediate value.
- So a 32 bit value can not be put into a 32 bit register
  - using immediate addressing and MOV.
  - E.G. MOV r3, #0xF97D5EC5 is not allowed
- The immediate can be one byte (8 bits) but it does not have to be the least significant byte, and the remaining 4 bits to specify the location of the 8 bits
  - MOV r11, #0x3FC0000 will put 0x03FC0000 into r11
  - <immediate>=immed\_8 rotate right (2\*rotate\_imm)
  - The Immediate in instruction machine code is 0x7FF



### **Indirect Addressing**

- Base plus offset addressing
- Uses a value in a register (the 'base') plus a binary number (the 'offset') to identify a memory address.
- E.g.
  - LDR r6, [r11, #12]
  - means load into r6 the data held in the memory location that has the address given by the value in register (base) r11 added to 12.



# **Automatic updating**

- In many applications there is a great deal of data movement between the CPU and memory and it can be very useful if the base register is updated on each load or store.
- The instruction:
  - LDR r6, [r11, #12]!
  - does the same as the instruction on the previous slide
  - but 12 is added to the value in r11.
  - The automatic updating is identified by the !



#### Pre-indexed and post-indexed

- Pre-indexing:
  - LDR r6, [r11, #12]!
  - Offset 12 is added to the base register r11, before r11 is used as a memory address.
- Post-indexing
  - LDR r6, [r11], #12
  - Offset 12 is added to the base register r11, after r11 is used for the memory address.



• What values are held in r4, r7 and r8 and is memory modified or not after the execution of the following? (assume little endian)

Programme:	Memory Address	Contents
MOV r4, #0x8000	0x00008000	0xF5
LDR r7, [r4], #4	0x00008001	0x04
STR r7, [r4], #4	0x00008002	0x4C
LDR r8, [r4, #-4]!	0x00008003	0x82



#### **Branch Instruction**


• If-then-else

```
C Program
if (a == 1)
    b = 3;
else
    b = 4;
```

```
; r1 = a, r2 = b
CMP r1, #1 ; compare a and 1
BNE else ; go to else if a ≠ 1
then MOV r2, #3 ; b = 3
B endif ; go to endif
else MOV r2, #4 ; b = 4
endif
```

CMP Rn, Op2 (Rn – Op2, Same as SUBS, except result is discarded.)

B label (branch to label.)



Compare	Signed	Unsigned	
>	BGT	BHI	
>=	BGE	BHS	
<	BLT	BLO	
<=	BLE	BLS	
==	BEQ		
ral Use Only!	В	NE	

For Inter



#### **Branch Instruction**

For Loop

```
C Program
int i;
int sum = 0;
for(i = 0; i < 10; i++){
   sum += i;
}</pre>
```

```
i = 0
sum = 0
i < 10
i++
```

```
MOV r0, #0 ; i
MOV r1, #0 ; sum

B check
loop ADD r1, r1, r0 ; sum += i
ADD r0, r0, #1 ; i++
check CMP r0, #10 ; check whether i < 10
BLT loop ; loop if signed less than endloop
```



#### **Branch Instruction**

While Loop

```
C Program
int i;
int sum = 0;
while (i < 10){
   sum += i;
   i++;
}</pre>
```

```
i = 0
sum = 0
i < 10
i ++
```

```
MOV r0, #0 ; i
MOV r1, #0 ; sum

loop CMP r0, #10 ; check whether i < 10
BGE endloop ; skip if ≥
ADD r1, r1, r0 ; sum += i
ADD r0, r0, #1 ; i++
B loop
endloop
```



#### CISC v.s. RISC

- CISC = Complex Instruction Set Computer
  - 1. Complicated CPU
  - 2. Each instruction takes longer to execute
  - 3. Fewer machine code instructions for each high level instruction
  - 4. Good code density
  - 5. Smaller semantic gap
  - 6. Simple compiler

- RISC = Reduced Instruction Set Computer
  - 1. Simple CPU
  - 2. Machine code instructions execute quickly
  - 3. More machine code instructions for each high level instruction
  - 4. Poor code density
  - 5. Larger semantic gap
  - 6. Complicated compiler