ixnet

Library scope: global **Named arguments:** supported

Introduction

provides functions for IxNetwork

RENAT will connect to the App server and control the test ports. Test files and result will be inside the RENAT server.

In order to run RENAT test case with IxLoad, the TCLServer must be activated with Administrator privileges on the Ixia App server.

Notes: Ignore the self parameters when using those keywords.

Shortcuts

Add Port · Add Quicktest · Apply Traffic · Change Frame Rate · Change Frame Rate Dynamic · Change Frame Size · Collect All Data · Collect Data · Get All Test Result · Get Quicktest List · Get Quicktest Result · Get Quicktest Result · Cat R

Keywords

Keyword	Arguments	Documentation
Add Port	self, force=True, time_out=2m, learn_time=2m	Add ports using the information from active local config
		 time_out is the wait time until port is connected (default is 2m) learn_time is the time waiting for arp to be learned (default is 2m)
		Sample of local config tester:
		tester: device: ixnet03_8009 config: quicktest.ixncfg real_port: - chassis: 10.128.4.41 card: 4 port: 3 ip: 10.100.11.2 mask: 24 gw: 10.100.11.1 - chassis: 10.128.4.41 card: 4
		port: 4
		ip: 10.100.14.2 mask: 24 gw: 10.100.14.1
Add Quicktest	self, name,	Create a new Quicktest with default value
	test_type=rfc2544throughput, tx_mode=interleaved, clear_all=True	Type could be one of following: rfc2544throughput, rfc2544frameLoss, rfc2544back2back. Use Tester. <u>Load Config</u> to load a customized quicktest
		When clear_all is True, any existed quicktests will be cleared.
		Transmit mode tx_mode takes following values: interleaved (default) or sequential. The mode should be identical with the transmit mod of the ports.
		Notes : The keyword does not create necessary ports. It should be used with a existed configuration by Tester. <i>Load Config</i> or Tester. <i>Add Port</i> keyword.
Apply Traffic	self	Applies the current traffic configuration
		Note: This is a blocking command
Change Frame	self, value, pattern=.*	Changes the frame rate
Rate		Parameter:
		 value: value to set. Depends on the current configuration, this could be percent line rate or bit per second etc. traffic_pattern: a regular expression to identify traffic item name, default is everything `.*
Change Frame		Changes the traffic flow rate on-fly
Rate Dynamic		No need to stop the running traffic to change the rate
		Parameter:
		value: value to set. Depend on the current configuration, this could be percent line rate or bit per second etc.
		pattern: a regular expression to identify traffic item name, default is everything .*
Change Frame	self, type, value, pattern=.*	Changes the frame size
Size		Parameter:

		 type: could be fixed size, increment_from`,`increment_step or increment_to value: value to set
		 value is value to set traffic_pattern: a regular expression to identify traffic item name, default is everything.*
Close	self	Disconnects the current tester client
Collect All Data	self, prefix=stat_	Deprecated. Use
Collect Data	self, view, prefix=stat_	Depricated. Use <u>Get Test Result</u>
Get All Test	self, prefix=stat_	Collects all Ixia traffic data after traffic is stopped.
Result		Results are CSV files that are stored in result folder. The prefix prefix is appended to the original view nar
Get Quicktest List	self	Returns current loaded Quicktest list
Get Quicktest	self, test_index=-1, prefix=,	Get the result.csv file from the latest Quicktests
Result	enable_all=True	test_index is a index of the current Quicktest1 means that last one.
Get Quicktest	self, test_index=-1	Returns the path of the newest run of a Quicktest
Result Path		test index is a index of the current Quicktest1 means that last one.
Get Test Report	self	Generates and get report of the current active test in PDF format
от госторог	local_name=ixnet_report.pdf, enable_all=True	local_name: name of the report on local machine. Default is ixnet_report.pdf
Get Test Result	self, view, prefix=stat_	Collects traffic data of a view and export to a CSV file in result folder
	. –	Currently, supported views are:
		27 11
		Port Statistics, Global Protocol Statistics, BGP Aggregated Statistics, BGP Aggregated State Counts, OSPF Aggregated Statistics, OSPF Aggregated State Counts, OSPFv3 Aggregated Statistics, OSPFv3 Aggregated Statistics, OSPFv3 Aggregated Statistics, Counts, L2-L3 Test Summary Statistics, Flow Statistics, Flow Detective, Data Plane Port Statistics, User Defin Statistics, Traffic Item Statistics
		Result were store as CSV files in result folder. If there is no valid data, view will be silently ignored
		The prefix prefix is appended to the view name for the CSV file.
Load And Start	self, wait_time1=10s,	Combines <u>Load Traffic</u> and <u>Start Traffic</u> to one keyword.
Traffic	wait_time2=10s	·
Load Config	self, config_name=, wait_time=2m, wait_time2=2m, apply=True, protocol=True, force=True, tx_mode=interleaved	loads traffic configuration, applies and start protocol if necessary. The config file name was defined in the 'local.yaml which is a Ixia Network configuration file and located i the config folder of the test.
		The keyword remap the vports to real port when data is specified in the local configuration file. For some reasons, the txMode is cleared when remapping happens. Use tx_mode to set the TxMode of the remapping ports.
		Parameters:
		■ apply: applies traffic when True otherwise
		■ protocol: starts all protocols when True otherwise
		force : force to reclaim the ports when True otherwise
		 tx_mode: sequential or interleaved(default) wait time: wait time after applying protocols
		 wait_time : wait time arei applying protocols wait time2: maximum wait time befor all ports become available. In
		common case, this is calculated automatically so user does not need to change this value.
		, , , , , , , , , , , , , , , , , , ,
	16 14 14 10	See Common for more details about the yaml configuration files.
Load Traffic	self, wait_time=2m, wait_time2=2m, apply=True,	
	protocol=True, force=True,	
	tx_mode=interleaved	
Loss From File	self,	Returns packet loss by miliseconds and delta frame.
	file_name=Flow_Statistics.csv, tx_frame_i=3,	The calculation should be performed when traffic is stopped. The calculation supposed traffic is configure
	frame_delta_i=5, time1_i=23,	frame per second
	time2_i=24	
Ping	self, dst_ip, src_port_index=0,	Ping from Ixia to dst_ip
	src_intf_index=0	The keyword return the output string as it is. The return could be
		- Port <portname>: ping failed: port not assigned - Response received from <sourcelp>/unknown . Sequence Number <sequencenumber> - Ping request to <destinationlp>/unknown ip failed: <genericpingerror>/<error>: <genericerror>unknown reas - Error: Couldn't find any source interface for Send Ping to <destinationlp> on <portname> Id <id></id></portname></destinationlp></genericerror></error></genericpingerror></destinationlp></sequencenumber></sourcelp></portname>
		- Error: Couldn't find any source IP for Send Ping to <destinationlp> on <portname> ld <id></id></portname></destinationlp>
		Parameters:
		 src_port_index: index of Ixia port (starts from 0) src_intf_index: index of interface insides the port (starts from 0)
		Examples:
		Examples:
		Tester. <u>Ping</u> 1.1.1.1 0 0
Reset Config	self	

Set All Traffic Item	self, enabled=True	Enables/Disables all traffic items at once
Set Bgp Items	self, port_index, neighbor_index, route_range_index, is_enable	Enables/Disables BGP entry by a set of port,neighbor,route_range index Parameters: port_index: index of the port neighbor_index: index of the neighbor or * route_range_index: index of the route range or * is_enable: \${TRUE} or \${FALSE} Note Examples: Tester. Set BGP Items 0 * * \${FALSE} Tester. Set BGP Items 0 * * \${TRUE}
Cat Ban	a olf *indovoo **kuvaraa	
Set Bgp Neighbor	self, *indexes, **kwargs	Enables/Disables BGP entry by neighbor index kwargs contains following parameters: indexes: is a list of index of BGP neighbor (index is started from zero) vport_index: is the target vport index enabled: TRUE or FALSE Examples: Tester.Set BGP Item 0 1 vport_index=0 enabled=\${FALSE} Tester.Set BGP Item 0 1 vport_index=1 enabled=\${TRUE}
Set Capture	self, data_mode=True,	Capture packets for follow port
Port	control_mode=True, port_index=0	port_index: is a index of current test port (start from 0) data_mode: capture data packets and save in <intf>_HW.cap file control_mode: capture controls packets and save in <intf>_SW.cap file Note: control_mode saves all control packets and data_mode only saves data packets. Note: control_mode saves all control packets and data_mode only saves data packet Examples: Tester.Set Capture Port 0 Tester.Set Capture Port control_mode=\${TRUE} 0 1</intf></intf>
	self, *items, **kwargs	Enables/Disables some traffic items items Parameters: Items: a list of Ixia traffic item name Interest enabled: False or True, the mode to set traffic item to, default is True (enabled) Note: traffic item could be specified by :: <num> format. In this case the num is the order of traffic item count from zero. Returns True if all items are set coordinately or otherwise Examples: Set Traffic Item Traffic Item 1 Traffic Item 2 Set Traffic Item @{item_list} Set Traffic Item Traffic Item 1 enabled = \${FALSE}</num>
Should Be Pingable	<pre>self, dst_ip, src_port_index=0, src_intf_index=0</pre>	Ping from Ixia and raise an error if ping fails The keyword return <i>True</i> if succeeds
Start Capture	self, wait_time=30s	Start packet capture Terret parts are set by the configuration file or by [Set Capture] knowledge.
Start Protocol	self, wait_time=1m	Target ports are set by the configuration file or by [Set Capture] keyword Starts all protocols and wait for wait_time Default wait_time is 1 minute. Make sure wait_time is big engouh to start all protocols.
Start Traffic	self, wait_time=30s	Starts the current traffic settiing and wait for wait_time. Note: This is a asynchronus action. After called, the keyword finishes immediatly but it will take a while before traffic starts By default the keyword will wait for 30 seconds.
Stop All Protocols	self, wait_time=30s	Stop all running protocols
Stop And Save Capture	self, prefix=, wait_until_finish=True, monitor_interval=5s	Stop current capture and save the resuls to folder specified by path Captured files will be saved in current result folder with prefix appended in their names. Examples: Tester. Start Capture Sleep 10s
		Tester. Stop And Save Capture \${RESULT_FOLDER}/capture.zip
Stop Quicktest	self, test_index=0	Stops a running test

5	Stop Traffic	self, stop_protocol=False, wait time=10s	Stops the current traffic and wait for wait_time
			Parameters:
			■ stop_protocol: if True also stops all running protocols
			■ wait_time: time to wait after apply the command
١	Vait Until	self, timeout_str=5m	Waits until ports become enabled and connected
	Connected		

Altogether 36 keywords. Generated by <u>Libdoc</u> on 2018-04-13 09:34:20.

