ixnet

Library scope: global
Named arguments: supported

Introduction

provides functions for IxNetwork

To use IxNetwork module, a IxNetwork TCL server should be started properly.

RENAT will connect to the App server and control the test ports. Test files and result will be insde the RENAT server.

In order to run RENAT test case with IxLoad, the TCLServer must be activated with Administrator privileges on the Ixia App server.

Notes: Ignore the self parameters when using those keywords.

Shortcuts

Add Port · Add Quicktest · Apply Traffic · Change Frame Rate · Change Frame Rate Dynamic · Change Frame Size · Close · Collect All Data · Collect Data · Get All Test Result · Get Quicktest List · Get Quicktest Result · Get Quicktest Result · Get Test Composer Result · Get Test Report · Get Test Result · Load And Start Traffic · Load Config · Load Traffic · Loss From File · Ping · Regenerate · Reset Config · Run Quicktest · Set All Traffic Item · Set Bgp Items · Set Bgp Neighbor · Set Capture Port · Set Traffic Item · Should Be Pingable · Start Capture · Start Protocol · Start Test Composer · Start Traffic · Stop All Protocols · Stop And Save Capture · Stop Quicktest · Stop Test Composer · Stop Traffic · Wait Until Connected

Keywords

Keyword	Arguments	Documentation
Add Port	self, force=True, time_out=2m, learn_time=2m	Add ports using the real-port information from active local config
		 time_out is the wait time until port is connected (default is 2m) learn_time is the time waiting for arp to be learned (default is 2m)
		Sample of local config tester:
		tester: device: ixnet03_8009 config: quicktest.ixncfg real-port: - chassis: 10.128.4.41 card: 4 port: 3 ip: 10.100.11.2 mask: 24 gw: 10.100.11.1 - chassis: 10.128.4.41 card: 4
		port: 4
		ip: 10.100.14.2 mask: 24 gw: 10.100.14.1
Add Quicktest	self, name,	Create a new Quicktest with default value
	test_type=rfc2544throughput, tx_mode=interleaved, clear_all=True	Type could be one of following: rfc2544throughput, rfc2544frameLoss, rfc2544back2back. Use Tester. <u>Load Config</u> to load a customized quicktest
		When clear_all is True, any existed quicktests will be cleared.
		Transmit mode tx_mode takes following values: interleaved (default) or sequential. The mode should be identical with the transmit mod of the ports.
		Notes : The keyword does not create necessary ports. It should be used with a existed configuration by Tester. <i>Load Config</i> or Tester. <i>Add Port</i> keyword.
Apply Traffic	self, refresh=True	Applies the current traffic configuration
		refresh: Refreshed the learned information before apply the traffic or not Note: This is a blocking command
Change Frame	self, value, pattern=.*	Changes the frame rate
Rate		Parameter:
		 value: value to set. Depends on the current configuration, this could be percent line rate or bit per second etc. traffic_pattern: a regular expression to identify traffic item name, default is everything `.*
Change Frame Rate Dynamic	self, value, pattern=.*	Changes the traffic flow rate on-fly
		No need to stop the running traffic to change the rate
		Parameter:
		value: value to set. Depend on the current configuration, this could be percent line rate or bit per second etc.
		pattern: a regular expression to identify traffic item name, default is everything .*
Change Frame	self, type, value, pattern=.*	Changes the frame size

Size		Parameter:
		type: could be fixed size, increment_from`,`increment_step or increment_to
		 value: value to set traffic_pattern: a regular expression to identify traffic item name, default is everything:
Close	self	Disconnects the current tester client
Collect All Data	self, prefix=stat_	Deprecated. Use
Collect Data	self, view, prefix=stat_	Depricated. Use <u>Get Test Result</u>
Get All Test	self, prefix=stat	Collects all Ixia traffic data after traffic is stopped.
Result	_	Results are CSV files that are stored in result folder. The prefix prefix is appended to the original view nam
Get Quicktest List	self	Returns current loaded Quicktest list
Get Quicktest	self, test_index=-1, prefix=,	Get the result.csv file from the latest Quicktests
Result	enable_all=True	test_index is a index of the current Quicktest1 means that last one.
Get Quicktest	self, test_index=-1	Returns the path of the newest run of a Quicktest
Result Path		test_index is a index of the current Quicktest1 means that last one.
Get Test Composer Result	self, result_file=composer.log	Get the result of test composer script
Get Test Report	self,	Generates and get report of the current active test in PDF format
	local_name=ixnet_report.pdf, enable_all=True	local_name : name of the report on local machine. Default is ixnet_report.pdf
Get Test Result	self, view, prefix=stat_	Collects traffic data of a view and export to a CSV file in result folder
	_	Currently, supported views are:
		Port Statistics, Global Protocol Statistics, BGP Aggregated Statistics, BGP Aggregated State Counts, OSPF Aggregated Statistics, OSPF Aggregated Statistics, OSPFv3 Aggregated Statistics, OSPFv3 Aggregated Statistics, OSPFv3 Aggregated Statistics, Counts, L2-L3 Test Summary Statistics, Flow Statistics, Flow Detective, Data Plane Port Statistics, User Define Statistics, Traffic Item Statistics
		Result were store as CSV files in result folder. If there is no valid data, view will be silently ignored
		The prefix prefix is appended to the view name for the CSV file.
Load And Start Traffic	self, wait_time1=10s, wait_time2=10s	Combines Load Traffic and Start Traffic to one keyword.
Load Config	self, config_name=,	loads traffic configuration, applies and start protocol if necessary.
	wait_time=2m, apply=True, wait_time2=2m, apply=True, protocol=True, force=True, wait_time3=30s	The config file name was defined in the `local.yaml which is a Ixia Network configuration file and located in the config folder of the test.
		The keyword remap the vports to real port when data is specified in the local configuration file. For some reasons, the txMode is cleared when remapping happens. Use tx_mode to set the TxMode of the remappe ports.
		Parameters:
		 apply: applies traffic when True otherwise protocol: starts all protocols when True otherwise force: force to reclaim the ports when True otherwise wait_time: wait time after applying protocols wait_time2: maximum wait time befor all ports become available. In common case, this is calculated automatically so user does not need to change this value. wait_time3: default waiting time after config file is loaded (30s) More information about ports could be define in real port section like this:
		# tester information tester:
		tester: device: ixnet03_8009 config: bgp.ixncfg real-port: - chassis: 10.128.4.41 card: 4 port: 7 media: fiber tx_mode: interleaved
		Configurable port parameters ares:
		 tx_mode: sequential or interleaved(default) media: copper or fiber (Note: no default value)
		See Common for more details about the yaml configuration files.
Load Traffic	self, wait_time=2m, wait_time2=2m, apply=True, protocol=True, force=True, tx_mode=interleaved	
	self,	

	file_name=Flow_Statistics.csv, tx_frame=4, frame_delta=6, time1=21, time2=22	tx_frame, frame_delta,time1,time2 is indexes of TX frame, Frame Delta, Start Time, Stop Time in the csv (counted from zero)
		The calculation should be performed when traffic is stopped. The calculation supposed traffic is configured by frame per second
Ping	self, dst_ip, src_port_index=0,	Ping from Ixia to dst_ip
	src_intf_index=0	The keyword return the output string as it is. The return could be
		- Port <portname>: ping failed: port not assigned - Response received from <sourcelp>/unknown . Sequence Number <sequencenumber> - Ping request to <destinationlp>/unknown ip failed: <genericpingerror>/<error>: <genericerror>unknown reason - Error: Couldn't find any source interface for Send Ping to <destinationlp> on <portname> Id <id> - Error: Couldn't find any source IP for Send Ping to <destinationlp> on <portname> Id <id></id></portname></destinationlp></id></portname></destinationlp></genericerror></error></genericpingerror></destinationlp></sequencenumber></sourcelp></portname>
		Parameters: src_port_index: index of lxia port (starts from 0) src_intf_index: index of interface insides the port (starts from 0)
		Examples:
		Tester. <u>Ping</u> 1.1.1.1 0 0 Tester. <u>Ping</u> 1.1.1.1
Regenerate	self	Regenerates all flow of current traffic items
Reset Config	self	Clears current config and creates new blank config
Run Quicktest	self, test_index=0,	Runs the Quicktest and wait until it finishes
	wait_until_finish=True	Warning: it could take a long time to finish a quicktest
Set All Traffic	self, enabled=True	Enables/Disables all traffic items at once
Set Bgp Items	self, port_index,	Enables/Disables PCP ontry by a set of part paidbbar route range index
Set bgp items	neighbor_index,	Enables/Disables BGP entry by a set of port,neighbor,route_range index
	route_range_index, is_enable	Parameters:
		 port_index: index of the port neighbor index: index of the neighbor or *
		 reignbor_index or the heignbor or route_range_index: index of the route range or *
		■ is_enable: \${TRUE} or \${FALSE}
		Note
		Examples:
		Tester. Set BGP Items 0 * * \${FALSE}
		Tester. Set BGP Items 0 * * \${TRUE}
Set Bgp	self, *indexes, **kwargs	Enables/Disables BGP entry by neighbor index
Neighbor		kwargs contains following parameters:
		■ indexes: is a list of index of BGP neighbor (index is started from zero)
		 vport_index: is the target vport index enabled: TRUE or FALSE
		Examples:
		Tester.Set BGP Item 0 1 vport_index=0 enabled=\${FALSE}
		Tester.Set BGP Item 0 1 vport_index=1 enabled=\${TRUE}
Set Capture	self, data_mode=True,	Capture packets for follow port
Port	control_mode=True, port_index=0	port_index : is a index of current test port (start from 0) data_mode : capture data packets and save in
		<intf>_HW.cap file control_mode : capture controls packets and save in <intf>_SW.cap file</intf></intf>
		Note: control_mode saves all control packets and data_mode only saves data packets.
		Note: control_mode saves all control packets and data_mode only saves data packet
		Examples:
		Tester. Set Capture Port ocontrol_mode=\${TRUE} 0 1
Set Traffic Item	self, *items, **kwargs	Enables/Disables some traffic items items
		Parameters:
		 items: a list of Ixia traffic item name enabled: False or True ,the mode to set traffic item to, default is True (enabled)
		Note: traffic item could be specified by :: <num> format. In this case the num is the order of traffic item</num>
		count from zero.
		Returns True if all items are set coordinately or otherwise
		Examples:
		Set Traffic Item 1 Traffic Item 2
		Set Traffic Item @{item_list} Set Traffic Item 1 enabled = \${FALSE}
Chauld Da	and dat in our most index. O	Plantane like and action on some Haller talls

Snould Be Pingable	seii, asi_ip, src_port_inaex=u, src_intf_index=0	Ping from Ixia and raise an error it ping tails
		The keyword return <i>True</i> if succeeds
Start Capture	self, wait_time=30s	Start packet capture
		Target ports are set by the configuration file or by [Set Capture] keyword
Start Protocol	self, wait_time=1m	Starts all protocols and wait for wait_time
		Default wait_time is 1 minute. Make sure wait_time is big engouh to start all protocols.
Start Test	self,	Run a test composer script.
Composer	script_name=Main_Procedure, run_num=1, wait_for_test=True, parameter=, wait=10s	The test composer script should be included in an Ixia Network configuration file and loaded properly with <u>Load Config</u>
		Parameters:
		 script_name is the name of the script to run. Default value is Main_Procedure. wait_for_test: if \${TRUE} then wait until the script finishes. parameter: parameter that is passed to the script. Parameter could be in 2 formats: {{VAR1 VALUE1} {VAR2 VALUE2}} or simply as VALUE1 VALUE2.
		The script must prepare <i>VAR1</i> and <i>VAR2</i> properly by <i>Test parameter</i> . See Ixia Network anout composer script for more details.
		wait: wait time before go to next keyword
		Examples:
		Tester. <u>Start Test Composer</u> parameter=XXX YYY
		Tester. Get Test Composer Result result file=script1.log
		Tester. Start Test Composer parameter={{VAR1 AAA} {VAR2 BBB}}
		Tester. Get Test Composer Result result_file=script1.log
Start Traffic	self, wait_time=30s	Starts the current traffic settiing and wait for wait_time. Note: This is a asynchronus action. After called, the keyword finishes immediatly but it will take a while before traffic starts By default the keyword will wait for 30 seconds.
Stop All Protocols	self, wait_time=30s	Stop all running protocols
Stop And Save	self, prefix=,	Stop current capture and save the resuls to folder specified by path
Capture	wait_until_finish=True, monitor_interval=5s	Captured files will be saved in current result folder with prefix appended in their names. Examples:
		Tester. Start Capture
		Sleep 10s
		Tester. Stop And Save Capture \${RESULT_FOLDER}/capture.zip
Stop Quicktest	self, test_index=0	Stops a running test
Stop Test	self, wait=10s	Stop a running composer
Composer		Do nothing when a test composer has already stopped or no composer has been prepared.
Stop Traffic	self, stop_protocol=False, wait_time=10s	Stops the current traffic and wait for wait_time
		Parameters:
		 stop_protocol: if True also stops all running protocols wait time: time to wait after apply the command
Wait Until	solf timeout etr 5m	
Connected	self, timeout_str=5m	Waits until ports become enabled and connected

Altogether 40 keywords. Generated by <u>Libdoc</u> on 2018-11-30 13:34:55.

