DTC B0003:53

System malfunction location	Operation (deployment) inhibited due to configuration setting		
Detection condition	Warning Detection conditions are for understanding the DTC outline before performing an inspection. Performing an inspection according to only the detection conditions may cause injury due to an operating error, or damage the system. When performing an inspection, always follow the inspection procedure. The SAS control module configuration has not been set		
Fail-safe	_		
Possible cause	SAS control module configuration error SAS control module malfunction		
System wiring diagram	_		

Diagnostic Procedure

Step	Inspection	Action	
1	PERFORM SAS CONTROL MODULE	Yes	Go to the next step.
	CONFIGURATION (AS-BUILT DATA USE)	No	DTC troubleshooting completed.
	Perform the SAS control module configuration		
	using the M-MDS.		
	(See SAS CONTROL MODULE		
	CONFIGURATION (USING AS-BUILT DATA).)		
	Clear the DTC for the SAS control module using the M-MDS. (See CLEARING DTC.)		
	Perform the DTC inspection for the SAS control		
	module using the M-MDS. (See DTC		
	INSPECTION.)		
	Are the same DTCs present?		
2	PERFORM SAS CONTROL MODULE DTC INSPECTION • Clear the DTC for the SAS control module using the M-MDS. (See CLEARING DTC.)	Yes	Replace the SAS control module. (See SAS CONTROL
			MODULE REMOVAL/INSTALLATION.)
			Go to the next step.
		No	DTC troubleshooting completed.
	• Perform the DTC inspection for the SAS control		
	module using the M-MDS. (See DTC		
	INSPECTION.)		
3	Are the same DTCs present? VERIFY THAT NO OTHER DTCS ARE	Yes	Go to the applicable DTC inspection.
3	PRESENT	No	DTC troubleshooting completed.
	Clear the DTC for the SAS control module using	110	DTG troubleshooting completed.
	the M-MDS. (See CLEARING DTC.)		
	Perform the DTC inspection for the SAS control		
	module using the M-MDS. (See DTC		
	INSPECTION.)		
	Are any other DTCs output?		