My Project

Generated by Doxygen 1.13.2

1 Topic Index	1
1.1 Topics	1
2 Class Index	3
2.1 Class List	3
3 File Index	5
3.1 File List	5
4 Topic Documentation	7
4.1 DS3231 Real-Time Clock Driver	7
4.1.1 Detailed Description	8
4.1.2 Function Documentation	8
4.1.2.1 RTC_ClearFlagAlarm1()	8
4.1.2.2 RTC_ClearFlagAlarm2()	8
4.1.2.3 RTC_ConvertToBCD()	8
4.1.2.4 RTC_ConvertToDEC()	8
4.1.2.5 RTC_CtrlAlarm1()	9
4.1.2.6 RTC_CtrlAlarm2()	9
4.1.2.7 RTC_Deinit()	9
4.1.2.8 RTC_GetDate()	9
4.1.2.9 RTC_GetState()	0
4.1.2.10 RTC_GetTime()	0
4.1.2.11 RTC_Init()	0
4.1.2.12 RTC_Read()	0
4.1.2.13 RTC_SetDate()	1
4.1.2.14 RTC_SetDateDefault()	1
4.1.2.15 RTC_SetInterruptMode()	1
4.1.2.16 RTC_SetOscState()	1
4.1.2.17 RTC_SetTime()	2
4.1.2.18 RTC_SetTimeDefault()	2
4.1.2.19 RTC_Write()	2
5 Class Documentation	3
5.1 REC_config_t Struct Reference	3
5.1.1 Detailed Description	3
5.1.2 Member Data Documentation	3
5.1.2.1 baudrate	3
5.1.2.2 data_bits	4
5.1.2.3 free_space_limit_mb	4
5.1.2.4 max_bytes	4
5.1.2.5 parity	4
5.1.2.6 size	4
5.1.2.7 stop_bits	4

5.1.2.8 version	 14
5.2 RTC_date_t Struct Reference	 15
5.2.1 Detailed Description	 15
5.2.2 Member Data Documentation	 15
5.2.2.1 date	 15
5.2.2.2 day	 15
5.2.2.3 month	 15
5.2.2.4 year	 15
5.3 RTC_time_t Struct Reference	 16
5.3.1 Detailed Description	 16
5.3.2 Member Data Documentation	 16
5.3.2.1 format	 16
5.3.2.2 hrs	 16
5.3.2.3 min	 16
5.3.2.4 sec	 16
6 File Documentation	17
6.1 drivers/rtc_ds3231.c File Reference	
6.1.1 Macro Definition Documentation	
6.1.1 Macro Definition Documentation	
6.1.1.2 BYTE_2	
6.1.1.4 I2C_DATA_LENGTH	
6.1.2 Function Documentation	
6.1.2.1 AT_NONCACHEABLE_SECTION() [1/2]	
6.1.2.1 AT_NONCACHEABLE_SECTION() [1/2]	
6.1.2.3 lpi2c_callback()	
6.1.2.4 RTC_ConvertToBCD()	 19
6.1.2.5 RTC_ConvertToDEC()	
6.1.3 Variable Documentation	
6.1.3.1 gCompletionFlag	
6.1.3.2 gEdmaRxHandle	
6.1.3.3 gEdmaTxHandle	
6.1.3.4 xfer	
6.2 drivers/rtc_ds3231.h File Reference	
6.2.1 Macro Definition Documentation	
6.2.1.1 ALARM_DISABLED	
6.2.1.2 APP_SUCCESS	
6.2.1.3 DS3231_A1F	
6.2.1.4 DS3231_A1IE	
6.2.1.5 DS3231_A2F	
6.2.1.6 DS3231_A2IE	

6.2.1.7 DS3231_ADDR_CENT	23
6.2.1.8 DS3231_ADDR_DATE	23
6.2.1.9 DS3231_ADDR_DAY	24
6.2.1.10 DS3231_ADDR_HRS	24
6.2.1.11 DS3231_ADDR_I2C	24
6.2.1.12 DS3231_ADDR_MIN	24
6.2.1.13 DS3231_ADDR_MONTH	24
6.2.1.14 DS3231_ADDR_SEC	24
6.2.1.15 DS3231_ADDR_YEAR	24
6.2.1.16 DS3231_INTCN	25
6.2.1.17 DS3231_REG_CTRL	25
6.2.1.18 DS3231_REG_STATUS	25
6.2.1.19 E_FAULT	25
6.2.1.20 FRIDAY	25
6.2.1.21 I2C_BAUDRATE	25
6.2.1.22 I2C_MASTER	25
6.2.1.23 LPI2C_RX_DMA_CHANNEL	26
6.2.1.24 LPI2C_RX_EDMA_CHANNEL	26
6.2.1.25 LPI2C_TX_CHANNEL	26
6.2.1.26 LPI2C_TX_DMA_CHANNEL	26
6.2.1.27 MONDAY	26
6.2.1.28 OSC_STOPPED	26
6.2.1.29 SATURDAY	26
	27
6.2.1.31 THURSDAY	27
6.2.1.32 TIM_CYCLE_12H	27
6.2.1.33 TIM_CYCLE_12H_AM	27
6.2.1.34 TIM_CYCLE_12H_PM	27
6.2.1.35 TIM_CYCLE_24H	27
6.2.1.36 TUESDAY	27
6.2.1.37 WEDNESDAY	27
6.2.2 Enumeration Type Documentation	27
6.2.2.1 RTC_interrupt_mode_t	27
6.2.2.2 RTC_osc_state_t	28
6.3 rtc_ds3231.h	28
6.4 include/app_init.h File Reference	30
6.4.1 Function Documentation	30
6.4.1.1 APP_InitBoard()	30
11-	31
	31
	32
6.6.1.1 TASK_PRIO	32

6.6.2 Function Documentation	2
6.6.2.1 msc_task()	2
6.6.2.2 record_task()	2
6.6.2.3 vApplicationGetIdleTaskMemory()	3
6.6.2.4 vApplicationGetTimerTaskMemory()	3
6.6.3 Variable Documentation	3
6.6.3.1 g_xMscTaskHandle	3
6.6.3.2 g_xRecordTaskHandle	4
6.6.3.3 g_xSemMassStorage	4
6.6.3.4 g_xSemRecord	4
6.7 app_tasks.h	4
6.8 include/defs.h File Reference	5
6.8.1 Macro Definition Documentation	6
6.8.1.1 CONFIG_FILE	6
6.8.1.2 CONTROL_LED_ENABLED	6
6.8.1.3 DEBUG_ENABLED	6
6.8.1.4 DEFAULT_BAUDRATE	6
6.8.1.5 DEFAULT_DATA_BITS	7
6.8.1.6 DEFAULT_FREE_SPACE	7
6.8.1.7 DEFAULT_MAX_FILESIZE	7
6.8.1.8 DEFAULT_PARITY	7
6.8.1.9 DEFAULT_STOP_BITS	7
6.8.1.10 INFO_ENABLED	7
6.8.1.11 MSC_ENABLED	7
6.8.1.12 MSC_STACK_SIZE	8
6.8.1.13 NOT_IMPLEMENTED	8
6.8.1.14 PWRLOSS_DET_ACTIVE_IN_TIME	8
6.8.1.15 PWRLOSS_DET_PRIO	8
6.8.1.16 PWRLOSS_DETECTION_ENABLED	8
6.8.1.17 PWRLOSS_TEST_GPIOS	8
6.8.1.18 PWRLOSS_TIMER_PRIO	8
6.8.1.19 RECORD_STACK_SIZE	8
6.8.1.20 TAU5	9
6.8.1.21 TEMPERATURE_MEAS_ENABLED	9
6.8.1.22 UART_FIFO_ENABLED	9
6.8.1.23 UART_FIFO_LENGHT	9
6.8.1.24 UART_PRINT_ENABLED	9
6.8.1.25 UART_RECEIVE_PRIO	9
6.9 defs.h	0
	1
6.10.1 Macro Definition Documentation	1
6.10.1.1 FRROR ADMA	.1

6.10.1.2 ERROR_CLOSE	2
6.10.1.3 ERROR_CONFIG	2
6.10.1.4 ERROR_FILESYSTEM	2
6.10.1.5 ERROR_IRTC	2
6.10.1.6 ERROR_NONE	2
6.10.1.7 ERROR_OPEN	2
6.10.1.8 ERROR_OUT_OF_CYCLE	2
6.10.1.9 ERROR_READ	2
6.10.1.10 ERROR_RECORD	3
6.10.1.11 ERROR_UNKNOWN	3
6.10.2 Typedef Documentation	3
6.10.2.1 error_t	3
6.10.3 Function Documentation	3
6.10.3.1 ERR_HandleError()	3
6.10.3.2 ERR_Init()	3
6.10.3.3 ERR_SetState()	3
6.11 error.h	4
6.12 include/led.h File Reference	4
6.12.1 Macro Definition Documentation	6
6.12.1.1 BACKUP_POWER_LED_PIN	6
6.12.1.2 BACKUP_POWER_LED_PORT	6
6.12.1.3 ERROR_LED_PIN_RECORD	6
6.12.1.4 ERROR_LED_PORT	6
6.12.1.5 FLUSH_LED_PORT	6
6.12.1.6 MEMORY_LOW_LED_PIN	6
6.12.1.7 MEMORY_LOW_LED_PORT	7
6.12.1.8 RECORD_LED_PIN	7
6.12.1.9 RECORD_LED_PIN_FLUSH	7
6.12.1.10 RECORD_LED_PORT	7
6.12.2 Function Documentation	7
6.12.2.1 LED_ClearSignalFlush()	7
6.12.2.2 LED_SetHigh()	7
6.12.2.3 LED_SetLow()	8
6.12.2.4 LED_SignalBackUpPowerAvailable()	8
6.12.2.5 LED_SignalError()	8
6.12.2.6 LED_SignalFlush()	8
6.12.2.7 LED_SignalLowMemory()	8
6.12.2.8 LED_SignalReady()	9
6.12.2.9 LED_SignalRecording()	9
6.12.2.10 LED_SignalRecordingStop()	9
6.13 led.h	9
6.14 include/mass_storage.h File Reference	n

6.14.1 Function Documentation
6.14.1.1 MSC_DeviceMscApp()
6.14.1.2 MSC_DeviceMscAppTask()
6.15 mass_storage.h
6.16 include/parser.h File Reference
6.16.1 Enumeration Type Documentation
6.16.1.1 REC_version_t
6.16.2 Function Documentation
6.16.2.1 PARSER_ClearConfig()
6.16.2.2 PARSER_GetBaudrate()
6.16.2.3 PARSER_GetConfig()
6.16.2.4 PARSER_GetDataBits()
6.16.2.5 PARSER_GetFileSize()
6.16.2.6 PARSER_GetFreeSpaceLimitMB()
6.16.2.7 PARSER_GetMaxBytes()
6.16.2.8 PARSER_GetParity()
6.16.2.9 PARSER_GetStopBits()
6.16.2.10 PARSER_GetVersion()
6.16.2.11 PARSER_ParseBaudrate()
6.16.2.12 PARSER_ParseDataBits()
6.16.2.13 PARSER_ParseFileSize()
6.16.2.14 PARSER_ParseFreeSpace()
6.16.2.15 PARSER_ParseParity()
6.16.2.16 PARSER_ParseStopBits()
6.17 parser.h
6.18 include/pwrloss_det.h File Reference
6.18.1 Macro Definition Documentation
6.18.1.1 CTIMER
6.18.1.2 CTIMER_CLK_FREQ
6.18.1.3 CTIMER_EMT0_OUT
6.18.1.4 CTIMER_MAT0_OUT
6.18.1.5 LPCMP_BASE
6.18.1.6 LPCMP_DAC_CHANNEL
6.18.1.7 LPCMP_IRQ_ID
6.18.1.8 LPCMP_USER_CHANNEL
6.18.1.9 SPC_BASE
6.18.2 Function Documentation
6.18.2.1 PWRLOSS_DetectionInit()
6.19 pwrloss_det.h
6.20 include/record.h File Reference
6.20.1 Macro Definition Documentation
6 20 1 1 FLUSH TIMEOUT TICKS

6.20.2 Function Documentation	63
6.20.2.1 CONSOLELOG_CheckFileSystem()	63
6.20.2.2 CONSOLELOG_ClearTransferedBytes()	63
6.20.2.3 CONSOLELOG_CreateDirectory()	63
6.20.2.4 CONSOLELOG_CreateFile()	63
6.20.2.5 CONSOLELOG_Deinit()	64
6.20.2.6 CONSOLELOG_Flush()	64
6.20.2.7 CONSOLELOG_GetFlushCompleted()	64
6.20.2.8 CONSOLELOG_GetFreeSpaceMB()	64
6.20.2.9 CONSOLELOG_GetMaxBytes()	65
6.20.2.10 CONSOLELOG_GetTransferedBytes()	65
6.20.2.11 CONSOLELOG_Init()	65
6.20.2.12 CONSOLELOG_PowerLossFlush()	65
6.20.2.13 CONSOLELOG_ProccessConfigFile()	65
6.20.2.14 CONSOLELOG_ReadConfig()	66
6.20.2.15 CONSOLELOG_Recording()	66
6.21 record.h	66
6.22 include/task_switching.h File Reference	67
6.22.1 Function Documentation	68
6.22.1.1 USB_State()	68
6.22.2 Variable Documentation	68
6.22.2.1 g_msc	68
6.23 task_switching.h	69
6.24 include/temperature.h File Reference	69
6.24.1 Function Documentation	69
6.24.1.1 Read()	69
6.24.1.2 TMP_GetTemperature()	70
6.24.1.3 TMP_Init()	70
6.24.1.4 Write()	70
6.25 temperature.h	71
6.26 include/time.h File Reference	71
6.26.1 Macro Definition Documentation	72
6.26.1.1 LPI2C_DMA_BASEADDR	72
6.26.2 Function Documentation	72
6.26.2.1 TIME_InitIRTC()	72
6.27 time.h	72
6.28 include/uart.h File Reference	73
6.28.1 Macro Definition Documentation	73
6.28.1.1 LPUART3_CLK_FREQ	73
6.28.2 Function Documentation	73
6.28.2.1 UART_Deinit()	73
6.28.2.2 UART_Disable()	74

Index		77
6.29 uart.h		74
	6.28.2.5 UART_Print()	74
	6.28.2.4 UART_Init()	74
	6.28.2.3 UART_Enable()	74

Topic Index

1	.1	T	Ō	p	i	C	S
•	• •	-	•	r	-	_	_

Here is a list of all topics with brief descriptions:	
DS3231 Real-Time Clock Driver	-

2 Topic Index

Class Index

2.1 Class List

Here are the classes, structs, unions and interfaces with brief descriptions:

REC_config_t	
Configuration structure for the recording system	13
RTC_date_t	
Structure for Keeping Date	15
RTC_time_t	
Structure for Keeping Time	16

4 Class Index

File Index

3.1 File List

Here is a list of all files with brief descriptions:

drivers/rtc_ds3231.c	7
drivers/rtc_ds3231.h	0
include/app_init.h	0
include/app_tasks.h	1
$include/defs.h \\ \ldots \\ $	
include/error.h	1
$include/led.h \qquad . \qquad 4$	4
include/mass_storage.h	0
include/parser.h	1
include/pwrloss_det.h	8
include/record.h	1
include/task_switching.h	7
include/temperature.h	
include/time.h	1
include/uart b	٦,

6 File Index

Topic Documentation

4.1 DS3231 Real-Time Clock Driver

Real-Time Circuit Related Functions.

Functions

```
    uint8_t RTC_Init (void)

     Initialize The RTC DS3231.

    void RTC_Deinit (void)

     De-Initialize The RTC DS3231.

    static uint8_t RTC_ConvertToBCD (uint8_t dec)

     Converts Numbers From Decimal Base To BCD Base.

    static uint8_t RTC_ConvertToDEC (uint8_t bcd)

     Converts Numbers From BCD Base To Decimal Base.

    uint8_t RTC_GetState (void)

      This Function Checks If The Oscillator Is Still Running.

    void RTC_SetOscState (RTC_osc_state_t state)

     Sets The Oscillator Stop Flag (OSF).

    uint8_t RTC_Write (uint8_t regAddress, uint8_t val)

      Writes Value Into RTC Registers.

    uint8_t RTC_Read (uint8_t regAddress)

     Reads Value From RTC Register.

    void RTC_SetTime (RTC_time_t *pTime)

     Sets Time.

    void RTC_GetTime (RTC_time_t *pTime)

     Gets Time.

    void RTC_SetDate (RTC_date_t *pDate)

     Sets Date.
```

void RTC_GetDate (RTC_date_t *pDate)

Sets The INTCN Bit in Control Register.
• void RTC_CtrlAlarm1 (uint8_t enable)

Enables/Disables The Alarm 1.

void RTC_SetInterruptMode (RTC_interrupt_mode_t mode)

8 Topic Documentation

```
    void RTC_ClearFlagAlarm1 (void)
```

Clears The A1F Flag in Control Register.

void RTC_CtrlAlarm2 (uint8_t enable)

Enables/Disables The Alarm 2.

void RTC_ClearFlagAlarm2 (void)

Clears The A1F Flag in Control Register.

void RTC_SetTimeDefault (RTC_time_t *pTime)

Sets Time To Default.

void RTC_SetDateDefault (RTC_date_t *pDate)

Sets Date To Default.

4.1.1 Detailed Description

Real-Time Circuit Related Functions.

4.1.2 Function Documentation

4.1.2.1 RTC_ClearFlagAlarm1()

Clears The A1F Flag in Control Register.

4.1.2.2 RTC ClearFlagAlarm2()

Clears The A1F Flag in Control Register.

4.1.2.3 RTC_ConvertToBCD()

Converts Numbers From Decimal Base To BCD Base.

Parameters

```
dec Decimal Number.
```

Returns

Number in Binary Coded Decimal.

4.1.2.4 RTC_ConvertToDEC()

Converts Numbers From BCD Base To Decimal Base.

Parameters

bcd Binary-Coded Decimal Number.

Returns

Number in Decimal Base.

4.1.2.5 RTC_CtrlAlarm1()

Enables/Disables The Alarm 1.

Parameters

enable | Specifies If The Alarm Will Be Enabled or Not.

4.1.2.6 RTC_CtrlAlarm2()

Enables/Disables The Alarm 2.

Parameters

enable | Specifies If The Alarm Will Be Enabled or Not.

4.1.2.7 RTC_Deinit()

```
void RTC_Deinit (
          void )
```

De-Initialize The RTC DS3231.

Pins Should Also Be De-Initialised Lately.

Parameters

void

4.1.2.8 RTC_GetDate()

Gets Date.

10 Topic Documentation

Parameters

pDate Pointer To Date Structure.

4.1.2.9 RTC_GetState()

This Function Checks If The Oscillator Is Still Running.

Returns

Function Returns 1 If The Oscillator Is Running. If The Oscillator Has Stopped Returns 0.

4.1.2.10 RTC_GetTime()

Gets Time.

Parameters

pTime Pointer To Time Structure.

4.1.2.11 RTC_Init()

Initialize The RTC DS3231.

Parameters

void

Before Calling of RTC_Init Function Is Important To Prepare I2C (To Keep The Driver As Universal As Possible, e.g To Use I2C With DMA, Interrupt/Polling Mode,...). enableRoundRobinArbitration = false; enableHaltOnError = true; enableContinuousLinkMode = false; enableDebugMode = false;

4.1.2.12 RTC_Read()

Reads Value From RTC Register.

Parameters

regAddress	Address of Register From Which Will Be Read.

Returns

Read Value.

4.1.2.13 RTC_SetDate()

Sets Date.

Parameters

pDate Pointer To Date Structure.

4.1.2.14 RTC_SetDateDefault()

Sets Date To Default.

Parameters

pDate Pointer to Date Structure That Will Be Configured To Default.

4.1.2.15 RTC_SetInterruptMode()

Sets The INTCN Bit in Control Register.

Parameters

mode Interrupt Mode.

4.1.2.16 RTC_SetOscState()

Sets The Oscillator Stop Flag (OSF).

12 Topic Documentation

Parameters

state	State of The Flag.
-------	--------------------

4.1.2.17 RTC_SetTime()

Sets Time.

Parameters

4.1.2.18 RTC_SetTimeDefault()

```
void RTC_SetTimeDefault (  \label{eq:rtc_time_t}  \mbox{RTC\_time\_t * $pTime$} )
```

Sets Time To Default.

Parameters

pTime	Pointer to Time Structure That Will Be Configured To Default.
-------	---

4.1.2.19 RTC_Write()

Writes Value Into RTC Registers.

Parameters

regAddress	Address of Register To Which Will Be Value Written.
val	Value That Will Be Writen Into Register.

Returns

void

Class Documentation

5.1 REC_config_t Struct Reference

Configuration structure for the recording system.

```
#include <parser.h>
```

Public Attributes

- REC_version_t version
- uint32_t baudrate
- lpuart_stop_bit_count_t stop_bits
- lpuart_data_bits_t data_bits
- Ipuart_parity_mode_t parity
- uint32_t size
- uint32_t max_bytes
- uint32_t free_space_limit_mb

5.1.1 Detailed Description

Configuration structure for the recording system.

Structure Holds The Configuration Parameters Required For Initializing The Recording System, Including The Board Version and Baud Rate...

5.1.2 Member Data Documentation

5.1.2.1 baudrate

uint32_t REC_config_t::baudrate

Desired Baudrate

14 Class Documentation

5.1.2.2 data_bits

```
lpuart_data_bits_t REC_config_t::data_bits
```

Number of Data Bit

5.1.2.3 free_space_limit_mb

```
uint32_t REC_config_t::free_space_limit_mb
```

Defines The Threshold Level of Free Memory on The SD card, Below Which The Lack of Memory is Indicated.

5.1.2.4 max_bytes

```
uint32_t REC_config_t::max_bytes
```

Number of Bytes Between LED Signal

5.1.2.5 parity

```
lpuart_parity_mode_t REC_config_t::parity
```

Parity Bit

5.1.2.6 size

```
uint32_t REC_config_t::size
```

Maximum File Size Maximal Log. Time In Per File

5.1.2.7 stop_bits

```
{\tt lpuart\_stop\_bit\_count\_t~REC\_config\_t::stop\_bits}
```

Number of Stop Bit

5.1.2.8 version

```
REC_version_t REC_config_t::version
```

NXP Board That Will Be Recorded

The documentation for this struct was generated from the following file:

· include/parser.h

5.2 RTC_date_t Struct Reference

Structure for Keeping Date.

```
#include <rtc_ds3231.h>
```

Public Attributes

- uint8_t date
- uint8_t day
- uint8_t month
- uint8_t year

5.2.1 Detailed Description

Structure for Keeping Date.

5.2.2 Member Data Documentation

5.2.2.1 date

```
uint8_t RTC_date_t::date
Date (1 [SUNDAY] .. 31 [SATURDAY])
```

5.2.2.2 day

```
uint8_t RTC_date_t::day
Day (1..7)
```

5.2.2.3 month

```
uint8_t RTC_date_t::month
Month (1..12)
```

5.2.2.4 year

```
uint8_t RTC_date_t::year
Year (From Base Year 2000)
```

The documentation for this struct was generated from the following file:

· drivers/rtc_ds3231.h

16 Class Documentation

5.3 RTC_time_t Struct Reference

Structure for Keeping Time.

```
#include <rtc_ds3231.h>
```

Public Attributes

- uint8_t format
- uint8_t sec
- uint8_t min
- uint8_t hrs

5.3.1 Detailed Description

Structure for Keeping Time.

5.3.2 Member Data Documentation

5.3.2.1 format

```
uint8_t RTC_time_t::format
```

Time Format (e.g. AM/PM or 24H Cycle)

5.3.2.2 hrs

```
uint8_t RTC_time_t::hrs
```

Hours (0..12/0..24 Based on Parameter Time Format)

5.3.2.3 min

```
uint8_t RTC_time_t::min
```

Minutes (0..60)

5.3.2.4 sec

```
uint8_t RTC_time_t::sec
```

Seconds (0..60)

The documentation for this struct was generated from the following file:

· drivers/rtc_ds3231.h

File Documentation

6.1 drivers/rtc_ds3231.c File Reference

```
#include "rtc_ds3231.h"
```

Macros

- #define I2C_DATA_LENGTH (2) /* MAX is 256 */ Length of I2C Rx Buffer.
- #define BYTE_1 (0U)
- #define BYTE_2 (1U)
- #define CLK_STATE(x)

Functions

- AT_NONCACHEABLE_SECTION (uint8_t g_aRxBuff[I2C_DATA_LENGTH])
 - Reception Buffer.
- AT_NONCACHEABLE_SECTION (lpi2c_master_edma_handle_t gEdmaHandle)
 - eDMA Driver Handle Used For Non-Blocking DMA Transfer.
- static void lpi2c_callback (LPI2C_Type *base, lpi2c_master_edma_handle_t *handle, status_t status, void *userData)
- uint8_t RTC_Init (void)
 - Initialize The RTC DS3231.
- void RTC_Deinit (void)
 - De-Initialize The RTC DS3231.
- static uint8_t RTC_ConvertToBCD (uint8_t dec)
- static uint8_t RTC_ConvertToDEC (uint8_t bcd)
- RTC_osc_state_t RTC_GetState (void)
 - This Function Checks If The Oscillator Is Still Running.
- void RTC_SetOscState (RTC_osc_state_t state)
 - Sets The Oscillator Stop Flag (OSF).
- uint8_t RTC_Write (uint8_t regAddress, uint8_t val)
 - Writes Value Into RTC Registers.
- uint8_t RTC_Read (uint8_t regAddress)

18 File Documentation

Reads Value From RTC Register.

void RTC_SetTime (RTC_time_t *pTime)

Sets Time.

void RTC_GetTime (RTC_time_t *pTime)

Gets Time.

void RTC_SetDate (RTC_date_t *pDate)

Sets Date.

void RTC_GetDate (RTC_date_t *pDate)

Gets Date.

void RTC_SetInterruptMode (RTC_interrupt_mode_t mode)

Sets The INTCN Bit in Control Register.

void RTC_CtrlAlarm1 (uint8_t enable)

Enables/Disables The Alarm 1.

void RTC_ClearFlagAlarm1 (void)

Clears The A1F Flag in Control Register.

void RTC_CtrlAlarm2 (uint8_t enable)

Enables/Disables The Alarm 2.

void RTC_ClearFlagAlarm2 (void)

Clears The A1F Flag in Control Register.

void RTC_SetTimeDefault (RTC_time_t *pTime)

Sets Time To Default.

void RTC_SetDateDefault (RTC_date_t *pDate)

Sets Date To Default.

Variables

• edma_handle_t gEdmaTxHandle

Tx eDMA Handle.

edma_handle_t gEdmaRxHandle

Rx eDMA Handle.

volatile bool gCompletionFlag = false

Flag Indicating Whether The Transfer Has Finished.

• lpi2c_master_transfer_t xfer = {0}

Transfer Descriptor for I2C Communication.

6.1.1 Macro Definition Documentation

6.1.1.1 BYTE_1

#define BYTE_1 (0U)

6.1.1.2 BYTE_2

#define BYTE_2 (1U)

6.1.1.3 CLK_STATE

```
#define CLK_STATE(
     X)
```

Value:

```
(uint8_t)((x > 7) & 0x1)
```

6.1.1.4 I2C_DATA_LENGTH

```
#define I2C_DATA_LENGTH (2) /* MAX is 256 */
```

Length of I2C Rx Buffer.

6.1.2 Function Documentation

6.1.2.1 AT_NONCACHEABLE_SECTION() [1/2]

```
AT_NONCACHEABLE_SECTION ( {\tt lpi2c\_master\_edma\_handle\_t} \ \ \textit{gEdmaHandle})
```

eDMA Driver Handle Used For Non-Blocking DMA Transfer.

6.1.2.2 AT_NONCACHEABLE_SECTION() [2/2]

```
AT_NONCACHEABLE_SECTION ( uint8_t g_aRxBuff[I2C_DATA_LENGTH])
```

Reception Buffer.

Transmission Buffer.

Must Be In Non-Cacheable Memory Due To Usage of DMA.

6.1.2.3 lpi2c_callback()

6.1.2.4 RTC_ConvertToBCD()

20 File Documentation

6.1.2.5 RTC_ConvertToDEC()

6.1.3 Variable Documentation

6.1.3.1 gCompletionFlag

```
volatile bool gCompletionFlag = false
```

Flag Indicating Whether The Transfer Has Finished.

6.1.3.2 gEdmaRxHandle

```
edma_handle_t gEdmaRxHandle
```

Rx eDMA Handle.

6.1.3.3 gEdmaTxHandle

```
edma_handle_t gEdmaTxHandle
```

Tx eDMA Handle.

6.1.3.4 xfer

```
lpi2c_master_transfer_t xfer = {0}
```

Transfer Descriptor for I2C Communication.

Used to Configure and Execute Data Transfer Operations With The DS3231 via LPI2C using EDMA.

6.2 drivers/rtc_ds3231.h File Reference

```
#include <stdint.h>
#include "defs.h"
#include "fsl_lpi2c.h"
#include "fsl_lpi2c_edma.h"
#include "fsl_edma.h"
```

Classes

struct RTC_time_t

Structure for Keeping Time.

struct RTC_date_t

Structure for Keeping Date.

Macros

#define E_FAULT 1

General Error Return Code.

• #define APP_SUCCESS 0

Return Value If Operation Succeeded.

• #define LPI2C_TX_DMA_CHANNEL 0U

12C DMA Channel For Transmission.

#define LPI2C_RX_DMA_CHANNEL 1U

I2C DMA Channel For Reception.

#define LPI2C_TX_CHANNEL kDma0RequestMuxLpFlexcomm2Tx

Connection Between DMA Channel 0 and LP FLEXCOMM2 Tx.

#define LPI2C_RX_EDMA_CHANNEL kDma0RequestMuxLpFlexcomm2Rx

Connection Between DMA Channel 0 and LP_FLEXCOMM2 Rx.

#define I2C_MASTER ((LPI2C_Type *)LPI2C2_BASE)

Points To I2C Peripheral Unit (Specifically LPI2C2 Instance).

#define DS3231_A1IE (0x00u)

Alarm Interrupt Enable Bits.

- #define DS3231_A2IE (0x1u)
- #define DS3231_INTCN (0x2u)

Interrupt Control Bit.

#define DS3231_A1F (0x0u)

Alarm 1 & Alarm 2 Flags.

- #define DS3231_A2F (0x1u)
- #define ALARM_DISABLED (0x0u)
- #define OSC_STOPPED (0x00u)

Indicates That Oscillator Has Stopped & Time Has To Updated.

• #define DS3231_ADDR_SEC (0x00U)

Registers Addresses of DS3231.

- #define DS3231_ADDR_MIN (0x01U)
- #define DS3231_ADDR_HRS (0x02U)
- #define DS3231_ADDR_DAY (0x03U)
- #define DS3231_ADDR_DATE (0x04U)
- #define DS3231_ADDR_MONTH (0x05U)
- #define DS3231_ADDR_YEAR (0x06U)#define DS3231_ADDR_CENT (0x07U)
- #define DS3231_REG_STATUS (0x0Fu)

Address of Status Register.

• #define DS3231_REG_CTRL (0x0Eu)

Address of Control Register.

#define DS3231_ADDR_I2C (0x68U)

Address of I2C Slave.

#define SUNDAY (0x1)

Definition of Dates.

- #define MONDAY (0x2)
- #define TUESDAY (0x3)
- #define WEDNESDAY (0x4)
- #define THURSDAY (0x5)
- #define FRIDAY (0x6)
- #define SATURDAY (0x7)
- #define TIM_CYCLE_12H (0x0)

Definitions For Time Format Handling.

22 File Documentation

```
• #define TIM_CYCLE_12H_AM (0x0)
```

- #define TIM_CYCLE_12H_PM (0x1)
- #define TIM_CYCLE_24H (0x2)
- #define I2C_BAUDRATE 100000U

Application Configurable Items.

Enumerations

```
enum RTC_osc_state_t { OSC_OK = 0 , OSC_INTERRUPTED }
```

An Enum to Capture The State of The Oscillator,.

enum RTC_interrupt_mode_t { SQUARE_WAVE_INTERRUPT = 0 , ALARM_INTERRUPT }

Functions

uint8_t RTC_Init (void)

Initialize The RTC DS3231.

void RTC_Deinit (void)

De-Initialize The RTC DS3231.

static uint8_t RTC_ConvertToBCD (uint8_t dec)

Converts Numbers From Decimal Base To BCD Base.

static uint8_t RTC_ConvertToDEC (uint8_t bcd)

Converts Numbers From BCD Base To Decimal Base.

uint8_t RTC_GetState (void)

This Function Checks If The Oscillator Is Still Running.

void RTC_SetOscState (RTC_osc_state_t state)

Sets The Oscillator Stop Flag (OSF).

uint8_t RTC_Write (uint8_t regAddress, uint8_t val)

Writes Value Into RTC Registers.

uint8_t RTC_Read (uint8_t regAddress)

Reads Value From RTC Register.

void RTC_SetTime (RTC_time_t *pTime)

Sets Time.

void RTC_GetTime (RTC_time_t *pTime)

Gets Time.

void RTC_SetDate (RTC_date_t *pDate)

Sets Date.

void RTC_GetDate (RTC_date_t *pDate)

Gets Date.

void RTC_SetInterruptMode (RTC_interrupt_mode_t mode)

Sets The INTCN Bit in Control Register.

void RTC_CtrlAlarm1 (uint8_t enable)

Enables/Disables The Alarm 1.

void RTC_ClearFlagAlarm1 (void)

Clears The A1F Flag in Control Register.

void RTC_CtrlAlarm2 (uint8_t enable)

Enables/Disables The Alarm 2.

void RTC_ClearFlagAlarm2 (void)

Clears The A1F Flag in Control Register.

void RTC_SetTimeDefault (RTC_time_t *pTime)

Sets Time To Default.

void RTC_SetDateDefault (RTC_date_t *pDate)

Sets Date To Default.

6.2.1 Macro Definition Documentation

6.2.1.1 ALARM_DISABLED

#define ALARM_DISABLED (0x0u)

6.2.1.2 APP_SUCCESS

#define APP_SUCCESS 0

Return Value If Operation Succeeded.

6.2.1.3 DS3231_A1F

#define DS3231_A1F (0x0u)

Alarm 1 & Alarm 2 Flags.

A Logic 1 in The Alarm 'x' Flag Bit Indicates That The Time Matched The Alarm 'x' Registers.

6.2.1.4 DS3231_A1IE

#define DS3231_A1IE (0x00u)

Alarm Interrupt Enable Bits.

6.2.1.5 DS3231_A2F

#define DS3231_A2F (0x1u)

6.2.1.6 DS3231_A2IE

#define DS3231_A2IE (0x1u)

6.2.1.7 DS3231_ADDR_CENT

#define DS3231_ADDR_CENT (0x07U)

Century Flag Bit

6.2.1.8 DS3231_ADDR_DATE

#define DS3231_ADDR_DATE (0x04U)

Day of Month Register

24 File Documentation

6.2.1.9 DS3231_ADDR_DAY

#define DS3231_ADDR_DAY (0x03U)

Day of Week rRegister

6.2.1.10 DS3231_ADDR_HRS

#define DS3231_ADDR_HRS (0x02U)

Hours Register

6.2.1.11 DS3231_ADDR_I2C

#define DS3231_ADDR_I2C (0x68U)

Address of I2C Slave.

6.2.1.12 DS3231_ADDR_MIN

#define DS3231_ADDR_MIN (0x01U)

Minutes Register

6.2.1.13 DS3231_ADDR_MONTH

#define DS3231_ADDR_MONTH (0x05U)

Month Register

6.2.1.14 DS3231_ADDR_SEC

#define DS3231_ADDR_SEC (0x00U)

Registers Addresses of DS3231.

Seconds Register

6.2.1.15 DS3231_ADDR_YEAR

#define DS3231_ADDR_YEAR (0x06U)

Year Register

6.2.1.16 DS3231_INTCN

#define DS3231_INTCN (0x2u)

Interrupt Control Bit.

6.2.1.17 DS3231_REG_CTRL

#define DS3231_REG_CTRL (0x0Eu)

Address of Control Register.

6.2.1.18 DS3231_REG_STATUS

#define DS3231_REG_STATUS (0x0Fu)

Address of Status Register.

6.2.1.19 E_FAULT

#define E_FAULT 1

General Error Return Code.

6.2.1.20 FRIDAY

#define FRIDAY (0x6)

Friday

6.2.1.21 I2C_BAUDRATE

#define I2C_BAUDRATE 100000U

Application Configurable Items.

Desired Baud Rate For I2C Bus.

Frequency - 100kHz (Up To 400kHz -> Defined By DS3231).

6.2.1.22 I2C_MASTER

#define I2C_MASTER ((LPI2C_Type *)LPI2C2_BASE)

Points To I2C Peripheral Unit (Specifically LPI2C2 Instance).

26 File Documentation

6.2.1.23 LPI2C_RX_DMA_CHANNEL

#define LPI2C_RX_DMA_CHANNEL 1U

12C DMA Channel For Reception.

6.2.1.24 LPI2C_RX_EDMA_CHANNEL

#define LPI2C_RX_EDMA_CHANNEL kDma0RequestMuxLpFlexcomm2Rx

Connection Between DMA Channel 0 and LP_FLEXCOMM2 Rx.

6.2.1.25 LPI2C_TX_CHANNEL

#define LPI2C_TX_CHANNEL kDma0RequestMuxLpFlexcomm2Tx

Connection Between DMA Channel 0 and LP_FLEXCOMM2 Tx.

6.2.1.26 LPI2C_TX_DMA_CHANNEL

#define LPI2C_TX_DMA_CHANNEL OU

12C DMA Channel For Transmission.

6.2.1.27 MONDAY

#define MONDAY (0x2)

Monday

6.2.1.28 OSC_STOPPED

#define OSC_STOPPED (0x00u)

Indicates That Oscillator Has Stopped & Time Has To Updated.

6.2.1.29 SATURDAY

#define SATURDAY (0x7)

Saturday

6.2.1.30 SUNDAY

#define SUNDAY (0x1)

Definition of Dates.

From Sunday (0x1) To Saturday (0x7). Sunday

6.2.1.31 THURSDAY

#define THURSDAY (0x5)

Thursday

6.2.1.32 TIM_CYCLE_12H

#define TIM_CYCLE_12H (0x0)

Definitions For Time Format Handling.

12-Hour Format

6.2.1.33 TIM_CYCLE_12H_AM

#define TIM_CYCLE_12H_AM (0x0)

AM in 12-Hour Mode

6.2.1.34 TIM_CYCLE_12H_PM

#define TIM_CYCLE_12H_PM (0x1)

PM in 12-Hour Mode

6.2.1.35 TIM_CYCLE_24H

#define TIM_CYCLE_24H (0x2)

24-Hour Format

6.2.1.36 TUESDAY

#define TUESDAY (0x3)

Tuesday

6.2.1.37 WEDNESDAY

#define WEDNESDAY (0x4)

Wednesday

6.2.2 Enumeration Type Documentation

6.2.2.1 RTC_interrupt_mode_t

enum RTC_interrupt_mode_t

Enumerator

```
SQUARE_WAVE_INTERRUPT

ALARM_INTERRUPT
```

6.2.2.2 RTC_osc_state_t

```
enum RTC_osc_state_t
```

An Enum to Capture The State of The Oscillator,.

Enumerator

OSC_OK	RTC Oscillator Is OK
OSC_INTERRUPTED	RTC Oscillator Was Interrupted -> Need to Update the Time

6.3 rtc ds3231.h

Go to the documentation of this file.

```
00001 /*
00002 *
                      Tomas Dolak
          Author:
00003 *
          File Name:
                      rtc_DS3231.h
00004
          Description: Header File to RTC DS3231 Driver.
00005
          Created on:
                      Aug 7, 2024
00006 *
                  Tomas Dolak
Header File to RTC DS3231 Driver.
rtc_DS3231.h
          @author
00007 *
00008 *
          @brief
00009 *
          @filename
00010 */
00011
00012 #ifndef RTC_DS3231_H_
00013 #define RTC_DS3231_H_
00014
00018 #include <stdint.h>
00019
00020 #include "defs.h"
00021
00022 #include "fsl_lpi2c.h"
00023 #include "fsl_lpi2c_edma.h"
00024 #include "fsl_edma.h"
00028
00032 #define E_FAULT
00033
00037 #define APP_SUCCESS
00038
00039
00043 #define LPI2C_TX_DMA_CHANNEL
00044
00048 #define LPI2C_RX_DMA_CHANNEL
00049
00053 #define LPI2C TX CHANNEL
                               kDma0RequestMuxLpFlexcomm2Tx
00054
00058 #define LPI2C RX EDMA CHANNEL
                               kDma0RequestMuxLpFlexcomm2Rx
00059
00063 #define I2C_MASTER
                                ((LPI2C_Type *)LPI2C2_BASE)
00064
00068 #define DS3231_A1IE
                                (0x00u)
00069 #define DS3231_A2IE
                                (0x1u)
00073 #define DS3231_INTCN
                                (0x2u)
00078 #define DS3231_A1F
                                (0x0u)
00079 #define DS3231_A2F
                                (0x1u)
```

6.3 rtc ds3231.h 29

```
08000
00081 #define ALARM_DISABLED
00085 #define OSC_STOPPED
                                      (0x00u)
00086
00090 #define DS3231 ADDR SEC
                                     (Ux00U)
00091 #define DS3231_ADDR_MIN
00092 #define DS3231_ADDR_HRS
                                      (0x01U)
                                      (0x02U)
00093 #define DS3231_ADDR_DAY
                                      (0x03U)
00094
00095 #define DS3231_ADDR_DATE
                                     (0x04U)
00096 #define DS3231_ADDR_MONTH
00097 #define DS3231_ADDR_YEAR
                                      (0x05U)
                                      (0x06U)
00098 #define DS3231_ADDR_CENT
                                      (0x07U)
00099
00103 #define DS3231_REG_STATUS
                                     (0x0Fu)
00107
00108 #define DS3231 REG CTRL
                                     (0x0E11)
00112 #define DS3231_ADDR_I2C
                                     (0x68U) //<! The Slave Address Byte Contains In 7-bit: 1101000
00113
00118 #define SUNDAY
                                      (0x1)
00119 #define MONDAY
                                      (0x2)
00120 #define TUESDAY
                                      (0x3)
00121 #define WEDNESDAY
                                      (0 \times 4)
00122 #define THURSDAY
                                      (0x5)
00123 #define FRIDAY
                                      (0x6)
00124 #define SATURDAY
                                      (0x7)
00125
00129 #define TIM_CYCLE_12H
                                      (0x0)
00130 #define TIM_CYCLE_12H_AM
00131 #define TIM_CYCLE_12H_PM
                                     (0x0)
                                     (0x1)
00132 #define TIM CYCLE 24H
                                     (0x2)
00133
00134
00138
00139
00144 #define I2C_BAUDRATE
                                     100000U
00145
00147 * Structures
00152 typedef struct
00153 {
        uint8_t format;
00154
00155
        uint8_t sec;
00156
        uint8_t min;
00157
       uint8_t hrs;
00158
00159 } RTC_time_t;
00160
00164 typedef struct
00165 {
00166
        uint8_t date;
00167
        uint8_t day;
00168
        uint8_t month;
00169
        uint8_t year;
00170
00171 } RTC_date_t;
00172
00176 typedef enum
00177 {
00178
        OSC OK = 0.
        OSC_INTERRUPTED
00179
00180
00181 } RTC_osc_state_t;
00182
00183 /*
00184 \star @brief An Enum For Interrupt Mode. 00185 \star/
00186 typedef enum
00187 {
00188
        SQUARE_WAVE_INTERRUPT = 0,
00189
        ALARM_INTERRUPT
00190
00191 }RTC interrupt mode t:
00193 * Prototypes
00195
00201
00209 uint8 t RTC Init(void);
00210
00216 void RTC_Deinit (void);
00217
00223 static uint8_t RTC_ConvertToBCD(uint8_t dec);
00224
00230 static uint8_t RTC_ConvertToDEC(uint8_t bcd);
00231
```

```
00237 uint8_t RTC_GetState(void);
00243 void RTC_SetOscState(RTC_osc_state_t state);
00244
00251 uint8_t RTC_Write(uint8_t regAddress, uint8_t val);
00252
00258 uint8_t RTC_Read(uint8_t regAddress);
00259
00260
00265 void RTC_SetTime(RTC_time_t *pTime);
00266
00271 void RTC_GetTime(RTC_time_t *pTime);
00272
00277 void RTC_SetDate(RTC_date_t *pDate);
00278
00283 void RTC_GetDate(RTC_date_t *pDate);
00284
00289 void RTC_SetInterruptMode(RTC_interrupt_mode_t mode);
00295 void RTC_CtrlAlarm1(uint8_t enable);
00296
00300 void RTC_ClearFlagAlarm1(void);
00301
00306 void RTC_CtrlAlarm2(uint8_t enable);
00307
00311 void RTC_ClearFlagAlarm2(void);
00312
00317 void RTC_SetTimeDefault(RTC_time_t *pTime);
00318
00323 void RTC_SetDateDefault(RTC_date_t *pDate);
00324 // end of RTC group
00326
00327 #endif /* RTC_DS3231_H_*/
```

6.4 include/app_init.h File Reference

```
#include "fsl_device_registers.h"
#include "fsl_debug_console.h"
#include "fsl_clock.h"
#include "pin_mux.h"
#include "clock_config.h"
#include "board.h"
#include "led.h"
#include "uart.h"
#include "time.h"
#include "error.h"
#include "temperature.h"
#include "pwrloss_det.h"
```

Functions

void APP_InitBoard (void)

Initializes Board Peripherals And Modules For Proper Functionality of The Logger.

6.4.1 Function Documentation

6.4.1.1 APP_InitBoard()

```
void APP_InitBoard (
     void )
```

Initializes Board Peripherals And Modules For Proper Functionality of The Logger.

6.5 app_init.h 31

6.5 app_init.h

Go to the documentation of this file.

```
00001 /**************
00002 * Project: NXP MCXN947 Datalogger
00003 * File Name: init.c
00004 * Author: Tomas Dolak
00005 * Date: 31.03.2025
00006 * Description: Implements Datalogger Application.
00007 *
00008 * **********************
00009
00010 /*************
00018 #ifndef APP_INIT_H_
00019 #define APP_INIT_H_
00023 /* NXP Board Specific */
00024 #include "fsl_device_registers.h"
00025 #include "fsl_debug_console.h"
00026 #include "fsl_clock.h"
00027
00028 #include "pin_mux.h"
00029 #include "clock_config.h"
00030 #include "board.h"
00031
00032 /* Application Includes */
00033 #include "led.h"
                          // Control LEDs Module
00034 #include "uart.h"
                          // UART Module
00035 #include "time.h"
                          // Time Module
00036 #include "error.h"
00037 #include "temperature.h"
                            // Error Handling
                           // Temperature Measurement Module
00038 #include "pwrloss_det.h"
                           // Power Loss Detection Module
00039
00040 /****************************
00043
00044 /***************************
00045 * Global Structures
00049 * Function Prototypes
00050 **********
00051
00056 void APP InitBoard(void);
00057
00059 #endif /* APP_INIT_H_ */
```

6.6 include/app_tasks.h File Reference

```
#include "FreeRTOS.h"
#include "task.h"
#include "queue.h"
#include "semphr.h"
#include "timers.h"
#include <disk.h>
```

Macros

#define TASK_PRIO (configMAX_PRIORITIES - 1)

Functions

void msc_task (void *handle)

Task Responsible For Mass Storage Functionality in Device Mode.

void record_task (void *handle)

Task Recording Serial Data.

void vApplicationGetIdleTaskMemory (StaticTask_t **ppxIdleTaskTCBBuffer, StackType_t **ppxIdleTask
 StackBuffer, uint32_t *pulldleTaskStackSize)

Hook Function to Provide Memory For The Idle Task in FreeRTOS.

void vApplicationGetTimerTaskMemory (StaticTask_t **ppxTimerTaskTCBBuffer, StackType_t **ppxTimer
 — TaskStackBuffer, uint32_t *pulTimerTaskStackSize)

Hook Function to Provide Memory For The Timer Task in FreeRTOS.

Variables

- TaskHandle_t g_xMscTaskHandle
- TaskHandle_t g_xRecordTaskHandle
- SemaphoreHandle_t g_xSemRecord
- SemaphoreHandle_t g_xSemMassStorage

6.6.1 Macro Definition Documentation

6.6.1.1 TASK_PRIO

```
#define TASK_PRIO (configMAX_PRIORITIES - 1)
```

6.6.2 Function Documentation

6.6.2.1 msc_task()

Task Responsible For Mass Storage Functionality in Device Mode.

This Task Implements USB Mass Storage Class (MSC) Operations, Allowing The System to Act As a Mass Storage Device. It Handles Communication With The Host and Manages Read/Write Operations.

Parameters

handle Pointer to The Device Handle Used For The USB Operations.

6.6.2.2 record task()

Task Recording Serial Data.

The Task Provides Data Reception, Data Processing (For Example, Adding Time Stamps) And Also Data Storage. In Case The Monitored Device Is Disconnected From The Data Logger, All The Buffered Data In RAM Is Stored On The Memory Card.

Parameters

handle	Pointer to The Device Handle Used For The USB Operations.
--------	---

6.6.2.3 vApplicationGetIdleTaskMemory()

Hook Function to Provide Memory For The Idle Task in FreeRTOS.

This Hook Function Provides The Memory Needed For The Idle Task, Which Is Statically Allocated When config← SUPPORT_STATIC_ALLOCATION Is Set to 1. The FreeRTOS Scheduler Calls This Function to Get The Task Control Block (TCB) and Stack For The Idle Task.

Parameters

out	ppxIdleTaskTCBBuffer	Pointer to The TCB Buffer For The Idle Task.
out	ppxldleTaskStackBuffer	Pointer to The Stack Buffer For The Idle Task.
out	pulldleTaskStackSize	Pointer to a Variable Holding The Stack Size.

6.6.2.4 vApplicationGetTimerTaskMemory()

Hook Function to Provide Memory For The Timer Task in FreeRTOS.

This Hook Function Provides The Memory Needed For The Timer Task, Which Is Statically Allocated When config← SUPPORT_STATIC_ALLOCATION Is Set To 1 And configUSE_TIMERS Is Enabled. The FreeRTOS Scheduler Calls This Function to Get The Task Control Block (TCB) And Stack For The Timer Task.

Parameters

ου	ut	ppxTimerTaskTCBBuffer	Pointer to The TCB Buffer For The Timer Task.
ou	ut	ppxTimerTaskStackBuffer	Pointer to The Stack Buffer For The Timer Task.
ου	at <i>pulTimerTaskStackSize</i>		Pointer to a Variable Holding The Stack Size.

6.6.3 Variable Documentation

6.6.3.1 g_xMscTaskHandle

```
TaskHandle_t g_xMscTaskHandle [extern]
```

6.6.3.2 g_xRecordTaskHandle

TaskHandle_t g_xRecordTaskHandle [extern]

6.6.3.3 g_xSemMassStorage

```
SemaphoreHandle_t g_xSemMassStorage [extern]
```

6.6.3.4 g xSemRecord

SemaphoreHandle_t g_xSemRecord [extern]

6.7 app_tasks.h

Go to the documentation of this file.

```
00001 /**************
00002 * Project: NXP MCXN947 Datalogger
00003 * File Name:
    * File Name: app_tasks.c

* Author: Tomas Dolak

* Date: 14.09.2024
00004
00005
    * Date:
00006 * Description: Header File For Implementation of FreeRTOS Task.
00007 *
00008 * ***********************
00009
00010 /*************
00011 * @package NXP MCXN947 Datalogger
                app_tasks.c
Tomas Dolak
14.09.2024
00012
    * @file
00013 * @author
00014 * @date
00015 * @brief
                Header File For Implementation of FreeRTOS Task.
00016 * *************************
00018 #ifndef APP_TASKS_H_
00019 #define APP_TASKS_H_
00020
00025 /* FreeRTOS Include */
00026 #include "FreeRTOS.h"
00027 #include "task.h"
00028 #include "queue.h"
00029 #include "semphr.h"
00030 #include "timers.h"
00031
00032 /\star Mass Storage Includes \star/
00033 #include <disk.h>
00035 * Definitions
00037 #define TASK_PRIO
                   (configMAX_PRIORITIES - 1) //<! Task Priorities.
00038
00039 /*****************************
00040 * Global Variables
00042
00043 /* Task Handles
00044 extern TaskHandle_t g_xMscTaskHandle;
00045
00046 extern TaskHandle_t g_xRecordTaskHandle;
00047
00048 /* Semaphores
00049 extern SemaphoreHandle_t g_xSemRecord;
00050
00051 extern SemaphoreHandle_t g_xSemMassStorage;
00052
00054 * Prototypes
```

```
00056
00057
00067 void msc_task(void *handle);
00068
00078 void record_task(void *handle);
00079
00092 void vApplicationGetIdleTaskMemory(StaticTask_t **ppxIdleTaskTCBBuffer,
00093
                                          StackType_t **ppxIdleTaskStackBuffer,
00094
                                         uint32_t *pulIdleTaskStackSize);
00095
00108 void vApplicationGetTimerTaskMemory(StaticTask_t **ppxTimerTaskTCBBuffer,
                                          StackType_t **ppxTimerTaskStackBuffer,
00109
                                          uint32_t *pulTimerTaskStackSize);
00110
00111
00112 #endif /* APP_TASKS_H_ */
```

6.8 include/defs.h File Reference

```
#include <stdbool.h>
```

Macros

- #define NOT_IMPLEMENTED #error "This Feature Is Not Implemented!"
- #define MSC_STACK_SIZE ((uint32_t)(5000UL / (uint32_t)sizeof(portSTACK_TYPE)))

Defines The Stack Size For Mass Storage Task.

#define RECORD_STACK_SIZE ((uint32_t)(5000UL / (uint32_t)sizeof(portSTACK_TYPE)))

Defines The Stack Size For Recording Task.

#define MSC_ENABLED (true)

Enables/Disables Mass Storage Functionality.

#define INFO_ENABLED (false)

Enables/Disables Debug Mode.

#define DEBUG_ENABLED (false)

Enables/Disables Debug Mode.

• #define UART_FIFO_ENABLED (true)

Enables/Disables HW FIFO Queue on Application LPUART.

#define UART_FIFO_LENGHT (4u)

Defines The Size of HW FIFO Queue.

#define UART_PRINT_ENABLED (false)

Enables/Disables Print of Received Bytes From Application LPUART To Console.

• #define PWRLOSS_DETECTION_ENABLED (true)

Enables/Disables Power Loss Detection.

#define PWRLOSS_TEST_GPIOS (false)

Enables/Disables GPIO For Testing Power Loss Detection.

• #define TAU5 16.5

Constant 5 Tau, When Back-Up Power Capacitor is Charged To 99%.

#define PWRLOSS_DET_ACTIVE_IN_TIME TAU5

Time Interval When Power Loss Detection Became Active.

#define UART_RECEIVE_PRIO (6U)

Priority of LP_FLEXCOMM Interrupt (UART) For Rx Of Recorded Data.

#define PWRLOSS_DET_PRIO (5U)

Priority of Comparator Interrupt For Power Loss Detection.

#define PWRLOSS_TIMER_PRIO (7U)

Priority of Comparator Interrupt For Power Loss Detection.

#define TEMPERATURE_MEAS_ENABLED (false)

Enables/Disables Temperature Recording.

• #define CONTROL_LED_ENABLED (true)

Enables/Disables Signaling By LEDs.

#define DEFAULT_MAX_FILESIZE 8192

Default Maximal File Size If The Configuration File Could Not Be Read Properly.

• #define CONFIG_FILE "config"

Configuration File.

• #define DEFAULT_BAUDRATE 230400UL

Default Baud Rate If The Configuration File Could Not Be Read Properly.

• #define DEFAULT_DATA_BITS kLPUART_EightDataBits

Default Number of Data Bits If The Configuration File Could Not Be Read Properly.

• #define DEFAULT_STOP_BITS kLPUART_OneStopBit

Default Number of Stop Bits If The Configuration File Could Not Be Read Properly.

• #define DEFAULT_PARITY kLPUART_ParityDisabled

Default UART Parity If The Configuration File Could Not Be Read Properly.

• #define DEFAULT_FREE_SPACE 50UL

Defines The Threshold Level of Free Memory on The SD card, Below Which The Lack of Memory is Indicated.

6.8.1 Macro Definition Documentation

6.8.1.1 CONFIG FILE

```
#define CONFIG_FILE "config"
```

Configuration File.

6.8.1.2 CONTROL_LED_ENABLED

```
#define CONTROL_LED_ENABLED (true)
```

Enables/Disables Signaling By LEDs.

6.8.1.3 DEBUG_ENABLED

```
#define DEBUG_ENABLED (false)
```

Enables/Disables Debug Mode.

If Debug Mode Is Enabled Then Extended Logs Are Printed Into Debug Console.

6.8.1.4 DEFAULT_BAUDRATE

```
#define DEFAULT_BAUDRATE 230400UL
```

Default Baud Rate If The Configuration File Could Not Be Read Properly.

6.8.1.5 DEFAULT_DATA_BITS

#define DEFAULT_DATA_BITS kLPUART_EightDataBits

Default Number of Data Bits If The Configuration File Could Not Be Read Properly.

6.8.1.6 DEFAULT_FREE_SPACE

#define DEFAULT_FREE_SPACE 50UL

Defines The Threshold Level of Free Memory on The SD card, Below Which The Lack of Memory is Indicated.

In Megabytes.

6.8.1.7 DEFAULT_MAX_FILESIZE

#define DEFAULT_MAX_FILESIZE 8192

Default Maximal File Size If The Configuration File Could Not Be Read Properly.

6.8.1.8 DEFAULT_PARITY

#define DEFAULT_PARITY kLPUART_ParityDisabled

Default UART Parity If The Configuration File Could Not Be Read Properly.

6.8.1.9 DEFAULT_STOP_BITS

#define DEFAULT_STOP_BITS kLPUART_OneStopBit

Default Number of Stop Bits If The Configuration File Could Not Be Read Properly.

6.8.1.10 INFO ENABLED

#define INFO_ENABLED (false)

Enables/Disables Debug Mode.

If Debug Mode Is Enabled Then Extended Logs Are Printed Into Debug Console.

6.8.1.11 MSC_ENABLED

#define MSC_ENABLED (true)

Enables/Disables Mass Storage Functionality.

6.8.1.12 MSC_STACK_SIZE

```
#define MSC_STACK_SIZE ((uint32_t)(5000UL / (uint32_t)sizeof(portSTACK_TYPE)))
```

Defines The Stack Size For Mass Storage Task.

6.8.1.13 NOT_IMPLEMENTED

#define NOT_IMPLEMENTED #error "This Feature Is Not Implemented!"

6.8.1.14 PWRLOSS_DET_ACTIVE_IN_TIME

```
#define PWRLOSS_DET_ACTIVE_IN_TIME TAU5
```

Time Interval When Power Loss Detection Became Active.

In Seconds.

6.8.1.15 PWRLOSS_DET_PRIO

```
#define PWRLOSS_DET_PRIO (5U)
```

Priority of Comparator Interrupt For Power Loss Detection.

6.8.1.16 PWRLOSS_DETECTION_ENABLED

#define PWRLOSS_DETECTION_ENABLED (true)

Enables/Disables Power Loss Detection.

6.8.1.17 PWRLOSS_TEST_GPIOS

```
#define PWRLOSS_TEST_GPIOS (false)
```

Enables/Disables GPIO For Testing Power Loss Detection.

6.8.1.18 PWRLOSS_TIMER_PRIO

```
#define PWRLOSS_TIMER_PRIO (7U)
```

Priority of Comparator Interrupt For Power Loss Detection.

6.8.1.19 RECORD_STACK_SIZE

```
#define RECORD_STACK_SIZE ((uint32_t)(5000UL / (uint32_t)sizeof(portSTACK_TYPE)))
```

Defines The Stack Size For Recording Task.

6.8.1.20 TAU5

#define TAU5 16.5

Constant 5 Tau, When Back-Up Power Capacitor is Charged To 99%.

In Seconds (It's Actualy 16.5s).

6.8.1.21 TEMPERATURE_MEAS_ENABLED

```
#define TEMPERATURE_MEAS_ENABLED (false)
```

Enables/Disables Temperature Recording.

6.8.1.22 UART_FIFO_ENABLED

```
#define UART_FIFO_ENABLED (true)
```

Enables/Disables HW FIFO Queue on Application LPUART.

6.8.1.23 UART_FIFO_LENGHT

```
#define UART_FIFO_LENGHT (4u)
```

Defines The Size of HW FIFO Queue.

6.8.1.24 UART_PRINT_ENABLED

```
#define UART_PRINT_ENABLED (false)
```

Enables/Disables Print of Received Bytes From Application LPUART To Console.

6.8.1.25 UART RECEIVE PRIO

```
#define UART_RECEIVE_PRIO (6U)
```

Priority of LP_FLEXCOMM Interrupt (UART) For Rx Of Recorded Data.

6.9 defs.h

Go to the documentation of this file.

```
00001 /***************
00002 * Project: NXP MCXN947 Datalogger
00003 * File Name: defs.h
00004 * Author: Tomas Dolak
00005 * Date: 22.09.2024
00006
     * Description: Header File Providing Definitions To Set Up The Project.
00007 *
00008 * **************************
00009
00010 /************
00014 * @date
                    22.09.2024
00015
     * @brief
                     Header File Providing Definitions To Set Up The Project.
00016 * *********************
00017
00018 #ifndef DEFS_H_
00019 #define DEFS_H_
00020
00024 #include <stdbool.h>
00025
00026
00030 #define NOT IMPLEMENTED
                                  #error "This Feature Is Not Implemented!"
00031
00035 #define MSC_STACK_SIZE
                             ((uint32_t)(5000UL / (uint32_t)sizeof(portSTACK_TYPE)))
00036
00040 #define RECORD_STACK_SIZE
                              ((uint32_t)(5000UL / (uint32_t)sizeof(portSTACK_TYPE)))
00041
00045 #define MSC ENABLED
                                   (true)
00046
00051 #define INFO_ENABLED
                                   (false)
00052
00057 #define DEBUG_ENABLED
                                   (false)
00058
00062 #define UART FIFO ENABLED
                                   (true)
00063
00067 #define UART_FIFO_LENGHT
                                   (4u)
00068
00072 #define UART_PRINT_ENABLED
                                   (false)
00073
00077 #define PWRLOSS_DETECTION_ENABLED (true)
00078
00082 #define PWRLOSS_TEST_GPIOS
                                   (false)
00083
00088 #define TAU5
                                   16.5
00089
00094 #define PWRLOSS_DET_ACTIVE_IN_TIME TAU5
00095
00099 #define UART_RECEIVE_PRIO
                                   (6U)
00100
00104 #define PWRLOSS_DET_PRIO
                                   (5U)
00105
00109 #define PWRLOSS_TIMER_PRIO
                                   (7U)
00110
00111
00115 #define TEMPERATURE_MEAS_ENABLED
                                   (false)
00116
00120 #define CONTROL_LED_ENABLED
                                   (true)
00121
00122
00127 #define DEFAULT_MAX_FILESIZE
                                   8192
00128
00132 #define CONFIG_FILE
                                   "config"
00133
00138 #define DEFAULT BAUDRATE
                                   23040000.
00139
00144 #define DEFAULT DATA BITS
                                   kLPUART EightDataBits
00145
00150 #define DEFAULT_STOP_BITS
                                   kLPUART_OneStopBit
00151
00156 #define DEFAULT_PARITY
                                   kLPUART_ParityDisabled
00157
00163 #define DEFAULT_FREE_SPACE
                                   SOUT.
00164
00165 #endif /* DEFS_H_ */
```

6.10 include/error.h File Reference

#include <stdint.h>

Macros

• #define ERROR_NONE 0x0000u

Return Code When a Successful Operation is Performed.

• #define ERROR_IRTC 0x0001u

Error Related To Internal RTC Integrated In MCXN947 MCU.

• #define ERROR_RECORD 0x0002u

Error Related To Data Logging.

#define ERROR_OPEN 0x0005u

Error Related To Opening File.

• #define ERROR_READ 0x0006u

Error Related To Reading File.

• #define ERROR_CLOSE 0x0004u

Error Related To Closing File.

• #define ERROR_FILESYSTEM 0x0007u

Error Related To File System (e.g. Mount of File System, Setting Up File Meta-Data,...).

• #define ERROR_CONFIG 0x0008u

Error Related To Reading and Parsing Configuration File Stored On SDHC Card (config.txt).

• #define ERROR_ADMA 0x0003u

Error Related To Storing Data on SDHC Card Using ADMA (Advance DMA).

#define ERROR_OUT_OF_CYCLE 0xFFFEu

Out Of The Main Cycle Error.

• #define ERROR_UNKNOWN 0xFFFFu

Occurrence Of an Unclassified Error.

Typedefs

typedef uint16_t error_t

Functions

void ERR_HandleError (void)

Base Function For Error Handling.

- void ERR_Init ()
- void ERR_SetState (error_t err)

6.10.1 Macro Definition Documentation

6.10.1.1 ERROR_ADMA

#define ERROR_ADMA 0x0003u

Error Related To Storing Data on SDHC Card Using ADMA (Advance DMA).

6.10.1.2 ERROR_CLOSE

#define ERROR_CLOSE 0x0004u

Error Related To Closing File.

6.10.1.3 ERROR_CONFIG

#define ERROR_CONFIG 0x0008u

Error Related To Reading and Parsing Configuration File Stored On SDHC Card (config.txt).

6.10.1.4 ERROR_FILESYSTEM

#define ERROR_FILESYSTEM 0x0007u

Error Related To File System (e.g. Mount of File System, Setting Up File Meta-Data,...).

6.10.1.5 ERROR_IRTC

#define ERROR_IRTC 0x0001u

Error Related To Internal RTC Integrated In MCXN947 MCU.

6.10.1.6 ERROR_NONE

#define ERROR_NONE 0x0000u

Return Code When a Successful Operation is Performed.

6.10.1.7 ERROR_OPEN

#define ERROR_OPEN 0x0005u

Error Related To Opening File.

6.10.1.8 ERROR_OUT_OF_CYCLE

#define ERROR_OUT_OF_CYCLE 0xFFFEu

Out Of The Main Cycle Error.

6.10.1.9 ERROR_READ

#define ERROR_READ 0x0006u

Error Related To Reading File.

6.10.1.10 ERROR_RECORD

```
#define ERROR_RECORD 0x0002u
```

Error Related To Data Logging.

6.10.1.11 ERROR_UNKNOWN

```
#define ERROR_UNKNOWN 0xFFFFu
```

Occurrence Of an Unclassified Error.

6.10.2 Typedef Documentation

6.10.2.1 error_t

```
typedef uint16_t error_t
```

6.10.3 Function Documentation

6.10.3.1 ERR_HandleError()

```
void ERR_HandleError (
     void )
```

Base Function For Error Handling.

6.10.3.2 ERR_Init()

```
void ERR_Init ()
```

6.10.3.3 ERR_SetState()

6.11 error.h

Go to the documentation of this file.

```
00002 * Project: NXP MCXN947 Datalogger
00003 * File Name: error.h
00004 * Author: Tomas Dolak
00005 * Date: 22.01.2025
00006 * Description: Implements Error Handling Logic.
00007 *
00008 * *************************
00009
00010 /**************
00017
00018 #ifndef ERROR_H_
00019 #define ERROR_H_
00020
00024 #include <stdint.h>
00031 #define ERROR_NONE
                      0x0000u
00032
00036 #define ERROR IRTC
                      0x0001u
00037
00041 #define ERROR_RECORD
                      0x0002u
00042
00046 #define ERROR_OPEN
                      0x0005u
00047
00051 #define ERROR READ
                      0x000611
00055 #define ERROR_CLOSE
                      0x0004u
00056
00060 #define ERROR_FILESYSTEM
00061
00065 #define ERROR CONFIG
                      0x0008u
00066
00070 #define ERROR_ADMA
                      0x0003u
00071
00075 #define ERROR_OUT_OF_CYCLE
00076
00080 #define ERROR UNKNOWN
                      0xFFFFu
00084 typedef uint16_t error_t;
00085
00087 * Prototypes
00092 void ERR_HandleError(void);
00093
00094 void ERR_Init();
00095
00096 void ERR_SetState(error_t err);
00097
00098
00099 #endif /* ERROR_H_ */
```

6.12 include/led.h File Reference

```
#include "fsl_gpio.h"
#include "board.h"
```

Macros

#define ERROR_LED_PORT GPIO0

Error LED's Port Number.

• #define ERROR_LED_PIN_RECORD 0x09

Error LED's Pin 2.

• #define MEMORY_LOW_LED_PORT GPIO0

Low Memory LED's Port Number.

• #define MEMORY_LOW_LED_PIN 0x07

Error LED's Pin 1.

• #define FLUSH_LED_PORT GPIO0

Flush LED's Port Number.

#define RECORD_LED_PIN_FLUSH 0x0D

Error LED's Pin 3.

#define RECORD_LED_PORT GPIO2

Recording LED's Port Number.

• #define RECORD_LED_PIN 0x0B

Record LED's Pin.

• #define BACKUP_POWER_LED_PORT GPIO4

Recording LED's Port Number.

#define BACKUP_POWER_LED_PIN 0x11

Record LED's Pin.

Functions

void LED_SetHigh (GPIO_Type *port_base, uint32_t pin)

Sets Logic 1 on GPIO Pin.

void LED_SetLow (GPIO_Type *port_base, uint32_t pin)

Sets Logic 0 on GPIO Pin.

void LED_SignalReady (void)

Indicates Ready State of The Recording Device.

void LED_SignalRecording (void)

Signals That Device Is Currently Receiving Bytes (Recording).

void LED_SignalRecordingStop (void)

Signals That Device Is Stopped Receiving Bytes (Recording).

• void LED_SignalBackUpPowerAvailable (void)

Signals Configuration File Missing or Contains Unexpected Data.

void LED_SignalLowMemory (void)

Signals That There Will Be Empty Space on SD Card.

void LED_SignalError (void)

Signals Error During Recording.

void LED_SignalFlush (void)

Signals That Flush Has Been Activated.

void LED_ClearSignalFlush (void)

Clears Flush LED After UART Re-Inicialization.

6.12.1 Macro Definition Documentation

6.12.1.1 BACKUP_POWER_LED_PIN

#define BACKUP_POWER_LED_PIN 0x11

Record LED's Pin.

P4_17

6.12.1.2 BACKUP_POWER_LED_PORT

#define BACKUP_POWER_LED_PORT GPIO4

Recording LED's Port Number.

Signals That Device Records.

6.12.1.3 ERROR_LED_PIN_RECORD

#define ERROR_LED_PIN_RECORD 0x09

Error LED's Pin 2.

P0_9

6.12.1.4 ERROR_LED_PORT

#define ERROR_LED_PORT GPIO0

Error LED's Port Number.

6.12.1.5 FLUSH_LED_PORT

#define FLUSH_LED_PORT GPIO0

Flush LED's Port Number.

6.12.1.6 MEMORY_LOW_LED_PIN

#define MEMORY_LOW_LED_PIN 0x07

Error LED's Pin 1.

P0_7

6.12.1.7 MEMORY_LOW_LED_PORT

```
#define MEMORY_LOW_LED_PORT GPIO0
```

Low Memory LED's Port Number.

6.12.1.8 RECORD LED PIN

```
#define RECORD_LED_PIN 0x0B
```

Record LED's Pin.

P2_11

6.12.1.9 RECORD_LED_PIN_FLUSH

```
#define RECORD_LED_PIN_FLUSH 0x0D
```

Error LED's Pin 3.

P0_13

6.12.1.10 RECORD_LED_PORT

```
#define RECORD_LED_PORT GPIO2
```

Recording LED's Port Number.

Signals That Device Records.

6.12.2 Function Documentation

6.12.2.1 LED_ClearSignalFlush()

Clears Flush LED After UART Re-Inicialization.

6.12.2.2 LED_SetHigh()

Sets Logic 1 on GPIO Pin.

Parameters

port_base	Pointer to GPIO Instance.
pin	Pin.

6.12.2.3 LED_SetLow()

Sets Logic 0 on GPIO Pin.

Parameters

port_base	Pointer to GPIO Instance.
pin	Pin.

6.12.2.4 LED_SignalBackUpPowerAvailable()

Signals Configuration File Missing or Contains Unexpected Data.

6.12.2.5 LED_SignalError()

Signals Error During Recording.

6.12.2.6 LED_SignalFlush()

```
\begin{tabular}{ll} \beg
```

Signals That Flush Has Been Activated.

6.12.2.7 LED_SignalLowMemory()

```
\begin{tabular}{ll} \beg
```

Signals That There Will Be Empty Space on SD Card.

6.13 led.h 49

6.12.2.8 LED_SignalReady()

```
void LED_SignalReady (
     void )
```

Indicates Ready State of The Recording Device.

6.12.2.9 LED_SignalRecording()

```
void LED_SignalRecording ( void\ )
```

Signals That Device Is Currently Receiving Bytes (Recording).

6.12.2.10 LED_SignalRecordingStop()

```
\begin{tabular}{ll} {\tt void LED\_SignalRecordingStop (} \\ {\tt void )} \end{tabular}
```

Signals That Device Is Stopped Receiving Bytes (Recording).

6.13 led.h

Go to the documentation of this file.

```
00001 /***************
000002 * Project: NXP MCXN947 Datalogger
00003 * File Name: leds.c
00004 * Author: Tomas Dolak
00005 * Date: 06.02.2025
00006 \star Description: Implements The Logic For LEDs Control. 00007 \star
00008 * *************************
00009
00010 /*************
00011 * @package NXP MCXN947 Datalogger
00012 * @file leds.c
00013 * @author Tomas Dolak
00014 * @date 06.02.2025
00015 * @brief Implements The Logic For LEDs Control.
00016 * ***************************
00017
00018 #ifndef LED_H_
00019 #define LED_H_
00020
***********************
00025 #include "board.h"
00026 /***********
00027 * Functions Macros
00028
00032 #define ERROR_LED_PORT
00033
00038 #define ERROR_LED_PIN_RECORD
00039
00040
00044 #define MEMORY_LOW_LED_PORT
00045
00050 #define MEMORY_LOW_LED_PIN
00051
00052
00056 #define FLUSH_LED_PORT
                               GPI00
00062 #define RECORD_LED_PIN_FLUSH
```

```
00068 #define RECORD_LED_PORT
                              GPIO2
00069
                              0x0B
00074 #define RECORD_LED_PIN
00075
00080 #define BACKUP_POWER_LED_PORT
00086 #define BACKUP_POWER_LED_PIN
00088 * Functions Definitions
00090
00096 void LED_SetHigh(GPIO_Type *port_base, uint32_t pin);
00103 void LED_SetLow(GPIO_Type *port_base, uint32_t pin);
00104
00108 void LED_SignalReady(void);
00109
00113 void LED_SignalRecording(void);
00118 void LED_SignalRecordingStop(void);
00119
00123 void LED_SignalBackUpPowerAvailable(void);
00124
00128 void LED_SignalLowMemory(void);
00133 void LED_SignalError(void);
00134
00138 void LED_SignalFlush(void);
00139
00143 void LED_ClearSignalFlush(void);
00144
00145 #endif /* LED_H_ */
```

6.14 include/mass_storage.h File Reference

```
#include "disk.h"
```

Functions

void MSC_DeviceMscApp (void)

Process Extension to Mass Storage.

void MSC_DeviceMscAppTask (void)

Handles Mass Storage Application.

6.14.1 Function Documentation

6.14.1.1 MSC DeviceMscApp()

Process Extension to Mass Storage.

6.14.1.2 MSC DeviceMscAppTask()

Handles Mass Storage Application.

Communication and Data Transport Is Handled By USB1_HS ISR.

6.15 mass_storage.h 51

6.15 mass storage.h

Go to the documentation of this file.

```
00002 * Project: NXP MCXN947 Datalogger
00003 * File Name: mass_storage.h
00004 * Author: Tomas Dolak
00005 * Date: 06.02.2025
00006 * Description: Header File For USB Mass Storage.
00008 * *************************
00009
00010 /**************
00017
00018 #ifndef MASS_STORAGE_H_
00019 #define MASS_STORAGE_H_
00020
00021
00023 * Includes
00025 #include "disk.h"
00030
00034
00038 void MSC_DeviceMscApp (void);
00039
00044 void MSC_DeviceMscAppTask(void);
00046 #endif /* MASS_STORAGE_H_ */
```

6.16 include/parser.h File Reference

```
#include <stdint.h>
#include <string.h>
#include <errno.h>
#include <stdlib.h>
#include "fsl_lpuart.h"
#include "fsl_debug_console.h"
#include "error.h"
#include "defs.h"
```

Classes

struct REC_config_t

Configuration structure for the recording system.

Enumerations

enum REC_version_t { WCT_UNKOWN = 0 , WCT_AUTOS1 , WCT_AUTOS2 }

Enumeration of recording board versions.

Functions

REC_config_t PARSER_GetConfig (void)

Returns Active Configuration.

REC_version_t PARSER_GetVersion (void)

Returns the Version of The Device Being Recorded.

uint32_t PARSER_GetBaudrate (void)

Returns the Baudrate of The Device Being Recorded.

uint32_t PARSER_GetFileSize (void)

Returns the Maximal File Size.

Ipuart_data_bits_t PARSER_GetDataBits (void)

Returns The Number of Data Bits.

Ipuart_parity_mode_t PARSER_GetParity (void)

Returns The Parity.

lpuart_stop_bit_count_t PARSER_GetStopBits (void)

Returns The Number of Stop Bits.

uint32_t PARSER_GetFreeSpaceLimitMB (void)

Returns The Free Space Limit on SD Card For LED Signaling.

uint32_t PARSER_GetMaxBytes (void)

Returns The Number of Maximal Bytes Between LED Blinking.

void PARSER_ClearConfig (void)

Clears The Configuration To Default.

error_t PARSER_ParseBaudrate (const char *chContent)

Parse Baud Rate From Configuration File.

error_t PARSER_ParseFileSize (const char *chContent)

Parse Record File Size From Configuration File.

error_t PARSER_ParseParity (const char *chContent)

Parse Parity From Configuration File.

error_t PARSER_ParseStopBits (const char *chContent)

Parse The Number of Stop Bits From Configuration File.

error_t PARSER_ParseDataBits (const char *chContent)

Parse The Number of Data Bits From Configuration File.

error_t PARSER_ParseFreeSpace (const char *chContent)

Parse The Size of Free Space When Data Logger Will Signal To The User That Data Logger Is Running Out of Space.

6.16.1 Enumeration Type Documentation

6.16.1.1 REC version t

```
enum REC_version_t
```

Enumeration of recording board versions.

This enum defines the possible versions of the board for which the recording system is configured.

Note

Difference Between AUTOS1 and AUTOS2 Is In Baudrate.

Enumerator

WCT_UNKOWN	Unknown board version.
WCT_AUTOS1	AUTOS1 Reference Board.
WCT_AUTOS2	AUTOS2 Reference Board.

6.16.2 Function Documentation

6.16.2.1 PARSER_ClearConfig()

Clears The Configuration To Default.

6.16.2.2 PARSER_GetBaudrate()

Returns the Baudrate of The Device Being Recorded.

Returns

uint32_t Baud Rate of Recorded Device.

6.16.2.3 PARSER_GetConfig()

Returns Active Configuration.

This Function Returns The Global Configuration Structure That Contains The Settings For The Recording, Such as Baudrate, Version, And Other Relevant Parameters.

Returns

REC_config_t The Current Recording Configuration.

6.16.2.4 PARSER_GetDataBits()

Returns The Number of Data Bits.

Returns

Ipuart_data_bits_t Number of Data Bits.

6.16.2.5 PARSER_GetFileSize()

Returns the Maximal File Size.

Returns

uint32_t Maximal File Size.

6.16.2.6 PARSER_GetFreeSpaceLimitMB()

Returns The Free Space Limit on SD Card For LED Signaling.

Returns

uint32_t Free Space Limit.

6.16.2.7 PARSER_GetMaxBytes()

Returns The Number of Maximal Bytes Between LED Blinking.

Returns

uint32_t Number of Maximal Bytes Between LED Blinking.

6.16.2.8 PARSER_GetParity()

```
\label{lower_parity_mode_t_parser_GetParity} \mbox{ (} \\ \mbox{void )}
```

Returns The Parity.

Returns

Ipuart_parity_mode_t kLPUART_ParityDisabled, kLPUART_ParityEven or kLPUART_ParityOdd.

6.16.2.9 PARSER_GetStopBits()

Returns The Number of Stop Bits.

Returns

lpuart_stop_bit_count_t Number of Stop Bits.

6.16.2.10 PARSER_GetVersion()

Returns the Version of The Device Being Recorded.

Returns

REC_version_t Current Version of Recorded Device (WCT_UNKOWN, WCT_AUTOS1 or WCT_AUTOS2).

6.16.2.11 PARSER_ParseBaudrate()

Parse Baud Rate From Configuration File.

Parameters

in	chContent	Pointer To Content of Configuration File.
----	-----------	---

Returns

ERROR_NONE If The Parsing Succeed.

6.16.2.12 PARSER_ParseDataBits()

Parse The Number of Data Bits From Configuration File.

Parameters

in	chContent	Pointer To Content of Configuration File.
----	-----------	---

Returns

ERROR_NONE If The Parsing Succeed.

6.16.2.13 PARSER_ParseFileSize()

Parse Record File Size From Configuration File.

Parameters

in	chContent	Pointer To Content of Configuration File.
----	-----------	---

Returns

ERROR_NONE If The Parsing Succeed.

6.16.2.14 PARSER ParseFreeSpace()

Parse The Size of Free Space When Data Logger Will Signal To The User That Data Logger Is Running Out of Space.

Parameters

in	chContent	Pointer To Content of Configuration File.
----	-----------	---

Returns

ERROR_NONE If The Parsing Succeed.

6.16.2.15 PARSER_ParseParity()

Parse Parity From Configuration File.

Parameters

in	chContent	Pointer To Content of Configuration File.
----	-----------	---

Returns

ERROR_NONE If The Parsing Succeed.

6.16.2.16 PARSER_ParseStopBits()

Parse The Number of Stop Bits From Configuration File.

6.17 parser.h 57

Parameters

in	chContent	Pointer To Content of Configuration File.	
----	-----------	---	--

Returns

ERROR_NONE If The Parsing Succeed.

6.17 parser.h

Go to the documentation of this file.

```
00001 /***************
                NXP MCXN947 Datalogger
00002 * Project:
00003 * File Name: parser.h
00004 * Author: Tomas Dolak
00005 * Date: 16.04.2025
00006 \star Description: Header File Providing Definitions For Configuration File Parser.
00007 *
00008 * **********************
00009
00010 /**************
00011 * @package NXP MCXN947 Datalogger
00012 * @file parser.h
00012 * @file parser.h
00013 * @author Tomas Dolak
00014 * @date 16.04.2025
00015 * @brief Header File Providing Definitions For Configuration File Parser.
00016 * ************************
00017 #ifndef PARSER_H_
00018 #define PARSER_H_
00019
00023 #include <stdint.h>
00024 #include <string.h>
00025 #include <errno.h>
00026 #include <stdlib.h>
00028 #include "fsl_lpuart.h"
00029 #include "fsl_debug_console.h"
00030 #include "error.h"
00031 #include "defs.h"
00033 * Definitions
00035
00048 typedef enum
00049 {
00050
       WCT\_UNKOWN = 0,
00051
       WCT_AUTOS1,
      WCT_AUTOS2
00052
00053
00054 } REC_version_t;
00055
00062 typedef struct
00063 {
00064
        /* Recorded NXP Device */
00065
       REC_version_t version;
00066
       /* UART Setup */
00067
00068
       uint32_t
00069
       lpuart_stop_bit_count_t stop_bits;
       lpuart_data_bits_t data_bits;
lpuart_parity_mode_t parity;
00070
00071
00072
00073
       uint32_t
00074
                  max_bytes;
free_space_limit_mb;
       uint32_t
00076
00077
       uint32_t
00079
00080 } REC_config_t;
00082 * Prototypes
```

```
00093 REC_config_t PARSER_GetConfig(void);
00094
00101 REC_version_t PARSER_GetVersion(void);
00102
00109 uint32_t PARSER_GetBaudrate(void);
00110
00117 uint32_t PARSER_GetFileSize(void);
00118
00125 lpuart_data_bits_t PARSER_GetDataBits(void);
00126
00133 lpuart_parity_mode_t PARSER_GetParity(void);
00134
00141 lpuart_stop_bit_count_t PARSER_GetStopBits(void);
00142
00149 uint32_t PARSER_GetFreeSpaceLimitMB(void);
00150
00157 uint32 t PARSER GetMaxBytes (void);
00162 void PARSER_ClearConfig(void);
00163
00170 error_t PARSER_ParseBaudrate(const char *chContent);
00171
00178 error t PARSER ParseFileSize(const char *chContent);
00179
00186 error_t PARSER_ParseParity(const char *chContent);
00187
00194 error_t PARSER_ParseStopBits(const char *chContent);
00195
00202 error_t PARSER_ParseDataBits(const char *chContent);
00203
00211 error_t PARSER_ParseFreeSpace(const char *chContent);
00212
00213 #endif /* PARSER_H_ */
```

6.18 include/pwrloss_det.h File Reference

```
#include "fsl_lpcmp.h"
#include "fsl_spc.h"
#include "led.h"
#include "defs.h"
#include "fsl_ctimer.h"
```

Macros

#define LPCMP_BASE CMP1

Base Address of The Low-Power Comparator (LPCMP).

#define LPCMP_USER_CHANNEL 0x02

Comparator Input Channel Used For 5V Monitoring.

• #define LPCMP_DAC_CHANNEL 0x07

Comparator Internal DAC Reference Channel.

• #define LPCMP_IRQ_ID HSCMP1_IRQn

IRQ Number for The Comparator Peripheral.

#define SPC_BASE SPC0

Base Address of The Supply Power Controller (SPC).

• #define CTIMER CTIMER4

Timer Used To Control Delayed Activation of Power Loss Detection.

• #define CTIMER_MAT0_OUT kCTIMER_Match_0

Timer Match Output Channel 0.

#define CTIMER_EMT0_OUT (1u << kCTIMER_Match_0)

Timer External Match Output Mask For Channel 0.

#define CTIMER_CLK_FREQ CLOCK_GetCTimerClkFreq(4U)

Clock Frequency Retrieval Macro For The Timer Instance.

Functions

void PWRLOSS_DetectionInit (void)

Initializes Power Loss Detection Components.

6.18.1 Macro Definition Documentation

6.18.1.1 CTIMER

#define CTIMER CTIMER4

Timer Used To Control Delayed Activation of Power Loss Detection.

The Comparator is Enabled After a Delay of Stau, Which Corresponds To The Time Needed For The Backup Capacitor To Become Fully Charged. This Delay Ensures Valid Detection of Power Drop Events and Avoids False Triggering During Startup.

6.18.1.2 CTIMER_CLK_FREQ

```
#define CTIMER_CLK_FREQ CLOCK_GetCTimerClkFreq(4U)
```

Clock Frequency Retrieval Macro For The Timer Instance.

6.18.1.3 CTIMER_EMT0_OUT

```
\#define CTIMER_EMT0_OUT (1u << kCTIMER_Match_0)
```

Timer External Match Output Mask For Channel 0.

6.18.1.4 CTIMER_MAT0_OUT

```
#define CTIMER_MAT0_OUT kCTIMER_Match_0
```

Timer Match Output Channel 0.

6.18.1.5 **LPCMP_BASE**

```
#define LPCMP_BASE CMP1
```

Base Address of The Low-Power Comparator (LPCMP).

Used To Detect Loss of Primary 5V Supply. If The Voltage Drops Below a Defined Threshold, It Triggers a Transition To Backup Power Mode for Safe Data Preservation.

6.18.1.6 LPCMP_DAC_CHANNEL

```
#define LPCMP_DAC_CHANNEL 0x07
```

Comparator Internal DAC Reference Channel.

6.18.1.7 LPCMP_IRQ_ID

```
#define LPCMP_IRQ_ID HSCMP1_IRQn
```

IRQ Number for The Comparator Peripheral.

6.18.1.8 LPCMP_USER_CHANNEL

```
#define LPCMP_USER_CHANNEL 0x02
```

Comparator Input Channel Used For 5V Monitoring.

6.18.1.9 SPC_BASE

```
#define SPC_BASE SPC0
```

Base Address of The Supply Power Controller (SPC).

For Activation Analog Modules.

6.18.2 Function Documentation

6.18.2.1 PWRLOSS_DetectionInit()

Initializes Power Loss Detection Components.

This Function Configures The Comparator (LPCMP) for Monitoring The 5V Power Rail and The Timer (CTIMER4) That Delays The Activation of The Comparator Until The Backup Capacitor Is Fully Charged (\sim 5tau). After Initialization, The Timer is Started and The Comparator Will Be Enabled Upon Timer Match Event.

6.19 pwrloss_det.h

6.19 pwrloss det.h

Go to the documentation of this file.

```
00001 /****************
00002 * Project: NXP MCXN947 Datalogger
00003 * File Name: pwrloss_det.h
00004 * Author: Tomas Dolak
00005 * Date: 01.02.2024
00006 * Description: Implements The Logic Of Power Loss Detection.
00007 *
00008 * *************************
00009
00010 /**************
00011 * @package NXP MCXN947 Datalogger
00012 * @file pwrloss_det.h
00013 * @author
                    Tomas Dolak
00013 * eductior folias bolax

00014 * @date 01.02.2024

00015 * @brief Implements The Logic Of Power Loss Detection.
00016 * *************************
00017
00018 #ifndef PWRLOSS_DET_H_
00019 #define PWRLOSS_DET_H_
00020
00025 #include "fsl_lpcmp.h"
00026 #include "fsl_spc.h"
00027
00028 #include "led.h"
00029 #include "defs.h"
00031
00032 #include "fsl_ctimer.h"
00036
00042 #define LPCMP_BASE
00043
00047 #define LPCMP_USER_CHANNEL
                                0x02
00048
00052 #define LPCMP DAC CHANNEL
                                0x07
00053
00057 #define LPCMP_IRQ_ID
                                HSCMP1_IRQn
00058
00063 #define SPC_BASE
                                SPC0
00064
00071 #define CTIMER
                                CTIMER4
00072
00076 #define CTIMER_MAT0_OUT
                                kCTIMER_Match_0
00081 #define CTIMER_EMT0_OUT
                                (1u « kCTIMER_Match_0)
00082
00086 #define CTIMER CLK FREO
                                CLOCK GetCTimerClkFreg(4U)
00087
00089 * Prototypes
00098 void PWRLOSS_DetectionInit(void);
00099
00100
00101 #endif /* PWRLOSS_DET_H_ */
```

6.20 include/record.h File Reference

```
#include <led.h>
#include <string.h>
#include "fsl_sd.h"
#include "ff.h"
#include "ffconf.h"
#include <stdio.h>
#include "fsl_sd_disk.h"
#include "fsl_common.h"
```

```
#include "diskio.h"
#include "pin_mux.h"
#include "clock_config.h"
#include "board.h"
#include "sdmmc_config.h"
#include "rtc_ds3231.h"
#include "fsl_common_arm.h"
#include "task.h"
#include "error.h"
#include "uart.h"
#include "parser.h"
```

Macros

• #define FLUSH_TIMEOUT_TICKS pdMS_TO_TICKS(3000)

Timeout Interval Before Flush If No New Data Were Received [In Mili-Seconds].

Functions

uint32_t CONSOLELOG_GetFreeSpaceMB (void)

Gets Free Space on SD Card.

error_t CONSOLELOG_CreateDirectory (void)

Creates Directory Based Actual Date.

error_t CONSOLELOG_CreateFile (void)

Creates File Based Actual Date and Counter Value.

uint32_t CONSOLELOG_GetTransferedBytes (void)

Returns Currently Received Bytes Between LED Blinking.

bool CONSOLELOG_GetFlushCompleted (void)

Returns If Flush Was Completed or Not.

void CONSOLELOG_ClearTransferedBytes (void)

Clears Currently Received Bytes After LED Blinking.

uint32_t CONSOLELOG_GetMaxBytes (void)

Maximal Received Bytes Between LED Blinking.

FRESULT CONSOLELOG_CheckFileSystem (void)

Checks If The File System Is Initialized.

error_t CONSOLELOG_Init (void)

Initializes The Recording System and Mounts The File System.

error_t CONSOLELOG_Recording (uint32_t file_size)

Starts The Recording Process by Initializing the File System, Creating a Directory, and Writing to a File.

error_t CONSOLELOG_Flush (void)

Flushes Collected Data To The File If No Other Data Have Been Received By The Time Specified By TIMEOUT Macro.

error_t CONSOLELOG_PowerLossFlush (void)

Flushes Collected Data To The File If Power Loss Was Detected.

error_t CONSOLELOG_Deinit (void)

De-Initializes The Recording System and Un-Mounts The File System.

error_t CONSOLELOG_ReadConfig (void)

Reads and Processes The Configuration File From The Root directory.

error_t CONSOLELOG_ProccessConfigFile (const char *content)

Processes The Content of The Configuration File To Extract and Validate The Baudrate.

6.20.1 Macro Definition Documentation

6.20.1.1 FLUSH_TIMEOUT_TICKS

```
#define FLUSH_TIMEOUT_TICKS pdMS_TO_TICKS(3000)
```

Timeout Interval Before Flush If No New Data Were Received [In Mili-Seconds].

6.20.2 Function Documentation

6.20.2.1 CONSOLELOG_CheckFileSystem()

Checks If The File System Is Initialized.

return F_OK If File System Initialized.

6.20.2.2 CONSOLELOG_ClearTransferedBytes()

Clears Currently Received Bytes After LED Blinking.

6.20.2.3 CONSOLELOG_CreateDirectory()

Creates Directory Based Actual Date.

Returns

Returns Zero If Directory Creation Succeeded.

6.20.2.4 CONSOLELOG CreateFile()

Creates File Based Actual Date and Counter Value.

Returns

Returns Zero If File Creation Succeeded.

6.20.2.5 CONSOLELOG_Deinit()

De-Initializes The Recording System and Un-Mounts The File System.

Returns

```
error_t Returns 0 on Success, Otherwise E_FAULT.
```

6.20.2.6 CONSOLELOG_Flush()

Flushes Collected Data To The File If No Other Data Have Been Received By The Time Specified By TIMEOUT Macro.

If The Data Does Not Arrive By The Time Specified By The TIMEOUT Macro, Then This Function Flushes All The Data So Far Stored In The DMA Buffer, Saves It To a File on The Physical Media and Closes The File.

Returns

error_t Returns 0 on Success, Otherwise Returns a Non-Zero Value.

6.20.2.7 CONSOLELOG_GetFlushCompleted()

Returns If Flush Was Completed or Not.

Returns

If Recording Is Ongoing That Return False.

6.20.2.8 CONSOLELOG_GetFreeSpaceMB()

Gets Free Space on SD Card.

Returns

Returns Free Space on SD Card.

6.20.2.9 CONSOLELOG_GetMaxBytes()

Maximal Received Bytes Between LED Blinking.

6.20.2.10 CONSOLELOG_GetTransferedBytes()

```
uint32_t CONSOLELOG_GetTransferedBytes ( void )
```

Returns Currently Received Bytes Between LED Blinking.

Returns

uint32_t Received Bytes Between LED Blinking.

6.20.2.11 CONSOLELOG_Init()

Initializes The Recording System and Mounts The File System.

This Function Performs the Initialization of The Recording System, Which includes:

- Setting Default Configuration Parameters.
- · Mounting the File System on The Logical Disk.
- · Optionally Setting Up The Current Working Drive.
- Formatting The File System If It is Not Found (If Formatting is Enabled).

Returns

error_t Returns ERROR_NONE on Success, Otherwise ERROR_FILESYSTEM.

6.20.2.12 CONSOLELOG_PowerLossFlush()

Flushes Collected Data To The File If Power Loss Was Detected.

If Power Loss Was Detected, Then This Function Flushes All The Data So Far Stored In The DMA Buffer, Saves It To a File on The Physical Media and Closes The File.

Returns

error_t Returns 0 on Success, Otherwise Returns a Non-Zero Value.

6.20.2.13 CONSOLELOG_ProccessConfigFile()

Processes The Content of The Configuration File To Extract and Validate The Baudrate.

Parameters

in	content	Content The Content of The Configuration File as a Null-Terminated String.]
----	---------	--	---

Returns

error_t Returns 0 If Configuration File Is Correctly Processed, Otherwise Returns E_FAULT.

6.20.2.14 CONSOLELOG_ReadConfig()

Reads and Processes The Configuration File From The Root directory.

This Function Scans The Root Directory For a Configuration File, If The File is Found Reads its Contents Into g_config Buffer.

Returns

error_t Returns 0 If Configuration File Is Correctly Processed, Otherwise Returns E_FAULT.

6.20.2.15 CONSOLELOG_Recording()

Starts The Recording Process by Initializing the File System, Creating a Directory, and Writing to a File.

Function Uses CONSOLELOG_Init To Initialize The Recording System.

Returns

error_t Returns 0 on Success, Otherwise Returns a Non-Zero Value.

6.21 record.h

Go to the documentation of this file.

```
00018 #ifndef RECORD_H_
00019 #define RECORD_H_
00020
00021 /*****************************
00024 #include <led.h>
00025 #include <string.h>
00026 #include "fsl_sd.h"
00027 #include "ff.h"
                                  /*<! File System */
00028 #include "ffconf.h"
                                  /*<! File System Configuration */
00029 #include <stdio.h>
00030
00031 #include "fsl_sd_disk.h"
00032 #include "fsl_common.h"
00033 #include "diskio.h"
00034 #include "pin_mux.h"
00035 #include "clock_config.h"
00036 #include "board.h"
00037 #include "sdmmc_config.h"
00038 #include "rtc_ds3231.h"
00039 #include "fsl_common_arm.h"
00040
00041 #include "task.h"
00042
00043 #include "error.h"
00044 #include "uart.h"
00045 #include "parser.h"
00046 /****************************
00047 * Definitions
00052 #define FLUSH_TIMEOUT_TICKS pdMS_TO_TICKS(3000)
00053
00054 /***********************************
00057
00059 * Prototypes
00061
00067 uint32_t CONSOLELOG_GetFreeSpaceMB(void);
00068
00074 error_t CONSOLELOG_CreateDirectory(void);
00075
00081 error_t CONSOLELOG_CreateFile(void);
00082
00088 uint32_t CONSOLELOG_GetTransferedBytes(void);
00089
00095 bool CONSOLELOG_GetFlushCompleted(void);
00100 void CONSOLELOG_ClearTransferedBytes(void);
00101
00105 uint32_t CONSOLELOG_GetMaxBytes(void);
00106
00112 FRESULT CONSOLELOG_CheckFileSystem(void);
00127 error_t CONSOLELOG_Init(void);
00128
00138 error_t CONSOLELOG_Recording(uint32_t file_size);
00139
00149 error_t CONSOLELOG_Flush(void);
00150
00158 error_t CONSOLELOG_PowerLossFlush(void);
00159
00165 error_t CONSOLELOG_Deinit(void);
00166
00176 error t CONSOLELOG ReadConfig(void);
00177
00188 error_t CONSOLELOG_ProccessConfigFile(const char *content);
00189
00190
00191 #endif /* RECORD_H_ */
```

6.22 include/task_switching.h File Reference

```
#include "usb_device_dci.h"
```

Functions

• usb_device_notification_t USB_State (usb_device_struct_t *pDeviceHandle)

Checks If Application USB Is Attached To Digital Data Logger.

Variables

```
    usb_msc_struct_t g_msc
    Mass Storage Descriptor.
```

6.22.1 Function Documentation

6.22.1.1 USB_State()

```
usb_device_notification_t USB_State (
          usb_device_struct_t * pDevi ceHandle)
```

Checks If Application USB Is Attached To Digital Data Logger.

Checks Thru USB OTG (USB On-To-Go) SC Register.

Parameters

in	pDeviceHandle	Pointer to USB Device Handle (e.g. Mass Storage Handle).

Returns

kUSB_DeviceNotifyAttach if USB Is Attached Otherwise Returns kUSB_DeviceNotifyDetach.

6.22.2 Variable Documentation

6.22.2.1 g_msc

```
usb_msc_struct_t g_msc [extern]
```

Mass Storage Descriptor.

6.23 task_switching.h

6.23 task switching.h

Go to the documentation of this file.

```
00007 *
00008 * *************************
00009
00010 /***************
Includes Implementation of Task Switching (Record / USB Mass Storage).
00017
00018 #ifndef TASK_SWITCHING_H_
00019 #define TASK_SWITCHING_H_
00022 * Includes
00024 #include "usb_device_dci.h"
00025
00026 /*****************************
00027 * Global Variables
00032 extern usb_msc_struct_t g_msc;
00034 * Prototypes
00043 usb_device_notification_t USB_State(usb_device_struct_t *pDeviceHandle);
00044
00045
00046 #endif /* TASK_SWITCHING_H_ */
```

6.24 include/temperature.h File Reference

```
#include "error.h"
#include "fsl_lpi2c.h"
#include "fsl_lpi2c_edma.h"
#include "fsl_edma.h"
```

Functions

```
    uint8_t Write (uint8_t regAddress, uint8_t val[])
```

I2C Write Function.

uint16_t Read (uint8_t regAddress)

I2C Read Function.

float TMP_GetTemperature (void)

Gets Temperature From On-Board P3T1755 Temperature Sensor.

uint8_t TMP_Init (void)

Initialize On-Board P3T1755 Temperature Sensor.

6.24.1 Function Documentation

6.24.1.1 Read()

I2C Read Function.

Parameters

in	regAddress	Address of The Register From Which The Reading Will Take Place.	1
----	------------	---	---

Return values

rns The Read Value From The Registry.	Returns
---------------------------------------	---------

6.24.1.2 TMP_GetTemperature()

```
float TMP_GetTemperature ( void )
```

Gets Temperature From On-Board P3T1755 Temperature Sensor.

Return values

Returns	Temperature As Float Number.
---------	------------------------------

6.24.1.3 TMP_Init()

Initialize On-Board P3T1755 Temperature Sensor.

6.24.1.4 Write()

I2C Write Function.

Parameters

	in	regAddress	Address of The Register To Be Written To.
ſ	in	val	Array of Values To Be Written To The Register.

Return values

If	The Write Succeeds	Returns 0.

6.25 temperature.h 71

6.25 temperature.h

Go to the documentation of this file.

```
00001 /***************
000002 * Project: NXP MCXN947 Datalogger
00003 * File Name: temperature.h
00004 * Author: Tomas Dolak
00005 * Date: 11.02.2025
00006 \star Description: Implements The Logic For Temperature Measurement.
00007
00008 * *********************
00009
00010 /*************
00011 * @package NXP MCXN947 Datalogger
00012 * @file temperature.h
00013 * @author Tomas Dolak
00014 * @date 11.02.2025
00015 * @brief Implements The Logic For Temperature Measurement.
00016 * ***********************
00017
00018 #ifndef TEMPERATURE H
00019 #define TEMPERATURE H
00024
00025 #include "error.h"
00026
00027 #include "fsl_lpi2c.h"
00028 #include "fsl_lpi2c_edma.h"
00029 #include "fsl_edma.h"
00030 /**********
00031 \star Global Definitions
00034
00036 * Prototypes
00046 uint8_t Write(uint8_t regAddress, uint8_t val[]);
00055 uint16_t Read(uint8_t regAddress);
00056
00062 float TMP_GetTemperature(void);
00063
00067 uint8_t TMP_Init(void);
00068
00069 #endif /* TEMPERATURE_H_ */
```

6.26 include/time.h File Reference

```
#include "fsl_irtc.h"
#include "rtc_ds3231.h"
#include "fsl_debug_console.h"
#include "error.h"
```

Macros

#define LPI2C_DMA_BASEADDR (DMA0)
 I2C Definitions.

Functions

• error_t TIME_InitIRTC (void)

Initialize Internal And External Real-Time Circuits And Passes Timestamp Information From The External To The Internal.

6.26.1 Macro Definition Documentation

6.26.1.1 LPI2C DMA BASEADDR

```
#define LPI2C_DMA_BASEADDR (DMA0)
```

I2C Definitions.

6.26.2 Function Documentation

6.26.2.1 TIME InitIRTC()

Initialize Internal And External Real-Time Circuits And Passes Timestamp Information From The External To The Internal.

6.27 time.h

Go to the documentation of this file.

```
00001 /**************
000002 * Project: NXP MCXN947 Datalogger
00003 * File Name: mainc.c
00004 * Author: Tomas Dolak
00005 * Date: 07.08.2024
00006 * Description: Implements Datalogger Application.
00007 *
00008 * **************************
00009
00010 /**************
00011 * @package NXP MCXN947 Datalogger
00012 * @file main.c
00013 * @author Tomas Dolak
00014 * @date 07.08.2024
00015 * @brief Implements Datalogger Application.
00016 * **************************
00017
00018
00019 #ifndef TIME_H_
00020 #define TIME H
00021
00025 #include "fsl_irtc.h"
00026 #include "rtc_ds3231.h"
00027 #include "fsl_debug_console.h"
00028 #include "error.h"
00029
00033
00037 #define LPI2C_DMA_BASEADDR (DMA0)
00038
00040 * Prototypes
00042
00047 error_t TIME_InitIRTC(void);
00049 #endif /* TIME_H_ */
```

6.28 include/uart.h File Reference

```
#include "pin_mux.h"
#include "clock_config.h"
#include "board.h"
#include "fsl_lpuart.h"
#include "fsl_debug_console.h"
#include "fsl_clock.h"
```

Macros

#define LPUART3_CLK_FREQ CLOCK_GetLPFlexCommClkFreq(3u)
 Frequency of LPUART7.

Functions

```
    void UART_Init (uint32_t baudrate)
```

Initializes LPUART For Recording.

void UART_Print (uint8_t ch)

Prints Character on The Terminal.

void UART_Enable (void)

Enables Interrupt For Application LPUART.

void UART_Disable (void)

Disables Interrupt For Application LPUART.

void UART_Deinit (void)

De-Initialize LPUART.

6.28.1 Macro Definition Documentation

6.28.1.1 LPUART3_CLK_FREQ

```
#define LPUART3_CLK_FREQ CLOCK_GetLPFlexCommClkFreq(3u)
```

Frequency of LPUART7.

6.28.2 Function Documentation

6.28.2.1 **UART_Deinit()**

```
void UART_Deinit (
     void )
```

De-Initialize LPUART.

The Pins Should Be De-Initialized After This Function.

6.28.2.2 UART_Disable()

```
void UART_Disable (
     void )
```

Disables Interrupt For Application LPUART.

6.28.2.3 **UART_Enable()**

```
void UART_Enable (
     void )
```

Enables Interrupt For Application LPUART.

6.28.2.4 **UART_Init()**

Initializes LPUART For Recording.

6.28.2.5 UART_Print()

Prints Character on The Terminal.

Parameters

in	ch	Character in
		uint8_t.

6.29 uart.h

Go to the documentation of this file.

6.29 uart.h 75

```
00028
00037 #define LPUART3_CLK_FREQ CLOCK_GetLPFlexCommClkFreq(3u)
00038
00039
00043
00047 void UART_Init(uint32_t baudrate);
00048
00054 void UART_Print(uint8_t ch);
00055
00059 void UART_Enable(void);
00060
00064 void UART_Disable(void);
00065
00070 void UART_Deinit(void);
00071
00072 #endif /* UART_H_ */
00073
```

Index

ALARM_DISABLED	${\tt CONSOLELOG_GetFlushCompleted}$
rtc_ds3231.h, 23	record.h, 64
ALARM_INTERRUPT	CONSOLELOG_GetFreeSpaceMB
rtc_ds3231.h, 28	record.h, 64
app_init.h	CONSOLELOG_GetMaxBytes
APP_InitBoard, 30	record.h, 64
APP_InitBoard	CONSOLELOG_GetTransferedBytes
app_init.h, 30	record.h, 65
APP_SUCCESS	CONSOLELOG_Init
rtc_ds3231.h, 23	record.h, 65
app_tasks.h	CONSOLELOG_PowerLossFlush
g_xMscTaskHandle, 33	record.h, 65
g_xRecordTaskHandle, 33	CONSOLELOG_ProccessConfigFile
g_xSemMassStorage, 34	record.h, 65
g_xSemRecord, 34	CONSOLELOG_ReadConfig
msc_task, 32	record.h, 66
record_task, 32	CONSOLELOG_Recording
TASK_PRIO, 32	record.h, 66
vApplicationGetIdleTaskMemory, 33	CONTROL_LED_ENABLED
vApplicationGetTimerTaskMemory, 33	defs.h, 36
AT_NONCACHEABLE_SECTION	CTIMER
rtc_ds3231.c, 19	pwrloss_det.h, 59
	CTIMER_CLK_FREQ
BACKUP_POWER_LED_PIN	pwrloss_det.h, 59
led.h, 46	CTIMER_EMT0_OUT
BACKUP_POWER_LED_PORT	pwrloss_det.h, 59
led.h, 46	CTIMER_MATO_OUT
baudrate	pwrloss_det.h, 59
REC_config_t, 13	·
BYTE_1	data_bits
rtc_ds3231.c, 18	REC_config_t, 13
BYTE_2	date
rtc_ds3231.c, 18	RTC_date_t, 15
	day
CLK_STATE	RTC_date_t, 15
rtc_ds3231.c, 18	DEBUG_ENABLED
CONFIG_FILE	defs.h, 36
defs.h, 36	DEFAULT_BAUDRATE
CONSOLELOG_CheckFileSystem	defs.h, 36
record.h, 63	DEFAULT_DATA_BITS
CONSOLELOG_ClearTransferedBytes	defs.h, 36
record.h, 63	DEFAULT_FREE_SPACE
CONSOLELOG_CreateDirectory	defs.h, 37
record.h, 63	DEFAULT_MAX_FILESIZE
CONSOLELOG_CreateFile	defs.h, 37
record.h, 63	DEFAULT_PARITY
CONSOLELOG_Deinit	defs.h, 37
record.h, 63	DEFAULT_STOP_BITS
CONSOLELOG_Flush	defs.h, 37
record.h, 64	defs.h

CONFIG_FILE, 36 CONTROL_LED_ENABLED, 36 DEBUG_ENABLED, 36	rtc_ds3231.h, 23 DS3231_ADDR_DAY rtc_ds3231.h, 23
DEFAULT_BAUDRATE, 36 DEFAULT_DATA_BITS, 36	DS3231_ADDR_HRS rtc_ds3231.h, 24
DEFAULT_FREE_SPACE, 37	DS3231_ADDR_I2C
DEFAULT_MAX_FILESIZE, 37 DEFAULT_PARITY, 37	rtc_ds3231.h, <mark>24</mark> DS3231_ADDR_MIN
DEFAULT_STOP_BITS, 37 INFO_ENABLED, 37	rtc_ds3231.h, 24 DS3231_ADDR_MONTH
MSC_ENABLED, 37 MSC_STACK_SIZE, 37	rtc_ds3231.h, 24 DS3231_ADDR_SEC
NOT_IMPLEMENTED, 38	rtc_ds3231.h, 24
PWRLOSS_DET_ACTIVE_IN_TIME, 38 PWRLOSS_DET_PRIO, 38	DS3231_ADDR_YEAR rtc_ds3231.h, <mark>2</mark> 4
PWRLOSS_DETECTION_ENABLED, 38 PWRLOSS_TEST_GPIOS, 38	DS3231_INTCN rtc_ds3231.h, 24
PWRLOSS_TIMER_PRIO, 38	DS3231_REG_CTRL
RECORD_STACK_SIZE, 38 TAU5, 38	rtc_ds3231.h, <mark>25</mark> DS3231_REG_STATUS
TEMPERATURE_MEAS_ENABLED, 39 UART_FIFO_ENABLED, 39	rtc_ds3231.h, 25
UART_FIFO_LENGHT, 39 UART_PRINT_ENABLED, 39	E_FAULT rtc_ds3231.h, <mark>25</mark>
UART_RECEIVE_PRIO, 39	ERR_HandleError error.h, 43
drivers/rtc_ds3231.c, 17 drivers/rtc_ds3231.h, 20, 28	ERR_Init
DS3231 Real-Time Clock Driver, 7 RTC_ClearFlagAlarm1, 8	error.h, 43 ERR_SetState
RTC_ClearFlagAlarm2, 8 RTC_ConvertToBCD, 8	error.h, 43 error.h
RTC_ConvertToDEC, 8	ERR_HandleError, 43 ERR_Init, 43
RTC_CtrlAlarm1, 9 RTC_CtrlAlarm2, 9	ERR_SetState, 43
RTC_Deinit, 9 RTC_GetDate, 9	ERROR_ADMA, 41 ERROR_CLOSE, 41
RTC_GetState, 10	ERROR_CONFIG, 42 ERROR_FILESYSTEM, 42
RTC_GetTime, 10 RTC_Init, 10	ERROR_IRTC, 42
RTC_Read, 10 RTC_SetDate, 11	ERROR_NONE, 42 ERROR_OPEN, 42
RTC_SetDateDefault, 11 RTC_SetInterruptMode, 11	ERROR_OUT_OF_CYCLE, 42 ERROR_READ, 42
RTC_SetOscState, 11	ERROR_RECORD, 42 error_t, 43
RTC_SetTime, 12 RTC_SetTimeDefault, 12	ERROR_UNKNOWN, 43
RTC_Write, 12 DS3231_A1F	ERROR_ADMA error.h, 41
rtc_ds3231.h, 23	ERROR_CLOSE error.h, 41
DS3231_A1IE rtc_ds3231.h, 23	ERROR_CONFIG
DS3231_A2F rtc_ds3231.h, 23	error.h, 42 ERROR_FILESYSTEM
DS3231_A2IE rtc_ds3231.h, 23	error.h, 42 ERROR_IRTC
DS3231_ADDR_CENT	error.h, 42 ERROR_LED_PIN_RECORD
rtc_ds3231.h, 23 DS3231_ADDR_DATE	led.h, 46
	ERROR_LED_PORT

led.h, 46	include/parser.h, 51, 57
ERROR_NONE	include/pwrloss_det.h, 58, 61
error.h, 42	include/record.h, 61, 66
ERROR_OPEN	include/task_switching.h, 67, 69
error.h, 42	include/temperature.h, 69, 71
ERROR_OUT_OF_CYCLE	include/time.h, 71, 72
error.h, 42	include/uart.h, 73, 74
ERROR_READ	INFO_ENABLED
error.h, 42	defs.h, 37
ERROR_RECORD	20.000, 00
error.h, 42	led.h
error t	BACKUP_POWER_LED_PIN, 46
error.h, 43	BACKUP_POWER_LED_PORT, 46
ERROR_UNKNOWN	ERROR_LED_PIN_RECORD, 46
error.h, 43	ERROR_LED_PORT, 46
CHOLII, 40	FLUSH_LED_PORT, 46
FLUSH_LED_PORT	LED_ClearSignalFlush, 47
led.h, 46	LED_SetHigh, 47
FLUSH_TIMEOUT_TICKS	LED_SetLow, 48
record.h, 63	LED_SignalBackUpPowerAvailable, 48
format	LED_SignalError, 48
RTC_time_t, 16	LED_SignalFlush, 48
free_space_limit_mb	LED_SignalLowMemory, 48
REC_config_t, 14	LED_SignalReady, 48
FRIDAY	LED_SignalRecording, 49
rtc_ds3231.h, 25	LED_SignalRecordingStop, 49
11C_US3231.11, 23	MEMORY_LOW_LED_PIN, 46
g_msc	MEMORY_LOW_LED_PORT, 46
task_switching.h, 68	RECORD_LED_PIN, 47
g_xMscTaskHandle	RECORD_LED_PIN, 47 RECORD_LED_PIN_FLUSH, 47
app_tasks.h, 33	RECORD_LED_PORT, 47
g_xRecordTaskHandle	
app_tasks.h, 33	LED_ClearSignalFlush
• •	led.h, 47
g_xSemMassStorage	LED_SetHigh
app_tasks.h, 34	led.h, 47
g_xSemRecord	LED_SetLow
app_tasks.h, 34	led.h, 48
gCompletionFlag	LED_SignalBackUpPowerAvailable
rtc_ds3231.c, 20	led.h, 48
gEdmaRxHandle	LED_SignalError
rtc_ds3231.c, 20	led.h, 48
gEdmaTxHandle	LED_SignalFlush
rtc_ds3231.c, 20	led.h, 48
bro	LED_SignalLowMemory
hrs	led.h, 48
RTC_time_t, 16	LED_SignalReady
I2C_BAUDRATE	led.h, 48
rtc_ds3231.h, 25	LED_SignalRecording
I2C_DATA_LENGTH	led.h, 49
	LED_SignalRecordingStop
rtc_ds3231.c, 19	led.h, 49
I2C_MASTER	LPCMP_BASE
rtc_ds3231.h, 25	pwrloss_det.h, 59
include/app_init.h, 30, 31	LPCMP_DAC_CHANNEL
include/app_tasks.h, 31, 34	pwrloss_det.h, 59
include/defs.h, 35, 40	LPCMP_IRQ_ID
include/error.h, 41, 44	pwrloss_det.h, 60
include/led.h, 44, 49	LPCMP_USER_CHANNEL
include/mass_storage.h, 50, 51	pwrloss_det.h, 60

IniOn, and Ihand	DADCED CateroochanalimitMD E4
lpi2c_callback	PARSER_GetFreeSpaceLimitMB, 54
rtc_ds3231.c, 19	PARSER_GetMaxBytes, 54
LPI2C_DMA_BASEADDR	PARSER_GetParity, 54
time.h, 72	PARSER_GetStopBits, 54
LPI2C_RX_DMA_CHANNEL	PARSER_GetVersion, 55
rtc_ds3231.h, 25	PARSER_ParseBaudrate, 55
LPI2C_RX_EDMA_CHANNEL	PARSER_ParseDataBits, 55
rtc_ds3231.h, 26	PARSER_ParseFileSize, 55
LPI2C_TX_CHANNEL	PARSER_ParseFreeSpace, 56
rtc_ds3231.h, 26	PARSER_ParseParity, 56
LPI2C_TX_DMA_CHANNEL	PARSER_ParseStopBits, 56
rtc_ds3231.h, 26	REC_version_t, 52
LPUART3_CLK_FREQ	WCT_AUTOS1, 53
uart.h, 73	WCT_AUTOS2, 53
	WCT_UNKOWN, 53
mass_storage.h	PARSER_ClearConfig
MSC_DeviceMscApp, 50	parser.h, 53
MSC_DeviceMscAppTask, 50	PARSER_GetBaudrate
max_bytes	parser.h, 53
REC_config_t, 14	PARSER_GetConfig
MEMORY_LOW_LED_PIN	parser.h, 53
led.h, 46	PARSER_GetDataBits
MEMORY_LOW_LED_PORT	parser.h, 53
led.h, 46	PARSER_GetFileSize
min	parser.h, 53
RTC_time_t, 16	PARSER_GetFreeSpaceLimitMB
MONDAY	parser.h, 54
rtc_ds3231.h, 26	PARSER_GetMaxBytes
month	
RTC_date_t, 15	parser.h, 54
MSC_DeviceMscApp	PARSER_GetParity
mass_storage.h, 50	parser.h, 54
MSC_DeviceMscAppTask	PARSER_GetStopBits
mass_storage.h, 50	parser.h, 54
MSC_ENABLED	PARSER_GetVersion
defs.h, 37	parser.h, 55
MSC_STACK_SIZE	PARSER_ParseBaudrate
defs.h, 37	parser.h, 55
msc_task	PARSER_ParseDataBits
app_tasks.h, 32	parser.h, 55
αρρ_ια3κ3.11, 32	PARSER_ParseFileSize
NOT_IMPLEMENTED	parser.h, 55
defs.h, 38	PARSER_ParseFreeSpace
	parser.h, 56
OSC_INTERRUPTED	PARSER_ParseParity
rtc_ds3231.h, 28	parser.h, 56
OSC_OK	PARSER_ParseStopBits
rtc_ds3231.h, 28	parser.h, 56
OSC_STOPPED	pwrloss_det.h
rtc_ds3231.h, 26	CTIMER, 59
110_030201, 20	CTIMER_CLK_FREQ, 59
parity	CTIMER_EMT0_OUT, 59
REC_config_t, 14	CTIMER_MAT0_OUT, 59
parser.h	LPCMP_BASE, 59
PARSER_ClearConfig, 53	LPCMP_DAC_CHANNEL, 59
PARSER_GetBaudrate, 53	LPCMP_IRQ_ID, 60
PARSER_GetConfig, 53	LPCMP_USER_CHANNEL, 60
PARSER_GetDataBits, 53	PWRLOSS_DetectionInit, 60
PARSER_GetFileSize, 53	SPC_BASE, 60

PWRLOSS_DET_ACTIVE_IN_TIME	rtc_ds3231.c, 19
defs.h, 38	RTC_ConvertToDEC
PWRLOSS_DET_PRIO	DS3231 Real-Time Clock Driver, 8
defs.h, 38	rtc_ds3231.c, 19
PWRLOSS_DETECTION_ENABLED	RTC_CtrlAlarm1
defs.h, 38	DS3231 Real-Time Clock Driver, 9
PWRLOSS_DetectionInit	RTC_CtrlAlarm2
pwrloss_det.h, 60	DS3231 Real-Time Clock Driver, 9
PWRLOSS_TEST_GPIOS	RTC_date_t, 15
defs.h, 38	date, 15
PWRLOSS_TIMER_PRIO	day, 15
defs.h, 38	month, 15
	year, 15
Read	RTC_Deinit
temperature.h, 69	DS3231 Real-Time Clock Driver, 9
REC_config_t, 13	rtc_ds3231.c
baudrate, 13	AT_NONCACHEABLE_SECTION, 19
data_bits, 13	BYTE_1, 18
free_space_limit_mb, 14	BYTE_2, 18
max_bytes, 14	CLK_STATE, 18
parity, 14	gCompletionFlag, 20
size, 14	gEdmaRxHandle, 20
stop_bits, 14	gEdmaTxHandle, 20
version, 14	I2C_DATA_LENGTH, 19
REC_version_t	lpi2c_callback, 19
parser.h, 52	RTC_ConvertToBCD, 19
record.h	RTC_ConvertToDEC, 19
CONSOLELOG_CheckFileSystem, 63	xfer, 20
CONSOLELOG_ClearTransferedBytes, 63	rtc_ds3231.h
CONSOLELOG_CreateDirectory, 63	ALARM_DISABLED, 23
CONSOLELOG_CreateFile, 63	ALARM_INTERRUPT, 28
CONSOLELOG_Deinit, 63	APP_SUCCESS, 23
CONSOLELOG_Flush, 64	DS3231_A1F, 23
CONSOLELOG_GetFlushCompleted, 64	DS3231_A11E, 23
CONSOLELOG_GetFreeSpaceMB, 64	DS3231_ATIE, 23
CONSOLELOG_GetMaxBytes, 64	DS3231_A2IF, 23
CONSOLELOG_GetTransferedBytes, 65	DS3231_AZIL, 23 DS3231_ADDR_CENT, 23
CONSOLELOG_Init, 65	DS3231_ADDR_CENT, 23
CONSOLELOG_PowerLossFlush, 65	
CONSOLELOG_ProccessConfigFile, 65	DS3231_ADDR_DAY, 23
CONSOLELOG_ReadConfig, 66	DS3231_ADDR_HRS, 24
CONSOLELOG_Recording, 66	DS3231_ADDR_I2C, 24
FLUSH_TIMEOUT_TICKS, 63	DS3231_ADDR_MIN, 24
RECORD_LED_PIN	DS3231_ADDR_MONTH, 24
led.h, 47	DS3231_ADDR_SEC, 24
RECORD_LED_PIN_FLUSH	DS3231_ADDR_YEAR, 24
led.h, 47	DS3231_INTCN, 24
RECORD_LED_PORT	DS3231_REG_CTRL, 25
led.h, 47	DS3231_REG_STATUS, 25
RECORD_STACK_SIZE	E_FAULT, 25
defs.h, 38	FRIDAY, 25
	I2C_BAUDRATE, 25
record_task	I2C_MASTER, 25
app_tasks.h, 32	LPI2C_RX_DMA_CHANNEL, 25
RTC_ClearFlagAlarm1	LPI2C_RX_EDMA_CHANNEL, 26
DS3231 Real-Time Clock Driver, 8	LPI2C_TX_CHANNEL, 26
RTC_ClearFlagAlarm2	LPI2C_TX_DMA_CHANNEL, 26
DS3231 Real-Time Clock Driver, 8	MONDAY, 26
RTC_ConvertToBCD	OSC_INTERRUPTED, 28
DS3231 Real-Time Clock Driver, 8	

OSC_OK, 28	REC_config_t, 14
OSC_STOPPED, 26	SUNDAY
RTC_interrupt_mode_t, 27	rtc_ds3231.h, 26
RTC_osc_state_t, 28	
SATURDAY, 26	TASK_PRIO
SQUARE_WAVE_INTERRUPT, 28	app_tasks.h, 32
SUNDAY, 26	task_switching.h
THURSDAY, 27	g_msc, 68
TIM_CYCLE_12H, 27	USB_State, 68
TIM_CYCLE_12H_AM, 27	TAU5
TIM_CYCLE_12H_PM, 27	defs.h, 38
TIM_CYCLE_24H, 27	temperature.h
TUESDAY, 27	Read, 69
WEDNESDAY, 27	TMP_GetTemperature, 70
RTC_GetDate	TMP_Init, 70
DS3231 Real-Time Clock Driver, 9	Write, 70
RTC GetState	TEMPERATURE_MEAS_ENABLED
DS3231 Real-Time Clock Driver, 10	defs.h, 39
RTC_GetTime	THURSDAY
DS3231 Real-Time Clock Driver, 10	rtc_ds3231.h, 27
	TIM_CYCLE_12H
RTC_Init DS3231 Real-Time Clock Driver, 10	rtc_ds3231.h, 27
	TIM_CYCLE_12H_AM
RTC_interrupt_mode_t	rtc_ds3231.h, 27
rtc_ds3231.h, 27	TIM_CYCLE_12H_PM
RTC_osc_state_t	rtc_ds3231.h, 27
rtc_ds3231.h, 28	TIM_CYCLE_24H
RTC_Read	rtc_ds3231.h, 27
DS3231 Real-Time Clock Driver, 10	time.h
RTC_SetDate	LPI2C_DMA_BASEADDR, 72
DS3231 Real-Time Clock Driver, 11	TIME_InitIRTC, 72
RTC_SetDateDefault	TIME_InitIRTC
DS3231 Real-Time Clock Driver, 11	time.h, 72
RTC_SetInterruptMode	TMP_GetTemperature
DS3231 Real-Time Clock Driver, 11	temperature.h, 70
RTC_SetOscState DS3231 Real-Time Clock Driver, 11	TMP_Init
	temperature.h, 70
RTC_SetTime DS3231 Real-Time Clock Driver, 12	TUESDAY
	rtc_ds3231.h, 27
RTC_SetTimeDefault	110_030201.11, 27
DS3231 Real-Time Clock Driver, 12	uart.h
RTC_time_t, 16	LPUART3_CLK_FREQ, 73
format, 16	UART_Deinit, 73
hrs, 16 min, 16	UART_Disable, 73
	UART_Enable, 74
sec, 16	UART Init, 74
RTC_Write	UART_Print, 74
DS3231 Real-Time Clock Driver, 12	UART_Deinit
SATURDAY	uart.h, 73
rtc_ds3231.h, 26	UART_Disable
sec .	uart.h, 73
RTC_time_t, 16	UART_Enable
size	uart.h, 74
REC_config_t, 14	UART_FIFO_ENABLED
SPC_BASE	defs.h, 39
pwrloss_det.h, 60	UART_FIFO_LENGHT
SQUARE_WAVE_INTERRUPT	defs.h, 39
rtc_ds3231.h, 28	UART_Init
stop_bits	uart.h, 74
· ·	

```
UART_Print
    uart.h, 74
UART_PRINT_ENABLED
    defs.h, 39
UART_RECEIVE_PRIO
    defs.h, 39
USB_State
    task_switching.h, 68
vApplicationGetIdleTaskMemory
    app_tasks.h, 33
vApplicationGetTimerTaskMemory
    app_tasks.h, 33
version
    REC_config_t, 14
WCT_AUTOS1
    parser.h, 53
WCT_AUTOS2
    parser.h, 53
WCT_UNKOWN
    parser.h, 53
WEDNESDAY
    rtc_ds3231.h, 27
Write
    temperature.h, 70
xfer
    rtc_ds3231.c, 20
year
    RTC_date_t, 15
```