
18-447 Lecture 20: ILP to Multicores

James C. Hoe
Department of ECE
Carnegie Mellon University

Midterm 2 Histogram



Housekeeping

- Your goal today
 - transition from sequential to parallel
 - enjoy (only slides before \$14 on midterm3)
- Notices
 - get going on Lab 4: status check 4/26, due 5/7
 - Handout #15: HW5
- Readings (advanced optional)
 - MIPS R10K Superscalar Microprocessor, Yeager
 - Synthesis Lectures: Processor Microarchitecture:
 An Implementation Perspective, 2010

Parallelism Defined


- T₁ (work measured in time):
 - time to do work with 1 PE
- T_∞ (critical path):
 - time to do work with infinite PEs
 - T_∞ bounded by dataflow dependence
- Average parallelism: let's call p

$$P_{avg} = T_1 / T_{\infty}$$
 concurrency

For a system with p PEs

$$T_p \ge \max\{ T_1/p, T_\infty \}$$

• When $P_{avg} >> p$ $T_p \approx T_1/p$, aka "linear speedup"



ILP: Instruction-Level Parallelism

• Average ILP =
$$T_1/T_{\infty}$$

= no. instruction / no. cyc required

code1:
$$ILP = 1$$

i.e., must execute serially

$$code2: ILP = 3$$

i.e., can execute at the same time

code1:
$$r1 \leftarrow r2 + 1$$

 $r3 \leftarrow r1 / 17$
 $r4 \leftarrow r0 - r3$

code2:
$$r1 \leftarrow r2 + 1$$


 $r3 \leftarrow r9 / 17$
 $r4 \leftarrow r0 - r10$

Superscalar Speculative Out-of-Order Execution

Exploiting ILP for Performance


Scalar in-order pipeline with forwarding

- operation latency (OL)= 1 base cycle
- peak IPC = 1 // no concurrency
- required ILP ≥ 1 to avoid stall



Superpipelined Execution


OL = M minor-cycle; same as 1 base cycle
peak IPC = 1 per minor-cycle // has concurrency though
required ILP ≥ M



Achieving full performance requires always finding **M** "independent" instructions in a row


Superscalar (Inorder) Execution

OL = 1 base cycle peak IPC = N required ILP ≥ N




Achieving full performance requires finding N "independent" instructions on every cycle

Lab 4: 2-way, In-order Superscalar




Lab 4: 2-way Supercalar BP



Limitations of Inorder Pipeline

- Achieved IPC of inorder pipelines degrades rapidly as NxM approaches ILP
- Despite high concurrency potential, pipeline never full due to frequent dependency stalls!!



Out-of-Order Execution

• ILP is scope dependent

ILP=1
$$\begin{cases} r1 \leftarrow r2 + 1 \\ r3 \leftarrow r1 / 17 \\ r4 \leftarrow r0 - r3 \\ r11 \leftarrow r12 + 1 \\ r13 \leftarrow r19 / 17 \\ r14 \leftarrow r0 - r20 \end{cases}$$
ILP=2

Accessing ILP=2 requires (1) larger scheduling window but also (2) out-of-order execution (even Lab 4 can go slightly OOO)

Superscalar Speculative Out-of-Order Execution

Dataflow Execution Ordering

- Maintain a buffer of many pending instructions,
 a.k.a. reservation stations (RSs)
 - wait for functional unit to be free
 - wait for register RAW hazards to resolve (i.e., required input operands to be produced)
- Decouple execution order from who is first in line (program order)
 - select inst's in RS whose operands are available
 - give preference to older instructions (heuristical)
- A completing instruction frees pending, RAWdependent instructions to execute

What about WAW and WAR?

Tomasulo's Algorithm [IBM 360/91, 1967]

Dispatch an instruction to a RS slot after decode

decode received from RF either operand

value or placeholder RS-tag


 mark RF dest with RS-tag of current inst's RS slot

 Inst in RS can issue when all operand values ready

 Completing instruction, in addition to updating RF dest,


broadcast its RS-tag and value to all RS slots

RS slot holding matching RS-tag placeholder pickup value



WAW and WAR

- No WAW and WAR before because
 - single write stage
 - write stage at the end (later than any read stage)
 - in-order progression in pipeline



Removing False Dependencies


- With out-of-order execution comes WAW and WAR hazards
- Anti and output dependencies are false dependencies on register names rather than data

$$r_3 \leftarrow r_1 \text{ op } r_2$$
 $r_5 \leftarrow r_3 \text{ op } r_4$
 $r_3 \leftarrow r_6 \text{ op } r_7$

 With infinite number of registers, anti and output dependencies avoidable by using a new register for each new value

Register Renaming: Example

Original




Renamed

$$r1 \leftarrow r2 / r3$$

 $r4 \leftarrow r1 * r5$
 $r8 \leftarrow r3 + r6$
 $r9 \leftarrow r8 - r5$

On-the-fly HW Register Renaming



- Maintain mapping from ISA reg. names to physical registers
- When decoding an instruction that updates 'r_x':
 - allocate unused physical register t_v to hold inst result
 - set new mapping from 'r_x' to t_v
 - younger instructions using 'r_x' as input finds t_v
- De-allocate a physical register for reuse when it is <u>never needed again</u>?

^^^^when is this exactly?

$$r1 \leftarrow r2 / r3$$

$$r4 \leftarrow r1 * r5$$

$$r1 \leftarrow r3 + r6$$

Superscalar Speculative Out-of-Order Execution

Control Speculation

- Modern CPUs can have over 100 instructions in out-of-order execution scope
 - if 14% of avg. instruction mix is control flow, what is average distance between control flow?
 - instruction fetch must make multiple levels of branch predictions (condition and target) to fetch far ahead of execution and commit

Question:


- how much more ILP is uncovered with look ahead
- how much useful work is done during look ahead
 Ans: not much and not much

Speculative Out-of-order Execution

- A mispredicted branch after resolution must be rewound and restarted and fast!
- Much trickier than 5-stage pipeline . . .
 - can rewind to an intermediate speculative state
 - a rewound branch could still be speculative and itself be discarded by another rewind!
 - rewind must reestablish both architectural state (register value) and microarchitecture state (e.g., rename table)
 - rewind/restart must be fast (not infrequent)
- Also need to rewind on exceptionsbut easier

Instruction Reorder Buffer (ROB)


- Program-order bookkeeping (circular buffer)
 - instructions enter and leave in program order
 - tracks 10s to 100s of in-flight instructions in different stages of execution
- Dynamic juggling of state and dependency
 - oldest finished instruction "commit" architectural state updates on exit
 - all ROB entries considered
 "speculative" due to potential for exceptions and mispredictions



In-order vs Speculative State

- In-order state:
 - cumulative architectural effects of all instructions committed in-order so far
 - can never be undone!!
- Speculative state, as viewed by a given inst in ROB
 - in-order state + effects of older inst's in ROB
 - effects of some older inst's may be pending
- Speculative state effects must be reversible
 - remember both in-order and speculative values for an RF register (may have multiple speculative values)
 - store inst updates memory only at commit time
- Discard younger speculative state to rewind execution to oldest remaining inst in ROB


Not Entirely New Concept for You privileged mode



- Kill faulting and younger inst; drain older inst
- Don't start handler until faulting inst. is oldest
- Better yet, don't start handler until pipeline is empty

Better to be safe than to be fast

Superscalar Speculative OOO All Together



Read [Yeager 1996, IEEE Micro] if you are interested

Truth about Superscalar Speculative OOO

- If memory speed kept up with core speed, we would still be building in-order pipelines
- But, by 2005 we were seeing
 e.g., Intel P4 at 4+GHz
- 16KB L1 D-cache
 t₁ = 4 cyc int (9 cycle fp)
- 1024KB L2 D-cache
 - $t_2 = 18 \text{ cyc int } (18 \text{ cyc fp})$
- Main memory
 - $t_3 = ~50$ ns or 180 cyc
- Speculative OOO has really been about
 - finding independent work to do after cache hit&miss
 - getting to future cache misses as early as possible
 - overlapping multiple cache misses for BW

At the 2005 Peak of Superscalar OOO


	Alpha 21364	AMD Opteron	Intel Xeon	IBM Power5	MIPS R14000	Intel Itanium2
clock (GHz)	1.30	2.4	3.6	1.9	0.6	1.6
issue rate	4	3 (x86)	3 (rop)	8	4	8
pipeline int/fp	7/9	9/11	22/24	12/17	6	8
inst in flight	80	72(rop)	126 rop	200	48	inorder
rename reg	48+41	36+36	128	48/40	32/32	328
transistor (10 ⁶)	135	106	125	276	7.2	592
power (W)	155	86	103	120	16	130
SPECint 2000	904	1,566	1,521	1,398	483	1,590
SPECfp 2000	1279	1,591	1,504	2,576	499	2,712

At peak minus 5 years


	Alpha 21264	AMD Athlon	Intel P4	MIPS R12000	IBM Power3	HP PA8600	SUN Ultra3
clock (MHz)	833	1200	1500	400	450	552	900
issue rate	4	3 (x86)	3 (rop)	4	4	4	4
pipeline int/fp	7/9	9/11	22/24	6	7/8	7/9	14//15
inst in flight	80	72(rop)	126 rop	48	32	56	inorder
rename reg	48+41	36+36	128	32+32	16+24	56	inorder
transistor (10 ⁶)	15.4	37	42	7.2	23	130	29
power (W)	75	76	55	25	36	60	65
SPECint 2000	518		524	320	286	417	438
SPECfp 2000	590	304	549	319	356	400	427

Performance (In)efficiency

- To hit "expected" performance target
 - push frequency harder by deepening pipelines
 - used the 2x transistors to build more complicated microarchitectures so fast/deep pipelines don't stall (i.e., caches, BP, superscalar, out-of-order)
- The consequence of performance inefficiency is



Efficiency of Parallel Processing



At peak plus 1 year


	AMD 285	Intel 5160	Intel 965	Intel Itanium2	IBM P5+	MIPS R16000	SUN Ultra4
cores/threads	2x1	2x2	2x2	2x2	2x2	1x1	2x1
clock (GHz)	2.6	3.03	3.73	1.6	2.3	0.7	1.8
issue rate	3 (x86)	4 (rop)	3 (rop)	6	8	4	4
pipeline depth	11	14	31	8	17	6	14
inst in flight	72(rop)	96(rop)	126(rop)	inorder	200	48	inorder
on-chip\$ (MB)	2x1	4	2x2	2x13	1.9	0.064	2
transistor (10 ⁶)	233	291	376	1700	276	7.2	295
power (W)	95	80	130	104	100	17	90
SPECint 2000 per core	1942	(1556*)	1870	1474	1820	560	1300
SPECfp 2000 per core	2260	(1694 ⁺⁾	2232	3017	3369	580	1800

^{*3086/+2884} according to www.spec.org

At peak plus 3 years

	AMD Opteron 8360SE	Intel Xeon X7460	Intel Itanium 9050	IBM P5	IBM P6	Fijitsu SPARC 7	SUN T2
cores/threads	4x1	6x1	2x2	2x2	2x2	4x2	8x8
clock (GHz)	2.5	2.67	1.60	2.2	5	2.52	1.8
issue rate	3 (x86)	4 (rop)	6	5	7	4	2
pipeline depth	12/ 17	14	8	15	13	15	8/12
out-of-order	72(rop)	96(rop)	inorder	200	limited	64	inorder
on-chip\$ (MB)	2+2	9+16	1+12	1.92	8	6	4
transistor (10 ⁶)	463	1900	1720	276	790	600	503
power max(W)	105	130	104	100	>100	135	95
SPECint 2006 per-core/tota	14.4/170	22 /274	14.5/1534	10.5/197	15.8/1837	10.5/ <mark>2088</mark>	/142
SPECfp 2006 per-core/tota	18 5/156	22/142	17.3/1671	12.9/229	20.1/1822	25.0/1861	/111

On to Mainstream Parallelism in Multicores and Manycores



Remember, we got here because we need to compute faster while using less energy per operation