Building the Cross-Compilation Toolchain

Piptor F

To compile software for the Raspberry Pi, you need a cross-compilation toolchain. It's a collection of files and programs that you can run on your computer, and that produce a binary that can be executed on the Raspberry Pi.

If you want to do development on the Pi itself, you'll need a native toolchain as well. This is a toolchain that runs on the Pi, and produces binaries for the Pi.

Docker

I don't like to do a lot of installations on my main Linux box, so I build most of it inside of a Docker container. This has the added benefit that all builds are reproducible, and it's easy to undo the previous step or even start from scratch.

Installation

You need Docker to build the toolchain. Docker Compose is optional. You can find detailed installation instructions here:

- <u>DigitalOcean How to Install and Use Docker</u>
- <u>DigitalOcean How to Install Docker Compose</u>

Dockefiles

The actual Dockerfiles can be found on my GitHub, I'll briefly go over them on this page.

Building the toolchain using the provided shell scripts

If you just want to build the toolchain, without understanding how it works, and without changing anything to the configuration, you can use the shell scripts provided in the toolchain folder:

\$./toolchain/build-and-export-toolchain.sh <board>

Where <boxd> is one of the following:

- rpi: Raspberry Pi 1 or Zero, cross-compilation toolchain
- rpi-dev: Raspberry Pi 1 or Zero, cross-compilation toolchain and native toolchain
- rpi3-armv8: Raspberry Pi 3, 32-bit, cross-compilation toolchain
- rpi3-armv8-dev: Raspberry Pi 3, 32-bit, cross-compilation toolchain and native toolchain
- rpi3-aarch64: Raspberry Pi 3, 64-bit, cross-compilation toolchain
- rpi3-aarch64-dev: Raspberry Pi 3, 64-bit, cross-compilation toolchain and native toolchain

Building one toolchain took around 25 minutes on a 2018 Dell XPS i7-8750H, and 40 minutes on a 2017 Dell XPS i7-7700HQ.

The cross-compilation toolchain will be located in $toolchain/x-tools/\langle arch>-rpi*-linux-\langle abi>\rangle$, and the native toolchain will be in $toolchain/x-tools/HOST-\langle arch>-linux-\langle abi>\rangle/\langle arch>-rpi*-linux-\langle abi>\rangle$.

Deleting the toolchains

The toolchains are read-only, to prevent you from accidentally breaking them during a build. If you try to delete them using the usual methods, you'll get **Permission denied**. The solution is to make them writable first, using **chmod**.

The toolchain/clean.sh script will do this for you, and deletes all toolchains in the toolchain folder:

\$./toolchain/clean.sh

The toolchains will still be available in the Docker images used to build them. This means that next time you run the <code>build-and-export-toolchain.sh</code> script, it will finish in just a couple of seconds, as it just has to export the toolchain, it doesn't build it from scratch.

If you want to delete these Docker images as well (to save disk space, for instance), you can use **docker image ls** to inspect all images on your system, and then you can delete them using **docker image rm <image>**.

Detailed information about configuring and building toolchains

Crosstool-NG

The toolchain is built using Crosstool-NG

It is installed in a CentOS 7 Docker container, because CentOS 7 was the oldest OS that I had to run the toolchain on. In this context, oldest refers to the Linux kernel version and the glibc version. They are backwards compatible, so you can run software compiled for an old version on a computer with a newer version, but you can't run software compiled for a new version on a computer with an older version.

The following Dockerfile downloads, builds and installs Crosstool-NG to the ~/.local directory of the container.

Dockerfile

```
FROM centos:7 as ct-ng
      Install dependencies to build toolchain
    RUN yum -y update && \
yum install -y epel-release && \
yum install -y autoconf gperf bison file flex texinfo help2man gcc-c++
         libtool make patch ncurses-devel python36-devel perl-Thread-Queue bzip2 \
         git wget which xz unzip &&
 8
         yum clean all
10
11
     # Add a user called `develop` and add him to the sudo group
    RUN useradd -m develop && echo "develop:develop" | chpasswd && \
13
14
         usermod -aG wheel develop
15
    USER develop
16
17
    WORKDIR /home/develop
      Download and install the latest version of crosstool-ng
19
20
    21
22
23
    WORKDIR /home/develop/crosstool-ng
    RUN ./bootstrap && \
./configure --prefix=/home/develop/.local && \
         make -j$(($(nproc) * 2)) &&
25
        make install && \
cd && rm -rf crosstool-ng
26
    ENV PATH=/home/develop/.local/bin:$PATH
```

The list of dependencies can be found on Crosstool-NG's GitHub: https://github.com/crosstool-ng/crosstool-ng/crosstool-ng/crosstool-ng/blob/master/testing/docker/centos7/Dockerfile

Cross-Compilation Toolchain

The following Dockerfile builds the toolchain, all settings can be found in the config files on GitHub.

Dockerfile

```
FROM crosstool-ng-master as aarch64-toolchain

WORKDIR /home/develop
RUN mkdir /home/develop/RPi3 && mkdir /home/develop/src
WORKDIR /home/develop/RPi3
COPY config .config

RUN ct-ng build || { cat build.log && false; } && rm -rf .build

ENV TOOLCHAIN_PATH=/home/develop/x-tools/aarch64-rpi3-linux-gnu
ENV PATH=${TOOLCHAIN_PATH}/bin:$PATH
WORKDIR /home/develop
```

Raspberry Pi 3, 64-bit (AArch64)

This configuration is based on the aarch64-rpi3-linux-gnu sample that comes with Crosstool-NG: https://github.com/crosstool-ng/tree/master/samples/aarch64-rpi3-linux-gnu

I changed the GCC version to the latest stable one, and the Linux kernel and glibc versions to match the versions that the Ubuntu Server 18.04 image ships with.

The configuration file can be found on my GitHub: <a href="https://github.com/tttapa/RPi-Cpp-Toolchain/blob/master/toolchain/docker/rpi3/aarch64/aarch64-cross-toolchain/configuration-toolchain/configuration-toolchain/docker/rpi3/aarch64/aarch64-cross-toolchain/configuration-toolchain/configuration-toolchain/docker/rpi3/aarch64/aarch64-cross-toolchain/configuration-toolchain/configuration-toolchain/docker/rpi3/aarch64/aarch64-cross-toolchain/configuration-toolchain/docker/rpi3/aarch64/aarch64-cross-toolchain/configuration-toolchain/docker/rpi3/aarch64/aarch64-cross-toolchain/configuration-toolchain/docker/rpi3/aarch64/aarch64-cross-toolchain/configuration-toolchain/configuration-toolchain/docker/rpi3/aarch64/aarch64-cross-toolchain/configuration-toolchain/configura

Raspberry Pi 3, 32-bit (ARMv8)

This configuration is based on the armv8-rpi3-linux-gnueabihf sample that comes with Crosstool-NG: https://github.com/crosstool-ng/crosstool-ng/tree/master/samples/armv8-rpi3-linux-gnueabihf

Even though the CPU will be running in 32-bit mode, you can still use the ARMv8 NEON instructions, so I changed the compiler's default FPU flag to neon-fp-armv8. I haven't tested if it actually makes any difference.

I changed the GCC version to the latest stable one, and the Linux kernel and glibc versions to match the versions that the Ubuntu Server 18.04 image ships with. These are also supported on Raspbian Buster.

Raspberry Pi 1 & Zero, 32-bit (ARMv6)

This configuration is based on the armv6-rpi-linux-gnueabihf sample that comes with Crosstool-NG: https://github.com/crosstool-ng/crosstool-ng/crosstool-ng/crosstool-ng/tree/master/samples/armv6-rpi-linux-gnueabi

Native toolchain

Building the native toolchain for the Raspberry Pi is very similar.

Dockerfile

```
FROM aarch64-cross-toolchain as aarch64-cross-native-toolchain

RUN rm -rf /home/develop/RPi3 && mkdir /home/develop/RPi3
WORKDIR /home/develop/RPi3
COPY config .config
RUN ct-ng build || { cat build.log && false; } && rm -rf .build
WORKDIR /home/develop
```

The toolchain type is "Cross-Native", and is implemented as a special case of the "Canadian Cross" toolchain. It uses the cross-compilation toolchain that was built earlier. More information can be found in the <u>Crosstool-NG documentation</u>.

Customizing the toolchain

You can customize all previously mentioned toolchains by running ct-ng menuconfig on the corresponding configuration file. The easiest way to do this is by running it inside of crosstool-ng-master Docker container.

```
$ cd RPi-Cpp-Toolchain/
$ ./toolchain/docker/crosstool-ng-master/build.sh
$ docker run -it --rm --volume "$PWD/toolchain/docker:/mnt" crosstool-ng-master

[docker] $ cd /mnt/rpi3/aarch64/aarch64-cross-toolchain/ # Choose RPi model and architecture
[docker] $ cp config .config
[docker] $ ct-ng menuconfig
```

Now make your changes and save the result to .config.

```
[docker] $ mv config config.old # rename old configuration
[docker] $ mv .config config # replace with new configuration
[docker] $ exit
```

Now you can build the toolchain again using the build-and-export-toolchain.sh script, as explained earlier.