


# 08 Hardware Metering

Engr 399/599: Hardware Security

Andrew Lukefahr

*Indiana University*



Adapted from: Mark Tehranipoor of University of Florida

Course Website

enr599.github.io

Room  
Pass code:  
2-3-5

Write that down!

# Project 1: Hardware Trojan

Shareable  
board in  
LV

(running JTAG)

- Goal: “Corrupt” a working DES implementation
- We give you DES in HW
- You need to:
  - Deploy DES
  - Corrupt DES

Key points  
trick question  
→ might need  
2 rounds

# Group Assignments

#3

- Chris Sozio
- Will Fleming
- Clare Barnes

# 2

- Austin Parkes
- Max Harms
- Michael Foster

# |

- Trey Peterson
- Yifan Zhang
- Jack Ruocco

Due next  
Wednesday



**October 8th - 10th**

502 East Event Center  
502 E Carmel Dr  
Carmel, IN 46032

1st prize: \$4,000

2nd prize: \$2,000

3rd prize: \$1,000

HackIN is a unique Capture the Flag event revolving around hardware/firmware reverse engineering and analysis. At HackIN, you play the role of a security researcher with an elite organization. It's a race against time to analyze a mysterious device, discover vulnerabilities, and neutralize malicious capabilities – are you up for the challenge?

Seeking students engaged in Science, Technology, Engineering, and Math (STEM) fields/programs with hardware, firmware, and embedded software analysis skills. Juniors and Seniors highly encouraged!

Registration is free and includes access to a Game Kit that will put your skills to the test. Come to compete, learn, and network with industry experts!



**[www.hackin.tech](http://www.hackin.tech)**

Booz | Allen | Hamilton<sup>®</sup>



# Attacks

---




Software-only protection is not enough. Non-volatile memory technologies are vulnerable to invasive attack as secrets always exist in digital form

# Sharing a Secret with a Silicon PUF


---

Suppose Alice wishes to share a secret with the silicon PUF  
She has a challenge response pair that no one else knows,  
which can authenticate the PUF  
She asks the PUF for the response to a challenge



# Controlled PUF Implementation


---




# Background: Test and Yield

- Errors in fabrication process cause defects on chip which causes chip to malfunction.
- Chips are tested in order to detect defects
- Failing chips are discarded
- Fraction(percentage) of remaining good chips is called the yield.


$$\text{Yield} = \frac{\text{total chips} - \text{discarded chips}}{\text{total chips}}$$




- Foundry decides/predicts yield




# HW Threats




# HW Threats




# HW Threats



# HW Threats




# Chip Production Flow




- Little communication between IP Owner and Foundry.
- Foundry is trusted with full design.
- Responsible for production of requested amount of chips.
- IP holder provides foundry/assembly with all **test patterns** and **responses**.

# Chip Production Flow



- Foundry looks for its own profit.
- Once mask is produced, producing IC's is simple and cheap.
- Lack of communication makes it difficult for owner to track produced chips.


# Photomask (“Mask”) is the expensive part




# Need for Hardware Metering

---

- Need for better communication between IP Owner and foundry/assembly.



- Need for IP Owner to be able to track produced chips.



# Hardware Metering

---

- **Hardware metering (IC metering):**


- Set of security protocols that enable IP owners to achieve post-fabrication control over their ICs
- Methods attempt to **uniquely tag each chip** to facilitate tracing them
- Two main methods:
  - **Active metering**
  - **Passive metering**

- Could be applicable to PCBs, e.g., IoTs


---



# Taxonomy of Metering Methods




# Passive Metering



- ICs can be **passively monitored**.
- Can be achieved by physically identifying:
  - Serial numbers on chips
  - Storing unique identifiers in memory. These are called **Nonfunctional Identification**
    - E.g., Electronic Chip ID (ECID)
- Tagging an IC's functionality: **Functional Identification**

# Taxonomy of Metering Methods





# Nonfunctional Identification

---

- Unique ID is separate from the chip's functionality.
- Vulnerable to cloning and/or removal.
  - Once chip is tagged, foundry can copy same tag on other chips or simply remove tag so chip cannot be traced.
- Possible to overproduce.
  - Foundry can produce multiple chips with same tag.
  - Out of millions of chips, probability of finding two matching tags is small.
- Two main types:
  - Reproducible
  - Unclonable

# Nonfunctional Identification: Reproducible Identifiers

- Unique ID's are stored on the chip package, on die, or in a memory on-chip.
- Examples:
  - Indented serial numbers
  - Digitally stored serial numbers
- Advantages:
  - Do not depend on randomness
  - Easy to track / identify.
- Disadvantages:
  - Easy to clone/modify
  - Easy to overproduce



# Nonfunctional Identification: Unclonable Identifiers

---

- Uses random process variations in silicon to generate random unique numbers called **fingerprints**.
- If additional logic is needed to generate these value, the method is said to be **extrinsic**.
- If no additional logic is needed, the method is called **intrinsic**.
- Advantages:
  - Values cannot be reproduced due to randomness in process variations
- Disadvantages:
  - Foundry could overproduce ICs without knowledge of IP owner
    - i.e., these methods do not prevent counterfeiting. The over-produced chip can be detected if IP owner gets his/her hands on those chips by comparing the identifier on the chip with his/her database

# Unclonable Identifiers

---


## ■ Extrinsic methods:

- Require additional logic such as PUF (Physical Unclonable Function) or ICID
- ICID
  - Threshold mismatches in array of transistors incurred different currents and therefore unique random numbers.
- PUFs
  - Series of ring oscillators (ROs) generate random value due to process variations.

## ■ Intrinsic methods:

- Unique identification if external test vectors can be applied.
- Uses **IC leakage, power, timing, and path signatures** (unique due to process variations).
- Does not need additional logic and can be readily used on existing designs

# Taxonomy of Metering Methods



# Functional Metering

---


- Identifiers linked to chip's internal functional details during synthesis.
- Each chip's function gets a unique signature.
  - E.g., additional states added to generate same output
- Function unchanged from input to output
- Internal transactions unique to each chip
- Challenge in fabricating ICs with different paths from same mask.

# Functional Metering

---

- One method is fabricating chips from same mask and maintaining one programmable path.
  - E.g., Datapath could be programmed post-silicon.
  - IP Owner provides correct input/key combination to foundry to program chip post-silicon.
- Additional work proposes adding redundant states.
  - Programmable read logic enables selecting correct permutation for a control sequence.
- Drawbacks:
  - Testing such circuitry provides low coverage because the actual functionality of the chip is hidden during the test process by foundry and assembly
  - It requires the chip to go back to a trusted facility to be activated.


# Taxonomy of Metering Methods




# Active Metering

---

- Provides active way for designer to enable, control, or disable IC.
- Unlike passive metering, active metering requires ***communication between design house (IP owner) and foundry.***
- Two types:
  - Internal
  - External



# Taxonomy of Metering Methods



# Internal (Integrated) Active Metering

---

- Hides states and transition in the design that can only be accessed by designer.
- Locks are embedded within structure of computation model in hardware design in form of FSM.
- Adding additional states or duplicating certain states in FSM adds ability for designer to decide which datapath (sequence of states) to use post-silicon.
  - Since states are added, specific combinations are needed to bring FSM to correct output. Only IP owner knows such combination.


# State Space Obfuscation


## Basic Idea:

- A locking approach where normal behavior is enabled only upon appn. of a key
- Provable robustness


## Key Innovations:

- It obfuscates the state space AND the comb. logic
- Uses rich theory of automata to transform the state space & associated logic






# The Flow




- Transforms underlying state machine



- Affects the dynamic behavior of the machine

# Challenges


1. How to measure level of obfuscation?
2. How to measure the corresponding security benefit?



Improvement in Trojan coverage (w.r.t. defense against Trojan attacks)!


# Internal (Integrated) Active Metering

- States and transitions for controlling chips are integrated within functional specifications
- $K = \log_2(S)$  flip flops needed to implement  $S$  states
- Adding  $S_1$  states requires  $K_1 = \log(S_1 + S)$  flip flops
- Few additional flip flops can exponentially increase the number of states.




# Internal (Integrated) Active Metering

- PUF generates random values, it sends device to random FSM state.
- Only IP owner with knowledge of FSM can find correct sequence to set FSM to reset state.
- Storing a sequence on chip requires additional logic such as clocks and memory and also requires chip to wait until entire sequence has been shifted in.





# Taxonomy of Metering Methods




# External Active Metering

---

- Uses external asymmetric cryptographic techniques to lock IC.
- Cryptographic circuits rely on public and private keys to give IP owner control over activation/correct function of the circuit.
- Only IP owner knows private key to unlock IC's functionality or testability.


pub  
key



# Background: Public Key Cryptography

---


- Uses two large prime numbers  $p$  and  $q$  to generate co-prime  $n=pq$
- Private ( $d$ ) and public ( $e$ ) keys based on  $n$ ,  $p$ , and  $q$  are calculated
  - $(e,n)$  are shared, message is encrypted using  $(d,n)$
  - Decryption can be done using  $(e,n)$
- Security relies on magnitude of prime numbers  $p$  and  $q$



# EPIC: Ending Piracy of Integrated Circuits


---

- This technique tries to allow IP Owner to have control over number of chips activated.
- Uses public-key encryption to lock correct functionality of chip.
- At the gate level, XOR gates are placed on selected non-critical paths.
- Requires that every chip be activated with an external key
  - Only IP owner can generate key



*Roy et al., DATE 2008*

# EPIC High Level



# EPIC

---

- Embedded in RTL is public Master Key (MK-Pub)
  - XOR gates are controlled by Common Key. Correct Common Key unlocks circuit's correct functionality.
    - k-XOR gates need a common key of length k
  - TRNG (True Random Number Generator) used to generate Random Chip Keys (RCK) on start up.
    - Upon power-up each chip generates a pair of private and public RCKs (RCK-private, RCK-public) which are **burned into programmable fuses**.
  - Fab sends RCK-public to IP owner.
-


# Analysis of EPIC

- Effective against cloned ICs.
  - Cloned ICs: Due to TRNG, each IC will have a unique random key, even cloned ICs. ICs need IK in order to be functional which only IP owner can generate.
- Not efficient against Over-produced ICs, Out-of-Spec ICs and defective ICs.
  - Over-produced ICs:
    - Fab could claim low yield and request more IKs than needed.
    - IP Owner has no way to verify yield or number of functional chips.
    - Foundry can still send keys to IP Owner. Keys are randomly generated and have no information on functionality of the IC.
  - Out-of-Spec ICs:
    - Foundry/assembly can send out the chip that are out of spec (their ID is a correct one)
  - Defective ICs:
    - Once IP owner sends Input Key, chip is activated. If chip is defective, IP Owner has no more communication with foundry and chip is already activated.

# Reconfigurable Logic Barriers (LB)

---

- Separates inputs from outputs such that every path from input to output passes through a barrier.
- Logic barrier (LB) is a group of logic that allows correct path only if correct key is applied.



# Reconfigurable Logic Barriers

---


- IP owner decomposes IC functionality into  $F_{\text{fixed}}$  and  $F_{\text{reconfig}}$ .
  - $F_{\text{fixed}}$  is given to foundry to fabricate.
  - $F_{\text{reconfig}}$  is location of reconfigurable logic in combination with key needed to configure them correctly
  - $F_{\text{reconfig}}$  can be programmed into reconfigurable locations using a secure key.
-

# LB: Public Key Cryptography

---

- ICs use PUFs or TRNGs to generate a private and public random keys.
  - Public key from chip is sent to IP Owner
- IP Owner uses public key and its own private key to encrypt unlocking key.
  - Encrypted key is decrypted on chip using IP Owner's public key and chip's private key.

# LB: Partitioning of Design



# Logic Barriers Analysis

---

- **Effective against cloned ICs.**
  - Chips are only functional if correct key is entered which only IP Owner can provide
- **Ineffective against over-produced, defective, and out-of-spec ICs**
  - Foundry can lower yield in order to receive additional keys to activate functionality.
  - Key generated by chip does not have information about its functionality. Once key is applied, chip is functional.
- **Disadvantages:**
  - Look up tables require significant area overhead – 5X more than using XOR gates, and timing overhead.

# Test Seems to be a Challenge!

---



Designer

Test Patterns  
Test Responses

A large blue arrow pointing diagonally upwards and to the right, containing the text "Test Patterns" and "Test Responses".


Most techniques do not take into account the role “test” plays in the decision making process



Foundry & Assembly

# Secure Split-Test (SST)

- Adds multiple layers of communication between IP owner, foundry, and assembly
- Ensures that IP owner will know exactly how many chips pass the test and how many have failed.
- Only chips that IP Owner has deemed functional will be given a functional key.



# Secure Split-Test



Designer

1. Designer has already put in hooks in the design that can ensure non-functional operation if the correct key is not included in the chip
2. Detecting a non-functional chip is significantly easier than using PUF and dealing with process variations

*Secure Split Test*


1. Foundry will not be able to ship any functional chips to the market
2. Same for defective chips and out-of-spec chips; the chips are simply non-functional.




Foundry & Assembly

# XOR Mask

- Three-input XOR logic added to non-critical paths.
- XOR logic additional inputs are IN1 and IN2



# SST



# SST Analysis


---

- Effective against overproduced ICs, cloned ICs, and defective ICs
  - **Overproduced:**
    - IP Owner has control over number of TRNs received and TKEY/FKEYS sent to foundry/assembly
  - **Cloned:**
    - Chips are not functional unless FKEY has been produced by IP Owner
  - **Defective ICs:**
    - Foundry sends test results to foundry who checks results and decides if chip has correct test responses (chip is not yet functional at this stage)

# SST Analysis

## ■ Prevents out-of-spec ICs

- Some specifications cannot be determined from patterns testing alone. If a chip does not meet these specifications, it could be considered as a passing chip.
- With the addition of a few sensors on the chip, these specifications can be tested and checked by IP Owner during SST
- The IP owner will then be able to decide whether or not a chip passes the desired specifications in order to prevent out-of-spec ICs from going into market.



# Remote Activation of ICs Through FSM Modification

---


- FSM: Finite State Machine
- Sequence of inputs drive machine through different functional states
- Correct transitions give functional output



# FSM




**Original  
states** ●




- Correct transitions give functional output
- Adding states to FSM gives IP owner controllability over sequence to reach functional states.

# Boosted FSM (BFSM)




# Remote Activation of ICs




- Redundant states are added.
  - Far less states needed than BFSM
  - PUF response will send FSM to one of redundant states.
- 
- **Challenge:** PUF is yet to be reliable.

# Remote Activation of ICs



- RUB: Random Unique Block
- RUB must be stable – not change over time



- PUF (RUB) response is sent to IP Owner to generate key
- Key is then used to send FSM to correct state.

# Analysis of Boosted FSM and Remote Activation

---

- BFSM requires many additional FSM states.
- Remote activation only uses a few redundant states.
- Both use PUF which is affected by age, temperature, noise, etc.
- Both effective against cloned ICs but not effective against defective, over-produced, or out-of-spec ICs.

# References

- F. Koushanfar and G Qu. Hardware Metering. In DAC 2001, 2001
- Y. Alkabani and F. Koushanfar. Active Hardware Metering for Intellectual Property Protection and Security. In USENIX Security, 2007
- F. Koushanfar, G. Qu, and M. Potkonjak. Intellectual Property Metering. In IH, pp.81-95, 2001.
- J.A. Roy, F. Koushanfar, and I.L. Markov. EPIC: Ending Piracy of Integrated Circuits. In EDAA, 2008.
- A. Boumgarten, A. Tyagi, and J. Zambreno. Preventing IC Piracy Using Reconfigurable Logic Barriers. In IEEE Design and Test of Computers, 2010
- M. Tehranipoor and C. Wang. Introduction to Hardware Security. Springer, pp. 103-120, 2012
- Y. Alkabani, F. Koushanfar, M Potkonjak. Remote Activation of ICs for Piracy Prevention and Digital Rights Management. In IEEE, 2007
- M. Tehranipoor. VLSI Design Verification and Testing: Test Economics.  
[http://www.engr.uconn.edu/~tehrani/teaching/test/03\\_Test%20Economics%20and%20Product%20Quality.pdf](http://www.engr.uconn.edu/~tehrani/teaching/test/03_Test%20Economics%20and%20Product%20Quality.pdf)
- R.L. Rivest, A. Shamir, and L. Adleman. A Method for Obtaining Digital Signatures and Public-Key Cryptosystems. Communication of the ACM, 1978.
- G. Contreras, T. Rahman, and M. Tehranipoor, "Secure Split-Test for Preventing IC Piracy by Untrusted Foundry and Assembly," Int. Symposium on Defect and Fault Tolerance in VLSI Systems (DFT), 2013.
- T. Rahman, D. Forte, Q. Shi, G. Contreras, and M. Tehranipoor, "CSST: Preventing Distribution of Unlicensed and Rejected ICs by Untrusted Foundry and Assembly," IEEE Int. Symposium on Defect and Fault Tolerance Symposium (DFTS), Oct. 2014.
- 
-