Università degli studi di Modena e Reggio Emilia Dipartimento di Ingegneria Enzo Ferrari

Automotive Connectivity

Indice

1	Intr	roduction	1
	1.1	Structure and Content	1
	1.2	Intra-Vehicles	2
	1.3	Architectures	2
	1.4	Basic Knowledge	3
		1.4.1 Multiple Access Protocols	3
		1.4.2 Bit Coding	5
2	Intr	ra-Vehicles	6
	2.1	ISO/OSI Layers	6
	2.2	Network Topology - The Bus System	8
	2.3	Controller Area Network	9
	2.4	Controller Area Network Flexible Data-Rate	20
	2.5	Local Interface Network	21
	2.6	FlexRay	4
	2.7	Ethernet	0
		2.7.1 Access	0
		2.7.2 Ethernet Frame	31
		2.7.3 Ethernet in the Autonomotive Domain	2
	2.8	EMI	34
	2.9	10BASE-T1S	5

Capitolo 1

Introduction

1.1 Structure and Content

• Module 1:

- 1. intra-vehicles communications: nodes, sensors, ECU
- 2. **signal busses**: CAN, LIN, FlexRay, MOST, Ethernet [T1/T1S]
- 3. car domain and OS

• Module 2:

- 1. *inter-vehicles communications*: V2V and V2X (car is a node)
- 2. wireless technologies: Bluetooth, LoRa, C-V2X, IEE 802.11p (bd)
- 3. application, messages, broadcast, GPS

Different **domain** or **application** needs different *communications protocols*, is important to understand how each nodes in domain communicate each other (inside the car).

1.2 Intra-Vehicles

From the 80's, where the car's control unit are isolated an there was a dedicated wires connect sensors and actuators with less electronic than now, until the reach the greatest goal of evolution in the automotive sector: autonomous drive. The complexity of the number of connection from each ECU's to the other, also the number of ECU's for each car, is growing. While the number of signal increase in a liner way, the connection between ECU's is growing with a quadratic complexity $O(n^2)$.

If we examine the evolutions of the ECUs number inside an "Audi A6" we can observe that in 1997 it has 5 ECUs and in the 2007 it has 50 ECUs, instead the "Tesla M3" in the 2017 has 70 ECUs. The quadratic increase of ECUs number, however has reach a cap for two main reason: the cost and the space inside the car. Traditionally one ECUs is responsible of one task, but nowadays it could be two type of trends:

- 1. distributed of function across ECUs
- 2. integration of multiple function in one ECU

1.3 Architectures



Figura 1.1: Domain Architecture

- 1. central domain controller (\mathbf{P}) or high performance computer
- 2. ability to handle more complex functions
- 3. cost optimization
- 4. cable harness is rigid and expensive



Figura 1.2: Zonal Architecture

- 1. local ethernet per zone (G)
- 2. ultra high-speed secured backbone between zone
- 3. centralized software
- 4. central computer storage

1.4 Basic Knowledge

1.4.1 Multiple Access Protocols

In the ISO/OSI stack the first layer is the *data link layer* and it is used, in a computer network, to transmit the data between two or more devices or nodes. The data link layer it is normally split in two different sub-layer:

- 1. data link control: is a reliable channel for transmitting data over a dedicated link using various techniques such as framing, error control and flow control of data packets in the computer network.
- 2. **multiple access protocol**: if the link doesn't connect only two nodes, but multiple nodes can access to the physical link is possible that two or more nodes start to communicate in the same time, and it could be possible to have collision and cross talk between two or more devices. In this case the *multiple access protocol* is required to reduce the collision and avoid cross talk between the channel.



In this course it could be useful to see in dept three type of *Multiple Access Protocols*: the first one is *Carrier Sense Multiple Access - Collision Detection*, next is the *Carrier Sense Multiple Access - Collision Avoidance* and the last one is

the *Time Division Multiple Access*. In the autonomotive domain indeed there is needs to have a bus topology network and it is important to avoid collision.

CSMA/CA - Carrier Sense Multiple Access - Collision Avoidance: the idea is that before transmitting, a node first listens the shared medium to determine if the channel is not used (idle), if not it could start to transmit, but the problem start when two nodes begins to write on the nodes together. The Collision Avoidance part get in the game when two or more device try to write in the channel simultaneously in this case if another nodes is sense the transmitting node wait for a period of time (usually random) before re-start the writing procedure.

CSMA/CD - Carrier Sense Multiple Access - Collision Detection: is use in early Ethernet technology for LAN. It use carrier-sense to detect if the media is idle and it is combined with collision-detection in which a transmission station sense collision by detecting transmissions from other stations while it is transmitting a frame.

- 1. is the frame ready for the transmission? if not, wait for the frame.
- 2. is medium idle? if not, wait until it becomes ready.
- 3. start transmission and monitor for collision during transmission.
- 4. did a collision occur? if yes, go to collision detecting procedure.
 - (a) continue the transmission (with **jam signal**) until minimum packet time is reached to ensure that all receiver detect the collision.
 - (b) increment re-transmission counter.
 - (c) was the maximum number of transmission (time out) attempts reached? if yes, abort transmission.
 - (d) restart from 1.
- 5. reset the transmission counter and complete frame transmission.

TDMA - Time Division Multiple Access: is a channel access method for share-medium networks. It allow several users to share the same frequency channel by dividing the signal into different time slot. The users transmit in rapid succession, one after the other, each using its own time slot. This type of access to the physical medium has higher syncronization overhead tha CSMA.

1.4.2 Bit Coding

The first thing is to introduce the *Electromagnetic Inferference - EMI* that is a disturbance generate by an external source that affects an electrical circuit by *electromagnetic induction*, *electromagnetic couplig* or from conduction. For reduce EMI there are three possible way: add shield to wires, used twisted pair wiring or use coding with few rising/falling signal edges. At this point we can introduce the two main coding techniques: *NRZ - Non Return to Zero* or *Manchester Coding* (original variant).



Figura 1.3: Non Return to Zeros

In the **Non Return to Zero** the digital ones is, usually, the positive voltage, while digital zeros are represented by other significat

condition, like negative voltage.

Figura 1.4: Manchester Coding

In the *Manchester Coding* (original variant) the digital ones is the rising edge of the signal, instead the digital zeros are represented by the falling edge of the signal.

In both case it must be identify the digital zeros or one on the rising edge of the clock, so the syncronization problem between the clock of the transmitting node and the receiving nodes it is foundamentals.

Capitolo 2

Intra-Vehicles

2.1 ISO/OSI Layers

In telecommunication the idea is to divide each steps into layers starting from the application layer to the fisical ones, every layers have different function and it needs different protocols. Each layer can interact with the one that is above or below it and the communication of two layers follow rigid and specifics rules. Nowadays the standard de iure is the ISO/OSI, instead the the de facto standard is the TCP/IP that relax the rigid guidelines. The ISO/OSI has seven layers (bottom to top):

- 1. **physical layer**: specifies the mechanical and electrical properties to transmit bit (in the "real" world) and to control time synchronization.
- 2. data link layer: checked the transmission of the frame, error checking, frame synchronization and flow control.
- 3. **network layer**: it is used for the transmission of the packets, it is also know as *IP Layer*, in is normally use in ethernet.
- 4. **transport layer**: reliable end to end transport segment, you can manage how the data have to flow. In 99.99 % of the car domain it doesn't need.
- 5. **session layer**: establish and tear down sessions.
- 6. **presentation layer**: define the syntax and the semantics of information.
- 7. application layer: uses data transmitted via physical medium.

In the first module we need only two layers: **physical layer** and **data link layer**. We have to study the behaviour of the communication protocols like CANBus, LIN, FlexRay, MOST and Ethernet in this two layers. Starting from the **transmission medium**, normally the hardware pieces that we use to interact with is:

- transceiver: is used to "convert" analog signal to bits (brain less).
- controller: control the communication (brain full).

Initially the idea is to focus a little more on CANBus, the *Physical Layer*: is compose by three component: Physical Signaling - PLS, Physical Medium Attachment - PMA and Media Dependant Interface - MDI.

- 1. **physical signaling**: the main purpose is to understand the bit encoding/decoding (if it is *NRZ* or *Manchester*) and to mantein the synchronization all over the network, every transceiver it must have a the same clock source. The synchronization is the most important things both for the bit encoding/decoding and for don't introduce delay in the communication.
- 2. **physical medium attachment**: driver/receiver characteristics based on the communication protocol.
- 3. **media dependant interface**: the connector for access to the physical medium.

Data Link Layer is compose by two component: Logical Link Control - LLC and Medium Access Control - MAC.

- 1. logical link control: from now on, we start to call frame the data that are send/receiver from the physical channel. It is used for acceptance filtering that permit to decide if a frame is important for the application above the controller and if not discard it. This component include also the overload notification and recovery management in the case there is an error on the communication they could ask to a re-transmit the data.
- medium access control: is purpose is error detection it could check the data encapsulation/decapsulation, frame coding and error detection/signaling/handling.

2.2 Network Topology - The Bus System



Figura 2.1: Line Topology Figura 2.2: Star Topology Figura 2.3: Ring Topology

In the **Line** topology also In the **Star** topology know like Bus topology each node is connected connected to a central by interface connectors to node called hub or switch. data to another, the data a single center cable. It is It has an higher cost and passes through each cheaper than the others and it has lower complexity but it is not very robust.

complexity than the bus topology, but it is much more robust (if the hubgoes down it is a *single* point of failure).

The **Ring** topology is a every peripheral nodes is daisy chain in a closed loop. When a node sends intermediate node on the ring until reach its destination (it use only one direction). It is not too munch expensive, but has higher complexity (if you want add a new node it could be troublesome).

In the autonomotive domain it is chosen the **Bus Topology**, why? The first thing is that in the automotive industry it is mandatory to maintain lower the cost. The busses are very cheap for the materials, the weight and the volume. In the bus topology it is possible to have higher modularity, you can plug & play a node "when you want", in that way it is possible to have fully customizability inside the vehicles. The last things is that there is shorter development cycles. In the autonomotive field there is three main component:

1. **transceiver**: it is the physical layer definition and implement the first layer of the ISO/OSI stack.

- 2. **communication controller**: it is the communication protocol and implement the first and the second layers of the *ISO/OSI* stack.
- 3. **ECU**: also know like **electronic controller unit** and implement the last layer of the *ISO/OSI* stack, the **application** layer.

The idea is to made possible to abstract the application layer in order to, if you want, change the first two layers, for example from CANBus to FlexRay, but nothing change at the application layer.

2.3 Controller Area Network

The Controller Area Network also know as CAN is a vehicle bus standard to enable efficient communication. It is originally developed to reduce complexity and cost of electrical wiring. CANBus use an electrical medium over wires and a broadcast data transmission. CANBus use the CSMA/CR like multiple access protocol, it means carrier sense multiple access collision resolution protocol, that permit to CANBus to have arbitration on the channel access. In this way there is random access to the physical channel, but it is impossible that there is some collision on the communications.



Figura 2.4: CANBus Network Topology

The **CANBus** network is compose by two wires: **CAN High** and **CAN Low**. The data is transmit over the wire using the *potential difference* on each transceiver. Two twisted wires are use because it gives to the protocol **noise resistance** and **increase resiliency**, if one brakes, CAN Low *survives*. At the end of the wire in the bus topology there are place two impedance R_T of 120 Ω . Each CANBus node has three element:

- CAN Transceiver: is directly connected to the medium access by two pin (one on CANH and the other on CANL). It has the goal to translate the voltage level into bits (during the reception) and send it to the CAN Controller and translate bit into voltage level (during the transmission).
- CAN Controller: is connect to the *CAN Transceiver* by two pin (CANTX and CANRX) and is scope is to: message completion, control bus access, transmission and reception of the message, bit timing.
- Microcontroller: application software communicating with other ECUs via messages over the bus.

	CAN Message												
1 bit	29 bit	1 bit	6 bit	0-64 bit	16 bit	2 bit	7 bit						
SOF	CAN-ID	RTR	Control	Data	CRC	ACK	EOF						

- **SOF**: is the **start of frame** is always set to *dominant 0* to tell the other ECUs that a message is coming.
- CAN-ID: contains the message identifier lower value have higher priority.
- RTR: is the remote transmission request allow to ECUs to "request" message from other ECUs.
- Control: informs the length of the *Data* in bytes (0 to 8 bytes), two bits are reserved for future implementation.
- Data: contains the actual data values, which need to be "scaled" or converted to be readable an ready for analysis.
- CRC: is the cyclic rendundancy check is used to ensure data integrity.
- ACK: is the acknoledgement this slot indicates if the CRC is OK all the bits must be recessive (logical 1).
- **EOF**: is the **end of frame** marks the end of CAN message all the bits must be recessive (*logical 1*).

The CANBus use a message passing technologies, it means, when a message is sent through the wire by an ECUs all the CAN Transceiver reciver the message, but if a application layer of one of another ECUs doesn't need that message it could ignore or if it need it, it could accept that message, using the CAN-ID as identifier. In other word the CANBus use the **receiver-selective** form of addressing. In the CANBus

the bit logic is pretty simple, each ECUs reads the wire (through a buffer) and each ECUs can write on the line (through a transistor), in this way the **basic state** is **up** (+5V or logical ones) when one or more ECUs want to set signal low turn on transistor conductive (diode), this connect the bus to signal ground in this case the bus level is **low** (0V, or logical zeros) indipendently from other ECUs. The **0** is named **dominant level**. It could be see the CANBus wires as **logical AND** (if an ECUs write zeros the state is zeros).

The CANBus is an **event-driven** bus system, it means that there is no need to wait a scheduled time slot for sending data and there is the possibility of collision over the communication channel. If an ECU X registers an event e it is authorized to access the busses immediately and send data, but if another ECU Y is alredy transmitting data, then X waits. We want to calculate how long it takes a message to be sent, the first thing to do is to calculate the maximum bits number that is allow in a CAN Message: 130 bits. The CANBus can have lots of different bus speed $B \in \{5k \cdot \frac{bit}{s}, 125k \cdot \frac{bit}{s}, 250k \cdot \frac{bit}{s}, 500k \cdot \frac{bit}{s}, 800k \cdot \frac{bit}{s}, 1M \cdot \frac{bit}{s}\}$, let's consideration der the average $B = 500k \cdot \frac{bit}{s}$, the resulting time for sending a message is equal to $T_x(time) = \frac{M}{B} = \frac{130bit}{500k \cdot \frac{bit}{s}} = 0.25ms$, but what is happen if two ECUs start the communication on the same time? Let's consider the case where there are three ECUs X, Y, Z, X and Y are waiting Z because it is using the medium access, but probably they start to transmit in the same time when the busses is free, in this case we have a collision, the solution is how CANBus implement the CSMA-CR, carrier sense multiple access - collision resolution, the two ingredients are how we can see the CAN busses (like a logical AND) and the CAN-ID to the logic prioritizing.

- 1. ECU X want to send: it must check if the bus is free (carrier sense \mathbb{CR}).
- 2. if it is busy the ECU have to wait.
- 3. when the bus is free, it could happen that one or more ECUs are ready to transmit, and start the communication together (multiple access MA).
- 4. the last incredient is how to avoid the impending damage born from the collsion? $(collision\ resolution\ -\ CR) \rightarrow bitwise\ arbitration.$

All the **bitwise arbitration** is base on the first two field of the CANBus Message:

SOF (it is for everyone a **dominant bit**: θ) and **CAN-ID** (it could be 11 bits, in the standard CANBus and 29 bits for the extended ones). We know that in CANBus the ones with the lower ID has the greatest priority. Another basic know is that the CANBus network work like a wired-AND so if a nodes wrote on the bus a $\boldsymbol{\theta}$ the entire network has logically low value, also if someone else try to wrote a logically high value.

	ID 10	ID 9	ID 8	ID 7	ID 6	ID 5	ID 4	ID 3	ID 2	ID 1	ID 0
A	1	1	0	0	1	0	0	1	1	0	0
bus	1	1	0	0	1	0	0	1	1	0	0
В	1	1	0	1			node B				

wired-and bus logic												
sender a	sender b	bus level										
1	1	1										
1	0	0										
0	1	0										
0	0	0										

aı	rbitra	tion logic
sender	bus	interpretation
0	0	\mathbf{next}
0	1	fault
1	0	stop
1	1	next

value of the CANBus network is logically high, the bus work as wired-AND and the logic $\boldsymbol{\theta}$ si the **dominant** value, so if the sender a or arbitration with another sender and sender b send over the bus the $\boldsymbol{\theta}$ value, it win the arbitration with the

other sender.

We have three knowledge: the default We alredy know that CANBus is carrier sense if the sender sent over the network a logical 1 but read logical $\boldsymbol{\theta}$ knows that it losts the have to stops the transmission.

Priorities instead of Collision: the bus logic and arbitration logic not only prevent collision, it ensure a priority-controlled bus access: smaller ECUs ID, higher priority.

CANBus Message Integrity: the idea is to use the Data field to generate a CRC to permit the check on the integrity of the message, but wee need some basic knowledge before start: *polynomial division* and *XOR*.

Polynomial Reminder Theorem: given two polynomials M(x) (the dividend) and G(x) (the divisor), asserts the existence (and the uniqueness) of a quotient Q(x) and a remainder R(x) such that:

$$M(x) = Q(x) \cdot G(x) + R(x)$$

N.B. the degree of R(x) is strictly lower than the degree of G(x).

In the calculation of *CRC* depends on the arithmetic of modulo 2 polynomial. A modulo 2 polynomial is like:

$$a_n \cdot x^n + a_{n-1} \cdot x^{n-1} + \dots + a_2 \cdot x^2 + a_1 \cdot x + a_0$$

 $a = \{0, 1\} \quad \forall a \in \{a_0, a_1, \dots, a_n\}$

An example of the representation of a binary polynomial is like: $x^3 + x + 1 = 1011$. If exist an x with a certain exponent e like: x^e in the binary representation the position e is fill with a 1.

\oplus	0	1
0	0	1
1	1	0

The XOR is a digital logic gate that gives a true (logical 1) when the input number is odd, otherwise is false (logical 0).

CRC Encoding:

- 1. we need to transmit a *n* bits **message** M(x): deg(M(x)) = n 1.
- 2. we have a m + 1 bits **generator** G(x): deg(G(x)) = m.
 - the **remainder** R(x) of the division $\frac{M(x)}{G(x)}$ will have strictly lower degree respect to G(x) and, in the worst case, the maximum value will be deg(R(x)) = m 1.

- R(x) can always expressed with m bits.
- 3. add m zeros at the end of M(x): this means to do the following $M(x) \cdot x^m$.
- 4. divide the **new message** $M(x) \cdot x^m$ with the **generator** G(x) to obtain the **reminder** of m bits called CRC.
- 5. the final message B(x) is equal to $M(x) \cdot x^m + CRC$: this means to add the CRC bits at the end of the message replacing the m zeros padded before.

Example:

$$M(x) = 1101011011$$
 $G(x) = 10011$ $(m = 4)$
 $M(x) \cdot x^m = 11010110110000$

The final message B(x) is equal to: $B(x) = \underbrace{1101011011}_{M(x)} \underbrace{10011}_{R(x)}$

CRC Decoding

- 1. the receiver **acquire** $B(x) = M(x) \cdot x^m + CRC$.
- 2. the receiver knows G(x).
- 3. the receiver divides the whole message by the generator: $B(x) = \frac{M_x \cdot x^m + CRC}{G(x)}$
- 4. if the receiver obtain **no reminder** the transmission was successfully (no errors detected).

CRC Error Resistance: consider an error E(x) occurs on the transmission channel and the receiver B(x) + E(x) instead of simply B(x), when the CRC logic can failed? The problem occure when E(x) is multiple of G(x) in this way $\frac{B(x)+E(x)}{G(x)}$ gives no reminder, so the receiver mark B(x) + E(x) as a correct message. To avoid this problem we need to choose in appropriate way the generator G(x), this is the reason why the G(x) it is standard in the CRC Encoding (by the protocol).

CRC Design Priciples: G(x) is extremely important in a way that E(x) cannot easily be multiple of G(x). For **detecting single bit of error**:

- $E(x) = x^i$ for error in i-th bit.
- if G(x) has more than 1 term it cannot divide x^i .

Mathematical theory help us to desing powerful G(x) with fancy characteristics, in CANBus the generator is: $G(x) = x^{15} + x^{14} + x^{10} + x^8 + x^7 + x^4 + x^3 + 1$. sender and receiver must to agree on the generator.

CANBus bit coding: we know that there are two main bit coding algorithm: Non return to Zero (is less noisy) and Manchester coding (carries the clock with him on every single bit). In CANBus is important the clock for the synchronization between nodes, so it could be thinks that Manchester coding is the best one to be used. The Manchester coding has a big problem: the clock drift problem. The clock drift problem is caused by natural variations of quartz (environment), for the correct working of CANBus the receiver must sample signal at the right time instant. Clock drift leads to de-synchronization of the clock that comport a bad interpretation of bit sequence. In order to avoid this type of problem, it is necessary to reduce the rising/falling edge of the signal, so it is advise the usage of NRZ.


Problem

When using NRZ coding, sending many identical bits leaves no signal edges that could be used to compensate for the clock drift.

Solution

Insertion of extra bits after n consecutive identical bits $\to Bit \ Stuffing$. In CANBus n=5.

Time Quanta (TQ): is the smallest time slice it could be count.



It is normally divided into four kind of field: synchronization segment, propagation segment, phase buffer segment 1 and phase buffer segment 2. A bit it is compose from 8 to 25 time quanta and it is the smallest discrete timing resolution used by CANBus node. Each TQ is generated by programmable divide of the oscillator. Each segment is composed by an integer number of TQs and segments are non-overlapping. The bitrate is selected by programming the width of the TQ and the number of TQ in the various segments.

- synchronization segment: it is used to synchronization the various node, only the receiver nodes have to adjust their own clock during the receiver of the payload. The length of the segment is always 1.
- 2. **propagation segment**: if one node transmits to another faraway ones (geographically speaking) how we can synchronize the first TQ of the *synchronization segment*? The **propagation segment** allow the signal propagation across the network and through the nodes. This segment it could be compose from 1 TQ to 8 TQs and it is necessary to compensate for signal propagation delays on the bus line and through the electornic interface circuit of the bus nodes.
- 3. buffer segment one & buffer segment two: this two segment it could have a programmable length between 1 TQ and 8 TQs. Between this two segment there is the sample point. This point is used from the node to sample the information through the bus channel. This two segment are used to the resynchronization, in some circumstances we need to compensate the oscillator tolerances within the different CAN nodes.

Jump Width

The jump width is the amount of TQs that we can add (in the phase buffer segment one) or remove (in the phase buffer segment two) that permit to adjust the length during the re-synch.

Nowadays in many CANBus Modules the propagation time segment and phase buffer segment one are combined in a new segment named timing segment 1 (the phase buffer segment two is renamed in timing segment 2).

Dynamic Sample Position: programming the sample point position allow **flexibility**:


- 1. *early sample*: decrease the sensitivity to oscillator tolerances and permit to use lower cost oscillators.
- 2. *late sampling*: allow maximum signal propagation time (**reachability**), maximum bus length and poor bus topologies can be handled (more *time quanta* in the *propagation segment*).

CANBus Error: there are six possible different error:

- 1. **Bit-Error**: write logical 0 over the bus and sense a logical 1 (or viceversa). In general if a transmitting ECU detects an **opposite bit** level on the CANBus we have a **bit-error**.
 - ECU writes logical θ and reads logical θ very bad error.
 - ECU writes logical 1 and reads logical 0 → it is "possible" when there is
 the bitwise arbitration or it is expected that the bus state will change to
 dominant as other nodes acknoledge the message
- 2. **Stuff Error**: reminder on the *bit stuffing*: it needs one opposite bit stuffed each 5 consecutive bits, it is used only from the beginning of the frame to the CRC delimiter. From the ACK field to the end is used the **fixed-form bit fields**. Each node receiving a message that breaks the bit stuffing rules will transmit an **error frame**.
- 3. **Format Error**: if one of the *CRC delimiter field*, *ACK field* or *End Of Frame* have an divergent form, the receiving nodes perform a check to ensure these are

correct, if not send a error frame.

- 4. *CRC Error*: *CRC delimiter field* is the only weapon to ensure the integrity of the message, it depends on the polynomials division, if the *CRC checks* (the reminder of message plus CRC divided by the Generator) is not 0 it generates a **CRC Error**.
- 5. **General Error**: the seven **recessive** bits in the *EOF* are used to inform the CANBus nodes about a general error occurred during the transmission. If a receiver node found out an error, it writes six consecutive "**zeros**" forcing an error in the current frame that can be captured from everyone.



6. **ACK Error**: it happen when no one of the receiver nodes write on the busses an **dominant** bit in the ACK field of the transmitting frame.

CANBus ACK

The transmitting nodes, after the DATA and the CRC, write in the bus a *logical 1* (**recessive**) and it hopes, in the mean time, that **at least** one receiver write a *logical 1* (**dominant**) in the ACK bit, if not the transmitting node (reads on the bus *logical 1*) and will resend the message.

There is two bits for the *ACK field* to absorbe possible delay. We need to allocate space for "not perfect synchronized receiver" to push a **dominant** bit on the bus.

The ACK is triggered by another node so the voltage value could be slightly different. These technologies have some implication on the CANBus protocol, like:

• also the recevier node/s can (have to) transmit during specific frame slot (the *ACK field* or *EOF*).

- all the receiver must check the *CRC* very quickly in order to know if the message have pass the integrity checks.
- a CANBus network *must have at least two nodes to work*, because with only one node no one can acknoledge a message.

For the calculous of the time in the circuit (in the CANBus controller) it is normally used $time\ crystal$, the smallest ICs possible is the $8MHz\ time\ crystal$. If we consider each clock cycle for the smallest unit in CANBus ($time\ quanta$) for each bit we have at least $8\ TQs$ (up to $25\ TQs$).

If we minimize the size of the of a single bit we have to consider 8 TQs. $\frac{8MHz}{8TQs} = 1MHz$ we can obtain the maximum bitrate for the CANBus.

CANBus Recap:

- 1. **low cost**: the price is **always** a costraint, with it's two wires has a good price-performance tradeoff. This enables the use of CANBus outside the autonomotive domain.
- 2. *reliability*: CANBus has sophisticated error detection and handling mechanisms. If failed the integrity checks of the frame it could repeat the sending of the same data and every nodes are informed about the error. CANBus has high immunity to EMI.
- 3. *latency*: CANBus means real-time (soft) because there is low latency between transmission and request and actual start of transmission. CANBus has inherent arbitration on message priority due to the bitwise arbitration logic.
- 4. *flexibility & speed*: CANBus nodes are "plug & play" and there are not limited number of nodes into a network.
- 5. *multi master operation*: (ECU peers) each nodes is able to access to the bus, if there is a fulty nodes the bus communication is not disturbed and they switch-off from the communication.
- 6. **broadcast capabilities**: message can be sento to single/multiple nodes and every node simultaneously receive common data.
- 7. Standardize: ISO-DIS 11898 (high speed), ISO-DIS 115192-2 low speed.

2.4 Controller Area Network Flexible Data-Rate

The CAN-FD is the evolution of the CANBus. The mainly disadvantages of CANBus are: 1MHz in some circumstances are not enough and only 8 bytes of payload are often restrictive. To be compliant to standard CANBus the arbitration phase (before the data) and ACK phase (after the data) must be mantein to the same frequency. CAN-FD data frames can be transmitted with two different bit-rates, in the arbitration phase and in the ACK phase the bitrate depends on the network topology and it is limited to 1MHz, instead in the data phase the bitrate is limited by the transceiver characteristics:

- support a bitrate higher than 1MHz.
- support a payload larger than 8 bytes.


The increase of the frame speed is possible by shortening the bit time. We define the **Bit Rate Shift - BRS** is the bit in the control field used to inform **ALL** the nodes that sender will transmit faster in the data transmission phase and the **Extended Data Lenght - EDL**. The implication of this change are:

- larger payload: it needs more *CRC bits* to maintain the robustness of CANBus, to have more *CRC bits* it needs a larger generator.
- shorter bit-time: new bit-time logic in the state machine, a factor is introduce between the bit time during arbitration phase and the bit-time during the transmission. The tipical factor is $8 \to \text{considerering}$ the fastest rate of CANBus arbitration phase and the longer header and CRC, the final result is more or less 6MHz.

	Arbitration Col			Con								End of frame							
I D L E	L E (11 b			ID (11 bit)	r 1	I D E	E D r 0	r 0	BRS	E S I	DLC (4 bit)	DATA (0 to 64 byte)	15-, 17-, or 21-bit CRC	D	A C K	D	EOF (7 bit)	IFS (3 bit)	I D L E
	Arbitration phase								Da	ata transmission phase			Arbitration phase						

To summarize the **CAN-FD** could reach in the *data transmission phase* the speed transmission of 6MHz and the possibility of sending a payload large up to **64 bytes**

2.5 Local Interface Network



The *LIN* is a message oriented communication protocol that is design and developed to create something cheaper than low speed CANBus, this purpose it was reach partaway. Like the CANBus, LIN, works on the first two layers of the ISO/OSI stack (physical and data link layers), but it uses a **master-slave** concept. Using this architecture, the LIN busses, can have only a quartz on the master that manage the synchronization on all the LIN network, to achieve without waste space on the vehicle, the master of the LIN mesh is part of the CANBus network. This is the reason why the LIN is also know like a *sub bus* of CANBus (Fig. 2.5). As result on the communication we can say that LIN network is self-synchronize, but for this reason it needs to have lax timing constraints because only one node (the **master**) can schedule the order of the transmission. In addition to this, LIN busses, has other difference between CANBus:

- LIN is a **bidirectional one-wire line** and it can reach the frequency up to 20kHz (CANBus can reach 1MHz).
- The **voltage** for the analog transmission over the channel is 40V, instead the CANBus is only up to 5V.
- Bit Transmission is *UART* like:

bit transmission									
1 bit	8 bits	1 bit							
start bit	data bits	stop bit							

In LIN protocol there is a rudimental error detection on the frame, it is a sum of all the payload bytes modulo 256 (in this way it can be stored into a single byte), but also on the channel, if a sender while monitoring the bus, read an unexpected state abort the

communication without correction. The **schedule** of the network is hardcoded on the **master's firmware** (static), the scheduler determines which node have to transmit in that specific slice of time. This consent to have a channel that is **mostly deterministic**, permit to the slave to not know how it is schedule the transmission and allow to the master to *change the order of transmission runtime*.

LIN Message: is divide into two component: Message Header and Message Response. The first one is sent over the channel by the master node and is like a request for a specific slave, instead it is possible to see the second one like the slave response.

Mess	sage He	eader	Message Response					
Break	Sync	Identifier	Data Check					
14 bits	4 bits 8 bits 8 bits		0 to 64 bits	8 bits				

Description for each field:

- 1. **Break**: is composed by two kinds of fields: **13 low bits** (*dominant*) and **1 high** bit (*recessive*) that is used to delimiter of the field.
- 2. **Sync**: is used to *synchronize* the bit timing of the slave, it is always **0x55** (01010101) in this way follow the profile of the clock.
- 3. *ID*: is used to individuate the right slave, different from the CANBus, in this identifier there are parity bit, to have a check on the integrity of the ID, because in this case is very important for the correct master-slave communication (protected field). ID is divide in two segment:
 - from LIN 2.0 the first 2 MSB bits define the length of the payload that could be 2, 4 or 8 bytes, previous version of LIN used static 8 bytes data length.
 - **4**[**6**] **bits** for the "real" ID.
 - 2 parity bits:

$$p_0 = id_0 \oplus id_1 \oplus id_2 \oplus id_4$$
$$p_1 = id_1 \oplus id_3 \oplus id_4 \oplus id_5$$

4. **Data**: contain the payload, and it was send by the slave selected by the master with the length settled in the identifier.

5. *Checksum*: is this case, like said before, the checksum is the sum of all the payload bytes modulo 256, in that way it can be stored into a single byte.

	d_7	d_6	d_5	d_4	d_3	d_2	d_1	d_0
carry		1	1	1		1		
first byte	0	0	0	1	0	1	1	0
second byte	0	0	0	1	0	1	1	1
third byte	0	0	0	1	0	1	1	0
forth byte	0	0	0	1	0	0	0	0
fifth byte	0	0	0	1	0	0	0	0
checksum	0	1	1	0	0	0	1	1

LIN nodes are typically bundled in clusters each with a master that interfaces with the backbone CANBus. We have introduce the general message/frame format, but in LIN protocol there are six kinds of different messages (encoded in the ID field):

- 1. **Unconditional Frames**: is defined by the ID 0x00 0x3B and is the default type of frame, where the master send a header over the channel and the request slave reply.
- 2. **Event Trigger Frames**: is defined by the ID **0x00 0x3B**, the master polls multiple slaves, the slave who have updated data response, if there are collision, the communication end and the master switch to *unconditional frame*.
- 3. **Sporadic Frames** is defined by the ID 0x00 0x3B in this type of message the master acts like a slave and reply to his own requests.
- 4. **Diagnostic Frames** is defined by the ID 0x3C 0x3D with this frame the communication becomes request-response, the 0x3C is the ID where the master make the request, instead the 0x3D is the ID where the slave reply.
- 5. *User Defined Frames* is define by the ID 0x3E is a user-defined frame and it can contain any types of information.
- 6. Reserved Frames: ID 0x3F

There is a reason why the **data lenght** of CANBus and LIN are equal. Since LIN is also called CANBus sub system, for compatibility reason the payload is equal. Message of CANBus can be sent over LIN too and viceversa.

2.6 FlexRay

This communication protocol it is design with the purpose of be more reliable in therm of determinism than the CANBus. To achieve this goal is necessary to increase the price, the **FlexRay** is more expensive than CANBus. The CANBus is prone to failure, the reason behind this problem are the topology of the network: if the channel is broken a frame could not be delivery to every node on the bus and there are not rendundant link to avoid that.


The CANBus frequency is up to 1MHz (6MHz is we consider CAN-FD), but it slowly regard the requirement of the modern vehicles (X-by-Wire) moreover in CANBus there isn't the assurance that each node have its own time slice where it can write over the busses, this is because in CANBus there is **not** a firmware that implement the **event scheduler**

X-by-Wire


Drive/Brake/Steer can be bypassed as an **input device**, the reason behind that is that it must be possible to control the vehicle's actuation not only in manual but also in autonomous drive. This involves two main requirements: **error** tolerances and time-determinism requirements

Requirements:

• more resilient topology: the topology of FlexRay is a *star-type* with bus termination where the maximum distance between each line is up to 24 m. Each connection is compose by two lines for rendundancy purpose (boost error tolerance). The second line it could be used or for backup or it could use to increase the frequency speed of transmission. Each line can reach the speed of 10Mbps if we split the message between the two line we can obtain the increase of the velocity by a 2x factor. Like in CANBus the default value is set to logical 1 but the wire are unshielded twisted pair.



• **Determinism**: the busses operates using a **scheduler** that is replicated for each **time cycle** during the communication time. Each cycle is divided into four different kinds of *segment*:



- static segment: is preallocated into slices that permit to be more deterministic and allow time constraints addressing, for each nodes are allocated a fixed period (at least one) into this segment.
- dynamic segment: the idea is like CANBus, nodes can take control over the channel if the bus is available (not busy) can simulate an behaviour event triggered, normally used for event based data that does not require determinism.
- symbol windows: typically used for network maintenance and signaling for starting the network.
- network idle time: a know "quite" time used to maintain synchronization between node clocks.
- different message class: allow latency-constraints.
- other characteristics:
 - differential signaling on each pair of wires reduces the effects of external noise on the network without expensive shielding.
 - flexray busses require termination at the ends.
 - need synchronization clock in sender and receiver (and timestamp synchronization).

FlexRay - Access to the bus

The FlexRay uses the **TDMA** as methods for access to the physical medium, this allow to all nodes to be synchronize (using the same clock). In *TDMA* each nodes on the bus has its own turn (time slice of the cycle) where it can write on the channel. The *TDMA* permit **time consistency** that allow to the communication protocol **determinism**

(one of the constraints).

While for the CANBus each node has to know only the communication baudrate, in this case nodes on flexray must know the schedule of the transmission and all pieces of the network to communicate. For the autonomotive domain, there the majority of nodes are *embedded system* where there are a closed configuration and it is difficult to change firmware after the installation, this can be a problem for the scalarity of the system. After the installation it's difficult to add a nodes in the flexray network, but thanks to this there isn't the necessary for the nodes to use a discovery algorithm to understand how the network is composed.

For a **TDMA** network (such flexray) to work correctly, all node must be configured in a correct way:

- in the *embedded system* it is mandatory to have static configuration network.
- there is an increment of **relaibility**, but **not flexibility** this leads to configuration tradeoff:
 - data rate
 - deterministic volume
 - dynamic data volume
 - topology




Figura 2.5: FlexRay Cycle

The **static segment** must be decided a **priori**, in this way it is possible to divide the segment in at least n slot, n as the number of the nodes on the network. In each slot a defined node can transmit data over the bus, while the other nodes have to wait their slot. In this way we know exactly when the nodes are going to transmit, this is the definition of **determinism**. The disadvantage of the TDMA is that, if the ECU number two doesn't have nothing to transmit we loose resource (time). If we are all

synchronize there is no way to collide.

The **dynamic segment** use a different protocol to access the medium, in this segmente there is the same as the CANBus, **CSMA-CR**. The segment is divide in mini-slot, each slot is assign to a specific ECU, for each slot the defined ECU sense from the bus if no one is broadcasting data, it can start to transmit, when it ends the time slice, the transmission interrupt, but the next node scheduled sensing the bus finds a busy state, so it doesn't start to sense. It could be possible for some ECU to lose each type of arbitration on the *dynamic segment*.

FlexRay: Frame

FlexRay communicate using frames, each frame contains data as bytes $b_0...b_{m-1}$, and




Figura 2.6: FlexRay Message Frame

it is structure like:

- first bit is part of the start signal (BSS0).
- second bit is part of the start signal (BSS1).
- \bullet there are n bits for the data.

The framing of data is usefull for the **determinism**. Bit stuffing is not used in this standard because given the number of bytes of a message you exactly know the amount of frame bits needed for the transmission.

FlexRay: Message Format

5 bits	11 bits	7 bits	11 bits	6 bits	n bits	24 bits
control	frame ID	lenght	header	cycle	payload	CRC
bits			CRC	counter		

• Control Bits:

1. b_0 is reserved: always **zero**.

- 2. b_1 is used to distinguish static/dynamic slot message.
- 3. b_2 is *null frame* indicator, it is used to sign a frame without payload (also in static segment).
- 4. b_3 is *synch frame* indicator, it is used to sign a frame used for synchronizing clock, to be send to a few "reliable" ECUs.
- 5. b_4 is *startup frame* indicator, used for synchronization during bootstrap and it is send by cold start node.
- Frame ID: identify the message.
- Lenght: lenght of payload.
- Header CRC
- *Cycle Counter*: global counter of passed bus cycles (it is important to always know the time).
- Payload: it could be from 0 to 254 bytes.
- *CRC*: it is used to check the integrity of payload.

Time Synchronization

In flexray is important to have synchronize all the clock of each node inside the network, it is important to have synchronize bit clock and slot counter. In flexray we do not want to have a dedicated node for that goal, but something distributed. Normally there are three nodes named *cold start node*. This node has the goal of the *cold start procedure* that consist:

- 1. check if bus is *idle*, if not abort the trasmission.
- 2. **transmit wakeup** [**WUP**] pattern, if collision occure abort the transmission, if not this is the **leading cold start node**.
- 3. the leading cold start node send over the bus a Collision Avoidance Symbol (CAS). It need to start regular operation (cycle counter start at 0) and to set the BSS0 and BSS1.
- 4. after the **CAS** signal the other cold stard node wait **4 frames** before start the cycle counter (for the other cold node start from 4).
- 5. they start the regular operation (BSS0 and BSS1).
- 6. other regular ECUs wait other 2 frames before starting regular operation.

leading	wup	wup	cas	0	1	2	3	4	5	6	7	8	•••
cold	wup	abort						4	5	6	7	8	
cold	abort							4	5	6	7	8	
regular										6	7	8	
regular										6	7	8	

Comparison

bus	LIN	CANBus	FlexRay
speed	40 kbit/s	1 Mbit/s	10 Mbit/s
cost	\$	\$\$	\$\$\$
wires	1	2	2 o 4

If we consider the typical application:

- LIN: body electornics \rightarrow mirrors, power seats, accesories.
- CANBus: powertrain \rightarrow engine, transmission, ABS.
- FlexRay: High performance Powertrain Safety $(X-by-Wire) \rightarrow$ active suspension, adaptive cruise control, keep lane assist.

2.7 Ethernet

2.7.1 Access

Ethernet use the CSMA/CD:

- CS: carrier sense: if the bus is busy, do not transmit.
- MA: multiple access: once the transmission start, the collision could be happen.
- CD: collision detection: listen while communicate the information over the bus, if collision detected, jamming sequence.

The problem of this type of access protocol has a problem when two distant node (geographically speaking) try to transmit information in the same time, if the propagation of the frame over the channel it's not fast enough, the two different node does not see the collision and generate some noise. This case cannot happen into the autonomotive domain, it is necessary to fulfill a codition: the frame sent from a node have to reach all node before the end of the transmission.

The idea is to work on the **frame lenght** and the **bitrate**, ad example given the minimum frame lenght is possible to reach the maximum bitrate.

Hp

F is the minimum frame size, b is the maximum bitrate

c speed of light (considering a costant)

 $t = \frac{F}{B}$ is the transmission time

 $l = c \cdot t \ l$ is the distance covered by the transmission


 $d_{max} = \frac{l}{2} d_{max}$ is the maximum length between the two terminal node.

Ethernet **topology** was born like bus, but nowadays it have changed into star topology; and it is configured using a switch (layer 2 TCP/IP) or router (layer 3 TCP/IP) with all node connected with this component.

Ethernet use a two different type of **bit coding**:

• Non Return to Zero Inverted - NRZI (used until the ethernet version of 10Mbps): the logical value is determine by the transition of the analog signal. If


nothing change in the signal the logical value is $\mathbf{0}$, but during the falling edge it will be a logical $\mathbf{1}$.



• 4B5B (used in the ethernet version of 100Mbps): it maps 4 bits words in 5 bits group on the medium, using the NRZ (it prevents three equal consecutive bit).

Data (4B)	Codeword (5B)	Data (4B)	Codeword (5B)
0000	11110	1000	10010
0001	01001	1001	10011
0010	10100	1010	10110
0011	10101	1011	10111
0100	01010	1100	11010
0101	01011	1101	11011
0110	01110	1110	11100
0111	01111	1111	11101

2.7.2 Ethernet Frame



- *Preamble*: it is used for the synchronization of the receiver (it is 8 bytes that alternating a logical 1 and a logical 0).
- **Destination MAC Address**: is the destination address of the ethernet interface (MAC Medium Access Control).
- Source MAC Address: same as before, but for the source node.
- *Ethernet*: is used for indicating the type of data carried by the frame or the data lenght.

- *Data*: the data to be transmitted, for the incapsulating principes, inside it can be found the **iP Datagram**.
- *CRC*: is compose by 4 bytes of **checksum** that it is calculate on the entire frame (without the *preamble*). It is always calculated like the remainder of the polynomial division by a known generator (*Standardize CRC-32*):

$$x^{32} + x^{26} + x^{23} + x^{22} + x^{16} + x^{12} + x^{11} + x^{10} + x^8 + x^7 + x^5 + x^4 + x^2 + x + 1$$

2.7.3 Ethernet in the Autonomotive Domain

Previous Limititation

Ethernet is a 45 years old protocol, but why only now is started the interest by the autonomotive company in the ethernet protocol, and why it coul be used right now?

- 1. ethernet produce to much EMI/RFI, for the automotive domain.
- 2. ethernet could not guarantee latency down to the low microsecond range (not guarantee time constraints).
- 3. ethernet did not have a way to control bandwidth allocation to different stream so it could not be used to transmit shared data from multiple types of source.
- 4. ethernet did not have a way of synchronizing time between device and having multiple device sample data at the same time.


The big need for find something like ethernet for the autonomotive domain is the current research for the fully *autonomous driving* system for the autonomotive. For resolve these problem, it was born the *One-Pair EtherNet (OPEN) alliance*, that is a non-profit, special interest group (SIG) of mainly automotive industry and technology providers collaborating to encurage wide scale adoption of Ethernet-based communication.

Solution

- 1. change the waveform of the signal we can put into effect the reduction of the EMI/RFI. The 100Base-tx is the standard ethernet that has fast rise time and three clear level, instead; in the 100Base-t1 the autonomotive ethernet it is posssible to notice that there is slower rise time and the three level are not very clear. This reduce the pollution of the EMI/RFI.
- 2. to solve the problem to not guarantee time constraints, the *autonomotive* ethernet define a new type of frame: **Express Packet**. For these type of frame is possible to interrupt the transmission of existing packet, that can be reload when the express packet have finished its work. The express packet can "guarantee" latency in the single microsecond range.
- 3. to control bandwidth allocation to different streams it is create two different approachs:
 - *stream reservation*: simple reservation protocol to notify the various network elements in a path to reserve the resources necessary to support a particular stream.
 - queuing and forwarding for AV bridges: defines rules to ensure that an AV stream will pass through the network within the delay specified in the reservation.
- 4. for the synchronization purpose it is created a new standard *IEEE* 802.1AS (Timing and Synchronization for Time-Sensitive Application in Bridge Local Area Network), this standard introduce simpler/faster methods for choosing master clocks.
- (bonus) to reduce the wiring needed in a car, it is choose to use Power on Ethernet - PoE

2.8 EMI

ElectroMagnetic Interface is a disturbance generated by an external source that affects an electrical circuit by electromagnetic induction, electrostatic coupling or conduction.



An **analog** signal absorbs the noise that becomes part of the information itsef. The only possibility is *filtering* (Fourier Theory).

In **digital** signal if you are still able to distinguish well between **1** and **0** you are **errorless** and **noise immune**. If the noise "change" a bit there is an **error**.

All intra- and inter-vehicle communications are digital, but there is an easy experiment to realize how much a car is "noise"

2.9 10BASE-T1S