Università degli studi di Modena e Reggio Emilia Dipartimento di Ingegneria Enzo Ferrari

Automotive Connectivity

Indice

1	Intr	oduction	ion		1
	1.1	Structu	ture and Content		1
	1.2	Intra-V	Vehicles		2
	1.3	Archite	tectures		2
	1.4	Basic I	Knowledge		3
		1.4.1	Multiple Access Protocols		3
		1.4.2	Bit Coding		5
2	Intr	a-Vehi	icles		6
_					
	2.1	ISO/O	OSI Layers	•	6
	2.2	Networ	ork Topology - The Bus System		8
	2.3	Contro	oller Area Network		9

Capitolo 1

Introduction

1.1 Structure and Content

• Module 1:

- 1. intra-vehicles communications: nodes, sensors, ECU
- 2. **signal busses**: CAN, LIN, FlexRay, MOST, Ethernet [T1/T1S]
- 3. car domain and OS

• Module 2:

- 1. *inter-vehicles communications*: V2V and V2X (car is a node)
- 2. wireless technologies: Bluetooth, LoRa, C-V2X, IEE 802.11p (bd)
- 3. application, messages, broadcast, GPS

Different **domain** or **application** needs different *communications protocols*, is important to understand how each nodes in domain communicate each other (inside the car).

1.2 Intra-Vehicles

From the 80's, where the car's control unit are isolated an there was a dedicated wires connect sensors and actuators with less electronic than now, until the reach the greatest goal of evolution in the automotive sector: autonomous drive. The complexity of the number of connection from each ECU's to the other, also the number of ECU's for each car, is growing. While the number of signal increase in a liner way, the connection between ECU's is growing with a quadratic complexity $O(n^2)$.

If we examine the evolutions of the ECUs number inside an "Audi A6" we can observe that in 1997 it has 5 ECUs and in the 2007 it has 50 ECUs, instead the "Tesla M3" in the 2017 has 70 ECUs. The quadratic increase of ECUs number, however has reach a cap for two main reason: the cost and the space inside the car. Traditionally one ECUs is responsible of one task, but nowadays it could be two type of trends:

- 1. distributed of function across ECUs
- 2. integration of multiple function in one ECU

1.3 Architectures



Figura 1.1: Domain Architecture

- 1. central domain controller (\mathbf{P}) or high performance computer
- 2. ability to handle more complex functions
- 3. cost optimization
- 4. cable harness is rigid and expensive



Figura 1.2: Zonal Architecture

- 1. local ethernet per zone (G)
- 2. ultra high-speed secured backbone between zone
- 3. centralized software
- 4. central computer storage

1.4 Basic Knowledge

1.4.1 Multiple Access Protocols

In the ISO/OSI stack the first layer is the *data link layer* and it is used, in a computer network, to transmit the data between two or more devices or nodes. The data link layer it is normally split in two different sub-layer:

- 1. data link control: is a reliable channel for transmitting data over a dedicated link using various techniques such as framing, error control and flow control of data packets in the computer network.
- 2. **multiple access protocol**: if the link doesn't connect only two nodes, but multiple nodes can access to the physical link is possible that two or more nodes start to communicate in the same time, and it could be possible to have collision and cross talk between two or more devices. In this case the *multiple access protocol* is required to reduce the collision and avoid cross talk between the channel.



In this course it could be useful to see in dept three type of *Multiple Access Protocols*: the first one is *Carrier Sense Multiple Access - Collision Detection*, next is the *Carrier Sense Multiple Access - Collision Avoidance* and the last one is

the *Time Division Multiple Access*. In the autonomotive domain indeed there is needs to have a bus topology network and it is important to avoid collision.

CSMA/CA - Carrier Sense Multiple Access - Collision Avoidance: the idea is that before transmitting, a node first listens the shared medium to determine if the channel is not used (idle), if not it could start to transmit, but the problem start when two nodes begins to write on the nodes together. The Collision Avoidance part get in the game when two or more device try to write in the channel simultaneously in this case if another nodes is sense the transmitting node wait for a period of time (usually random) before re-start the writing procedure.

CSMA/CD - Carrier Sense Multiple Access - Collision Detection: is use in early Ethernet technology for LAN. It use carrier-sense to detect if the media is idle and it is combined with collision-detection in which a transmission station sense collision by detecting transmissions from other stations while it is transmitting a frame.

- 1. is the frame ready for the transmission? if not, wait for the frame.
- 2. is medium idle? if not, wait until it becomes ready.
- 3. start transmission and monitor for collision during transmission.
- 4. did a collision occur? if yes, go to collision detecting procedure.
 - (a) continue the transmission (with **jam signal**) until minimum packet time is reached to ensure that all receiver detect the collision.
 - (b) increment re-transmission counter.
 - (c) was the maximum number of transmission (time out) attempts reached? if yes, abort transmission.
 - (d) restart from 1.
- 5. reset the transmission counter and complete frame transmission.

TDMA - Time Division Multiple Access: is a channel access method for share-medium networks. It allow several users to share the same frequency channel by dividing the signal into different time slot. The users transmit in rapid succession, one after the other, each using its own time slot. This type of access to the physical medium has higher syncronization overhead tha CSMA.

1.4.2 Bit Coding

The first thing is to introduce the *Electromagnetic Inferference - EMI* that is a disturbance generate by an external source that affects an electrical circuit by *electromagnetic induction*, *electromagnetic couplig* or from conduction. For reduce EMI there are three possible way: add shield to wires, used twisted pair wiring or use coding with few rising/falling signal edges. At this point we can introduce the two main coding techniques: *NRZ - Non Return to Zero* or *Manchester Coding* (original variant).



Figura 1.3: Non Return to Zeros

In the **Non Return to Zero** the digital ones is, usually, the positive voltage, while digital zeros are represented by other significat

condition, like negative voltage.

Figura 1.4: Manchester Coding

In the *Manchester Coding* (original variant) the digital ones is the rising edge of the signal, instead the digital zeros are represented by the falling edge of the signal.

In both case it must be identify the digital zeros or one on the rising edge of the clock, so the syncronization problem between the clock of the transmitting node and the receiving nodes it is foundamentals.

Capitolo 2

Intra-Vehicles

2.1 ISO/OSI Layers

In telecommunication the idea is to divide each steps into layers starting from the application layer to the fisical ones, every layers have different function and it needs different protocols. Each layer can interact with the one that is above or below it and the communication of two layers follow rigid and specifics rules. Nowadays the standard de iure is the ISO/OSI, instead the the de facto standard is the TCP/IP that relax the rigid guidelines. The ISO/OSI has seven layers (bottom to top):

- 1. **physical layer**: specifies the mechanical and electrical properties to transmit bit (in the "real" world) and to control time synchronization.
- 2. data link layer: checked the transmission of the frame, error checking, frame synchronization and flow control.
- 3. **network layer**: it is used for the transmission of the packets, it is also know as *IP Layer*, in is normally use in ethernet.
- 4. **transport layer**: reliable end to end transport segment, you can manage how the data have to flow. In 99.99 % of the car domain it doesn't need.
- 5. **session layer**: establish and tear down sessions.
- 6. **presentation layer**: define the syntax and the semantics of information.
- 7. application layer: uses data transmitted via physical medium.

In the first module we need only two layers: **physical layer** and **data link layer**. We have to study the behaviour of the communication protocols like CANBus, LIN, FlexRay, MOST and Ethernet in this two layers. Starting from the **transmission medium**, normally the hardware pieces that we use to interact with is:

- transceiver: is used to "convert" analog signal to bits (brain less).
- controller: control the communication (brain full).

Initially the idea is to focus a little more on CANBus, the *Physical Layer*: is compose by three component: Physical Signaling - PLS, Physical Medium Attachment - PMA and Media Dependant Interface - MDI.

- 1. **physical signaling**: the main purpose is to understand the bit encoding/decoding (if it is *NRZ* or *Manchester*) and to mantein the synchronization all over the network, every transceiver it must have a the same clock source. The synchronization is the most important things both for the bit encoding/decoding and for don't introduce delay in the communication.
- 2. **physical medium attachment**: driver/receiver characteristics based on the communication protocol.
- 3. **media dependant interface**: the connector for access to the physical medium.

Data Link Layer is compose by two component: Logical Link Control - LLC and Medium Access Control - MAC.

- 1. logical link control: from now on, we start to call frame the data that are send/receiver from the physical channel. It is used for acceptance filtering that permit to decide if a frame is important for the application above the controller and if not discard it. This component include also the overload notification and recovery management in the case there is an error on the communication they could ask to a re-transmit the data.
- medium access control: is purpose is error detection it could check the data encapsulation/decapsulation, frame coding and error detection/signaling/handling.

2.2 Network Topology - The Bus System



Figura 2.1: Line Topology Figura 2.2: Star Topology Figura 2.3: Ring Topology

In the **Line** topology also In the **Star** topology know like Bus topology each node is connected connected to a central by interface connectors to node called hub or switch. data to another, the data a single center cable. It is It has an higher cost and passes through each cheaper than the others and it has lower complexity but it is not very robust.

complexity than the bus topology, but it is much more robust (if the hubgoes down it is a *single* point of failure).

The **Ring** topology is a every peripheral nodes is daisy chain in a closed loop. When a node sends intermediate node on the ring until reach its destination (it use only one direction). It is not too munch expensive, but has higher complexity (if you want add a new node it could be troublesome).

In the autonomotive domain it is chosen the **Bus Topology**, why? The first thing is that in the automotive industry it is mandatory to maintain lower the cost. The busses are very cheap for the materials, the weight and the volume. In the bus topology it is possible to have higher modularity, you can plug \mathcal{E} play a node "when you want", in that way it is possible to have fully customizability inside the vehicles. The last things is that there is shorter development cycles. In the autonomotive field there is three main component:

1. **transceiver**: it is the physical layer definition and implement the first layer of the ISO/OSI stack.

- 2. **communication controller**: it is the communication protocol and implement the first and the second layers of the *ISO/OSI* stack.
- 3. **ECU**: also know like **electronic controller unit** and implement the last layer of the *ISO/OSI* stack, the **application** layer.

The idea is to made possible to abstract the application layer in order to, if you want, change the first two layers, for example from CANBus to FlexRay, but nothing change at the application layer.

2.3 Controller Area Network

The Controller Area Network also know as CAN is a vehicle bus standard to enable efficient communication. It is originally developed to reduce complexity and cost of electrical wiring. CANBus use an electrical medium over wires and a broadcast data transmission. CANBus use the CSMA/CR like multiple access protocol, it means carrier sense multiple access collision resolution protocol, that permit to CANBus to have arbitration on the channel access. In this way there is random access to the physical channel, but it is impossible that there is some collision on the communications.



Figura 2.4: CANBus Network Topology

The **CANBus** network is compose by two wires: **CAN High** and **CAN Low**. The data is transmit over the wire using the *potential difference* on each transceiver. Two twisted wires are use because it gives to the protocol **noise resistance** and **increase resiliency**, if one brakes, CAN Low *survives*. At the end of the wire in the bus topology there are place two impedance R_T of 120 Ω . Each CANBus node has three element:

- CAN Transceiver: is directly connected to the medium access by two pin (one on CANH and the other on CANL). It has the goal to translate the voltage level into bits (during the reception) and send it to the CAN Controller and translate bit into voltage level (during the transmission).
- CAN Controller: is connect to the *CAN Transceiver* by two pin (CANTX and CANRX) and is scope is to: message completion, control bus access, transmission and reception of the message, bit timing.
- Microcontroller: application software communicating with other ECUs via messages over the bus.

CAN Message									
1 bit	29 bit	1 bit	6 bit	0-64 bit	16 bit	2 bit	7 bit		
SOF	CAN-ID	RTR	Control	Data	CRC	ACK	EOF		

- **SOF**: is the **start of frame** is always set to *dominant 0* to tell the other ECUs that a message is coming.
- CAN-ID: contains the message identifier lower value have higher priority.
- RTR: is the remote transmission request allow to ECUs to "request" message from other ECUs.
- Control: informs the length of the *Data* in bytes (0 to 8 bytes), two bits are reserved for future implementation.
- Data: contains the actual data values, which need to be "scaled" or converted to be readable an ready for analysis.
- CRC: is the cyclic rendundancy check is used to ensure data integrity.
- ACK: is the acknoledgement this slot indicates if the CRC is OK.
- **EOF**: is the **end of frame** marks the end of CAN message.

The CANBus use a message passing technologies, it means, when a message is sent through the wire by an ECUs all the CAN Transceiver reciver the message, but if a application layer of one of another ECUs doesn't need that message it could ignore or if it need it, it could accept that message, using the CAN-ID as identifier. In other word the CANBus use the **receiver-selective** form of addressing. In the CANBus the bit logic is pretty simple, each ECUs reads the wire (through a buffer) and each ECUs can write on the line (through a transistor), in this way the **basic state** is **up**

(+5V or logical ones) when one or more ECUs want to set signal low turn on transistor conductive (diode), this connect the bus to signal ground in this case the bus level is low (0V, or logical zeros) indipendently from other ECUs. The **0** is named **dominant** level. It could be see the CANBus wires as logical AND (if an ECUs write zeros the state is zeros).

The CANBus is an **event-driven** bus system, it means that there is no need to wait a scheduled time slot for sending data and there is the possibility of collision over the communication channel. If an ECU X registers an event e it is authorized to access the busses immediately and send data, but if another ECU Y is alredy transmitting data, then X waits. We want to calculate how long it takes a message to be sent, the first thing to do is to calculate the maximum bits number that is allow in a CAN Message: 130 bits. The CANBus can have lots of different bus speed $B \in \{5k \cdot \frac{bit}{s}, 125k \cdot \frac{bit}{s}, 250k \cdot \frac{bit}{s}, 500k \cdot \frac{bit}{s}, 800k \cdot \frac{bit}{s}, 1M \cdot \frac{bit}{s}\}$, let's consideration der the average $B = 500k \cdot \frac{bit}{s}$, the resulting time for sending a message is equal to $T_x(time) = \frac{M}{B} = \frac{130bit}{500k \cdot \frac{bit}{s}} = 0.25ms$, but what is happen if two ECUs start the communication on the same time? Let's consider the case where there are three ECUs X, Y, Z, X and Y are waiting Z because it is using the medium access, but probably they start to transmit in the same time when the busses is free, in this case we have a collision, the solution is how CANBus implement the CSMA-CR, carrier sense multiple access - collision resolution, the two ingredients are how we can see the CAN busses (like a logical AND) and the **CAN-ID** to the logic prioritizing.

- 1. ECU X want to send: it must check if the bus is free (carrier sense \mathbb{CR}).
- 2. if it is busy the ECU have to wait.
- 3. when the bus is free, it could happen that one or more ECUs are ready to transmit, and start the communication together (multiple access MA).
- 4. the last incredient is how to avoid the impending damage born from the collsion? $(collision\ resolution\ -\ CR) \rightarrow bitwise\ arbitration.$

All the *bitwise arbitration* is base on the first two field of the CANBus Message: **SOF** (it is for everyone a **dominant bit**: θ) and **CAN-ID** (it could be 11 bits, in the standard CANBus and 29 bits for the extended ones). We know that in CANBus

the ones with the lower ID has the greatest priority. Another basic know is that the CANBus network work like a wired-AND so if a nodes wrote on the bus a $\boldsymbol{\theta}$ the entire network has logically low value, also if someone else try to wrote a logically high value.

	ID 10	ID 9	ID 8	ID 7	ID 6	ID 5	ID 4	ID 3	ID 2	ID 1	ID 0
A	1	1	0	0	1	0	0	1	1	0	0
bus	1	1	0	0	1	0	0	1	1	0	0
В	1	1	0	1	node B loses $arbitration$ \rightarrow stop sending and re-start sensing						

wired-and bus logic						
sender a	sender b	bus level				
1	1	1				
1	0	0				
0	1	0				
0	0	0				

arbitration logic						
sender	interpretation					
0	0	\mathbf{next}				
0	1	fault				
1	0	stop				
1	1	next				

We have three knowledge: the default We alredy know that CANBus is value of the CANBus network is logically high, the bus work as wired-AND and the logic $\boldsymbol{\theta}$ si the **dominant** value, so if the sender a or arbitration with another sender and sender b send over the bus the $\boldsymbol{\theta}$ value, it win the arbitration with the other sender.

carrier sense if the sender sent over the network a logical 1 but read logical $\boldsymbol{\theta}$ knows that it losts the have to stops the transmission.

Priorities instead of Collision: the bus logic and arbitration logic not only prevent collision, it ensure a priority-controlled bus access: smaller ECUs ID, higher priority.

CANBus Message Integrity: the idea is to use the Data field to generate a CRC to permit the check on the integrity of the message, but wee need some basic knowledge before start: polynomial division and XOR.

Polynomial Reminder Theorem: given two polynomials M(x) (the dividend) and G(x) (the divisor), asserts the existence (and the uniqueness) of a quotient Q(x) and a remainder R(x) such that:

$$M(x) = Q(x) \cdot G(x) + R(x)$$

N.B. the degree of R(x) is strictly lower than the degree of G(x).

In the calculation of *CRC* depends on the arithmetic of modulo 2 polynomial. A modulo 2 polynomial is like:

$$a_n \cdot x^n + a_{n-1} \cdot x^{n-1} + \dots + a_2 \cdot x^2 + a_1 \cdot x + a_0$$

 $a = \{0, 1\} \quad \forall a \in \{a_0, a_1, \dots, a_n\}$

An example of the representation of a binary polynomial is like: $x^3 + x + 1 = 1011$. If exist an x with a certain exponent e like: x^e in the binary representation the position e is fill with a 1.

+	0	1
0	0	1
1	1	0

The XOR is a digital logic gate that gives a true (logical 1) when the input number is odd, otherwise is false (logical 0).

CRC Encoding:

- 1. we need to transmit a *n* bits **message** M(x): deg(M(x)) = n 1.
- 2. we have a m + 1 bits **generator** G(x): deg(G(x)) = m.
 - the **remainder** R(x) of the division $\frac{M(x)}{G(x)}$ will have strictly lower degree respect to G(x) and, in the worst case, the maximum value will be deg(R(x)) = m 1.
 - R(x) can always expressed with m bits.
- 3. add m zeros at the end of M(x): this means to do the following $M(x) \cdot x^m$.

- 4. divide the **new message** $M(x) \cdot x^m$ with the **generator** G(x) to obtain the **reminder** of m bits called CRC.
- 5. the final message B(x) is equal to $M(x) \cdot x^m + CRC$: this means to add the CRC bits at the end of the message replacing the m zeros padded before.

Example:

$$M(x) = 1101011011 \qquad G(x) = 10011 \qquad (m = 4)$$

$$M(x) \cdot x^m = 11010110110000$$

$$\frac{110001010}{10011}$$

$$\frac{10011}{10011}$$

$$\frac{10011}{010100}$$

$$\frac{10011}{10011}$$

The final message B(x) is equal to: $B(x) = \underbrace{1101011011}_{M(x)} \underbrace{10011}_{R(x)}$

CRC Decoding

- 1. the receiver acquire $B(x) = M(x) \cdot x^m + CRC$.
- 2. the receiver knows G(x).
- 3. the receiver **divides** the whole message by the generator: $B(x) = \frac{M_x \cdot x^m + CRC}{G(x)}$
- 4. if the receiver obtain **no reminder** the transmission was successfully (no errors detected).

CRC Error Resistance: consider an error E(x) occurs on the transmission channel and the receiver B(x) + E(x) instead of simply B(x), when the CRC logic can failed? The problem occure when E(x) is multiple of G(x) in this way $\frac{B(x)+E(x)}{G(x)}$ gives no reminder, so the receiver mark B(x) + E(x) as a correct message. To avoid this problem we need to choose in appropriate way the generator G(x), this is the reason why the G(x) it is standard in the CRC Encoding (by the protocol).

CRC Design Priciples: G(x) is extremely important in a way that E(x) cannot easily be multiple of G(x). For **detecting single bit of error**:

- $E(x) = x^i$ for error in i-th bit.
- if G(x) has more than 1 term it cannot divide x^i .

Mathematical theory help us to desing powerful G(x) with fancy characteristics, in CANBus the generator is: $G(x) = x^{15} + x^{14} + x^{10} + x^8 + x^7 + x^4 + x^3 + 1$. **sender** and **receiver** must to agree on the **generator**.