
# FLOATING POINT NUMBERS



Assignment Project Exam Help

ing point standard

https://eduassistpro.github.io/

Add WeChat edu\_assist\_pro

Bernhard Kainz (with thanks to

N. Dulay and E.

**Edwards**)

b.kainz@imperial.ac.uk

## IEEE floating point standard

- IEEE: institute of electrical and electronic engineers (USA)
- Comprehensive standard of the intermediate of the comprehensive standard of the comprehensive
- Widely adopted https://eduassistpro.githubpie/dent of architecture

  Add WeChat edu\_assist\_pro
- Standard defines:
  - Format of binary floating point numbers, i.e. how the fields are stored in memory
  - Semantics of arithmetic operations
  - Rules for error conditions

## Single precision format (32-bit)

Sign Exponent Significand

1 Assignment Project Exan? Help

- Coefficient is cahttps://eduassistpro.glthubfid/standard
- Value represented is ±1. E × 2
   The normal bit (the 1.) is omit e significand
- field → a hidden bit
- Single precision yields 24 bits (approx. 7 decimal digits) of precision)
- Normalised ranges in decimal are approximately:

$$-10^{38}$$
 to  $-10^{-38}$ , 0,  $10^{38}$  to  $10^{-38}$ 

## Exponent field

 In the IEEE standard, exponents are stored as excess values, not as 2's complement

Assignment Project Exam Help

 Allows non-negative floating point numbers to be compared using simple integer comparisons

## Double precision format (64-bit)

Sign Exponent Significand
S E F

1 Assignment Project Exam 4 Help

- Value represent https://eduassistpro.github.io/
- Double precision vields 52 bit edu\_assist procision)

  digits of precision)
- Normalised ranges in decimal are approximately:

$$-10^{308}$$
 to  $-10^{-308}$ , 0,  $10^{308}$  to  $10^{-308}$ 

 Single precision generally reserved for when memory is scarce or for debugging numerical calculations since rounding errors show up more quickly

## Example: conversion to IEEE format

What is 42.6875 in IEEE single precision format?

- 1. Convert to Abing nynouth Beerjeett. Estata Hed p 1010.1011
- Normalise: https://eduassistpro.github.io/ Normalise:

Add We@hatedu\_assistopoo 0000 000

**Exponent field** is (5 + 127 = 132): 1000 0100

Sign	Exponent	Significand
S	E	F
0	1000 0100	0101 0101 1000 0000 0000 000

Hex: 422A C000

### Example: conversion from IEEE format

What is the IEEE single precision value represented by BEC0 0000 in decimal?

- 1. Exponent field: 1 = 125 Add WeChat edu\_assist\_pro\_2. True binary exponent: 7 = -2
- Significand field + hidden bit:

 $1.1000\ 0000\ 0000\ 0000\ 0000\ 000$ 

- 4. So unsigned value is  $1.1 \times 2^{-2} = 0.011$  (binary) = 0.25 + 0.125 = 0.375 (decimal)
- 5. Adding sign bit gives finally -0.375

## Example: addition

Carry out the addition 42.6875 + 0.375 in IEEE single precision arithmetic

Assignment Project Exam Help

Number	Sign	Significand
42.6875	0	https://eduassistpro.github.pg/ 0000 0000 0000 0000 0000 0000 0000 0
0.375	0	00 0000 0000 0000 000

- To add these numbers, expon
   e the same →
   make the smaller exponent equal to the larger by shifting
   significand accordingly
- Note: must restore hidden bit when carrying out floating point operations

## Example: addition (cont.)

- **Significand** of larger no.: 1.0101 0101 1000 0000 0000 000
- Significand of smaller no.: 1.1000 0000 0000 0000 0000 000
- Assignment Project Exam Help
  Exponents differ by (1000 0100 0111 1101 = 7) so shift binary point of smaller no. https://eduassistpro.github.io/
- Significand of smalledob. We@lateedu\_assist@prop0000000
- **Significand** of larger no.: 1.0101 0101 1000 0000 0000 000
- **Significand** of **sum**: 1.0101 1000 1000 0000 0000 000
- So **sum** is  $1.0101\ 1000\ 1 \times 2^5 = 10\ 1011.0001 = 43.0625$ Sign Exponent Significand F

## Special values

• IEEE formats can encode five kinds of values: **zero**, **normalised numbers**, **denormalised numbers**, **infinity** and **not-a-number (NaNP)**roject Exam Help

Single precision

https://eduassistpro.github.io/ **IEEE** value True exponent Add WeChat edu\_assist\_pro +00 or 1 0 (all zeros) 0 + denormalised no. 0 Any non-zero bit -1260 or 1 pattern 1 ... 254 +normalised no. 0 or 1 Any bit pattern  $-126 \dots 127$ 0 or 1 255 0 (all zeros)  $+\infty$ Not-a-number 0 or 1 255 Any non-zero bit pattern

#### Denormalised numbers

- An all zero exponent is used to represent both zero and denormalised numbers
- An all one expopente at Page to the present in the second and not-a-numbers
- Means range fohttps://eduassistpro.githuheit/iced, for single precision the exponent redu\_assist\_pro 127 rather than -127 ... 128
- **Denormalised numbers** represent values between the underflow limits and zero, i.e. for single precision we have  $\pm 0.F \times 2^{-126}$
- Allows a more gradual shift to zero useful in some numerical applications

#### Infinities and NaNs

- Infinities represent values exceeding the overflow limits and for divisions of non-zero quantities by zero
- · You can do Assigiarithm Ptio jwith Exam, Help
- NaNs represent https://eduassistpro.github.io/ (real) mathematical interpret edu\_assist\_pro
  - $\frac{0}{0}$ ,  $+\infty + -\infty$ ,  $0 \times \infty$ , square root of a negative number
- Operations resulting in NaNs can either yield a NaN result (quiet NaN) or an exception (signalling NaN)

## **Special Operations**

Operation	Result
Assignment Pr	oject Exam Help
± Infinity ×	uassistpro.github.io/
± non-z nttps://edt	lassistpro.github.io/
Infinity + AntipityWeC	hat edu_assist_pro
± 0 ÷ ± 0	<b>_</b>
Infinity - Infinity	NaN
± Infinity ÷ ± Infinity	NaN
± Infinity × 0	NaN



https://eduassistpro.github.io/

## Floating Point Precision

C code:

```
#include <stdio.h>
int main() {
            Assignment Project Exam Help
 float a, b, c;
 float EPSILON = https://eduassistpro.github.io/
 a = 1.345f; b = 1.123f;
Add WeChat edu_assist_pro
 c = a + b;
 if (c == 2.468)
   printf ("They are equal.\n");
  else
   printf ("\nThey are not equal! The value of c is %.10f or %f\n",c,c);
 // With some tolerance
 if (((2.468 - EPSILON) < c) \&\& (c < (2.468 + EPSILON)))
   printf ("\n^{.10}f is equal to 2.468 with tolerance\n^{.}, c);
```

#### Run-time

Assignment Project Exam Help

https://eduassistpro.github.io/

## Finding Machine Epsilon

Pseudo-code

```
Set Assignment Project Exam Help

Loop https://eduassistpro.github.io/

machineEps machineE
Add WeChat edu_assist_pro

Until ((1 + machineEps/2.0) != 1)

Print machineEps
```

## Finding Machine Epsilon

C code

```
#include <stdio.h>
Assignment Project Exam Help int main(int argc, char **argv)
  float machEphttps://eduassistpro.github.io/
                Add WeChat edu_assist_pro
  do {
    machEps /= 2.0f;
    // If next epsilon yields 1, then break, because current
    // epsilon is the machine epsilon.
  while ((float)(1.0 + (machEps/2.0f)) != 1.0);
  printf( "\nCalculated Machine epsilon: %G\n\n", machEps );
  return 0;
```

## Finding Machine Epsilon

In Java

```
public class machEps
 Assignment Project Exam Help private static void calculateMachineEpsilonFloat() {
     float machE
                 https://eduassistpro.github.io/
     do {
       machEps /= 2.0f;
     } while ((float) do We Contate edu_assist_pro
     System.out.println( "Calculated machine epsilon: " + machEps );
 }
 public static void main (String args[])
     calculateMachineEpsilonFloat ();
```

#### Run-time

Assignment Project Exam Help

https://eduassistpro.github.io/

## **Special Operations**

Example

```
#include <stdio.h>
int managing amenth Broject by Exam Help
 float a = https://eduassistpro.github.io/
 float b = a*dd WeChat edu_assist_pro
 float c = b/a;
 int d = 2 * 10 + 3;
 printf ("\nValue of a = \%f\n\n", a);
 printf ("\nValue of b = %f\n\n", b);
 printf ("\nValue of c = %f\n\n", c);
 printf ("\nValue of d = %d\n\n", d);
```

#### Run-time

Assignment Project Exam Help

https://eduassistpro.github.io/