

Lecture # 32

Interrupts and related concepts # 1

Covered by these slides and chapter # 17 (section 17.4)



Basic Input/Output Operations

- ☐ We have seen instructions to:
 - ◆ Transfer information between the processor and the memory.
 - Perform arithmetic and logic operations
 - Program sequencing and flow control.
- ☐ Input/Output operations which transfer data from the processor or memory to and from the real world are essential.
- □ In general, the rate of transfer from any input device to the processor, or from the processor to any output device is likely to the slower than the speed of a processor.
 - ◆ The difference in speed makes it necessary to create mechanisms to synchronize the data transfer between them.




Accessing I/O devices

- ☐ I/O devices and the memory may share the same address space:
 - ◆ Memory-mapped I/O.
 - ◆ Any machine instruction that can access memory can be used to transfer data to or from an I/O device.
 - ◆ Simpler software.
- ☐ I/O devices and the memory may have different address spaces:
 - ◆ Special instructions to transfer data to and from I/O devices.
 - ◆ I/O devices may have to deal with fewer address lines.
 - ◆ I/O address lines need not be physically separate from memory address lines.
 - ◆ In fact, address lines may be shared between I/O devices and memory, with a control signal to indicate whether it is a memory address or an I/O address.




Accessing I/O devices



- •Multiple I/O devices may be connected to the processor and the memory via a bus.
- •Bus consists of three sets of lines to carry address, data and control signals.
- •Each I/O device is assigned an unique address.
- •To access an I/O device, the processor places the address on the address lines.
- •The device recognizes the address, and responds to the control signals.




Processing with IORQ uses IN and OUT Instruct.





Class example of Programmed I/O






Q: How to do a synchronized programmed I/O?

- □ Let us consider a simple task of reading a character from a keyboard and displaying that character on a display screen.
- ☐ Buffer registers DATAIN and DATAOUT, and status flags SIN and SOUT are part of a circuitry known as <u>device</u> <u>interface</u>.

☐ Write Assembly programs using IN / OUT instructions from the two scenarios described in the next two slides.



Data read from DATAIN by checking SIN




Input:

- •When a key is struck on the keyboard, an 8-bit character code is stored in the buffer register DATAIN.
- •A status control flag SIN is set to 1 to indicate that a valid character is in DATAIN.
- •A program monitors SIN, and when SIN is set to 1, it reads the contents of DATAIN.
- •When the character is transferred to the processor, SIN is automatically cleared.
- •Initial state of SIN is 0.



Data written to DATAOUT by checking SOUT



Output:

- •When SOUT is equal to 1, the display is ready to receive a character.
- •A program monitors SOUT, and when SOUT is set to 1, the processor transfers a character code to the buffer DATAOUT.
- •Transfer of a character code to DATAOUT clears SOUT to 0.
- •Initial state of SOUT is 1.



Accessing I/O devices (contd..)

- ☐ Program-controlled I/O:
 - Processor repeatedly monitors a status flag to achieve the necessary synchronization.
 - Processor polls the I/O device.

- ☐ Two other mechanisms used for synchronizing data transfers between the processor and memory:
 - ◆ Interrupts.
 - ◆ Direct Memory Access (Not covered in this course).

Interrupts

- ☐ In program-controlled I/O, when the processor continuously monitors the status of the device, it does not perform any useful tasks.
- ☐ An alternate approach would be for the I/O device to alert the processor when it becomes ready.
 - Do so by sending a hardware signal called an interrupt to the processor.
 - ◆ At least one of the bus control lines, called an interruptrequest line is dedicated for this purpose.
- ☐ Processor can perform other useful tasks while it is waiting for the device to be ready.




Polled IO versus Interrupt Driven IO

- Polled Input/Output (IO) processor continually checks IO device to see if it is ready for data transfer
 - Inefficient, processor wastes time checking for ready condition
 - Either checks too often or not often enough
- Interrupt Driven IO IO device interrupts processor when it is ready for data transfer
 - Processor can be doing other tasks while waiting for last data transfer to complete – very efficient.
 - All IO in modern computers is interrupt driven.




Interrupts (contd..)



- •Processor is executing the instruction located at address i when an interrupt occurs.
- •Routine executed in response to an interrupt request is called the interrupt-service routine.
- •When an interrupt occurs, control must be transferred to the interrupt service routine.
- •But before transferring control, the current contents of the PC (i+1), must be saved in a known location.
- This will enable the return-from-interrupt instruction to resume execution at i+1.
- •Return address, or the contents of the PC are usually stored on the processor stack.





- 1. Processor received Interrupt
- 2. Save context (return address, registers, flags, etc.) and JMP to ISR
- 3. Interrupt Service Routing (ISR) or Interrupt Handler is executed
- 4. IRET instruction is last in the ISR and it returns controls to the main program



Interrupts (contd..)


- ☐ Treatment of an interrupt-service routine is very similar to that of a subroutine.
- ☐ However there are significant differences:
 - ◆ A subroutine performs a task that is required by the calling program.
 - ◆ Interrupt-service routine may not have anything in common with the program it interrupts.
 - ◆ Interrupt-service routine and the program that it interrupts may belong to different users.
 - ◆ As a result, before branching to the interrupt-service routine, not only the PC, but other information such as condition code flags, and processor registers used by both the interrupted program and the interrupt service routine must be stored.
 - ◆ This will enable the interrupted program to resume execution upon return from interrupt service routine.



Midterm # 2 Selected Solutions



Question 3(a)





Question 3(b)

```
15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0
          DODDWWWWAXXXXXXX
· data
                               Year 2017 can't
   bmonth byte ?
                                 be stoned here.
     MOU AX, SAFOH
     ROL AX, 4.
     AND AX, OOOFh.
     MOU bononth, AL.; Au other bits of Ax are ZERO. except lower hibble.
```



Question 4(a)

```
ASCII-Str byte 30,31,32,33,...,46h
ASCII-Str byte & DUP(?).
         MOU EAX, EAFCZUFAL.
MOU ESE, O
MOU EDX, EAX
HERE: ROL EDX, 4.
         AND EOX, 0000000Fh.; Now DL have night most show
          MOV.
               CL, ASCII_t[EOX]
               ASCII-SH [ESI], CL.
          NOV
           INC ESI.
           CMP ESI, 8; There are 8 nibbles.
                HERE
            JL
```



Question 4(b)

```
Push ESI > YP
Push EDI > XP.
                                       Call swap.
                                                [EBP+12] (Ye) EST (Address)
                                                 [EBP+87 (XP) EDI (Add (A))
mou EBP, ESP.
; we shouldn't use local variable.
                                                            RA (main)
                                                              EBP.
     MOVER EST, [FBP+1] ; XP.
                                                         No value returned by
           ·MOV EDX, [BDI].; temp= *xp.
                                                        This procedue. No legister changed
            MOU CEDI], EAX.; *xp= *yp.

MOU CESI], EOX; *yp = temp(EOX)
               bob EDX
                PUP GAX
```