All of Bare Metal!

Processor and memory architecture

Peripherals: GPIO, timers, UART

Assembly language and machine code

From C to assembly language

Function calls and stack frames

Serial communication and strings

Modules and libraries: Building and linking

Memory management: Memory map & heap

Memory Management

Sections and memory map Initializing memory Heap memory allocation

linking/

```
// initialized variables
int x = 1;
const int x const = 2;
static int x static = 3;
static const int x static const = 4;
// uninitialized variables (equal to 0)
int y;
const int y const;
static int y static;
static const int y static const;
```

```
% arm-none-eabi-nm main.o
00000000 T main
         U tricky
         Ux
         U x const
         Uy
         U y_const
% arm-none-eabi-nm tricky.o
00000000 T tricky
0000000 D x
00000000 R x_const
00000004 d x static
00000004 C y
00000004 C y_const
00000000 b y static
```

Guide to Symbols

T/t - text

D/d - read-write data

R/r - read-only data

B/b - bss (Block Started by Symbol)

C - common (instead of B)

lower-case letter means static

Data Symbols


Types


- global vs static
- read-only data vs data
- initialized vs uninitialized data
- common (shared data)


```
.text : {
    start.o (.text)
    *(.text*)
} > ram
.data : { *(.data*) } > ram
.rodata : { *(.rodata*) } > ram
bss start__ = .;
.bss : {
    *(.bss*)
    * (COMMON)
} > ram
. = ALIGN(8);
bssend = .;
```


```
% arm-none-eabi-nm -n main.elf
00008000 T start
00008008 t hang
0000800c T cstart
0000805c T tricky
000080a8 T main
00008108 D x
0000810c d x static
00008110 R x const
00008114 R bss start
00008114 b y static
00008118 B y const
0000811c B y
00008120 B bss end
```


```
// cstart.c - initializes bss to 0
extern int bss start ;
extern int bss end ;
void main();
void cstart() {
    int* bss = & bss start ;
    int* bss end = & bss end ;
    while( bss < bss end )</pre>
        *bss++ = 0;
   main();
```












```
void f() {
   int x;
}
```

```
char* ptr = malloc(len);
```

global variables

code



Heap Memory Allocation

Memory Allocation

Compile-time vs. run-time memory allocation

Why run-time memory allocation?

- I. Don't know the size of an array when compiling
- 2. Dynamic data structures such as strings, lists and trees

Strings

strings.c


Bump Memory Allocator


malloc.c


API

```
void *malloc( size_t size );
void free( void *pointer );

// Note that void* is a generic pointer
// Note that size_t is for sizes
```







Questions

What happens if you forget to free a pointer after you are done using it?

Can you refer to a pointer after it has been freed?

What is stored in the memory that you malloc?

Calling free with a pointer that you didn't malloc?

Can you free the same pointer twice?

Wouldn't it be nice to not have to worry about freeing memory?

Lists

list.c

block.c


newblock(nelements=6, nsize=16);

```
Block *blockhead = ;

NULL
```

```
typedef struct b {
    struct b *next;
} Block;
```

```
Block *blockhead =
        block = getblock( &blockhead, 16 );
```



getblock(&blockhead, block);

Variable Size malloc/free

just malloc is easy



malloc with free is hard



- free returns blocks that can be re-allocated
- malloc should search to see if there is a block of sufficient size. Which block should it choose (best-fit, first-fit, largest)?
- malloc may use only some of the block. It splits the block into two sub-blocks of smaller sizes
- splitting blocks causes fragmentation

Buddy allocators, slab allocators, lots of approaches