Goals for today

Leftover from previous

Stack, APCS full frame

Thanks for the memory!

Linker memory map

Address space layout

Loading

How an executable file becomes a running program

Heap allocation

Malloc and free

This week:

printf perseverance and pride!!






```
// start.s
mov sp, #0x8000000
                                                     gpio
                                                             0x20200000
bl main
void main(void)
                                                             0x8000000
                                           sp
                                                     main
                                           sp
    delta(10,7);
                                                     delta
                                           spp \rightarrow
 int delta(int x, y)
                                                      abs
                                           sp
   return abs(x - y);
                                           pc
 int abs(int v)
                                                     code
                                           pc
                                                             0x8000
   return v < 0 : -v : v;
                                           pc
                            Diagram not to scale
                                                             0x0
```

Add frame pointer

Dedicate **fp** register to be used as fixed anchor

Assign on entry to function to point to new stack frame

fp doesn't change, can access data at fixed offset relative to fp



APCS "full frame"

APCS = ARM Procedure Call Standard

Conventions for frame pointer and frame layout

Enable reliable stack introspection

CFLAGS to enable: -mapcs-frame

r11 used as fp

Adds a prolog/epilog to each function that sets up/tears down the standard frame and manages **fp**

Trace APCS full frame

Prolog

push fp, sp*, lr, pc
set fp to location of first pushed word

Body

fp stays anchored during body access data on stack fp-relative offsets don't vary even if sp changing

Epilog

pop fp, sp*, lr, pc*

* I am fudging a bit about direct use of push and pop **sp** cannot be directly pushed/popped, instead moved through r12 **pc** not popped, instead removed from stack, no restore orig value caller's frame

sp 👈

рс

lr

sp fp

§β ⇉

locals/ scratch/call other fns


sp →

Frame pointers form linked chain

Can start at currently executing call (abs) and back up to caller (delta), from there to its caller (main).

Where does chain end?

```
// start.s
// init fp = NULL
mov sp, #0x8000000
mov fp, #0
bl main
```



Memory Map

32-bit address space

512 MB of physical RAM

0xffffffff **GPU CPU** Peripheral Registers 0x20000000 You are here!

Ref: BCM2835-ARM-Peripherals.pdf

Use this memory for heap ©

(zeroed data) .bss

(read-only data) .rodata

(initialized data) .data

.text

```
_cstart
 main
            _start:
               mov sp, #0x800000
               mov fp, #0
               bl _cstart
          void _cstart(void) {
             int *bss = &__bss_start__;
            while (bss < &__bss_end__)</pre>
                *bss++ = 0:
            main();
         __bss_end__
0000000
0000000
         __bss_start__
20200008
63733130
00002017
                        blink.bin
00000365
e3a0b000
e3a0d302
         0x8000
```

0x8000000

Global allocation

+ Convenient

Fixed location, shared across entire program

+ Fairly efficient, plentiful

No explicit allocation/deallocation Oversize pays bootloader cost

+ Reasonable type safety

- Size fixed at declaration, no option to resize

+/- Scope and lifetime is global

No encapsulation, hard to track use/dependencies One shared namespace, have to manually manage conflicts Frowned upon stylistically

Stack allocation

- + Convenient, plentiful
 - Automatic alloc/dealloc on function entry/exit
- + Efficient, fairly plentiful
 - Fast to allocate/deallocate, ok to oversize
- + Reasonable type safety
- Size fixed at declaration, no option to resize
- +/- Scope/lifetime dictated by control flow
 - Private to stack frame
 - Does not persist after call exits

Heap allocation

+ Moderately efficient

Have to search for available space, update record-keeping

+ Very plentiful

Heap enlarges on demand to limits of address space

+ Versatile, under programmer control

Can precisely determine scope, lifetime

Can be resized

Low type safety

Interface is raw void *, number of bytes

Lots of opportunity for error

(allocate wrong size, use after free, double free)

- Leaks (less critical, but annoying nonetheless)

Heap interface

```
void *malloc(size_t nbytes);
void free(void *ptr);
void *realloc(void *ptr, size_t nbytes);
```

void* pointer

Variable of type address with unspecified/unknown pointee type

What you can do with a void *

Pass to/from function, pointer assignment

What you cannot

Cannot dereference (must cast first)

Cannot do pointer arithmetic (cast to char * to manually control scaling)


Cannot use array indexing

Why do we need a heap?


Let's see an example!

code/heap.c

How is a heap implemented?




Tracing the bump allocator



Bump Memory Allocator

malloc.c

Pre-block header, implicit list



Header struct (with bitfield)

```
struct header {
    unsigned int size : 31;
    unsigned int status : 1;
};
enum { IN_USE = 0, FREE = 1};
void *malloc(size_t nbytes)
{
    nbytes = roundup(nbytes, 8);
    struct header *hdr = heap_end;
    heap_end = (char *)heap_end + nbytes + sizeof(struct header);
    hdr->size = nbytes;
    hdr->status = IN_USE;
    return (char *)hdr + sizeof(struct header);
}
```

Challenges for malloc client

- Correct allocation (size)
- Correct access to block (within bounds, not freed)
- Correct free at correct time

What happens if you...

- forget to free a pointer after you are done using it?
- access a memory block after it has been freed?
- free a block twice?
- free a pointer you didn't malloc?
- access past the bounds of a heap block?

Challenges for malloc implementor

```
just malloc is easy some malloc with free is hard some malloc with free ....Yikes!
```

Tricky code (pointer math, typecasts) Testing is difficult (even more than usual) Critical system component

correctness is non-negotiable, ideally also fast and compact

Survival strategies:

```
draw pictures printf (you've earned it!!)
Early tests on examples small enough to trace by hand if need be
```