EBmonitor Target Integration

by Gerard Zagema (EmBitz okt 2025)

This document explains how to use ebmon.c in your embedded target, configure its defines, and control **blocking vs non-blocking mode**.

1. Adding EBmonitor to Your Target

- 1. Copy ebmon.c and ebmon.h into your target project.
- 2. Include the header in your source files:

#include "ebmon.h"

3. Link ebmon.c in your build system so it compiles with your firmware.

2. Configurable Defines

Several macros control buffer sizes, initialization, and behavior:

Define	Purpose	Default
STDOUT_BUFFERSIZE	Size of stdout buffer	512 (example)
STDIN_BUFFERSIZE	Size of stdin buffer	512 (example)
NO_EBMON_INIT	Disable automatic initialization	Not defined
EBMON_WRITE_WAIT	Enable blocking writes if buffer is full	Not defined

Example Configuration

```
#define STDOUT_BUFFERSIZE 1024
#define STDIN_BUFFERSIZE 512
#define EBMON_WRITE_WAIT // enable blocking mode for writes
```

Place these defines in your project configuration header or at the top of ebmon.c before includes.

3. Initialization

EBmonitor automatically initializes buffers on the first _write() call unless NO_EBMON_INIT is defined.

You can manually initialize using:

```
#ifndef NO_EBMON_INIT
ebmonitor_init();
#endif
```

This sets up _eb_monitor_stdout and clears the screen on the host by sending a formfeed \f.

4. Using STDIO Pipes

EBmonitor exposes two primary pipes:

- _eb_monitor_stdout write data to host
- _eb_monitor_stdin read data from host

Writing to stdout

```
_write(1, "Hello World\n", 12);
```

- file argument is ignored, ptr points to buffer, len is number of bytes.
- Sending \f to _write() clears the host screen.

Reading from stdin

```
char buf[32];
int n = _read(0, buf, sizeof(buf));
if(n > 0) {
    // process input
}
```

Returns -1 if no data is available.

Flushing a pipe

```
EBmonitor_flush(stdout);
EBmonitor_flush(stdin);
```

• Clears the respective buffer.

Check if data is available

```
if(EBmonitor_kbhit()) {
    // data ready
}
```

5. Blocking vs Non-Blocking Mode

EBmonitor can operate in **blocking** or **non-blocking** mode depending on EBMON_WRITE_WAIT:

Mode	Behavior
Blocking (EBMON_WRITE_WAIT defined)	_write() waits if buffer is full until space is available.
Non-Blocking (default)	_write() returns the number of characters actually written, may drop characters if buffer is full.

Choosing the Mode

- **Blocking Mode:** Use when data integrity is critical and you cannot afford to drop characters.
- **Non-Blocking Mode:** Use when your firmware must continue running without delay even if the buffer is temporarily full.

6. Notes

- Buffers are aligned to 4 bytes for performance on most MCUs.
- _eb_monitor_stdout and _eb_monitor_stdin are circular buffers, so always respect the head and tail indices if you directly access them.
- To clear the host terminal screen, send a formfeed character \f via _write().

7. Example Firmware Loop

```
char input[64];
printf("\f"); // clear terminal screen
while(1) {
    if(EBmonitor_kbhit()) {
        int n = _read(0, input, sizeof(input));
        // process input
    }
    _write(1, "Heartbeat\n", 10);
    delay_ms(1000);
}
```

This simple loop demonstrates reading commands from the host and writing periodic status updates.