Back to search page


Click to download printable version of this guide.

<u>AWR Microwave Office Element Catalog</u> > <u>Sources</u> > Current Noise Source: INOISE

<u>Prev</u> <u>Next</u>

Current Noise Source: INOISE

Symbol



Parameters

Name	Description	Unit Type	Default
ID	Element ID	Text	IN1
I	Noise current in pA/sqrt(Hz)		17.9

Layout

This element does not have an assigned layout cell. You can assign artwork cells to any element. See <u>"Assigning Artwork Cells to Layout of Schematic Elements"</u> for details.

Implementation Details

INOISE implements a white noise source having the stated noise spectral density. For I=17.897294, T=290K in 50Ω .

<u>Up</u>
Home

Please send email to awr.support@cadence.com if you would like to provide feedback on this article. Please make sure to include the article link in the email.

Legal and Trademark Notice