AVR Interfacing

IO Ports

Agenda

- I/O Ports.
- I/O Ports Programming.
- Interfacing with Switches and Leds.
- Interfacing with 7-Segment.
- Interfacing with DC-Motor.
- Interfacing with LCD.
- Interfacing with Keypad.

- ATmega328p has programmable I/O lines divided into:
 - ➤ PORTB(PB7.....PB0)
 - ➤ PORTC(PC6.....PC0)
 - ➤ PORTD(PD7.....PD0)
- Each PORT is controlled by 3 registers:
 - > DDRx:

Data Direction Register to set the pin either output or input pin.


> PORTx


Output Register to assign a value to the port (from μC to interface).


> PINx:

Input Register where it holds the input value from interface.

Note: Most pins in µC make more than one function (multiplexed functions)







- To decided which Port is input and which is output:
 - Configure the port direction use register DDRX
 - $1 \rightarrow$ for Output.
 - $0 \rightarrow$ for Input.
- To Read(input case):
 - Use register PINx
- To Write(output case) :
 - Use register PORTx.

Note:

In case you set any PIN as **input** you can activate the **internal pull up** resistor by setting the corresponding bit in **PORTX** register.

- How to set values in registers
 - ➤ DDRA=5; /*(decimal)mean I activate pin 0 and pin 2 as output and the rest as input pins */
 - ➤ DDRB=0x14; /*(hexadecimal)mean I activate pin 2 and pin 4 as output and the rest as input pins */
 - ➤ DDRC=0b0000011; /*(binary)mean I activate pin 0 and pin 1 as output pins and the rest as input pins */
- How to deal with a specific pin with conserving other pins
 - > To set specified bit in register

Make OR operation on the register with The pin number.

☐ For example if we want to set pin number 5 in PORTA

$$PORTA = PORTA \mid (1 << PA5);$$

> To clear specified bit in register

Make AND operation on the register with (NOT) The pin number.

☐ For example if we want to set pin number 3 in PORTB

$$PORTB = PORTB \& (\sim (1 << PB3));$$

> To toggle specified bit in register

Make XOR operation on the register with The pin number \square For example if we want to toggle pin number 2 in PORTC $PORTC = PORTC \land (1 << PC2);$

Example:

➤ To set the pin 2 in PORTB as input pin and use the internal pull up resistor of this pin.

$$DDRB = DDRB \& (\sim (1 \ll PB2))$$
$$PORTB = PORTB \mid (1 \ll PB2)$$

```
DDRA = 0xFF; //initialize portA as output
DDRB = 0x00; //initialize portB as input
if ((PINB & 0b00000001) == 1) //read a switch on PB0
      PORTA = 0xFF; //All LEDs on
else
      PORTA = 0x00; //All LEDs off
```


I/O Port applications

- As Output
 - LED and 7-Segemnt
 - LCD display
 - Motors.
 - Buzzer.
 - Signal to another μC.
 - Output to PC through PC Serial Port.
- As Input
 - Switches(push button, keypad etc.)
 - Analog/Digital sensors.
 - Signal from another μC.
 - Input from PC through PC Serial Port.


Interfacing with Switches and Leds

LED Configuration

Negative Logic




Positive Logic




Interfacing with Switches and Leds

Switch Configuration

Pull Down Resistor




Pull UP Resistor




Interfacing with Switches and Leds


Switch de-bounce problem




- Could be handled using software or hardware.
- It relies on the fact that bouncing takes a maximum period of 20-30 ms.
- The basic idea is to implement a delay after the first detected edge, during which no scanning for the switch is done. after the delay period is finished, scanning can proceed (Exercise 3).


Interfacing with 7-Segment





Common Anode






Common Cathode

Interfacing with 7-Segment

In order to reduce the number of pins can be used to interface the 7 segment, we use decoder connected and follows;



Digit	Decoder inputs			
	C3	C2	C1	CO
0	0	0	0	0
1	0	0	0	1
2	0	0	1	0
3	0	0	1	1
4	0	1	0	0
5	0	1	0	1
6	0	1	1	0
7	0	1	1	1
8	1	0	0	0
9	1	0	0	1