
# Electronics Basics




## **Atomic Structure**

- In a single atom, electrons occupy shells (discrete energy levels).
- In solids, these levels overlap and form continuous energy bands.
- The valence band holds bound electrons.
- The conduction band holds electrons free to move.
- The band gap is the energy needed to jump from the valence to conduction band.




## Metals

- In metals the conduction band overlaps, so electrons are already free to move.
- These delocalised electrons form an electron sea around positive ion cores.
- No voltage → random motion, no net current.
- Voltage applied → electrons drift → electric current.



## Insulators

- Atoms hold electrons tightly in their outer shells.
- The valence band is full and separated from the conduction band by a large band gap.
- Electrons cannot move freely → no conduction under normal conditions.
- Examples: glass, rubber, plastic, wood.
- Insulators are used to stop current flow and provide safety in circuits.




## Conventional vs Electron Flow


#### Electron Flow

- Actual physical movement of electrons.
- Electrons drift from negative (–) to positive (+) terminal.
- Matches what's really happening in the conductor.

#### Conventional Current Flow


- Defined historically before electrons were discovered.
- Current assumed to flow from positive (+) to negative (–).
- Still used today in circuit diagrams and engineering.





## Charge

- We measure charge (Q) in coulombs
  (C)
- Electron charge is  $1.6 * 10^{-19}$  C
- Q = I \* t (charge = current \* time)




## Current

- Current is the flow of charge per second
- It has the symbol I with the unit Ampere (A)

### **Analogy**

- Like the flow of water in a pipe → how much passes a point each second.
- Wider pipe = less resistance → more flow.
- Narrow pipe = more resistance  $\rightarrow$  less flow.




## Voltage

- Voltage is the energy per unit charge
- It has the symbol V with the unit Volt (V)

#### **Analogy**

- Like water pressure pushing water through a pipe.
- High voltage = each charge carries more energy.
- Source of voltage: batteries, power supplies, generators.




## Resistance

- Resistance is the opposition to current flow
- It has the symbol R with the unit Ohm  $(\Omega)$

### **Analogy**


- Like a narrow pipe restricting water flow.
- Factors affecting resistance:
  - Material (copper vs rubber)
  - Length (longer wire = more resistance)
  - Thickness (thicker wire = less resistance)
  - Temperature (hotter wire = more resistance)




## V = IR

- Ohm's Law links voltage (V), current (I), and resistance (R).
- V=IR only really works for DC circuits


### Electricity is like a water hose






## Energy

- Energy is the ability to do work or cause change.
- It has the symbol E and the unit Joule (J)
- It has the formula:  $E = V \times I \times t$
- Where:
  - V = Voltage (volts)
  - I = Current (amps)
  - t = Time (seconds)
- Examples:
  - A 60W bulb lit for 1 hour uses 216,000J.
  - Phone battery stores energy in the range of 10,000– 15,000 J.



### Power

- Power is the rate of energy transfer.
- It has the symbol P and the units Watts (W)
- Higher voltage or higher current → more power delivered.
- Power tells us how much energy a device uses per second.
- Examples:
  - Phone charger ≈ 10 W
  - Kettle ≈ 2000 W
  - Light bulb ≈ 60 W





## Electric Force

- There are a few rules which dictate how electricity functions
- Electric force or Coulomb's Law dictates:
  - Like charges repel, unlike charges attract
  - Force gets stronger if charges are larger or closer
- The force is equivalent to the equation:

• Where:

$$F=k_erac{q_1q_2}{r^2}$$





- F is the force (newtons, N)
- $q_1$  and  $q_2$  are the charges (coulombs, C)
- R is the distance between them (metres, m)
- $K_e$  is coulombs constant which is  $8.99 * 10^9$