
Chain and Belt Drives




Mechanical power transmission types

- We can split our power transmission based on how it moves:
 - Rotary: circular motion (e.g. motor shaft, gears)
 - Linear: straight-line motion (e.g. piston, actuator)
 - Oscillating: back-and-forth motion (e.g. cam follower, lever)
- But we can also split them on the properties of the transmitter
 - Flexible drives: belts, chains
 - Rigid drives: gears, cams
 - Special drives: harmonic, cycloidal



Key Concept – Centre Distances

- The centre distance is the distance between the centre of two pulleys/gears
- It affects belt tension, wrap angle, and the overall layout of the drive system.
- Choosing the correct centre distance is important for maintaining grip, reducing wear, and ensuring smooth power transmission.



Center distance (D4) = D1/2 + D2/2 +D3


Positive Engagement vs Friction Drive


Positive Engagement Drive

- Positive engagement means two components transmit motion through interlocking geometry (not friction).
- Behaves well under high torque scenarios
- Examples include gears, chains and sprockets, or timing belts, where the teeth physically mesh to prevent slip.

Friction Drive

- Friction drives transmit motion by surface contact and grip between components.
- This means they are prone to slipping in high torque scenarios
- Examples include flat or V-belt pulley systems, where friction between the belt and pulley transfers power.






Direction of Rotation

Gears:

- Gears mesh directly, so they reverse the direction of rotation.
- If the driver turns clockwise \rightarrow the driven turns anticlockwise.
- Each additional gear reverses direction again (odd = reversed, even = same).

Belts and Chains:

- Belts and chains loop around pulleys or sprockets, so the direction stays the same.
- If the driver turns clockwise → the driven also turns clockwise.
- The same applies if both rotate anticlockwise.



Belt Drives

• Purpose:

 Transfer power between rotating shafts using flexible belts and pulleys.

How it works:

- Power is transmitted by friction between the belt and pulley.
- The belt wraps around pulleys to change speed, direction, or torque.

• Types:

- Flat Belt
- V-Belt
- Timing (synchronous) Belt






Sprockets

- Sprockets are like gears, but instead of meshing with another gear, they engage with a chain (or occasionally a toothed belt).
- They transmit motion through positive engagement the sprocket's teeth fit precisely into the chain's rollers or links, ensuring no slip and maintaining a fixed speed ratio.
- Sprocket teeth are shaped specifically to match the chain pitch and roller diameter, not the involute profile used in gears.







Flat Belts

- Description:
 - A flat, flexible strip of rubber, leather, or fabric that wraps around flat pulleys.
- Power Transmission Method:
 - Relies purely on friction between the belt and pulley.
 - The belt slips slightly under load.
- Typical Uses:
 - Older machinery, fans, small conveyors, textile or woodworking equipment.

Flat Belt



Flat Belts


Advantages:

- Simple, inexpensive, and easy to align.
- Can run at high speeds and over long distances.
- Quiet operation and low maintenance.

• Limitations:

- Can slip under high torque or sudden loads.
- Requires good tensioning and alignment.
- Not suitable for precise motion or hightorque transfer.

Flat Belt



V-Belts

Description:


 A belt with a trapezoidal cross-section that fits into a matching V-shaped pulley groove.

Power Transmission Method:

- Uses wedging action for friction.
- As tension increases, the belt wedges deeper into the pulley groove, increasing grip.

Typical Uses:

 Automotive alternators and compressors, industrial machines, HVAC blowers, small mechanical drives.




V-Belts

Advantages:

- Higher torque capacity than flat belts.
- Less slippage due to wedge effect.
- Compact and efficient for short-distance drives.

• Limitations:

- Generates more heat at high speeds.
- Not ideal for very long centre distances.
- Still subject to some slip, so not suitable for precision timing.



Timing Belts (Toothed Belts or Synchronous Belts)

Description:

 A rubber or polymer belt with moulded teeth that mesh with matching grooves on the pulley.

Power Transmission Method:

 The teeth on the belt mesh with the sprocket/pulley making sure there is no slip

Typical Uses:

 Robotics, 3D printers, CNC machines, automotive camshafts, timing systems where position accuracy matters.



Timing Belts (Toothed Belts or Synchronous Belts)

Advantages:

- Precise synchronization between shafts (constant speed ratio).
- High efficiency and quiet operation.
- No lubrication required.

Limitations:

- Limited torque capacity compared to chains or gears.
- Sensitive to debris or wear that can damage teeth.
- More expensive than friction belts.



Chain Drives

Purpose:

 Transmit power between rotating shafts using a linked chain and sprockets

How It Works:

- Power is transmitted by positive engagement between chain links and sprocket teeth — no slip.
- The centre distance between sprockets determines chain length and tension.
- Used where consistent speed ratio and higher torque are required.

Key Features:

- Roller Chain is most common (bushings, rollers, and pins).
- Chains can connect parallel or offset shafts.
- Direction and speed depend on sprocket sizes (like gears).



Chain Drives

Advantages:

- Maintains accurate speed ratio with no slip.
- Handles high torque and load.
- Simple to replace or reconfigure for different ratios.

• Limitations:

- Needs proper lubrication and alignment.
- Chain wear can cause backlash over time.
- Generates more noise and vibration than belts.

