CHAPTER 5 INSTRUCTION SET SUMMARY

This chapter provides an abridged overview IA-32 instructions, divided into the following groups:

- General purpose
- x87 FPU
- x87 FPU and SIMD state management
- Intel MMX technology
- SSE extensions
- SSE2 extensions
- SSE3 extensions
- System instructions

5.1. GENERAL-PURPOSE INSTRUCTIONS

The general-purpose instructions preform basic data movement, arithmetic, logic, program flow, and string operations that programmers commonly use to write application and system software to run on IA-32 processors. They operate on data contained in memory, in the general-purpose registers (EAX, EBX, ECX, EDX, EDI, ESI, EBP, and ESP) and in the EFLAGS register. They also operate on address information contained in memory, the general-purpose registers, and the segment registers (CS, DS, SS, ES, FS, and GS).

This group of instructions includes the data transfer, binary integer arithmetic, decimal arithmetic, logic operations, shift and rotate, bit and byte operations, program control, string, flag control, segment register operations, and miscellaneous subgroups. The sections that following introduce each subgroup.

5.1.1. Data Transfer Instructions

The data transfer instructions move data between memory and the general-purpose and segment registers. They also perform specific operations such as conditional moves, stack access, and data conversion.

MOV Move data between general-purpose registers; move data between memory and general-purpose or segment registers; move immediate to general-purpose registers.

Conditional move if equal/Conditional move if zero. CMOVE/CMOVZ CMOVNE/CMOVNZ Conditional move if not equal/Conditional move if not zero. Conditional move if above/Conditional move if not below or equal. CMOVA/CMOVNBE Conditional move if above or equal/Conditional move if not below. CMOVAE/CMOVNB Conditional move if below/Conditional move if not above or equal. CMOVB/CMOVNAE Conditional move if below or equal/Conditional move if not above. CMOVBE/CMOVNA Conditional move if greater/Conditional move if not less or equal. CMOVG/CMOVNLE Conditional move if greater or equal/Conditional move if not less. CMOVGE/CMOVNL Conditional move if less/Conditional move if not greater or equal. CMOVL/CMOVNGE CMOVLE/CMOVNG Conditional move if less or equal/Conditional move if not greater.

CMOVC Conditional move if carry.
CMOVNC Conditional move if not carry.
CMOVO Conditional move if overflow.
CMOVNO Conditional move if not overflow.
CMOVS Conditional move if sign (negative).

CMOVNS Conditional move if not sign (non-negative).

CMOVP/CMOVPE Conditional move if parity/Conditional move if parity even.

CMOVNP/CMOVPO Conditional move if not parity/Conditional move if parity odd.

XCHG Exchange. BSWAP Byte swap.

XADD Exchange and add.
CMPXCHG Compare and exchange.
CMPXCHG8B Compare and exchange 8 bytes.

PUSH Push onto stack. POP Pop off of stack.

PUSHA/PUSHAD Push general-purpose registers onto stack. POPA/POPAD Pop general-purpose registers from stack.

CWD/CDQ Convert word to doubleword/Convert doubleword to quadword.
CBW/CWDE Convert byte to word/Convert word to doubleword in EAX register.

MOVSX Move and sign extend. MOVZX Move and zero extend.

5.1.2. Binary Arithmetic Instructions

The binary arithmetic instructions perform basic binary integer computations on byte, word, and doubleword integers located in memory and/or the general purpose registers.

ADD Integer add.
ADC Add with carry.
SUB Subtract.

SBB Subtract with borrow. **IMUL** Signed multiply. MUL Unsigned multiply. Signed divide. **IDIV** Unsigned divide. DIV Increment. INC DEC Decrement. NEG Negate. **CMP** Compare.

5.1.3. Decimal Arithmetic Instructions

The decimal arithmetic instructions perform decimal arithmetic on binary coded decimal (BCD) data.

DAA Decimal adjust after addition.
DAS Decimal adjust after subtraction.
AAA ASCII adjust after addition.
AAS ASCII adjust after subtraction.
AAM ASCII adjust after multiplication.
AAD ASCII adjust before division.

5.1.4. Logical Instructions

The logical instructions perform basic AND, OR, XOR, and NOT logical operations on byte, word, and doubleword values.

AND Perform bitwise logical AND. OR Perform bitwise logical OR.

XOR Perform bitwise logical exclusive OR.

NOT Perform bitwise logical NOT.

5.1.5. Shift and Rotate Instructions

The shift and rotate instructions shift and rotate the bits in word and doubleword operands. SAR Shift arithmetic right

SHR Shift logical right.

SHL Shift arithmetic left/Shift logical left. SAL/

SHRD Shift right double. **SHLD** Shift left double. ROR Rotate right. Rotate left. ROL

Rotate through carry right. **RCR** Rotate through carry left. **RCL**

5.1.6. Bit and Byte Instructions

Bit instructions test and modify individual bits in word and doubleword operands. Byte instructions set the value of a byte operand to indicate the status of flags in the EFLAGS register.

BTBit test. **BTS** Bit test and set. **BTR** Bit test and reset. **BTC** Bit test and complement. Bit scan forward. **BSF BSR** Bit scan reverse.

Set byte if equal/Set byte if zero. SETE/SETZ Set byte if not equal/Set byte if not zero. SETNE/SETNZ SETA/SETNBE Set byte if above/Set byte if not below or equal.

SETAE/SETNB/SETNC Set byte if above or equal/Set byte if not below/Set byte if not carry. SETB/SETNAE/SETC Set byte if below/Set byte if not above or equal/Set byte if carry. SETBE/SETNA Set byte if below or equal/Set byte if not above.

Set byte if greater/Set byte if not less or equal. SETG/SETNLE Set byte if greater or equal/Set byte if not less. SETGE/SETNL SETL/SETNGE Set byte if less/Set byte if not greater or equal. SETLE/SETNG Set byte if less or equal/Set byte if not greater.

SETS Set byte if sign (negative).

SETNS Set byte if not sign (non-negative).

SETO Set byte if overflow. **SETNO** Set byte if not overflow.

SETPE/SETP Set byte if parity even/Set byte if parity. SETPO/SETNP Set byte if parity odd/Set byte if not parity.

TEST Logical compare.

5.1.7. Control Transfer Instructions

The control transfer instructions provide jump, conditional jump, loop, and call and return operations to control program flow.

JMP Jump.

JE/JZ Jump if equal/Jump if zero. JNE/JNZ Jump if not equal/Jump if not zero. JA/JNBE Jump if above/Jump if not below or equal. JAE/JNB Jump if above or equal/Jump if not below. JB/JNAE Jump if below/Jump if not above or equal. JBE/JNA Jump if below or equal/Jump if not above.

JG/JNLE Jump if greater/Jump if not less or equal.

JGE/JNL Jump if greater or equal/Jump if not less.

JL/JNGE if less/Jump if not greater or equal.

JLE/JNG Jump if less or equal/Jump if not greater.

JC
Jump if carry.

JNC
Jump if not carry.

JO
Jump if overflow.

JNO
Jump if not overflow.

JS
Jump if sign (negative).

JNS
Jump if not sign (non-negative).

JPO/JNP
Jump if parity odd/Jump if not parity.

JCXZ/JECXZ Jump register CX zero/Jump register ECX zero.

LOOP Loop with ECX counter.

LOOPZ/LOOPE Loop with ECX and zero/Loop with ECX and equal.

LOOPNZ/LOOPNE Loop with ECX and not zero/Loop with ECX and not equal.

Jump if parity even/Jump if parity.

CALL Call procedure.

RET Return.

JPE/JP

IRET Return from interrupt.

INT Software interrupt.

INTO Interrupt on overflow.

BOUND Detect value out of range.

ENTER High-level procedure entry.

LEAVE High-level procedure exit.

5.1.8. String Instructions

The string instructions operate on strings of bytes, allowing them to be moved to and from memory.

MOVS/MOVSB Move string/Move byte string.

MOVS/MOVSW Move string/Move word string.

MOVS/MOVSD Move string/Move doubleword string.

CMPS/CMPSB Compare string/Compare byte string.

CMPS/CMPSW Compare string/Compare word string.

CMPS/CMPSD Compare string/Compare doubleword string.

SCAS/SCASB
SCAS/SCASW
SCAS/SCASW
SCAS/SCASD
LODS/LODSB
LODS/LODSW
LODS/LODSD
LODS/LODSD
STOS/STOSB
STOS/STOSW
Scan string/Scan doubleword string.
Load string/Load byte string.
Load string/Load word string.
Store string/Store byte string.
Store string/Store word string.

STOS/STOSW Store string/Store word string.
STOS/STOSD Store string/Store doubleword string.
REP Repeat while ECX not zero.

REPE/REPZ

Repeat while equal/Repeat while zero.

REPNE/REPNZ

Repeat while not equal/Repeat while not zero.

REPNE/REPNZ Repeat while not equal/Repeat while not zero.

5.1.9. I/O Instructions

These instructions move data between the processor's I/O ports and a register or memory.

IN Read from a port.
OUT Write to a port.

INS/INSB Input string from port/Input byte string from port.

INS/INSW Input string from port/Input word string from port.
INS/INSD Input string from port/Input doubleword string from port.

OUTS/OUTSB Output string to port/Output byte string to port.
OUTS/OUTSW Output string to port/Output word string to port.
OUTS/OUTSD Output string to port/Output doubleword string to port.

5.1.10. Enter and Leave Instructions

These instructions provide machine-language support for procedure calls in block-structured languages.

ENTER High-level procedure entry. LEAVE High-level procedure exit.

5.1.11. Flag Control (EFLAG) Instructions

The flag control instructions operate on the flags in the EFLAGS register.

STC Set carry flag.
CLC Clear the carry flag.
CMC Complement the carry flag.
CLD Clear the direction flag.
STD Set direction flag.

LAHF
Load flags into AH register.
SAHF
Store AH register into flags.
PUSHF/PUSHFD
PUSHFD
POPF/POPFD
POP EFLAGS from stack.
STI
Set interrupt flag.
CLI
Clear the interrupt flag.

5.1.12. Segment Register Instructions

The segment register instructions allow far pointers (segment addresses) to be loaded into the segment registers.

LDS Load far pointer using DS.
LES Load far pointer using ES.
LFS Load far pointer using FS.
LGS Load far pointer using GS.
LSS Load far pointer using SS.

5.1.13. Miscellaneous Instructions

The miscellaneous instructions provide such functions as loading an effective address, executing a "no-operation," and retrieving processor identification information.

LEA Load effective address. NOP No operation.

UD2 Undefined instruction.
XLAT/XLATB Table lookup translation.
CPUID Processor Identification.