Erriez DHT22 library for Arduino 1.2.0

Generated by Doxygen 1.8.11

Contents

Index

1	DHT	22 - AM	2302/AM2	2303 temperature and humidity sensor library for Arduino	1
2	Clas	s Index			5
	2.1	Class I	_ist		5
3	File	Index			7
	3.1	File Lis	st		7
4	Clas	s Docu	mentatior	n	9
	4.1	DHT22	Class Re	eference	9
		4.1.1	Detailed	Description	9
		4.1.2	Construc	ctor & Destructor Documentation	10
			4.1.2.1	DHT22(uint8_t pin)	10
		4.1.3	Member	Function Documentation	10
			4.1.3.1	available()	10
			4.1.3.2	begin(uint8_t numSamples=0)	10
			4.1.3.3	readHumidity()	11
			4.1.3.4	readSensorData()	11
			4.1.3.5	readTemperature()	11
5	File	Docum	entation		13
	5.1	Erriez	OHT22.cpp	p File Reference	13
		5.1.1	Detailed	Description	13
	5.2	Erriez	OHT22.h F	File Reference	13
		5.2.1	Detailed	Description	14
		5.2.2	Macro D	efinition Documentation	14
			5.2.2.1	DHT22_MIN_READ_INTERVAL	14
			5.2.2.2	DHT22_NUM_DATA_BITS	14

15

DHT22 - AM2302/AM2303 temperature and humidity sensor library for Arduino

This is an Arduino library for the calibrated AM2302/AM2303 digital temperature and relative humidity sensor on a DHT22 breakout PCB.

Library features

- Read 16-bit temperature (synchronous blocking)
- Read 16-bit relative humidity (synchronous blocking)
- Configurable number of read retries when a read error occurs (default is 1 read + 2 retries)
- · Long time duration example
- Temperature and humidity average with a configurable number of samples to remove jitter

AM2302/AM2303 sensor specifications

- · Voltage: 3.3 .. 5V
- · Ultra-low power:
 - Typical 15uA dormancy
 - Typical 500uA measuring
- · Single wire digital serial interface
- · Calibrated digital signal
- · Outstanding long term stability
- · No additional electronic components needed
- · Humidity:
 - Range: 0 .. 99.9 RH (Relative Humidity)
 - Resolution: 0.1 RH
 - Accuracy: +/-2 RH (at 25 degree Celsius)

· Temperature:

Range: -40 .. +125 degree Celsius
Resolution: 0.1 degree Celsius
Accuracy: +/- 0.4 degree Celsius

· Minimum read interval: 2000 ms

 \bullet \sim 31ms to synchronous read humidity, temperature and parity data from sensor (5 Bytes)

Safety warning

According to the datasheet, the AM2302/AM2303 is a low cost consumer temperature sensor. It may not be used in safety critical applications, emergency stop devices or any other occasion that failure of AM2302/AM2303 may cause personal injury.

Hardware

Pull-up resistor DAT pin

- Connect an external 3k3..10k pull-up resistor between the DAT and VCC pins only when:
 - Using a AM2302/AM2303 sensor without a DT22 breakout PCB and the MCU IO pin has no built-in or external pull-up resistor.
- The DHT22 breakout PCB contains a 3k3 pull-up resistor between DAT and VCC.
- Please refer to the MCU datasheet or board schematic for more information about IO pin pull-up resistors.

External capacitor

• Tip: Connect a 100nF capacitor between the sensor pins VCC and GND when read errors occurs. This may stabilize the power supply.

Board - DHT22 pins	VCC	GND	DAT
Arduino UNO / Nano / Micro (ATMega328 boards)	5V (or 3V3)	GND	2 (DIGITAL pin)
Arduino Leonardo	5V (or 3V3)	GND	2 (DIGITAL pin)
Arduino Mega2560	5V (or 3V3)	GND	2 (DIGITAL pin)
Arduino DUE (ATSAM3X8E)	3V3	GND	2 (DIGITAL pin)
ESP8266 (ESP12E / WeMos D1 R2 / NodeMCU v2 or v3)	3V3	GND	GPIO4 (D2)
ESP32 (WeMos Lolin32 OLED / WeMos LOLIN D32)	3V3	GND	GPIO4

Notes:

- GPIO4 uses sketch pin number 4 and is labeled as D2 on some WeMos ESP8266 boards.
- Other MCU's may work, but are not tested.

Examples

Arduino IDE | Examples | Erriez DHT22 Temperature & Humidity:

- DHT22 Getting started example.
- DHT22Average Calculate average temperature and humidity.
- DHT22DurationTest Test reliability connection.
- DHT22Logging Write temperature and humidity every 10 minutes to .CSV file on SD-card with DS3231 RTC.
- DHT22LowPower LowPower AVR targets only. Arduino Pro or Pro Mini at 8MHz is recommended.

Documentation

- Doxygen online HTML
- Doxygen PDF
- AM2303 datasheet
- DHT22 datasheet

Usage

Initialization

```
2 #include <ErriezDHT22.h>
4 // Connect DTH22 DAT pin to Arduino board
6 // Connect DTH22 DAT pin to Arduino DIGITAL pin
7 #if defined(ARDUINO_ARCH_AVR) || defined(ARDUINO_SAM_DUE)
8 #define DHT22_PIN
8 #define DHTZ2_PIN 2
9 #elif defined(ESP32) || defined(ESP32)
                          4 // GPIO4 (Labeled as D2 on some ESP8266 boards)
10 #define DHT22_PIN
11 #else
12 #error "May work, but not tested on this target"
13 #endif
15 DHT22 dht22 = DHT22(DHT22_PIN);
16
17 void setup()
18 {
       // Initialize serial port
20
       Serial.begin(115200);
      Serial.println(F("DHT22 temperature and humidity sensor example\n"));
21
2.2
23
       // Initialize sensor
       dht22.begin();
25 }
```

Read temperature and humidity

```
1 {c++}
2 void loop()
3 {
        // Check minimum interval of 2000 ms between sensor reads
       if (dht22.available()) {
    // Read temperature from sensor
5
             int16_t temperature = dht22.readTemperature();
8
9
             // Read humidity from sensor
              int16_t humidity = dht22.readHumidity();
10
11
              if (temperature == ~0) {
12
                    // Print error (Check hardware connection)
Serial.print(F("Temperature: Error"));
13
15
              } else {
                    // Print temperature
Serial.print(F("Temperature: "));
16
17
                    Serial.print(temperature / 10);
18
                    Serial.print(F("."));
19
                    Serial.print(temperature % 10);
21
                    Serial.println(F(" *C"));
22
              }
2.3
              if (humidity == ~0) {
    // Print error (Check hardware connection)
    Serial.print(F("Humidity: Error"));
2.4
25
27
                    // Print humidity
Serial.print(F("Humidity: "));
28
29
                    Serial.print(humidity / 10);
Serial.print(F("."));
30
31
                    Serial.print(f('.'),')
Serial.print(humidity % 10);
Serial.println(F(" %"));
33
34
35
36
              Serial.println();
37
```

Serial output

```
1 DHT22 temperature and humidity sensor example
2
3 Temperature: 17.7 *C
4 Humidity: 41.0 %
5
6 Temperature: 17.8 *C
7 Humidity: 41.1 %
8
9 ...
```

Library dependencies

• LowPower library for DHT22LowPower.ino.

Library installation

Please refer to the Wiki page.

Other Arduino Libraries and Sketches from Erriez

• Erriez Libraries and Sketches

Class Index

_			
2	1	Clace	l iet

Here are the	e classes, structs, unions and interfaces with brief descriptions:	
DHT22	DHT22 sensor class	9

6 Class Index

File Index

3.1 File List

Here is a list of all documented files with brief descriptions:

ErriezDH122.cpp	
DHT22 (AM2302/AM2303) Humidity and Temperature sensor library for Arduino	13
ErriezDHT22.h	
DHT22 (AM2302/AM2303) Humidity and Temperature sensor library for Arduino	13

8 File Index

Class Documentation

4.1 DHT22 Class Reference

DHT22 sensor class.

#include <ErriezDHT22.h>

Public Member Functions

• DHT22 (uint8_t pin)

Constructor DHT22 sensor.

void begin (uint8_t numSamples=0)

Initialize sensor.

• bool available ()

Check if new temperature or humidity read is allowed.

• bool readSensorData ()

Read data from sensor.

• int16_t readTemperature ()

Read temperature from sensor.

int16_t readHumidity ()

Read humidity from sensor.

4.1.1 Detailed Description

DHT22 sensor class.

According to the datasheet, the AM2302/AM2303 is a low cost consumer temperature sensor. It may not be used in safety critical applications, emergency stop devices or any other occasion that failure of AM2302/AM2303 may cause personal injury.

The AM2302/AM2303 is factory calibrated. However, deviation may occur with aging.

The temperature/humidity read interval in this library is cached for 2 seconds to prevent heating-up the internal chip with continues reading.

Global interrupts are disabled during a synchronous sensor read transfer. This is required to sample the data bit lengths at maximum speed on low-end devices without any application interrupts. The read calls are protected with a timeout.

The application is responsible for checking \sim 0 values after a read which means that the read failed or a timeout occurred. Multiple reads by the application with an average calculation is recommended.

Definition at line 80 of file ErriezDHT22.h.

10 Class Documentation

4.1.2 Constructor & Destructor Documentation

4.1.2.1 DHT22::DHT22(uint8_t *pin*) [explicit]

Constructor DHT22 sensor.

Parameters

pin	Data pin sensor.

Definition at line 39 of file ErriezDHT22.cpp.

4.1.3 Member Function Documentation

4.1.3.1 bool DHT22::available ()

Check if new temperature or humidity read is allowed.

The application should call this function and check if a new temperature and humidity can be read to prevent too fast sensor reads.

Return values

true	Available, interval between sensor reads >= 2000 ms and sensor read was successful.
false	Not available, interval between sensor reads too short, or read failed.

Definition at line 101 of file ErriezDHT22.cpp.

4.1.3.2 void DHT22::begin (uint8_t numSamples = 0)

Initialize sensor.

Parameters

numSamples	Number of samples to calculate temperature and humidity average. This allocates
	sizeof(int16_t) * number of samples. Value 0 (default) will disable average calculation.

Call this function from setup(). \n

- Connect an external 3k3..10k pull-up resistor between the DAT and VCC pins only when:\n using a AM2302/AM2303 sensor without a DT22 breakout PCB\n
 - the MCU IO pin has no built-in or external pull-up resistor. $\ensuremath{\text{N}}$
- The DHT22 breakout PCB contains a 3k3 pull-up resistor between DAT and VCC.\n
- Please refer to the MCU datasheet or board schematic for more information about IO pin\n pull-up resistors.

Definition at line 75 of file ErriezDHT22.cpp.

4.1 DHT22 Class Reference 11

4.1.3.3 int16_t DHT22::readHumidity()

Read humidity from sensor.

Return values

Humidity	Signed humidity with last digit after the point.
\sim 0	Invalid conversion: Sensor read error occurred.

Definition at line 164 of file ErriezDHT22.cpp.

```
4.1.3.4 bool DHT22::readSensorData ( )
```

Read data from sensor.

5 Bytes data will be read when interval between previous read \geq = 2000 ms.

The sensor data is read until a valid conversion has been performed. A valid conversion consists of:

- A valid start condition
- A successful sensor read (5 Bytes data)
- · A correct checksum

Return values

true	Last conversion was successful.
false	Last conversion was unsuccessful.

Definition at line 212 of file ErriezDHT22.cpp.

```
4.1.3.5 int16_t DHT22::readTemperature ( )
```

Read temperature from sensor.

Returns the actual temperature, or a cached temperature when read interval is too short.

Return values

Temperature	Signed temperature with last digit after the point.
\sim 0	Invalid conversion: Sensor read occurred.

Definition at line 121 of file ErriezDHT22.cpp.

The documentation for this class was generated from the following files:

- ErriezDHT22.h
- ErriezDHT22.cpp

12 Class Documentation

File Documentation

5.1 ErriezDHT22.cpp File Reference

DHT22 (AM2302/AM2303) Humidity and Temperature sensor library for Arduino.

```
#include "ErriezDHT22.h"
```

5.1.1 Detailed Description

DHT22 (AM2302/AM2303) Humidity and Temperature sensor library for Arduino.

Source: https://github.com/Erriez/ErriezDHT22 Documentation: https://erriez. \leftarrow github.io/ErriezDHT22

5.2 ErriezDHT22.h File Reference

DHT22 (AM2302/AM2303) Humidity and Temperature sensor library for Arduino.

```
#include <Arduino.h>
```

Classes

class DHT22

DHT22 sensor class.

Macros

- #define DHT22_MIN_READ_INTERVAL 2000
 - Enable debug prints to Serial.
- #define DHT22 NUM DATA BITS (5 * 8)
- #define DEBUG_PRINTLN(...) {}

Debug print configuration.

14 File Documentation

5.2.1 Detailed Description

DHT22 (AM2302/AM2303) Humidity and Temperature sensor library for Arduino.

5.2.2 Macro Definition Documentation

5.2.2.1 #define DHT22_MIN_READ_INTERVAL 2000

Enable debug prints to Serial.

Minimum interval between sensor reads in milli seconds

Definition at line 42 of file ErriezDHT22.h.

5.2.2.2 #define DHT22_NUM_DATA_BITS (5 * 8)

Number of data bits is 5 Bytes * 8 bits: 1 Byte: Humidity high 1 Byte: Humidity low 1 Byte: Temperature high 1 Byte: Temperature low 1 Byte: Parity

Definition at line 50 of file ErriezDHT22.h.

Index

```
available
    DHT22, 10
begin
    DHT22, 10
DHT22, 9
    available, 10
    begin, 10
    DHT22, 10
    readHumidity, 10
    readSensorData, 11
    readTemperature, 11
DHT22_MIN_READ_INTERVAL
    ErriezDHT22.h, 14
DHT22_NUM_DATA_BITS
    ErriezDHT22.h, 14
ErriezDHT22.cpp, 13
ErriezDHT22.h, 13
    DHT22_MIN_READ_INTERVAL, 14
    DHT22_NUM_DATA_BITS, 14
readHumidity
    DHT22, 10
readSensorData
    DHT22, 11
readTemperature
    DHT22, 11
```