A16	ABS control module		
B161	AC refrigerant pressure sensor		
B138	Accelerator pedal position (APP) sensor		
G1	Alternator		
31	Battery -		
30	Battery +		
S13	Brake pedal position (BPP) switch		
CAN-H	Controller area network (data bus) high		
CAN-L	Controller area network (data bus) low		
B54	Crankshaft position (CKP) sensor		
X1	Data link connector (DLC)		
A207	Electronic stability program (ESP) control module		
A35	Engine control module (ECM)		
M6	Engine coolant blower motor		
K12	Engine coolant blower motor relay		
K12-I	Engine coolant blower motor relay 1		
K12-II	Engine coolant blower motor relay 2		
R46	Engine coolant blower motor resistor		
B24	Engine coolant temperature (ECT) sensor		
S186	Engine coolant temperature (ECT) switch		
H63	Engine malfunction indicator lamp (MIL)		
Y104	Evaporative emission (EVAP) canister purge valve		
M12	Fuel pump		
F	Fuse		
X28-II	Fuse box/relay plate, engine bay 1		
X28-III	Fuse box/relay plate, engine bay 2		
X28-I	Fuse box/relay plate, fascia		
B72-I	Heated oxygen sensor (HO2S) 1		
B72-II	Heated oxygen sensor (HO2S) 2		
T1	Ignition coil		
S1	Ignition switch		
15	Ignition switch - ignition ON		
Y3	Injector		
A5	Instrument panel		
A75	Instrumentation control module		
B25	Intake air temperature (IAT) sensor		
B69	Knock sensor (KS)		
B83	Manifold absolute pressure (MAP) sensor		
A11-I	Multifunction control module 1		
A11-II	Multifunction control module 2		
S231	Power steering pressure (PSP) switch		
M89	Throttle motor		
B169	Throttle motor position sensor		
VAN	Vehicle area network		
B33	Vehicle speed sensor (VSS)		

```
□19 □18 □17 □16 □15 □14 □13 □12 □11 □10 □9 □8 □7 □6 □5 □4 □3 □2 □1 □37 □36 □35 □34 □33 □32 □31 □30 □29 □28 □27 □26 □25 □24 □23 □22 □21 □20 □55 □54 □53 □52 □51 □50 □49 □48 □47 □46 □45 □44 □43 □42 □41 □40 □39 □38 □47 □46 □45 □44 □43 □42 □41 □40 □39 □38
```

bl = blue	br = brown	el = cream	ge = yellow
gn = green	gr = grey	nf = neutral	og = orange
rs = pink	rt = red	sw = black	vi = violet
ws = white	hbl = light blue	hgn = light green	rbr = maroon
x = braided cable	y = high tension	z = non-cable connection	


NOTE: In certain diagrams (Citroen, Peugeot & Renault), colour codes are replaced by numbers which are used to identify a particular cable and not the colour. In this instance, the cables will be numbered at each end close to the harness connector.

Manufacturer: Peugeot Engine code: TU5J4 (NFU) Tuned for: R-Cat **Model:** 206 1,6 16V **Output:** 80 (109) 5800


Year: 2000-08

© Autodata Limited 2010

Valid forever. 07.10.2020







Manufacturer: Peugeot Engine code: TU5J4 (NFU) Tuned for: R-Cat

Model: 206 1,6 16V Output: 80 (109) 5800 Year: 2000-08 © Autodata Limited 2010

Valid forever. 07.10.2020

V8.500- /Autodata