A16	ABS control module			
B161	AC refrigerant pressure sensor			
B138	Accelerator pedal position (APP) sensor			
G1	Alternator			
31	Battery -			
30	Battery +			
S13	Brake pedal position (BPP) switch			
S258	Clutch pedal position (CPP) switch			
CAN-H	Controller area network (data bus) high			
CAN-L	Controller area network (data bus) low			
B54	Crankshaft position (CKP) sensor			
X1	Data link connector (DLC)			
A207	Electronic stability program (ESP) control module			
A35	Engine control module (ECM)			
M6	Engine coolant blower motor			
K12	Engine coolant blower motor relay			
K12-I	Engine coolant blower motor relay 1			
K12-II	Engine coolant blower motor relay 2			
R46	Engine coolant blower motor resistor			
R46-I	Engine coolant blower motor resistor 1			
R46-II	Engine coolant blower motor resistor 2			
B24	Engine coolant temperature (ECT) sensor			
S186	Engine coolant temperature (ECT) switch			
H63	Engine malfunction indicator lamp (MIL)			
Y104	Evaporative emission (EVAP) canister purge valve			
M12	Fuel pump			
F	Fuse			
X28-II	Fuse box/relay plate, engine bay			
X28-I	Fuse box/relay plate, fascia			
B72-I	Heated oxygen sensor (HO2S) 1			
B72-II	Heated oxygen sensor (HO2S) 2			
T1	Ignition coil			
15	Ignition switch - ignition ON			
S39	Inertia fuel shut-off (IFS) switch			
Y3	Injector			
A5	Instrument panel			
A75	Instrumentation control module			
B69	Knock sensor (KS)			
B83	Manifold absolute pressure (MAP) sensor			
A11-I	Multifunction control module 1			
A11-II	Multifunction control module 2			
S231	Power steering pressure (PSP) switch			
M89	Throttle motor			
B169	Throttle motor position sensor			
VAN	Vehicle area network			
B33	Vehicle speed sensor (VSS)			

bl = blue	br = brown	el = cream	ge = yellow
gn = green	gr = grey	nf = neutral	og = orange
rs = pink	rt = red	sw = black	vi = violet
ws = white	hbl = light blue	hgn = light green	rbr = maroon
x = braided cable	y = high tension	z = non-cable connection	

NOTE: In certain diagrams (Citroen, Peugeot & Renault), colour codes are replaced by numbers which are used to identify a particular cable and not the colour. In this instance, the cables will be numbered at each end close to the harness connector.

Manufacturer: Citroen
Engine code: KFW (TU3JP/L4)
Tuned for: Sagem S2000 PM1

Model: Berlingo/Berlingo First I/II 1,4

© Autodata Limited 2010 **Valid forever.** 30.10.2020





