ECE_3142: MICROPROCESSOR LAB V Semester B.Tech

Electronics & Communication Engineering

CONTENTS

Expt. No.	TITLE	Page No.
	COURSE OBJECTIVES	3
	INSTRUCTIONS TO THE STUDENTS	3
	EVALUATION PLAN	3
	PRE-LAB PREPARATION	4
1	INTRODUCTION TO ARM7 ASSEMBLY LANGUAGE PROGRAMMING (ADDRESSING MODES)	5
2	INTRODUCTION TO ARM7 ASSEMBLY LANGUAGE PROGRAMMING (DATA PROCESSING-I)	9
3	INTRODUCTION TO ARM7 ASSEMBLY LANGUAGE PROGRAMMING (DATA PROCESSING-II)	11
4	ASSEMBLY LANGUAGE PROGRAMMING GPIOS TO INTERFACE LEDS, SWITCHES BUZZER AND RELAY	14
5	INTERFACING STEPPER MOTOR AND DC MOTOR	17
6	INTERFACING SEVEN SEGMENT LEDS AND HEX KEYPAD	19
7	INTERFACING EXTERNAL DAC AND PROGRAMMING INTERNAL DAC AND ADC	22
8	ASSEMBLY LANGUAGE PROGRAMMING FOR ARM 7 INTERRUPTS	25
9	ARM 7 C PROGRAMMING – I	29
10	ARM 7 C PROGRAMMING - II	33

COURSE OBJECTIVES

CO1: Write ARM7 assembly language program and simulate using Keil IDE

CO2: Demonstrate interfacing ARM7 with peripheral devices

CO3: Write ARM7 programs in embedded C

CO4: Develop and demonstrate project on Microcontrollers

INSTRUCTIONS TO THE STUDENTS

- 1. Students should carry the Lab Manual and Observation Book to every lab session.
- 2. Be on time and follow the institution dress code.
- 3. You should try to analyze and understand the solved problems and then try to solve all the exercise problems of the experiment in the lab.
- 4. Maintaining an observation copy is compulsory for all, where in the results of all the problems solved in the lab should be properly noted down.
- 5. You have to get your results verified and observation copies checked by the instructor before leaving the lab for the day.
- 6. You should maintain a folder of all the programs you do in the lab in the computer you use by your registration number. You are also advised to keep a back-up of it.
- 7. Use of external storage media during lab is not allowed.
- 8. Maintain the timings and the discipline of the lab.

EVALUATION PLAN

- Internal Assessment Marks: 60% (60 marks)
- ✓ Continuous evaluation component (for each experiment):10 marks
- ✓ Assessment is based on, preparation, conduction of each experiment, exercise problems, maintaining the observation note and answering the questions related to the experiment.
- ✓ Total marks of the 10 experiments scaled to 60 marks.

Note: Follow code of conduct (punctual, discipline, and sincere)

- End semester assessment: 40% (40 marks)
- ✓ Write up: 12 marks
- ✓ Conduction: 12 marks
- ✓ Results: 8 marks
- ✓ Viva –Voce: 8 marks
- Mini Project assessment: 100% (100 marks)
- ✓ Abstract and Synopsis: 20 marks
- ✓ Progress of the Project: 20 marks
- ✓ Mid-term Presentation and Demonstration of the Project: 20 marks

✓ Final Presentation and Demonstration of the Project: 40 marks

Final grading will be the average of Mini-project (100 marks) and Regular labs (100 marks)

Note: (i) Best projects will be selected from each batch for project exhibition

(ii) Three best projects will be awarded.

PRE-LAB PREPARATION

- Each lab experiment requires preparation that may involve a significant amount of work.
- The pre-lab work must be completed before arrival at the lab. The pre-lab work will be part of your lab grade and will be evaluated every week.
- The student must revise concepts related to Logic design and Verilog Programming before coming to lab.

LAB JOURNAL

The students have to maintain Lab Journals and need to submit the same to the faculty at start of each lab.

Lab Observation:

- Separate notebook to be maintained for noting the observations made during the conduction of the lab.
- Follow the instructions on the allotted exercises given in Lab Manual.
- Show the program and results to the faculty on completion of experiments and get it verified by them.
- Corrected lab observation book will be the reference for writing the lab record.

Lab Record:

Corrected lab observation book will be the reference for writing up the record. Each experiment must be written neatly and include the following details as applicable.

- Experiment Number and Date
- Experiment Title and Objective
- ARM7 Programs in assembly language/embedded C for each experiment
- Simulation results and analysis
- Conclusion
- Solution to additional assignment problems if any given by faculty

Expt. No. 1 INTRODUCTION TO ARM7 ASSEMBLY LANGUAGE PROGRAMMING (ADDRESSING MODES)

Aim: To understand basics of ARM7 programming and simulation

1.To get familiar with ARM7 programming

```
AREA PROGRAM1, CODE, READONLY; AREA CAN NOT START FROM FIRST COLUMN
01
02
   ENTRY
03
       MOV R1, # OXFFFFFFFF ; MOV IMMEDIATE DATA TO RO
       MOV RO, #8_257 ; MOV IMMEDIATE DATA TO R1
04
05
       MOV R2, #82
       MOV R3,#2_1011101
06
       MOV R4,R1
07
       MOV R5, R2
08
09
```

Note: For the above program try following with immediate data:

- a. line3: 0Xffff, line4: 8 25765, line5:825 and conclude
- b. line3: 0x3E8, line4: 8 275, line5:16000 and conclude
- c. line3: 0xC000003F, line4: 8 275, line5:16000 and conclude
- d. Replace MOV instruction with MVN.

2. Program to use EQU, and Access address/data from data / code Memory

```
01 AD1 EQU 0xAB
02 NUM2 EQU 247
03 NUM3 EQU AD1+1
  AREA PROGRAM1, CODE, READONLY
05 ENTRY
      MOV RO, #AD1 ; 2
06
07
       MOV R1, #NUM2 ; 2
       MOV R2, #NUM3 ;?
08
09
       LDR RO,Q
                  ;2
       LDR R1,=Q
10
11
       ADR R3, P
                   :2
       LDR R5,=R
12
                   :2
13
       ;LDR R6,R
14 s B s
15 Q
       DCD 0xAABBCCDD
16
       DCD 0xABCDEF78
17
18
    AREA
          MEMORY, DATA, READWRITE ; ?
19 VALU DCD 0X11223344
20 R DCD OXABBCCDDE
21 T
       DCD 0X11223344
22
23 RES SPACE 10 ; RESERVE 10 LOCATIONS
       end
24
```

Note: For the above program try following:

- a. Remove semicolon in line13, and check.
- b. Remove semicolon in line13 and use ADR instead of LDR, and check

c. Use ADR in line 12 instead of LDR, and check

3. Program to read from memory and write to memory

```
AREA PROGRAM1, CODE, READONLY
02 ENTRY
03
       ADR RO,Q
04
       LDR R1, [R0] ; ?
       ldrb r2,[r0]
05
       ldrh r3,[r0]
06
       LDR R4,=RES ;?
07
       STR R1, [r4]
08
       strb r2, [r4, #4]
09
       strh r3, [r4, #8]
10
       LDR R6,=VALU ; Specify desired value at 0x40000000
11
                     ; in memory window during runtime
12
       LDR R7, [R6]
13
14
       mov r8, #4;
15
       ldr r9, [r0, r8]
16 3
       В
17 Q
       DCD 0xAABBCCDD
18 P
       DCD 0xABCDEF78
19
20
     AREA
           MEMORY, DATA, READWRITE ;?
  VALU DCD 0X11223344 ; these values never get
       DCD OXABBCCDDE
                       ; initialized in data memory
23 T
       DCD 0X11223344
24
25 RES SPACE 10 ; RESERVE 10 LOCATIONS
       end
```

Note: For the above program try following: Line11: write 8 instead of 5 and check

4.Program on pre and post increments (Use memory window with address 0 for during LDR and use address 0x40000000 during STR)

```
AREA PROGRAM1, CODE, READONLY
01
02 ENTRY
      ADR RO,Q
03
       LDR R1, [R0], #4 ; ?
05
       ldrb r2,[r0]
       LDR R3, [R0, #4]! ;2
06
       ldrh r4,[r0] ;?
07
08
       LDR R5,=R
                        :2
       STR R0, [r5], #4 ;?
09
10
       strb r1,[r5]
11
       strh r2, [r5, #4]!;?
       MOV R6,#8
12
       STRB R1, [R5], R6;?
13
14
       STRH R2, [R5, R6] !;?
      STR R3, [R5]
15
       B s
16 5
       DCB "MANIPAL INSTITUTE OF TECHNOLOGY, MANIPAL"
17 Q
18
       DCD 0xABCDEF78
19
           MEMORY, DATA, READWRITE ;?
20
21 VALU DCD 0X11223344 ; these values never get
      DCD OXABBCCDDE ; initialized in data memory
       DCD 0X11223344
24 RES SPACE 10 ; RESERVE 10 LOCATIONS
25
       end
```

Note: Use **LTORG** between line8 and 9 and check the difference.

Exercise:

Write a program to read one byte, one half-word and on word at data memory locations starting from 0x4000000 (enter during runtime) and store these data back at data memory locations starting from 0x4000001C.

5.Program on data transfer with shift/rotate

```
AREA PROGRAM1, CODE, READONLY
01
02 ENTRY
03
       ADR RO,Q
       LDR R1, =VAL
04
       LDRB R3, [R0]
05
       MOV R4, R3, LSL#2
06
07
       MOV R4, R4, LSR#1
       LDR R5, [R0], R4, LSL#2
08
09
       STRB R5, [R1]
10 S
       B S
11 Q
       DCB 1
12
    AREA MEMORY, DATA, READWRITE ;?
13 VAL DCD 0X11223344
       End
14
```

Note:

- a. Use ROR, RRX, and ASR.
- b. Can rotate left instruction be used?

6.Program to understand SWP instruction

```
AREA PROGRAM1, CODE, READONLY
02 ENTRY
       ADR RO,Q
03
       LDR R1, =VAL
04
05 UP LDRB R3, [R0], #1
       CMP R3,#0
06
       BEQ DN
07
       ADDS R2,#1
08
09
       STRB R3, [R1], #1
       B UP
10
11
  DN LDR RO,=VAL
12 UP1 LDRB R3, [R0]
       SWPB R3, R3, [R1]
13
       SWPB R3, R3, [R0]
14
       ADD R1,#1
15
16
       ADD R0, #1
17
       SUBS R2,#1
       BNE UP1
18
19 S B S
      DCB "ABCDEFGH", 0
20 Q
21
22
     AREA MEMORY, DATA, READWRITE ;?
23 VAL DCD 0X11223344
       END
24
```

7. Program for Multi-word data transfer

```
AREA ASCENDING , CODE, READONLY
02 ENTRY
03
       LDR R12, = SOURCE
       LDR R13, = DEST
04
       MOV R14, #12
05
       LDMIA R12!, {R0-R11}
06
07
       STMIA R13!, {R0-R11}
       LDMIA R12!, {R0-R2}
08
09
       STMIA R13!, {R0-R2}
   ;LOAD/STORE 12 WORDS TO/FROM REGISTERS FROM/TO MEMORY
10
11
  ; CAN BE MEADE TO LOAD/STORE MULTIPLE OF 12 WORDS
12 S
       В
   SOURCE DCD 1,2,3,4,5,6,7,8,9,0XA,0XB,0XC,0XD,0XE,0XF
13
14
   AREA DATA1, DATA, READWRITE
15
          DCW 0X0045
16 DEST
       END
17
```

8. Program to find square of a decimal number (0 to 10) using lookup table

```
AREA SQUARE , CODE, READONLY
01
02 ENTRY
                       ;Mark first instruction to execute
03 START
04
       LDR RO, = TABLE1 ; Load start address of Lookup table
05
       LDR R1,=INP ; Initialize value at 0x40000000
06
       MOV R2,R1
07
       LDR R1, [R1]
                      ; Load no whose square is to be find
       MOV R1,R1,LSL#0x2; R1=Value at INPx4. to point at corresponding square
08
09
       ADD RO,RO,R1
                     ; Load address of element in Lookup table
       LDR R3, [R0]
10
                       ; Get square of given no in R3
       STR R3, [R2, #4]!
11
12 5
       В
13
   ;Lookup table contains Squares of nos from 0 to 10
   TABLE1 DCD 0,1,4,9,0x16,0x25,0x36,0x49,0x64,0x81,0x100;
   AREA DATA1, DATA, READWRITE
16 INP DCD 0X0045
       END
17
                       ; Mark end of file
```

Expt. No. 2 INTRODUCTION TO ARM7 ASSEMBLY LANGUAGE PROGRAMMING (DATA PROCESSING-I)

Aim: To understand data processing

1.Program to check whether the number is even or odd.

```
AREA PROGRAM1, CODE, READONLY
2
  ENTRY
3
      MOV RO, #NUMBER ; READ NUMBER FROM MEMORY
4
      MOVS R1, R0, LSR #1 ; SHIFT LSB TO CARRY
5
      MOVCS R2, #0XFFFFFFFF; IF EVEN
6
      LDRCC R2,=0X55555555; ELSE ODD
7
  S
      B S
8
      END
```

Note: Try with LSL, ASR, ROR and RRX

2. Program to logical operations

```
1 AREA PROGRAM1, CODE, READONLY
2 ENTRY
3 LDR RO, NUMBER1 ; READ NUMBER FROM MEMORY
4 LDR R1, NUMBER2; READ NUMBER FROM MEMORY
5 AND R2,R0,R1
6 EOR R3,R0,R1
7 ORR R4,R0,R1
8 S B S
```

Exercise:

Write a program to perform logical operations on two 48 bit numbers

3. Program to sort in ascending order

```
01 AREA ASCENDING , CODE, READONLY
02 ENTRY
           MOV R8,#4
                               ; INTIALISE COUNTER TO 4(i.e. N=4)
03
04
           LDR R2,=CVALUE
                              ; ADDRESS OF CODE REGION
           LDR R3,=DVALUE
05
                              ; ADDRESS OF DATA REGION
06 LOOPO
          LDR R1, [R2], #4
                              ; LOADING VALUES FROM CODE REGION
           STR R1, [R3], #4
SUBS R8, R8, #1
                              ; STORING VALUES TO DATA REGION
07
                              ; DECREMENT COUNTER
08
                               ; COMPARE COUNTER TO 0
09
           CMP R8,#0
           BNE LOOPO
                               ; LOOP BACK TILL ARRAY ENDS
10
11 START1 MOV R5,#3
        1 MOV R5,#3
MOV R7,#0
LDR R1,=DVALUE
LDR R2,[R1],#4
                               ; INTIALISE COUNTER TO 3 (i.e. N=4)
                               ; FLAG TO DENOTE EXCHANGE HAS OCCURED
12
13
                              ; LOADS THE ADDRESS OF FIRST VALUE
14 LOOP
                              ; WORD ALIGN TO ARRAY ELEMENT
           LDR R3, [R1]
CMP R2,R3
15
                              ; LOAD SECOND NUMBER
16
                               ; COMPARE NUMBERS
                              ; IF THE FIRST NUMBER IS < THEN GOTO LOOP2
17
           BLT LOOP2
           STR R2, [R1], #-4
STR R3, [R1]
                              ; INTERCHANGE NUMBER R2 & R3
18
19
                               ; INTERCHANGE NUMBER R2 & R3
          MOV R7,#1
                               ; FLAG DENOTING EXCHANGE HAS TAKEN PLACE
20
           ADD R1,#4
21
                               ; RESTORE THE PTR
22 LOOP2
         SUBS R5,R5,#1
                               ; DECREMENT COUNTER
           CMP R5,#0
23
                               ; COMPARE COUNTER TO 0
24
           BNE LOOP
                              ; LOOP BACK TILL ARRAY ENDS
          CMP R7,#0
25
                              ; COMPARING FLAG
           BNE START1
26
                              ; IF FLAG IS NOT ZERO THEN GO TO START1 LOOP
27 S
           В
```

```
28 CVALUE DCD 0X44444444 ;DATA
29 DCD 0X11111111
30 DCD 0X33333333
31 DCD 0X2222222
32 AREA DATA1,DATA,READWRITE
33 DVALUE DCD 0X00000000 ;STORE RESULT
34 END
```

4.Program to reverse half-word

```
AREA ASCENDING , CODE, READONLY
02 ENTRY
03
       LDR RO, = NUMBER
04
       LDR R1, [R0]
       AND R2,R1,#0XF
05
06
       MOV R2, R2, LSL#12
07
       AND R3, R1, #0XF0;
       MOV R3, R3, LSL#4
08
       orr r2,r3
09
       AND R4,R1,#0XF00
10
       MOV R4, R4, LSR#4
11
       orr r2, r4
12
       AND R5,R1,#0XF000;
13
       MOV R5, R5, LSR#12
14
15
        orr r2, r5
16
17
    AREA DATA1, DATA, READWRITE
18
19
  NUMBER DCW 0X0045
20
       END
```

- 1. Write a program to check whether or not read number is positive.
- 2. Write a program to separate an array ten numbers into even array and odd array.
- 3. Write a program to count number of 1's present in a word.
- 4. Write a program to arrange N half-words in descending order.
- 5. Write a program to verify that word read from memory is nibble-wise palindrome (ex: 0x1221 is nibble-wise palindrome)
- 6. Write a program to verify that byte read from memory is bit-wise palindrome (ex: b_10111101 is bit-wise palindrome)

Expt. No. 3 INTRODUCTION TO ARM7 ASSEMBLY LANGUAGE PROGRAMMING (DATA PROCESSING-II)

Aim: To understand data processing (Arithmetic operations)

1. Program with different arithmetic instructions.

```
AREA PROGRAM1, CODE, READONLY;
02 ENTRY
03
            LDR R1, NUM1
04
            LDR R2, NUM2
05
            LDR RO, = RES
06
            ADD R3,R1,R2
                             ;R3=R1+R2
            STR R3, [R0], #4
07
            ADC R3,R1,R2
                            ;R3=R1+R2+C
08
09
            STR R3, [R0], #4
           SUB R3,R1,R2 ;R3=R1-R2
10
11
           STR R3, [R0], #4
12
           SBC R3,R1,R2
                            ;R3=R1-R2+C
13
           STR R3, [R0], #4
           RSB R3,R1,R2 ;R3=R2-R1
14
15
           STR R3, [R0], #4
           RSC R3,R1,R2 ;R3=R2-R1+C-1
16
17
           STR R3, [R0], #4
18
           BIC R3,R1,R2 ;R3=R1 AND (~R2)
            STR R3, [R0]
19
20 S
           B S
21 NUM1 DCD 0XF7654321
22 NUM2 DCD 0XF2345678
      AREA MEMORY, DATA, READWRITE ; ?
24 RES DCD 0
                   ; starting address is 0x40000000
       FMD
25
```

Note: Include S at the end in ADD, ADC, SUB, SBC,RSB, RSC and BIC of the above program and observe the CPSR register and data memory.

2. Program to add two 16-bit numbers

```
01 :/* PROGRAM TO ADD two 16-BIT NUMBERS & STORE IN INTERNAL RAM
02 ;/* THE RESULT CAN BE VIEWED IN LOCATION 0X40000000 & ALSO IN RO
03
       AREA ADDITION , CODE, READONLY
04
05 ENTRY
                       ;Mark first instruction to execute
                      ; INTIALISE SUM TO ZERO
; LOADS THE --
06 START
07
       MOV RO,#0
08
       LDR R1, VALUE1
                         ; LOADS THE FIRST VALUE
       LDR R3,MASK
09
                       ; MASK TO GET 16 BIT
       AND R1,R1,R3
10
                          ; MASK MSB
       ADD RO,RO,R1
11
                           ; ADD THE ELEMENTS
       LDR R2, VALUE2
12
       AND R2,R2,R3
13
       ADD RO,RO,R2
14
       LDR R4,=RESULT
15
                          ; LOADS THE ADDRESS OF RESULT
       STR RO, [R4]
                      ; STORES THE RESULT IN R1
16
17 here b here
18 MASK DCD 0X0000FFFF
                          ; MASK MSB
19 VALUE1 DCW OXAAAA
20
   ALIGN
21
   VALUE2 DCW 0X2222
22
23
   AREA DATA2, DATA, READWRITE
                                   ; TO STORE RESULT IN GIVEN ADDRESS
24 RESULT DCD 0X0, 0x0
25
26
       END
                   ; Mark end of file
```

3. Program to add two 64 bit numbers

```
:/* PROGRAM TO ADD two 64-BIT NUMBERS & STORE IN INTERNAL RAM
   :/* THE RESULT CAN BE VIEWED IN LOCATION 0X40000000 onward
       AREA ADDITION , CODE, READONLY
03
04 ENTRY
                        ;Mark first instruction to execute
05
  START
06
       LDR RO, VALUE1+4
                           ; LOADS THE LEAST SIGNIFICANT PART OF FIRST VALUE
       LDR R2, VALUE2+4 ; LOADS THE LEAST SIGNIFICANT PART OF SECOND VALUE
07
       LDR R7, =RESULT
                           ; LOADS THE ADDRESS OF RESULT STORAGE LOCATION
08
                           ; ADJUST RESULT ADDRESS FOR LITTLE ENDIAN FORMAT
       ADD R7, R7, #8
09
       ADDS R4, R0, R2
                            ; ADD THE LSB PART OF THE NUMBERS
10
                            ; STORES THE RESULT IN MEMORY
       STR R4, [R7]
11
                           ; ADJUST RESULT ADDRESS FOR LITTLE ENDIAN FORMAT
       SUB R7, R7, #4
12
       LDR R1, VALUE1
                           ; LOADS THE MOST SIGNIFICANT PART OF FIRST VALUE
13
       LDR R3, VALUE2
                           ; LOADS THE MOST SIGNIFICANT PART OF SECOND VALUE
14
                           ; ADD THE MOST PART OF THE NUMBERS
       ADCS R5, R1, R3
15
16
       STR R5, [R7]
                           ; STORES THE RESULT IN MEMORY
       SUB R7, R7, #4
17
                     ; STORING THE END AROUND CARRY, IF ANY
18
       MOV R6, #0
       ADC r6, r6, #0
19
       STR R6, [R7]
20
21 here b here
   VALUE1 DCD 0XFFA2E640, 0xF2100123 ; NUMBER IS VALUE1 = 0XFFA2E640F2100123
VALUE2 DCD 0XAA1019BF, 0x40023F51 ; NUMBER IS VALUE2 = 0XFFA2E640F2100123
22
      AREA DATA2, DATA, READWRITE ; TO STORE RESULT IN GIVEN ADDRESS
24
25 RESULT DCD 0X0, 0x0, 0x0
26
       END
27
                       ; Mark end of file
```

4. Program to add array 16 bit unsigned array

```
01 ; PROGRAM TO ADD an array of unsigned 16-BIT NUMBERS & STORE IN INTERNAL RAM
02 ; THE RESULT CAN BE VIEWED IN LOCATION 0X40000000 & ALSO IN RO
       AREA ADDITION , CODE, READONLY
03
04 ENTRY
                       ;Mark first instruction to execute
05 START
       MOV RO, #0
                           ; INTIALISE SUM TO ZERO
06
       MOV R0, #0 ; INTIALISE SUM TO ZERO nov r5, #10 ; number of half words to add
07
       LDR R6, =num_array
08
                                   ; points to the array
09 next element
       LDRH R1, [r6]
10
                                ; read the number from array into r1
11
       ADD RO, RO, R1
12
                               ; ADD THE ELEMENTS
13
       add r6, r6, #2
                               ; update pointer for next element
                               ; reduce the count of number of elements in the array
       subs r5, r5, #1
14
15
       bne next element
16
       LDR R4, =RESULT ; LOADS THE ADDRESS OF RESULT STR R0, [R4] ; STORES THE RESULT IN R1
17
18
       STR RO, [R4]
                               ; STORES THE RESULT IN R1
19
20 here b here
21
22 num array DCW 0X1111, 0X2222, 0x3333, 0x4444, 0x5555, 0x6666, 0XAAAA, 0XBBBB, 0xCCCC, 0XDDDD
23
24
       AREA DATA2, DATA, READWRITE ; TO STORE RESULT IN GIVEN ADDRESS
25 RESULT DCD 0X0, 0x0
                 ; Mark end of file
26
       END
```

Exercises

a. Write a program add two four digit Binary Coded Decimal numbers.

5. Program to simulate subtraction

```
1 ; trial of SUB, SBC, RSB instruction
    area Program, CODE, READONLY
 3
   ENTRY
 4 Main
 5
       LDRB R1, x
                       ; load a byte into r1
 6
       LDRH r2, y
                        ; load a word into r2
       LDR r4, =Result
 7
 8
       sub r3, r1, r2 ; normal subtraction, r3 = r1 = r2
 9
       strh r3, [r4]
                        ; store half word result at location pointed by r4
10
       add r4, r4, #4
       rsb R3, R1, r2 ; reverse subtract- r2 - r1 = r3
11
       strh r3, [r4]
12
                        ; store half word result at location pointed by r4
       add r4, r4, #4
13
       sbc r3, r1, r2 ; sbc r3 = r1-r2-!Carry
14
       strh r3, [r4]
                        ; store half word result at location pointed by r4
15
       add r4, r4, #4
16
17
   stop b stop
18
   x DCW
               -0X0001 ; Value to be tried
               -0X0001 ; Value to be tried
19
       DCW
20
       try with same values of x and y and analyse results
21
    AREA Example1_data, data, READWRITE
22
                    ; Need to do this because working with a series of 16-bit data
23
   Result DCW
                   0 ;Storage space
25 END
```

Exercise:

a. Write a program to demonstrate reverse subtraction of two 16 bit numbers with carry

6.Program to multiply two 32 bit numbers

```
THE RESULT CAN BE VIEWED IN LOCATION 0X40000000 & ALSO IN RO
       AREA multiply , CODE, READONLY
 3 ENTRY
                      ;Mark first instruction to execute
 4
   START
                    ; LOADS THE FIRST VALUE
 5
       LDR R1, x
                     ; LOADS THE FIRST VALUE
       LDR R2, y
 6
                       ; LOADS THE ADDRESS OF RESULT
 7
      LDR R4, = RESULT
 8
       mul RO, R1, R2 ; Multiply the numbers
 9
       STR RO, [R4] ; STORES THE RESULT IN RO
10
      umull RO, R3, R1, R2 ; Multiply THE numbers
11
      add R4, R4, #4 ; LOADS THE ADDRESS OF RESULT
12
      STR RO, [R4] ; STORES THE RESULT IN RO
                       ; LOADS THE ADDRESS OF RESULT
13
      add R4, R4, #4
      STR R3, [R4] ; STORES THE RESULT IN R3
14
      smull RO, R3, R1, R2 ; Multiply THE numbers
15
      add R4, R4, #4 ; LOADS THE ADDRESS OF RESULT
16
      STR R0,[R4] ; STORES THE RESULT IN R0
17
       add R4, R4, #4 ; LOADS THE ADDRESS OF RESULT
18
                    ; STORES THE RESULT IN R3
19
       STR R3, [R4]
20 here b here
21 x DCD -0x1
22 v DCD 0X2
23 ; give different set of values for x and y and analyse the results
   AREA DATA2, DATA, READWRITE ; TO STORE RESULT IN GIVEN ADDRESS
25 RESULT DCD 0X0
26
       END
```

- a. Write a program to multiply two 16 bit signed numbers.
- b. Write a program to multiply two 64 bit numbers


Expt. No. 4 ASSEMBLY LANGUAGE PROGRAMMING GPIOs TO INTERFACE LEDS, SWITCHES BUZZER AND RELAY

Aim: To program general purpose input output pins of Arm7 to interface switches, LEDs and Buzzer

1. Program to display ring count on (P0.16-P0.23 pins) LEDs (Active low)

```
IOODIR EQU 0xE0028008 ; Address for configuring Port0 as I/O
   IOOSET EQU 0xE0028004 ; Register address for setting Port0 pins
   IOOCLR EQU 0xE002800C ; Register address for clearing Port0 pins
03
04
       AREA CHANG, CODE, READONLY
       EXPORT __main ; refer the line no 416 of startup.s file
05
06
     main
07
       ENTRY
           LDR r1,=IOODIR ; load the address of the IODIR reg to R1
08
            LDR r0,=0x00FF0000; To set pins P0.16 to P0.23 as output pins
09
10
           STR r0, [r1]
                             ;This configure P0.16 to P0.23 as output pins
           LDR r2,=IOOCLR ; load the address of the IOCLR reg to R2
11
           LDR r3,=I00SET ; load the address of the IOSET reg to R3
12
13
           MOV r4, #0x00010000 ; write a control word to set one bit
   repeat
           STR r4, [r2]
14
   next
15
           LDR r5, =0x2FFFFF ; Delay program to retain the bit for some time.
16
           SUBS r5, r5, #1
   delay
17
           BNE delay
           STR r0, [r3] ; set all pins
18
19
           MOV r4, r4, LSL #1
20
           CMP r4, #0x1000000
21
           BNE next
22
           B repeat
23
```

Light Emitting Diodes (LED's) are components most commonly used for displaying the port line status. There are 8 LEDs on the board; these lines are connected to the Port lines P0.16 (PB0) to P0.23 (PB7) through buffer.




- a. Write an Assembly Language Program (ALP) to display 8-bit Johnson's count.
- b. Write an ALP to display Mod-16 up count on LED circuit.
- c. Write an ALP to display 8-bit BCD up count on LED circuit.

2. Program to interface switch circuit and LEDs

```
01 ; PROGRAM TO READ FROM PORT1 (P1.16-1.23) AND DISPLAY THE SAME ON PORT ( P0.16-0.23
02 IOODIR EQU 0xE0028008 ; Address for configuring Port0 as I/O
   IOOSET EQU 0xE0028004 ; Register address for setting Port0 pins
04 IOOCLR EQU 0xE002800C ; Register address for clearing Port0 pins
05 IO1DIR EQU 0xE0028018 ; UPON RESET CONFIGURED AS INPUT
  IO1PIN EQU 0xE0028010
07
    AREA CHANG, CODE, READONLY
08
       EXPORT main ; refer the line no 416 of startup.s file
09
     main
10
       ENTRY
11
           LDR r1,=IOODIR ; load the address of the IODIR reg to R1
           LDR r0,=0x00FF0000; To set pins P0.16 to P0.23 as output pins
12
13
           STR r0, [r1]
                              ;This configure P0.16 to P0.23 as output pins
           LDR r2,=IOOCLR ; load the address of the IOCLR reg to R2 \,
14
           LDR r3,=IOOSET ; load the address of the IOSET reg to R3
15
           LDR R4, = IO1PIN; TO READ INPUT
16
17
           LDR r1,=IO1DIR
18
           str R0, [R3]
           LDR R5, [R4]
                            ;READ A SWITCH
19
   repeat
           AND R5, #OXFF0000 ; RETAIN ONLY INPUT PORT CONTENT
20
           CMP R5, #0XFF0000 ; CHECK IF SWITCH PRESSED
21
22
           BEQ repeat
23
           str R0, [R3]
                            ; IF TRUE TURN-OFF LEDS
           EOR R5, #OXFF0000; CLEAR THE BIT CORRESPONDIG TO SWITCH PRESSED
24
25
           str R5, [R2]
                            ; DISPLAY CORRESPONDING LED
26
           B repeat
27
```


The switches **SW1** to **SW8** are organized. One end of all the switches are connected to port lines P1.16 – P1.23 and other ends are Ground.



Exercise:

a. Write a program to interface with switches to perform following operations: If SW8 is pressed, turn on, one LED, if SW7 is pressed, turn on, 2 LEDs, if SW6 is pressed, turn on, 4 LEDs and turn on, 8 LEDs if SW5 is pressed.

3. Program to interface Buzzer




```
IOODIR EQU 0xE0028008 ;Address for configuring Port0 as I/O
   IOOSET EQU 0xE0028004 ; Register address for setting Port0 pins
03 IOOCLR EQU 0xE002800C ; Register address for clearing Port0 pins
    AREA CHANG, CODE, READONLY
Π4
       EXPORT __main ; refer the line no 416 of startup.s file
05
06
     main
07
       FNTRY
08
            LDR r1,=IOODIR ; load the address of the IODIR reg to R1
            LDR r0,=0x200; To set P0.9 as output pin for buzzer
09
                              ;This configures PO.9 as output pin
10
            STR r0, [r1]
            LDR r2,=IOOCLR ; load the address of the IOCLR reg to R2
11
            LDR r3,=IOOSET ; load the address of the IOSET reg to R3
12
   ς
            STR RO, [R3];
13
            LDR R4,=0x2FF; Keep varying this value and hear the buzzer
14
15
   delay
            SUBS R4, R4, #1
            BNE delay
16
17
            STR R0, [R2]
            LDR R4,=0x2FFFF; Keep varying this value
18
           SUBS R4, R4, #1
19
   delav1
20
            BNE delay1
21
            В
            END
22
```

b. Write a program to interface Buzzer to generate different tones on buzzer

4. Program to interface relay (P0.10 pin is connected to relay)

```
01 IOODIR EQU 0xE0028008 ; Address for configuring Port0 as I/O
   IOOSET EQU 0xE0028004 ;Register address for setting Port0 pins
Π2
   IOOCLR EQU 0xE002800C ; Register address for clearing Port0 pins
03
    AREA CHANG, CODE, READONLY
04
       EXPORT __main ;refer the line no 416 of startup.s file
05
06
     main
07
       ENTRY
08
            LDR r1,=IOODIR ; load the address of the IODIR reg to R1
09
            LDR r0,=0x400; To set P0.10 as output pin for relay
            STR r0,[r1]
10
                              ;This configure P0.10 as output pin
            LDR r2,=IOOCLR ; load the address of the IOCLR reg to R2
11
12
            LDR r3,=I00SET ; load the address of the IOSET reg to R3
  BACK
            STR RO, [R2]
13
                            ; Relay Open (Turn off LED)
            LDR R4,=0x2FFFFF
14
            SUBS R4, R4, #1
15
   delay
            BNE delay
16
17
            STR R0, [R3]
                           ;Relay Closed (Turn on LED)
            LDR R4,=0x5FFFF
18
19
   delav1
            SUBS R4, R4, #1
20
            BNE delay1
            B BACK
21
22
            END
```



Expt. No. 5 INTERFACING STEPPER MOTOR AND DC MOTOR


Aim: Assembly language programming to interface Stepper and DC motors

1. Program to rotate stepper motor anticlockwise (Full stepping with single coil energized at a time). It is full stepping (step angle 1.80 per step). Note: Short JP13

```
IOODIR EQU 0xE0028008 ; Address for configuring Port0 as I/O
   IOOSET EQU 0xE0028004 ; Register address for setting Port0 pins
   IOOCLR EQU 0xE002800C ; Register address for clearing Port0 pins
   AREA CHANG, CODE, READONLY
05
       EXPORT main ; refer the line no 416 of startup.s file
06
     main
07
08
           LDR r1,=IOODIR ; load the address of the IODIR reg to R1
           LDR r0,=0xF000; To set P0.9 as output pin for buzzer
09
10
           STR r0, [r1]
                             ;This configure P0.12-P0.15 as output pins
           LDR r2,=IOOCLR ; load the address of the IOCLR reg to R2
11
           LDR r3,=I00SET ; load the address of the IOSET reg to R3
12
13
   S
           LDR R5,=0X8000 ; Energise single coil at a time
14 BACK
           STR RO,[R3]
                         ; Set all 4 pins to 1 to turnoff motor
15
           STR R5, [R2]
                          ; Clears one bit at a time to enable a coil (Active low)
16
           LDR R4,=0x2FFF; Keep varying this value for different speed
           SUBS R4, R4, #1;
17
   delay
18
           BNE delay
19
           MOV R5,R5,LSR #1; shift for energising next coil
20
           CMP R5,0X800
                           ; Are all coils energised?
21
           BNE BACK
           B S
22
23
           END
```

Note:

- i. Full stepping can be achieved by energizing two adjacent coils at a time (step angle 1.8° per step).
- ii. Half stepping can be achieved by alternately energizing two coils at a time and then one coil at a time (step angle 0.9° per step)



- a. Write an alp to rotate the stepper motor clockwise to have step angle of 0.9° per step.
- b. Write an alp to rotate stepper motor anticlockwise for 180°.

```
05
       EXPORT main ; refer the line no 416 of startup.s file
06
     main
07
       ENTRY
08
            LDR r1,=IOODIR ; load the address of the IODIR reg to R1
09
            LDR r0,=0x900; To set P0.8 AND P0.11 as output pins for the motor
10
           STR r0, [r1]
                              ;This configure PO.8and PO.11 as output pins
11
            LDR r2,=IOOCLR ; load the address of the IOCLR reg to R2
12
            LDR r3,=IOOSET ; load the address of the IOSET reg to R3
13
            ;LDR R5,=0X800 ; TO SWITCH DIRECTION
14
            LDR R6,=0X100 ; TO TURN ON OR OFF THE MOTOR
15
           STR RO, [R2] ; keep the motor off
16 BACK
           STR R6, [R3]
                          ;TURN ON MOTOR ANTICLOCKWISE DIRECTION
17
           BL delay
18
           STR RO, [R2]
                          ;TURN OFF MOTOR
19
           BL delay
20
           STR RO, [R3]; Motor to rotate clockwise
           BL delay
21
22
           STR RO, [R2] ; TURN OFF MOTOR
23
           BL delay
           B BACK
24
25 delay
           ;subroutine
           LDR R4, = 0x2FFFFF
26
           SUBS R4, R4, #1;
27 up
           BNE up
28
           BX LR
29
           END
30
```

a. Write an alp to control the speed of the DC motor (for some time low speed , then for some time medium speed , high speed and repeat)

Expt. No. 6 INTERFACING SEVEN SEGMENT LEDS AND HEX KEYPAD

Aim: Assembly language programming to interface Seven segment LEDs and Hex keypad.

1.Program to interface Seven Segment Display (Short Jumper JP2 (right two pins))

```
ENTRY
            LDR r1,=IOODIR ; load the address of the IODIR reg to R1
10
            LDR r0,=0xF0FF0000; pins P0.16 to P0.23 and P0.28-P0.31 as output pins
11
12
            STR r0, [r1]
                              ;This configure P0.16 to P0.23 as output pins
            LDR r2,=IOOSET ; load the address of the IOCLR reg to R2
13
            LDR r3,=IOOCLR ; load the address of th
14
                            ; Turn off display
15
            STR RO, [R3]
            LDR R1,=0X803F0000 ; To display 0 on rightmost segment
16
17
            STR R1, [R2]
18
            BL DELAY
            STR RO, [R3]
19
                             ; Turn off display
20
            LDR R1,=0X40060000; To display 1 on third segment
            STR R1, [R2]
21
22
            BL DELAY
23
            STR RO, [R3]
                             ; Turn off display
            LDR R1,=0X205B0000; To display 2 on second segment
24
25
            STR R1, [R2]
26
            BL DELAY
27
            STR RO, [R3]
                             ; Turn off display
28
            LDR R1,=0X104F0000; To display 3 on leftmost segment
29
            STR R1, [R2]
30
            BL DELAY
31
            В
               S
32
   DELAY
33
            LDR r5, =0x2FF ; Delay program to retain the bit for some time.
34 delay
            SUBS r5, r5, #1
            BNE delay
35
36
            BX LR
P0.16
P0.17
P0.18-
P0.19-
      d
P0.20 -
      е
P0.22
P0.23
        P0.28
                P0.29
                        P0.30
                                 P0.31
```

Exercise:


- a. Write an ALP to display Characters of your choice (displayable) on Seven segment display.
- b. Write a program to display ring count on seven segment display unit (as if 4 bit ring)

2. Program to interface hex keypad and seven segment display. Value of the key pressed displayed on the seven segment display

```
INCLUDE VICVPB.S
    AREA key_7, CODE, READONLY
02
03
       EXPORT main ; refer the line no 416 of startup.s file
04
     main
05
       ENTRY
       LDR r1,=IOODIR ; load the address of the IODIR reg to R1
06
07
       LDR r0,=0x10FF0000; pins P0.16 to P0.23 and P0.28 as output pins
NΒ
       STR r0.[r1]
                         ;This configure P0.16 to P0.23 as output pins
       LDR r1,=IO1DIR ; load the address of the IODIR reg to R1
09
       LDR r0,=0x0F00000; configure p1.20-p1.23 as output(scan lines)p1.16-p1.19 as input
10
11
       STR RO, [R1]
```

```
LDR R1,=IO1PIN
12
13
        LDR R2, = IOOPIN
        LDR R4, = IO1CLR
14
  BK1 LDR r0,=0x0F00000
15
16
       STR RO, [R4]; CLEAR SCAN LINES TO CHECK THAT NO KEYS ARE RELEASED
17
       LDR R5, [R1]; READ FROM KEYBOARD
        AND R5,R5,#0X0F0000; RETAIN ONLY RETURN VALUE
18
19
       CMP R5, #0XF0000 ; IF KEY STILL PRESSED, THEN R5 NOT EQUAL TO 0XF0000
20
       BNE BK1 ; CHECK TILL KEYS ARE RELEASED
   BK2 BL DELAY ; WAIT FOR SOME TIME
21
       LDR R5, [R1] ; READ FROM KEYBOARD
22
23
       AND R5, R5, #0XF0000; RETAIN ONLY RETURN VALUE
24
       CMP R5, #0XF0000 ; IF KEY PRESSED, THEN R5 NOT EQUAL TO 0XF0000
25
       BEQ BK2 ; IF KEY IS NOT PRESSED THE GO BACK TO BK2
26
       BL DELAY
27
       LDR R5, [R1] ; READ INPUT
       AND R5,R5,#0XF0000; RETAIN ONLY RETURN VALUE
28
29
       CMP R5, #0XF0000
30
       BEQ BK2 ; CHECK AGAIN FOR KEY PRESSED
31
       LDR RO, = 0XE00000; NOW APPLY 0 ONLY TO ROWO THROUGH P1.20
32
        STR R0, [R1]
33
       LDR R5, [R1]
                     ; READ FROM RETURN LINES
       AND R5, R5, #0XF0000; RETAIN ONLY RETURN VALUE
34
35
        CMP R5, #0XF0000 ; CHECK WHETHER KEY FOR CORRESPONDING ROWO IS PRESSED OR NOT
       BNE ROWO
36
37
        LDR RO, = OXD00000; NOW APPLY 0 ONLY TO ROW1 THROUGH P1.21
       STR R0, [R1]
38
39
       LDR R5, [R1]
                      ; READ FROM RETURN LINES
40
       AND R5, R5, #0XF0000; RETAIN ONLY RETURN VALUE
41
       CMP R5, #0XF0000 ; CHECK WHETHER KEY FOR CORRESPONDING ROWO IS PRESSED OR NOT
       BNE ROW1
42
43
        LDR RO, = 0XB00000; NOW APPLY 0 ONLY TO ROW1 THROUGH P1.22
44
       STR R0, [R1]
45
       LDR R5, [R1]
       AND R5, R5, #0XF0000; RETAIN ONLY RETURN VALUE
46
47
       CMP R5, #0XF0000
       BNE ROW2
48
49
        LDR RO, = 0X700000; NOW APPLY 0 ONLY TO ROW1 THROUGH P1.23
50
       STR RO, [R1]
51
       LDR R5, [R1]
52
       AND R5, R5, #0XF0000; RETAIN ONLY RETURN VALUE
53
       CMP R5, #0XF0000
54
       BNE ROW3
55
       B BK2
56
   ROWO LDR R6, = SEG_CODEO; STARTING ADDRESS SEVEN SEGMENT CODE FOR ROWO
57
        B FIND
58 ROW1 LDR R6, = SEG CODE1; STARTING ADDRESS SEVEN SEGMENT CODE FOR ROW1
59
        B FIND
60
   ROW2 LDR R6, = SEG CODE2 ; STARTING ADDRESS SEVEN SEGMENT CODE FOR ROW3
61
        B FIND
   ROW3 LDR R6, = SEG_CODE3; STARTING ADDRESS SEVEN SEGMENT CODE FOR ROWO
62
   FIND MOV R8,#16
                          ;SHIFTIN TO LEFT TO CHECK FOR CARRY FLAG
63
   NXT MOVS R7, R5, LSL R8
64
       BCC MATCH ; CHECK TILL CARRY FLAG CLEAR SUB R8,R8,#1 ; FOR NEXT BIT SHIFT
65
                        ; FOR NEXT BIT SHIFT
66
        ADD R6,R6,#1
67
                         ; TO POINT TO NEXT MEMORY LOCATION IN THE SAME ROW
       B NXT
68
           LDR RO, = 0X10000000; SELECT AEGMENT FOR DISPLAY
69 MATCH
70
            LDRB R9. [R6]
                           ; FETCH CODE FOR KEY PRESSED
            MOV R9,R9,LSL#16 ; SHIFT TO FIT INTO P0.16-P0.23
71
72
            ORR R9,R9,R0 ; RETAIN BOTH SEGMENT SELSCTION AND CODE
73
            STR R9, [R2]
                              ; SEND TO PORTO TO DISPLAY
            B BK1
74
```

```
75 DELAY
           ;subroutine
76
            LDR R10,=0x2ff
            SUBS R10, R10, #1;
77 up
78
            BNE up
79
            BX LR
80 SEG CODEO
                     DCB 0X3F, 0X06, 0X5B, 0X4F
81 SEG_CODE1
                     DCB 0X66,0X6D,0X7D,0X07
   SEG CODE2
                     DCB 0X7F, 0X6F, 0X77, 0X7C
82
83 SEG CODE3
                     DCB 0X39,0X5E,0X79,0X71
84
85
             END
```



- a. Write a program to display square of a number pressed from the hex keypad on to seven segment display.
- b. Write a program to use hex keypad and seven segment display as a simple calculator that performs single digit addition, subtraction, multiplication and division.

Expt. No. 7 INTERFACING EXTERNAL DAC AND PROGRAMMING INTERNAL DAC AND ADC

Aim: To interface external, 8-bit Digital to Analog Converter (DAC) and programming internal 10 bit, DAC and Analog to Digital Converter (ADC)

1.Program to interface external DAC to generate a square waveform (Short JP3)

```
INCLUDE VICVPB.S
02
       AREA CHANG, CODE, READONLY
03
       EXPORT main ; refer the line no 416 of startup.s file
04
05
       ENTRY
06
           LDR r1,=IOODIR ; load the address of the IODIR reg to R1
07
           LDR r0,=0xFF0000; P0.0 to P0.7 as output
08
           STR r0, [r1]
                            ;This configure PO.O to PO.7 as output pins
09
           LDR r2,=IOOCLR ; load the address of the IOCLR reg to R2
           LDR r3,=IOOSET
10
11 BACK
           STR R0, [R2]
           BL DELAY
12
13
           STR RO, [R3]
           BL DELAY
14
15
           B BACK
16 DELAY
           ;subroutine
17
           LDR R5,=0x2FFF
           SUBS R5, R5, #1;
18 up
19
           BNE up
20
           BX LR
21
           END
```

Exercise:

- a. Write an ALP to generate (i) Ramp wave (ii) Triangle wave (iii) Stair case wave of 10 steps
- b. Write an ALP to generate sinewave [Use the formula $(1+\sin\theta)*128$, with θ varying in steps of 150, Maximum DAC input value is 0xFF].
- 2. Programming internal DAC to generate a ramp waveform using internal DAC (10 bit). To see waveform: Open JP9 (at ADC module) and Observe the Analog output waveform by connecting Oscilloscope (CRO) probe to right side pin of JP9.

```
PINSEL1 EQU 0XE002C004; register to configure P0.16-P0.31 for specific operation
           EQU 0XE006C000; DAC register address
02
03
       AREA CHANG, CODE, READONLY
04
       EXPORT __main ; refer the line no 416 of startup.s file
05
     main
06
       ENTRY
            LDR RO. = PINSEL1:
07
08
            LDR R1, = DACR;
09
            LDR R2,=0X00080000; P0.25 as DAC output
            STR R2, [R0]
10
11 BACK
           MOV R4, R3, LSL#6
12
           STR R4, [R1]
            ADD R3, R3, #1
13
14
            B BACK
15
            END
```

Refer to the datasheet, UM10139.pdf for the description of DACR register

- a. Write an ALP to generate (i) Ramp wave (ii) Triangle wave (iii) Stair case wave of 10 steps
- b. Write an ALP to generate sinewave [Use the formula $(1+\sin\theta)*512$, with θ varying in steps of 1.80 (generate values using MATLAB), Maximum DAC input value is 0x3FF].

3. Program to interface internal ADC. Displays output on seven segment

```
include VICVPB.s
02
    AREA ADC, CODE, READONLY
03
       EXPORT main ; refer the line no 416 of startup.s file
04
     main
05
       ENTRY
06
           LDR R1, = VPBDIV; For Pclk = 30MHz
07
           LDR R0,=0X02
           STR R0, [R1]
08
           LDR r1, = PINSEL1 ;
09
10
           LDR r0,=0X40000; PIN PO.25 AS ADO.
           STR r0,[r1]
11
           LDR r1,=IOODIR ;
12
           LDR r0,=0X30FF0000
13
14
           STR r0, [r1]
15 UP1
           LDR r1,=ADOCR ;
16
           LDR r0,=0X00200410; To select operating mode for A/D conversion
17
           STR r0, [r1]
18
           LDR R2,=1
19
           ORR RO,R2,LSL#24; TO START CONVERSION, SET 24TH BIT OF ADOCR
20
           STR r0, [r1]
21 UP
           LDR R1,=AD0DR4
22
           LDR RO, [R1]
23
           AND R2, R0, #0X80000000
24
           CMP R2,#0X80000000
25
           BNE UP
           MOV RO, RO, LSR#6
26
           LDR R3,=0X3FF
27
28
           AND RO,RO,R3 ; RETAIN LOWER 10 BITS
            LDR R3,=310 ; FOR VOLTAGE L.T. 1 V
29
30
            CMP RO, R3
            BPL NXT1
31
32
            LDR R3,=0
            B CODE
33
  NXT1
            LDR R3,=621 ; FOR VOLTAGE L.T. 2 V
34
35
            CMP RO, R3
            BPL NXT2
36
37
            LDR R3,=0X10
38
            B CODE
            LDR R3,=931; FOR VOLTAGE L.T. 3 V
39
  NXT2
40
            CMP RO, R3
41
            BPL NXT3
42
            LDR R3,=0X20
43
            B CODE
   NXT3
            LDR R3,=1023;3.3V
44
45
            CMP RO, R3
            BPL NXT4
46
47
            LDR R3,=0X30
            B CODE
48
49 NXT4
          LDR R3,=0X33
50
   CODE
            LDR R1, = SEG CODEL
            AND R2,R3,#0X0F
51
52
            LDRB R0, [R1,R2]
53
            LDR R4,=0X20000000
54
            MOV RO, RO, LSL#16 ; SHIFT TO FIT IN TO PO.16-PO.23
55
            ORR RO, RO, R4
            LDR R1,=IOOPIN
56
```

```
57
            STR R0, [R1]
            BL DELAY
58
            LDR R1, = SEG CODEU
59
60
            AND R2,R3,#0XF0
            MOV R2, R2, LSR#4
61
62
            LDRB R0, [R1,R2]
            LDR R4,=0X10000000
63
64
            MOV RO,RO,LSL#16 ; SHIFT TO FIT IN TO PO.16-PO.23
65
            ORR RO, RO, R4
66
            LDR R1,=IOOPIN
67
            STR R0, [R1]
            BL DELAY
68
69
            B UP1
70
   DELAY
            ;subroutine
71
            LDR R10,=0x2FF
72
   up1
            SUBS R10, R10, #1;
            BNE up1
73
74
            BX LR
75
   SEG CODEL DCB 0X3F,0X06,0X5B,0X4F
   SEG CODEU DCB 0XBF,0X86,0XDB,0XCF
77
            END
```


a. Write a program to interface seven segment display to show the readings with the resolution of 0.1 Volts for input analog voltage

Expt. No. 8 ASSEMBLY LANGUAGE PROGRAMMING FOR ARM 7 INTERRUPTS

Aim: To program arm 7 interrupts like EINT0, EINT1, Timer0 and UART0

1. Program to understand External Hardware Interrupt1 (EINT1). Short Jumper JP12. After programming press the switch, SW12.

```
01 INCLUDE VICVPB.S
    AREA INTRUPT, CODE, READONLY
112
03
    EXPORT main ; refer the line no 416 of startup.s file
04
     main
05
       ENTRY
06
       LDR R1,=MEMMAP; User Flash Mode. Interrupt vectors are
07
       LDR R0,=0X01 ;not re-mapped and reside in Flash.
08
       STR R0, [R1]
09
       LDR R1,=IO1DIR
                           ; to configure P1.25 as output
       LDR R0,=0X02000000
10
11
       STR RO, [R1]
12
       LDR R1,=PINSEL0
13
       LDR RO, = 0XCO; TO CONFIGURE PO.3 AS EINT1
       STR R0, [R1]
14
       LDR R1, = EXTMODE
15
16
       LDR RO, = 0X02; TO SELECT EINT1 AS EDGE TRIGGERED(1 FOR EDGE, 0 FOR LEVEL)
17
       STR RO, [R1]
       LDR R1, =EXTPOLAR
18
       LDR RO, = 0X0; TO SELECT EINT1 AS negative EDGE TRIGGERED (0 for negative, 1 for positive)
19
20
       STR RO, [R1]
21
       LDR R1,=VICVectCntl0; slot0 with highest priority
22
       LDR RO,=0x2F; EINT1 number is 15 and 2 for vectored IRQ slot is enabled
23
       STR RO, [R1]
24
       LDR R1,=VICVectAddr0
25
       LDR RO, = IRQ_EInt1; ISR address to be stored in VICVectAddr0
26
       STR R0, [R1]
27
       LDR R1, = VICIntEnable
       LDR R0,=0x00008000; enable EINT1
28
29
       STR RO, [R1]
30
   S
       B S
   IRQ_EInt1
31
        STMDB R13!, {R0-R1}
32
33
       LDR R1, = EXTINT
34
       LDR R0,=0x2
35
       STR R0, [R1]
36
       ldr r2,=0x40000000; Starting address of data memory
37
       ldr r0, [r2]
38
       LDR R1,=IO1PIN
39
       EOR RO, RO, #0X02000000
40
       STR RO, [R1]
41
       str r0, [r2]
        LDR R1, = VICVectAddr
42
        LDR R0,=0
43
        STR RO, [R1]
44
45
        LDMIA R13!, {R0-R1}
        subs\ pc,r14,\sharp4 ; Adjust the PC to jump back to where it was interrupted
46
47
```



- a. Write an ARM7 ALP to program EINT0 (P0.16) to perform same as done in the above program
- b. Write an ARM7 ALP to display the count of events on EINT1, on seven segment LED.
- c. Write an ALP to generate following waveforms using DACR, based on interrupts on EINT1:

No Interrupt	Sinewave
First Interrupt	Square wave
Second Interrupt	Saw tooth wave
Third Interrupt	Triangular wave
Fourth Interrupt and so on	Repeat sine wave

2. Program for Timer0 Interrupt to display every second count on LEDs.

```
INCLUDE VICVPB.S
    AREA TO INT, CODE, READONLY
03
    EXPORT __main ; refer the line no 416 of startup.s file
04
    main
05
       ENTRY
06
       LDR R1, = VPBDIV; For Pclk = 30MHz
07
       LDR R0,=0X02
08
       STR RO, [R1]
09 📜
       LDR R1, = MEMMAP; User Flash Mode. Interrupt vectors are
10 ;
       LDR R0,=0X01 ;not re-mapped and reside in Flash.
11 ;
       STR R0, [R1]
       LDR R1,=IOODIR
12
       LDR R0,=0x00FF0000; Configure P0.16-23 and P0.28,29 as output for seven segment
13
       STR R0, [R1]
14
15
       STR R0, [R1]
16
       LDR R1,=VICVectCntl0; slot0 with highest priority
17
       LDR R0,=0x24; T0 number is 4 and 2 for vectored IRQ slot is enabled
18
       STR RO, [R1]
       LDR R1,=VICVectAddr0
19
20
       LDR RO,=IRQ TIMO; ISR address for TimerO to be stored in VICVectAddrO
21
       STR R0, [R1]
22
       LDR R1, = VICIntEnable
23
       LDR RO, =0x10; enable Timer0
24
       STR RO, [R1]
25
       LDR R1,=TOPR;LOAD 29 SO THAT 30MHz/30= 1 microseconds
26
       LDR R0,=29;
27
       STR R0, [R1]
28
       LDR R1, =TOTCR
       LDR RO,=1; Enable timer
29
       STR R0, [R1]
30
       LDR R1,=TOMR0;
31
       LDR RO,=1000000; Load timer match register0 to generate 1 second
32
33
       STR RO, [R1]
34
       LDR R1, = TOMCR:
35
       LDR RO,=3; To generate interrupt on match Interrupt on MRO
       STR RO,[R1] ; and Reset on MRO: the TC will be reset if MRO matches it.
36
37
       LDR R2, = 0XFF; initial count 0
38 S
       B S
39 IRQ_TIMO
40
       STMDB R13!, {R0-R1}
41
       LDR R1, =TOIR;
42
       LDR R0,=1
43
       STR RO, [R1]
44
       LDR R1, = VICVectAddr
45
       LDR R0,=0
       STR R0, [R1]
46
```

- a. Write a program to display every second count in decimal on seven segment display
- b. Write a program to display any 4 waveforms one after the other every 5 seconds

3.Program to send a character received

After downloading is completed, Open the hyper terminal (Flash Magic->Tools-> TERMINAL), set the Com1 port, baud rate as programmed and Newlines: CR. Push both pins of dip-switch SW11 to OFF position. Open the jumper JP7. Press RESET switch (SW9). Pres any key on the PC keyboard the same will be displayed on the monitor.

```
INCLUDE VICVPB.S
02
    AREA SERIAL, CODE, READONLY
03
    EXPORT __main ; refer the line no 416 of startup.s file
04
    main
05
       ENTRY
06
       LDR R1, = VPBDIV ; PCLK = 30MHzS
07
       LDR R0,=2;
08
       STR R0, [R1]
09
       LDR R1,=PINSEL0 ; P0.0 and P0.1 configured as
10
       LDR RO,=0X05
                      ; TX0 and RX0 respectively
11
       STR R0, [R1]
12
       LDR R1,=UOLCR ; DLAB=1 and 8 bit Caharacter length
13
       LDR RO,=0X83; and one stop bit
       STR R0, [R1]
14
15
       LDR R1,=U0DLL ; for generating baud of 9600
16
       LDR RO,=195;
17
       STR RO, [R1]
       LDR R1, =UODLM ;
18
       LDR R0,=0;
19
       STR R0, [R1]
20
       LDR R1, = UOLCR
21
22
       LDR R0,=0X03;
       STR R0, [R1]; DLAB =0
23
24
       LDR R1, = U0IER
25
       LDR RO, = 0X03; Enable THRE (bit1) and RBR (bit0) interrupt
26
       STR R0, [R1]
27
       LDR R1,=VICVectCntl0; slot0 with highest priority
        LDR RO, = 0x26; UARTO(slot6) and 2 for vectored IRQ is enabled
28
29
        STR R0, [R1]
30
        LDR R1,=VICVectAddr0
31
        LDR RO, = IRQ UARTO; ISR address to be stored in VICVectAddr0
32
        STR R0, [R1]
33
        LDR R1,=VICIntEnable
        LDR RO, = 0x40; enable UARTO interrupt
34
        STR R0, [R1]
35
36 S
       B S
```

```
IRQ_UARTO
37
38
            STMDB R13!, {R0-R1}
39
            LDR R1,=U0IIR; Interrupt identification reg
40 UP1
            LDR RO, [R1]
41
            AND R2,R0,#0X4; Check for receive data available
            CMP R2, #0X4 ;interrupt
42
43
            BNE UP1
                         ; if not equal keep monitoring for interrupt
44
            LDR R1,=UORBR; If interrupt, data is in UORBR
45
            LDRB RO, [R1]
46
            LDR R2, = UOTHR ; Same Character placed in UOTHR
47
            STRB RO, [R2]
48
            LDR R1, = VICVectAddr
            LDR R0,=0;
49
50
            STR R0, [R1]
51
            LDMIA R13!, {R0-R1}
52
            subs pc, r14, #4 ; Adjust the PC to jump back
53
            END
```

- a. Write a program to display the ASCII hex equivalent of the character received by the ARM7 kit sent from the computer keyboard on the LED/ seven segment LED unit
- b. Should be able to program any task such as generation of desired waveform of desired amplitude/frequency, controlling the speed of motors, controlling display units based on the command/s sent from the computer keyboard.

Expt. No. 9 ARM 7 C PROGRAMMING – I

Aim: To program ARM7 in C programming language

1. Program to display up count with a delay of 1 second on LED display unit using Timer.

```
01 #include<1pc21xx.h>
02 void delay(void);
03 int main (void)
04 {
05
   unsigned long int c=0xFF0000;
06
     IOODIR = c;
07
     VPBDIV=2;
     TOMCR=(1<<0)|(1<<2); //Generates interrupt and reset on match
08
                           //Loading match register value
      TOMR0=1000000;
09
10
      TOPR=29;
                             //Loading Prescalar register value
11
12
     while (1)
13
      -{
      IOOSET = c; // Turn ? LEDs
14
15
           delay();
           c-=0x10000;
16
17
           IOOCLR = 0xfF0000; // Turn them ?
18
      }
19 }
20
21 void delay (void)
22
23
      TOTCR= (1<<0);
24
                             //Starting Timer
      while(!(TOIR&(1<<0)));//Waiting for interrupt
25
26
      TOIR=(1<<0); //Clearing interrupt
27
      TOTCR= (1<<1);
                            //Reset Timer0
28 }
```

Exercise:

a) Write a program to generate (i) down count (ii) ring count (iii) Johnson's count (iv) decimal count

2.Program to read input from switches (P1.16-P1.23) and display corresponding LED of LED unit.

```
01 #include <1pc214x.h>
02 int main (void)
03 {
       unsigned long int c=0xFF0000;
04
       IOODIR = c; // Configure pins(?) on Port 0 as Output
05
       IOOSET=c;
06
       while (1)
07
       { c=IO1PIN;
           IOOPIN = c; // Turn ? LEDs
08
09
       }
10 }
```

- a. Write a C program to interface with switches to perform following operations: If SW8 is pressed one LED, if SW7 is pressed display 2 LEDs, if SW6 is pressed display 4 LEDs and, display 8 LEDs if SW5 is pressed.
- b. Write a C program to interface Buzzer

3. Programming LCD to display desire message on it.

```
#include<1pc21xx.h>
002 #include<stdio.h>
003 void lcd init(void);
004 void clr disp(void);
005 void lcd com(void);
006 void lcd data(void);
007 void wr_cn(void);
008 void wr dn (void);
009 void display(void);
010 void delay (unsigned int);
011 unsigned char temp, temp1;
012 unsigned int r,r1,com[]={0x30,0x30,0x20,0x28,0x0c,6,0x80};
013 unsigned char *ptr,disp[] = "WELCOME MANIPAL";
014 int main()
015 { IOODIR = 0x000000FC;
                                  //port intialisation for LCD
        lcd init();
016
                                  //lcd intialisation
017
        delay (3200);
                                  //delay
        clr disp();
018
        delay (3200);
019
020
        ptr = disp;
        while (*ptr!='\0')
021
022
023
             temp1 = *ptr;
024
            lcd data();
025
             ptr ++;
026
        }
027
    while (1);
028 }
029 void lcd init (void)
030  { temp = 0x30;
031
        wr cn();
032
        delay(3200);
       temp = 0x30;
033
       wr cn();
034
035
       delay(3200);
       temp = 0x30;
036
       wr cn();
037
038
       delay(3200);
        temp = 0x20;
039
        wr cn();
040
041
        delay (3200);
042 // load command for lcd function setting with lcd in 4 bit mode,
043 // 2 line and 5x7 matrix display
044
        temp = 0x28;
045
        lcd_com();
046
        delay (3200);
047 // load a command for display on, cursor on and blinking off
048
       temp1 = 0x0C;
049
        lcd com();
050
        delay(800);
051
   // command for cursor increment after data dump
052
        temp1 = 0x06;
053
        lcd com();
054
        delay(800);
055
        temp1 = 0x80;
        lcd com();
056
```

```
057
        delay(800);
058
059
060 void 1cd data(void)
061 {
       temp = temp1 & 0xf0;
062
063
       wr dn();
064
       temp= temp1 & 0x0f;
       temp= temp << 4;
065
990
       wr dn();
067
       delay(100);
068 }
069 void wr dn(void)
                                ////write data reg
070 {
        IOOCLR = 0x000000FC;
071
                                // clear the port lines.
                             // Assign the value to the PORT lines
        IOOSET = temp;
072
                              // set bit RS = 1
073
        IOOSET = 0x00000004;
       IOOSET = 0x00000008;
074
                               // E=1
075
        delay(10);
        IOOCLR = 0x000000008;
076
077
078 void 1cd com (void)
079 {
       temp = temp1 & 0xf0;
080
       wr_cn();
081
       temp = temp1 & 0x0f;
082
       temp = temp << 4;
083
084
       wr cn();
084
      wr cn();
       delay(500);
085
086 }
087 void wr_cn(void)
                                   //write command reg
088 {
                                // clear the port lines.
089
       IOOCLR = 0x000000FC;
                                   // Assign the value to the PORT lines
090
       IOOSET = temp;
       IOOCLR = 0x00000004;
                                   // clear bit RS = 0
091
       IOOSET = 0x000000008;
                                   // E=1
092
093
       delay(10);
        IOOCLR = 0x000000008;
094
095 }
096 void clr disp(void)
097
098 // command to clear lcd display
       temp1 = 0x01;
099
100
        lcd com();
101
        delay(500);
102 }
103
104 void delay (unsigned int r1)
105 {
        for (r=0;r<r1;r++);
106
107 }
```

16X2 LCD interface details:

A 16X2 Alphanumeric LCD Display with back light is provided along with the Evaluation Board. The LCD is interfaced using 4 – bit mode.

RS = 0 for sending Command to the LCD, controlled by port P0.2

RS = 1 for sending Data to the LCD, controlled by port P0.2

R/W = 1 for reading from the LCD

R/W = 0 for writing to the LCD, normally it is grounded

EN = 0 for disabling the LCD

EN = 1 for enabling the LCD, controlled by port P0.3


D4 = P0.4

D5 = P0.5

D6 = P0.6

D7 = P0.7

LCD



- a. Write a C program to interface stepper motor/ DC motor clockwise/anticlockwise and control the speed.
- b. Write a C program to interface hex keypad and seven segment LEDs to display data corresponding to the key pressed.
- c. Write a C program to interface hex keypad and LCD to display data corresponding to the key pressed.
- d. Write a C program to display waveforms using internal DAC to display on the CRO.

Expt. No. 10 ARM 7 C PROGRAMMING - II

Aim: To program ARM7 interrupts, and PWM in C programming language

1. C-program to turn on or off the LED based in the external hardware interrupt1.

Note: After programming press the switch, SW12 (Short JP12).


```
01 #include<1pc214x.h>
02 void Extint1 Isr(void)
                                   //declaration of ISR
                           irq;
03 unsigned char int_flag=1;
04 unsigned long int c= 0X02000000;
05 int main (void)
                       //P1.25 output
06 {
       IO1DIR |=c;
07
       IO1SET = c;
08
       PINSELO =0X000000c0;
                               //P0.3 EINT1
       EXTMODE = 0 \times 02;
                          // falling egge trigger and active low
09
       EXTPOLAR = 0X00:
10
11
       VICVectAddr0 = (unsigned long) Extint1 Isr; // EINT1 ISR function name
       VICVectCntl0 = 0x20 | 15;//EINT1 to interrupt priority 0
12
       VICIntEnable |= 0x00008000;//Enable the EINT1 interrupt
13
14
       while (1)
                                //looping for interrupt
15
       if(int flag == 0x01)
16
          IO1SET = 0x020000000;
17
18
          else
          IO1CLR = 0X02000000;
19
20
21 }
22 void Extint1 Isr(void) irg //whenever there is a low edge on EINTO
23 {
24
       EXTINT = 0 \times 02;
                           //clear the interrupt
25
       VICVectAddr=0;//Acknowledge Interrupt
26
27
        int flag =~int flag ;// complement the flag
28 }
```

2. C-program to display up count on LEDs using Timer0 interrupt

```
01 #include <1pc214x.h>
02 unsigned long int c=0xff;
03
    irg void TO ISR (void)
04 {
     c-=1:
       IOOPIN = c<<16;
05
                          /* up count*/
       TOIR = ( TOIR | (0x01) );
06
07
       VICVectAddr = 0x00;
08 }
09 int main (void)
10
  VPBDIV = 2; /* For Pclk = 30MHz */
11
12 IOODIR = ( IOODIR | (0X00ff0000) ); /* p1.25 as output pin for LED */
13 IOOPIN = IOOPIN | 0X00ff0000; /* Writing 1 to LED pin P1.25 */
14 VICVectAddr0 = (unsigned) T0 ISR; /* T0 ISR Address */
15 VICVectCnt10 = 0x00000024; /* Enable T0 IRQ slot */
16 VICIntEnable = 0x00000010; /* Enable T0 interrupt */
17
  VICIntSelect = 0x00000000; /* TO configured as IRQ */
18 TOTCR = 0x02; /* Reset TC and PR */
19 TOCTCR = 0x00; /* Timer mode, increment on every rising edge */
20 TOPR = 0x1D; /* Load Pre-Scalar counter with 29, timer to count every 1usec */
21 TOMRO = 1000000; /* Load timer counter for 1sec delay */
22 TOMCR = 0x0003; /* Interrupt generate on match and reset timer */
23 TOTCR = 0x01; /* Enable timer */
24 while (1);
25 }
```

3.Program to generate duty cycle using PWM interrupt. This program generates 1 msec square wave.

```
#include <LPC21xx.h>
     irg void PWM ISR (void)
02
          PWMIR = 0x100; /* Clear PWM4 interrupt */
03
04
       VICVectAddr = 0x00000000;
05
06
  int main (void)
07
  {
       VPBDIV
                   = 0x000000002;
N8
       PINSEL0 = 0x00020000 ;// configure p0.8
09
10
       VICVectAddr0 = (unsigned) PWM ISR; /* PWM ISR Address */
       VICVectCntl0 = (0x00000020 | 8); /* Enable PWM IRQ slot */
11
       VICIntEnable = VICIntEnable | 0x00000100; /* Enable PWM interrupt */
12
       VICIntSelect = VICIntSelect | 0x00000000; /* PWM configured as IRQ */
13
   // For PWM4 double edge
14
15
       PWMTCR = 0x02; /* Reset and disable counter for PWM */
16
       PWMPR = 0x1D;
                      /* Prescale value for 1usec, Pclk=30MHz*/
17
       /* Duty Cycle=(PWMMR4/PWMMR0)*100*/
18
       PWMMR0 = 1000; /* Time period of PWM wave, 1msec */
       PWMMR4 = 100;
                       /* Value for duty cycle (10%) */
19
       PWMMCR = 0x1003;/* Reset and interrupt on MR0 match, interrupt on MR4 match */
20
       PWMLER = 0x0D; /* Latch enable for PWM3, PWM2 and PWM0 */
21
       PWMPCR = 0x1010;/* Enable PWM4 double edge controlled PWM on PWM4 */
22
       PWMTCR = 0x09; /* Enable PWM and counter */
23
24
       while (1);
25 }
```



- a. Write a program to control the directions of stepper motor and DC motor using EINT1.
- b. Write a c program to display count of hardware interrupt 1 on seven segment LEDs
- c. Write a c program to display waveforms based on hardware interrupts usind DACR
- d. Write a c program to display two digit decimal upcount on seven segment LEDs every second.