## Lecture 13: IO Hardware and Mechanisms

Seyed-Hosein Attarzadeh-Niaki

Based on the slides by Edward Lee

Embedded Real-Time Systems


-


### Review


- Network layers in embedded systems
- Wired and wireless networks


Embedded Real-Time Systems


)














### Raspberry Pi Pin Layout

- One of many configurations with SPI buses, analog I/O, etc.
- Many GPIO pins can be reconfigured to be PWM drivers, timers, etc.



Embedded Real-Time Systems





## Input/Output Mechanisms in Sequential Software


#### **Polling**

- Main loop uses each I/O device periodically.
- If output is to be produced, produce it.
- If input is ready, read it.

#### **Interrupts**

- External hardware alerts the processor that input is ready.
- Processor suspends what it is doing.
- Processor invokes an interrupt service routine (ISR).
- ISR interacts with the application concurrently.

Embedded Real-Time Systems



### Example: Send a Sequence of Bytes

```
for(i = 0; i < 8; i++) {
  while(!(UCSROA & 0x20));
  UDR0 = x[i];
}</pre>
```

#### How long will this take to execute? Assume:

- 57600 baud serial speed.
- 8/57600 =139 microseconds.
- Processor operates at 18 MHz.

Each for loop iteration will consume about 2502 cycles.

Embedded Real-Time Systems

13

## Example: Send a Sequence of Bytes (High-Level Version)


```
fd = open("/dev/ttyS0", O_WRONLY | O_NOCTTY);
for (i = 0; i < 8; i++)
    write(fd, &x[i], 1);
close(fd);</pre>
```


Delays are much more unpredictable!

Embedded Real-Time Systems

### Interrupts

- Interrupt Service Routine
  - Short subroutine that handles the interrupt





### Interrupts are Evil



[I]n one or two respects modern machinery is basically more difficult to handle than the old machinery. Firstly, we have got the interrupts, occurring at unpredictable and irreproducible moments; compared with the old sequential machine that pretended to be a fully deterministic automaton, this has been a dramatic change, and many a systems programmer's grey hair bears witness to the fact that we should not talk lightly about the logical problems created by that feature.

(Dijkstra, "The humble programmer" 1972)

Embedded Real-Time Systems

17

### Timed Interrupt **Processor Setup** Reset timer Timer Register Interrupt Service Routine When timer expires, interrupt processor **Initialize Timer** Update Tick / Sample **Execute Task Code** Resumes A bad design pattern: put all the embedded code in ISRs invoked on (timed) interrupts. ISRs must be small. Embedded Real-Time Systems 18

### Example: Set up a timer on an ATmega168 to trigger an interrupt every 1ms.

The frequency of the processor in the command module is 18.432 MHz.

1. Set up an interrupt to occur once every millisecond. Toward the beginning of your program, set up and enable the timer1 interrupt with the following code:

```
TCCR1A = 0x00:
TCCR1B = 0 \times 0 C;
OCR1A = 71:
TIMSK1 = 0x02:
```

The first two lines of the code put the timer in a mode in which it generates an interrupt and resets a counter when the timer value reaches the value of OCR1A, and select a prescaler value of 256, meaning that the timer runs at 1/256th the speed of the processor. The third line sets the reset value of the timer. To generate an interrupt every 1ms, the interrupt frequency will be 1000 Hz. To calculate the value for OCR1A, use the following formula:

```
OCR1A = (processor_frequency / (prescaler * interrupt_frequency)) - 1
OCR1A = (18432000 / (256 * 1000)) - 1 = 71
```

The fourth line of the code enables the timer interrupt. See the ATMega168 datasheet for more information on these control registers.

How do we handle the interrupt?

OTCCR: Timer/Counter Control Register

OOCR: output compare register OTIMSK: Timer Interrupt Mask

- The "prescaler" value divides the system clock to drive the timer.
- Setting a non-zero bit in the timer interrupt mask causes an interrupt to occur when the timer resets.

Source: iRobot Command Module Reference Manual v6

### Setting up the timer interrupt hardware in C

Figure 16-1. 8-bit Timer/Counter Block Diagram #include <avr/io.h> int main (void) { memory- $TCCR1A \neq 0x00;$ mapped register. TCCR1B = 0x0C;OCR1A = 71;But how is this TIMSK1 = 0x02;proper C code? This code sets the hardware up to trigger an interrupt every 1ms.

Embedded Real-Time Systems

20

Source: ATmega168 Reference Manual

```
#define _MMIO_BYTE(mem_addr) (*(volatile uint8_t *)(mem_addr))
#define _SFR_IO8(io_addr) _MMIO_BYTE((io_addr) + 0x20)
                                                                                      //Enable interrupts (interrupt.h)
#define _SFR_MEM8(mem_addr) _MMIO_BYTE(mem_addr)
                                                                                      # define sei() __asm__ _volatile__ ("sei" ::)
#define BV(bit) (1 << (bit))
                                                                                      //Disable interrupts (interrupt.h)
                                                                                      # define cli() __asm__ _volatile__ ("cli" ::)
            //Timer defines (iomx8.h)
                                                                                      #define SIGNAL(signame)
            #define TCCR1A _SFR_MEM8 (0x80)
                                                                                      void signame (void) __attribute__ ((signal)); \
            #define TCCR1B _SFR_MEM8 (0x81)
                                                                                      void signame (void)
            /* TCCR1B */
            #define WGM12 3
                                                                           SEI
                                                                                                                   Global Interrupt Enable
           #define CS12 2
                                                                           CLI
                                                                                                                    Global Interrupt Disable
                                                                                      // Global variables
        void initialize(void) {
                                                                                      volatile uint16_t timer_cnt = 0;
        cli();
                                                                                      volatile uint8_t timer_on = 0;
         // Set I/O pins
                                                                                     // Timer 1 interrupt to time delays in ms SIGNAL(SIG_OUTPUT_COMPARE1A) {
        DDRB = 0x10:
        PORTB = 0xCF;
                                                                                      if(timer_cnt) {
                                                                                        timer_cnt--;
                                                                                      } else {
         // Set up timer 1 to generate an interrupt every 1 ms
                                                                                        timer_on = 0;
         TCCR1A = 0x00:
         \mathsf{TCCR1B} = (\mathsf{\_BV(WGM12)} \mid \mathsf{\_BV(CS12)});
         OCR1A = 71;
        TIMSK1 = _BV(OCIE1A);
                                                                                      void delayMs(uint16_t time_ms) {
        // Set up the serial port with rx interrupt
                                                                                       timer_on = 1;
                                                                                       timer_cnt = time_ms;
                                                                                       while(timer_on);
         // Turn on interrupts
        sei();
                                                                                                                                             21
```

```
#define _MMIO_BYTE(mem_addr) (*(volatile uint8_t *)(mem_addr))
  #define SFR IO8(io_addr) _MMIO_BYTE((io_addr) + 0x20)
                                                                               //Enable interrupts (interrupt.h)
 #define _SFR_MEM8(mem_addr) _MMIO_BYTE(mem_addr)
                                                                               # define sei() __asm___volatile__ ("sei" ::)
 #define BV(bit) (1 << (bit))
                                                                               //Disable interrupts (interrupt.h)
                                                                               # define cli() __asm____volatile__ ("cli" ::)
             //Timer defines (iomx8.h)
                                                                               #define SIGNAL(signame)
             #define TCCR1A _SFR_MEM8 (0x80)
                                                                               void signame (void) __attribute__ ((signal)); \
             #define TCCR1B SFR MEM8 (0x81)
                                                                               void signame (void)
             /* TCCR1B */
             #define WGM12 3
                                                                                                          Ofear Zelv Hay
                                                                     SEI
                                                                                                          Global Interrupt Enable
             #define CS12 2
                                                                    CLI
                                                                                                         Global Interrupt Disable
                                                                               // Global variables
         void initialize(void) {
                                                                               volatile uint16_t timer_cnt = 0;
          cli():
                                                                               volatile uint8_t timer_on = 0;
          // Set I/O pins
                                                                               // Timer 1 interrupt to time delays in ms
          DDRB = 0x10;
                                                                               SIGNAL(SIG_OUTPUT_COMPARE1A) {
          PORTB = 0xCF;
                                                                                if(timer_cnt) {
                                                                                 timer_cnt--;
                                                                               } else {
          // Set up timer 1 to generate an interrupt every 1 ms
                                                                                 timer_on = 0;
          TCCR1A = 0x00;
          TCCR1B = (_BV(WGM12) | _BV(CS12));
          OCR1A = 71;
          TIMSK1 = _BV(OCIE1A);
                                                                               void delayMs(uint16_t time_ms) {
          // Set up the serial port with rx interrupt
                                                                                timer on = 1;
                                                                                timer_cnt = time_ms;
                                                                                while(timer_on);
          // Turn on interrupts
          sei();
                                                      Embedded Real-Time Systems
                                                                                                                                22
```

# Setting up the timer interrupt hardware in C #include <avr/io.h> Figure 16-1. 8-bit Timer/Counter Block Diagram

```
int main (void) {

TCCR1A = 0x00;

TCCR1B = 0x0C;

OCR1A = 71;

TIMSK1 = 0x02;

...
}

(*(volatile uint8_t *) (0x80)) = 0x00;
```

Embedded Real-Time Systems

23

### Set up a timer on an ARM board to trigger an interrupt every 1ms.

## Example: Do something for 2 seconds then stop

```
volatile uint timer count;
                                                     static variable: declared outside
                                                     main() puts them in statically
void ISR(void)
                                                     allocated memory (not on the
    timer_count--;
                                                     stack)
                                                     volatile: C keyword to tell the
 int main(void) {
                                                     compiler that this variable may
    // initialization code
                                                     change at any time, not (entirely)
    SysTickIntRegister(&ISR);
                                                     under the control of this program.
    ... // other init (prev slide)
                                                     Interrupt service routine
    timer count = 2000;
   while(timer count != 0) {
                                                   Registering the ISR to be invoked
      ... code to run for 2 seconds
                                                   on every SysTick interrupt
                                Embedded Real-Time Systems
```

### Concurrency

```
volatile uint timer_count;
void ISR(void) {
   timer_count--;
}

int main(void) {
   // initialization code
   SysTickIntRegister(&ISR);
   ... // other init
   timer_count = 2000;
   while(timer_count != 0) {
        ... code to run for 2 seconds
   }
}
```

concurrent code: logically runs at the same time. In this case, between any two machine instructions in main() an interrupt can occur and the upper code can execute.

### What could go wrong?

Embedded Real-Time Systems

### Concurrency

```
volatile uint timer_count;
void ISR(void) {
  timer_count--;
int main(void) {
  // initialization code
  SysTickIntRegister(&ISR);
                                                what if the interrupt
  ... // other init
  timer count = 2000;
                                                occurs twice during
  while(timer count != 0) {
                                                the execution of this
    ... code to run for 2 seconds
                                                code?
  }
                          What could go wrong?
                          Embedded Real-Time Systems
```

### Improved Example

```
volatile uint timer_count = 0;
void ISR(void) {
  if(timer_count != 0) {
    timer_count--;
int main(void) {
  // initialization code
  SysTickIntRegister(&ISR);
  ... // other init
                                               can an interrupt
  timer count = 2000;
                                               occur here? If it can,
  while(timer count != 0) {
                                               what happens?
    ... code to run for 2 seconds
  }
                          Embedded Real-Time Systems
                                                                28
```

### Issues to Watch For

- Interrupt service routine execution time
- · Context switch time
- Nesting of higher priority interrupts
- Interactions between ISR and the application
- Interactions between ISRs
- ...

Embedded Real-Time Systems

29

### A question:

What's the difference between

Concurrency and Parallelism

Embedded Real-Time Systems

### Concurrency and Parallelism

- A program is said to be concurrent if different parts of the program <u>conceptually</u> execute simultaneously.
- A program is said to be parallel if different parts of the program <u>physically</u> execute simultaneously on distinct hardware.
- A parallel program is concurrent, but a concurrent program need not be parallel.

Embedded Real-Time Systems

31

### Concurrency in Computing

- Interrupt Handling
  - Reacting to external events (interrupts)
  - Exception handling (software interrupts)
- Processes
  - Creating the illusion of simultaneously running different programs (multitasking)
- Threads
  - How is a thread different from a process?
- Multiple processors (multi-cores)

•

Embedded Real-Time Systems


## Modeling The Interrupt Handler Using State Machins volatile uint timerCount = 0;


```
volatile uint timerCount = 0;
void ISR(void) {
    ...... disable interrupts
    → if(timerCount!= 0) {
    E → timerCount--;
    }
    .... enable interrupts
}
int main(void) {
    // initialization code
    SysTickIntRegister(&ISR);
    .... // other init

A → timerCount = 2000;
    while(timerCount!= 0) {
    B → ... code to run for 2 seconds
    }
C .... whatever comes next
```

A key question: Assuming interrupt can occur infinitely often, is position C always reached?

variables: timerCount: uint
input: assert: pure
output: return: pure





What kind of composition is needed here?

Embedded Real-Time Systems

3

## Asynchronous vs Synchronous Composition volatile uint timerCount = 0;


```
void ISR(void) {
    ... disable interrupts
    if(timerCount != 0) {
        timerCount--;
    }
    ... enable interrupts
}
int main(void) {
    // initialization code
    SysTickIntRegister(&ISR);
    ... // other init
    timerCount = 2000;
    while(timerCount != 0) {
        ... code to run for 2 seconds
    }
}
```


Is synchronous composition the right model for this?


Is asynchronous composition (with interleaving semantics) the right model for this?


Answer: no to both.


Embedded Real-Time Systems

















### In short...

Interrupts introduce a great deal of nondeterminism into a computation. Very careful reasoning about the design is necessary.

Embedded Real-Time Systems