### Scilab Textbook Companion for A Course In Mechanical Measurements And Instrumentation by A. K. Sawhney And P. Sawhney<sup>1</sup>

Created by
Parul
Instrumentation
Electrical Engineering
Thapar University
College Teacher
Dr. Sunil K Singla
Cross-Checked by

August 4, 2014

<sup>1</sup>Funded by a grant from the National Mission on Education through ICT, http://spoken-tutorial.org/NMEICT-Intro. This Textbook Companion and Scilab codes written in it can be downloaded from the "Textbook Companion Project" section at the website http://scilab.in

## **Book Description**

Title: A Course In Mechanical Measurements And Instrumentation

Author: A. K. Sawhney And P. Sawhney

Publisher: Dhanpat Rai, New Delhi

Edition: 12

**Year:** 2001

**ISBN:** 8177000233

Scilab numbering policy used in this document and the relation to the above book.

Exa Example (Solved example)

**Eqn** Equation (Particular equation of the above book)

**AP** Appendix to Example(Scilab Code that is an Appednix to a particular Example of the above book)

For example, Exa 3.51 means solved example 3.51 of this book. Sec 2.3 means a scilab code whose theory is explained in Section 2.3 of the book.

## Contents

Li	st of Scilab Codes	4
2	Static Characteristics of Instruments and Measurement systems	12
3	Errors in Measurements and Their Statistical Analysis	25
4	Dynamic Characteristics of Instruments and Measurement systems	48
5	Primary Sensing Elements and Transducers	59
6	Signal Conditioning	84
7	Display Devices and recorders	100
8	Metrology	106
9	Pressure Measurements	111

# List of Scilab Codes

Exa 2.1	calculating static error and static correction	12
Exa 2.2	calculating true value of the temperature	12
Exa 2.3	calculating Relative error expressed as a percentage of f	
	s d	13
Exa 2.4	calculating static error and static correction	13
Exa 2.5	calculating maximum static error Span of the thermome-	
	ter degree C Accuracy of the thermometer in terms of	
	percentage of span	14
Exa 2.6	calculating the pressure for a dial reading of 100	14
Exa 2.7	calculating the noise output voltage of the amplifier .	15
Exa 2.8	calculating the noise voltage	15
Exa 2.9	calculating the signal to noise ratio at input calculating	
	the signal to noise ratio at output calculating the noise	
	factor and noise figure	16
Exa 2.10	calculating the ratio of output signal to noise signal	16
Exa 2.12	calculating the average force and range of error	17
Exa 2.13	calculating the sum of resistances connected in series	
	with uncertainity of one unit	17
Exa 2.14	calculating the power with uncertainity of one unit in	
	voltage and current	18
Exa 2.15	calculating the sum of resistances connected in series	
	with appropriate number of significant figure	18
Exa 2.16	calculating the voltage drop with appropriate number	
	of significant figure	19
Exa 2.17	calculating the sensitivity and deflection factor of wheat-	
	stone bridge	19
Exa 2.18	calculating the volume of the mercury thermometer	20

Exa 2.19	calculating the maximum position deviation resistance
E 2 20	deviation
Exa 2.20	calculating the dead zone
Exa 2.22	calculating the Resolution
Exa 2.23	calculating the Resolution
Exa 2.24	calculating the reading of the multimeter and percentage error
Exa 2.25	calculating the reading of the multimeter and percent-
LAG 2.20	age error
Exa 2.26	calculating the loading error
Exa 2.27	calculating the voltage across the oscilloscope
Exa 2.28	calculating the actual value of current measured value
Exa 2.20	of current and percentage error
Exa 2.29	calculating the maximum available power
Exa 3.1	calculating guarantee value of capacitance
Exa 3.2	calculating percentage limiting error
Exa 3.3	Calculate the range of readings
Exa 3.4	Calculate the limiting error in percent
Exa 3.5	Calculate the range of readings specified in terms of fsd
	and true value
Exa 3.6	Calculate the magnitude and limiting error in ohm and
2110 0.0	in percentage of the resistance
Exa 3.7	calculate the value of relative limiting error in resistance
Exa 3.8	Calculate the guaranteed values of the resistance
Exa 3.9	Calculate the percentage limiting error and range of re-
LAG 9.0	sistance values
Exa 3.10	Calculate the magnitude of power and limiting error .
Exa 3.11	Calculate the magnitude of Force and limiting error .
Exa 3.12	calculate the power loss and relative error
Exa 3.13	Calculate the true power as a percentage of measured
LAG 0.10	power
Exa 3.14	calculate the total resistance error of each register and
LAG 5.14	fractional error of total resistance
Exa 3.15	find the error
Exa 3.16	calculate the Volume and relative error
Exa 3.10 Exa 3.17	
⊔ха <b>3.1</b> 7	calculate the per unit change in the value of spring for
D 2.10	different temperature ranges
Exa 3.18	Calculate apparent resistance actual resistance and error

Exa 3.19	Calculate apparent resistance actual resistance and error
Exa 3.20	Calculate the error and percentage error in the measurement of deflection
Exa 3.21	to find the mean deviations from the mean Average de-
	viation standard deviation and variance
Exa 3.22	to find the mean standard deviation probable error and range
Exa 3.23	to find the arithematic mean maen deviation standard deviation prpobable error of 1 reading standard deviation and probable error of mean standard deviation of standard deviation
Exa 3.24	to find probable no of resistors
Exa 3.25	to find no of 100 rsding exceed 30mm
Exa 3.26	to find no of rods of desired length
Exa 3.27	to find standard deviation and probability of error
Exa 3.28	to find no of expected readings
Exa 3.29	to calculate precision index of instrument
Exa 3.30	to find confidence interval for given confidence levels .
Exa 3.31	to point out the reading that can be rejected by chavenets criterion
Exa 3.32	calculate standard deviation
Exa 3.34	determine value of total current considering errors as
	limiting errors and as standard deviations
Exa 3.35	determine probable error in the computed value of resistnce
Exa 3.37	to find Cq and its possible errors
Exa 3.38	calculate power disipated and uncertaainity in power .
Exa 3.39	to find uncertainity in combined resistance in both series and in parrallel
Exa 3.40	to calculate uncertainity in measurement
Exa 3.41	to calculate uncertainity in power
Exa 4.1	calculating the temperature
Exa 4.2	calculate time to read half of the temperature difference
Exa 4.4	Calculate the temperature after 10s
Exa 4.5	Calculate the value of resistance after 15s
Exa 4.6	Calculate the depth after one hour
Exa 4.8	Calculate time constant
Exa. 4.9	Calculate the temperature after 10s

Exa 4.10	Calculate the temperature at a depth of 1000 m
Exa 4.11	Calculate the value of resistance at different values of
	time
Exa 4.12	calculate the value of damping constant and frequency
	of damped oscillations
Exa 4.13	Calculate damping ratio natural frequency frequency of
	damped oscillations time constant and steady state error
	for ramp signal
Exa 4.14	Calculate the natural frequency
Exa 4.15	Calculate natural frequency and settleing time
Exa 4.16	Calculate time lag and ratio of output and input
Exa 4.17	Calculate the maximum allowable time constant and
	phase shift
Exa 4.18	Calculate maximum value of indicated temperature and
	delay time
Exa 4.19	Find the output
Exa 4.20	Calculate maximum and minimum value of indicated
	temperature phase shift time lag
Exa 4.21	determine damping ratio
Exa 4.22	Calculate the frequency range
Exa 4.23	determine the error
Exa 5.1	Calculate the deflection at center
Exa 5.2	Calculate the angle of twist
Exa 5.3	Calculate the Torque
Exa 5.4	Calculating the displacement and resolution of the po-
	tentiometer
Exa 5.5	plot the graph of error versus K
Exa 5.6	Calculating the output voltage
Exa 5.7	Calculating the maximum excitation voltage and the
	sensitivity
Exa 5.8	Calculating the resolution of the potentiometer
Exa 5.9	Checking the suitability of the potentiometer
Exa 5.10	Checking the suitability of the potentiometer
Exa 5.11	Calculating the possion ratio
Exa 5.12	Calculating the value of the resistance of the gauges .
Exa 5.13	calculate the percentage change in value of the gauge
	resistance
Exa 5.14	Calculating the Gauge factor

Exa 5.15	Calculating the change in length and the force applied	65
Exa 5.16	Calculate the linear approximation	65
Exa 5.17	Calculate the linear approximation	66
Exa 5.18	Calculate the resistance and the temperature	66
Exa 5.19	Calculate the resistance	67
Exa 5.20	Calculate the time	67
Exa 5.21	Calculate the resistance	67
Exa 5.22	find resistance	68
Exa 5.23	calculating the change in temperature	68
Exa 5.24	calculating the frequencies of oscillation	69
Exa 5.25	Calculating the sensitivity and maximum output voltage	69
Exa 5.26	Calculating the temperature	70
Exa 5.27	Calcating the series resistance and approximate error .	70
Exa 5.28	Calculate the values of resistance R1 and R2	70
Exa 5.29	Calculate the percentage linearity	71
Exa 5.30	Calculate senstivity of the LVDT	71
Exa 5.31	calculate the deflection maximum and minimum force	72
Exa 5.32	calculating the sensitivity of the transducer	72
Exa 5.33	Calculate the value of the capacitance afte the applica-	
	tion of pressure	73
Exa 5.34	Calculate the change in frequency of the oscillator	73
Exa 5.35	Calculate the dielectric stress change in value of capac-	
	itance	74
Exa 5.36	Calculate the value of time constant phase shift series	
	resistance amplitude ratio and voltage sensitivity	74
Exa 5.37	Calculate the change in capacitance and ratio	75
Exa 5.40	Calculate the output voltage and charge sensitivity	76
Exa 5.41	Calculate the force	76
Exa 5.42	Calculate the strain charge and capacitance clc	76
Exa 5.43	calculate peak to peak voltage swing under open and	
	loaded conditions calculate maximum change in crystal	
	thickness	77
Exa 5.44	Calculate the minimum frequency and phase shift	78
Exa 5.45	calculate sensitivity of the transducer high frequency	
	sensitivity Lowest frequency Calculate external shunt	
	capacitance and high frequency sensitivity after con-	
	necting the external shunt capacitance	78
Exa 5.46	calculate op volatge	79

Exa 5.47	to prove time constant should be approximately 20T .
Exa 5.48	calculate op volatge
Exa 5.49	Calculate the threshold wavelength
Exa 5.50	Calculate maximum velocity of emitted photo electrons
Exa 5.51	Calculate the resistance of the cell
Exa 5.52	Calculate incident power and cut off frequency
Exa 5.53	Calculate the internal resistance of cell and open circuit
	voltage
Exa 5.54	Find the value of current
Exa 6.1	calculating feedback resistance
Exa 6.2	calculating the closed loop gain
Exa 6.3	calculating the maximum output voltage
Exa 6.4	calculating output voltage due to offset voltage
Exa 6.5	calculating Amplification factor
Exa 6.6	calculating output voltage due to offset voltage
Exa 6.7	calculating gain and feedback resistance
Exa 6.8	Calculating the values of resistances
Exa 6.9	Calculating the value of resistance and capacitance
Exa 6.10	Calculating Difference mode gain and output voltage .
Exa 6.11	Calculating Difference mode Common mode gain and
	CMRR
Exa 6.12	Calculating Signal to noise ratio and CMRR
Exa 6.13	Calculating sensitivity and output voltage
Exa 6.14	calculating minimum maximum time constants and value
	of frequencies
Exa 6.15	calculating time constant and value of capacitance
Exa 6.16	calcuating the passband gain and upper and lower cut
	off frequencies
Exa 6.17	calcuating the value of C
Exa 6.19	calculate the output voltage and sensitivity
Exa 6.20	calculate the output voltage for different values of K .
Exa 6.21	calculating the resistance and output voltage
Exa 6.22	Calculating the bridge output
Exa 6.23	Calculating the resistance of unknown resistance
Exa 6.24	calculating the current
Exa 6.25	Calculating maximum permissible current through strain
	gauge supply voltage and Power dissipation in series re-
	sistance

Exa 6.26	Calculating the maximum voltage sensitivity of the bridge	95
Exa 6.27	Calculating the resolution of the instrument quantiza-	
	tion error and decesion levels	95
Exa 6.28	Calculating the weight of MSB and LSB	96
Exa 6.29	Calculating reference voltage and percentage change .	96
Exa 6.30	Calculating the number of bits Value of LSB Quantiza-	
	tion error minimum sampling rate Aperature time and	
	dynamic range	96
Exa 6.31	Calculating the value of resistance and smallest output	
	current	97
Exa 6.32	Calculating the output voltage	98
Exa 6.33	Calculate the output of successive approximation A to	
	D	98
Exa 6.34	to calculate op dc voltage	99
Exa 7.1	calculating resolution	100
Exa 7.2		100
Exa 7.3	calculating Total possible error and percentage error .	101
Exa 7.4	calculating frequency	102
Exa 7.5	calculating maximum error	102
Exa 7.6	calculating number of turns and current	102
Exa 7.7	calculating speed of the tape	103
Exa 7.8	calculating number density of the tape	103
Exa 7.9	Calculating possible phase angles	104
Exa 7.10	Calculating possible phase angles	104
Exa 8.1	calculate the arrangement of slip gauges	106
Exa 8.2	calculate the sensitivity	107
Exa 8.3	calculate uncertainity in displacement	108
Exa 8.4	calculate difference between height of workpieces and	
	pile of slip gauges	108
Exa 8.5	calculate seperation distance between two surfaces and	
	angle of tilt	109
Exa 8.6	Calculate the difference in two diameters	109
Exa 8.7	Calculate the change in thickness along its length	109
Exa 9.1	calculating the length of mean free path	111
Exa 9.2	Calculate Pressure of air source	112
Exa 9.3	Calculate Pressure head	112
Exa 9.4	calculate height	113
Exa 9.6	calculate error interms of pressure	113

Exa 9.7	calculate angle to which tube is incliend to vertical	113
Exa 9.8	calculate angle to which tube is incliend to horizontal	114
Exa 9.9	calculate Length of scale angle to which tube is incliend	
	to horizontal	114
Exa 9.10	calculate diameter of the tube	115
Exa 9.11	calculate amplification ratio and percentage error	115
Exa 9.12	calculate value of counter weight required	116
Exa 9.13	calculate damping factor time constant error and time	
	lag calculate damping factor natural frequency time con-	
	stant error and time lag	116
Exa 9.14	calculate thickness of diaphram and natural frequency	117
Exa 9.15	calculate the natural length of the spring and dispace-	
	ment	118
Exa 9.16	calculate the open circuit voltage	118
Exa 9.17	calculate the optimum setting	119
Exa 9.18	calculate the output voltage of bridge	120
Exa 9.19	calculate attenuation	120
Exa 9.20	calculate error	121

### Chapter 2

# Static Characteristics of Instruments and Measurement systems

Scilab code Exa 2.1 calculating static error and static correction

```
// calculating static error and static correction
clc;
disp('calculating static error and static correction
')

Am = 127.50;
At = 127.43;
e=Am-At;
disp(e, 'Static error(V)=');
Sc=-e;
disp(Sc, 'Static Correction(V)=');
```

Scilab code Exa 2.2 calculating true value of the temperature

```
1 // calculating true value of the temperature
```

```
2 clc;
3 disp('calculating true value of the temperature')
4 Am = 95.45;
5 Sc=-0.08;
6 At=Am+Sc;
7 disp(At, 'True Temperature(Degree C)=');
```

Scilab code Exa 2.3 calculating Relative error expressed as a percentage of f s d

```
1 // calculating Relative error (expressed as a
      percentage of f.s.d)
2 clc;
3 disp('calculating Relative error (expressed as a
      percentage of f.s.d)')
4 \text{ Am} = 1.46;
5 At = 1.50;
6 \text{ e=Am-At};
7 disp(e, 'Absolute error(V)=');
8 \text{ Sc}=-e:
9 disp(Sc, 'Absolute Correction(V)=');
10 RE=(e/At)*100;
11 disp(RE, 'Relative Error in terms of true value (in
      percentage)=');
12 REF=(e/2.5)*100;
13 disp(REF, 'Relative Error in terms of true value (in
      percentage)=');
```

Scilab code Exa 2.4 calculating static error and static correction

```
1 // calculating static error and static correction
2 clc;
```

```
disp('calculating static error and static correction
')

4 Am = 0.000161;
5 At = 0.159*10^-3;
6 e=Am-At;
7 disp(e, 'Static error(m3/s)=');
8 Sc=-e;
9 disp(Sc, 'Static Correction(m3/s)=');
```

Scilab code Exa 2.5 calculating maximum static error Span of the thermometer degree C Accuracy of the thermometer in terms of percentage of span

```
//calculating maximum static error
disp('calculating maximum static error');
//Span of the thermometer(degree C)
S=200-150;
//Accuracy of the thermometer(in terms of percentage of span)
A=0.0025;
e= A*S;
disp(e, 'Maximum Static error(degree C)=');
```

Scilab code Exa 2.6 calculating the pressure for a dial reading of 100

```
1 // calculating the pressure for a dial reading of
     100
2 clc;
3 disp('calculating the pressure for a dial reading of
     100')
4 P=((27.58-6.895)/150)*100+6.895;
5
```

```
6 disp(P, 'pressure for a dial reading of 100(kN/m2)=');
```

Scilab code Exa 2.7 calculating the noise output voltage of the amplifier

```
// calculating the noise output voltage of the
    amplifier

clc;
disp('calculating the noise output voltage of the
    amplifier')

Bw=100*10^3;
Sn=7*10^-21;
R=50*10^3;
A=(Sn*R*Bw)^0.5;
En=2*A;
disp(En,'Noise voltage at input(V)=');
Ga=100;
Eno=En*Ga;
disp(Eno,'Noise voltage at output(V)=');
```

#### Scilab code Exa 2.8 calculating the noise voltage

```
1 // calculating the noise voltage
2 clc;
3 disp('calculating the noise voltage')
4 Sn=20;
5 Vs=3;
6 Vn=Vs/(Sn)^0.5;
7 disp(Vn, 'noise Voltage(mV)=')
```

Scilab code Exa 2.9 calculating the signal to noise ratio at input calculating the signal to noise ratio at output calculating the noise factor and noise figure

```
1 // calculating the signal to noise ratio at input
2 // calculating the signal to noise ratio at output
3 //calculating the noise factor and noise figure
4 clc;
5 disp('signal to noise ratio at input')
6 Sni=(3*10^-6/(1*10^-6))^2;
7 disp(Sni, 'signal to noise ratio at input=')
8 disp('signal to noise ratio at output')
9 Sno=(60*10^--6/(20*10^--6))^2;
10 disp(Sno, 'signal to noise ratio at output=')
11 disp('New signal to noise ratio at output')
12 Snno=(60*10^--6/(25*10^--6))^2;
13 disp(Snno, 'signal to noise ratio at output=')
14 F=Sni/Snno;
15 disp(F, 'noise Factor=')
16 nf = 10 * log 10 (F);
17 disp(nf, 'noise Figure(dB)=')
```

Scilab code Exa 2.10 calculating the ratio of output signal to noise signal

```
11 Eno=0.12*10^-3;
12 disp(Eno,'Noise voltage at output(V)=');
13 Ra=Eno/En;
14 disp(Ra,'Ratio of signal votage to Noise voltage =');
;
```

Scilab code Exa 2.12 calculating the average force and range of error

```
1 //calculating the average force and range of error
2 clc;
3 F1=10.03;
4 F2=10.10;
5 F3=10.11;
6 F4=10.08;
7 Fav=(F1+F2+F3+F4)/4;
8 disp(Fav, 'Average Force(N) =');
9 Fmax=F3;
10 MaxR=Fmax-Fav;
11 Fmin=F1;
12 MinR=Fav-Fmin;
13 AvgR=(MaxR+MinR)/2;
14 disp(AvgR, 'Average range of error (N)=')
```

Scilab code Exa 2.13 calculating the sum of resistances connected in series with uncertainty of one unit

```
// calculating the sum of resistances connected in
series with uncertainity of one unit
clc;
R1=72.3;
R2=2.73;
R3=0.612;
R=(R1+R2+R3);
```

```
7 disp(R, 'sum of resistances(ohm) = ');
8
9 disp('the resultant resistance is 75.6 ohm with 6 as first doutful figure')
```

Scilab code Exa 2.14 calculating the power with uncertainty of one unit in voltage and current

```
//calculating the power with uncertainity of one
    unit in voltage and current

clc;
V=12.16;
I=1.34;
P=V*I;
disp(P, 'Power(W) =');

disp('the resultant is 16.2 W with 2 as first doutful figure')
```

Scilab code Exa 2.15 calculating the sum of resistances connected in series with appropriate number of significant figure

```
//calculating the sum of resistances connected in
    series with appropriate number of significant
    figure

clc;
R1=28.7;
R2=3.624;
R=(R1+R2);
disp(R, 'sum of resistances(ohm) = ');
```

9 disp('the resultant resistance is 32.3 ohm as one of the resistance is accurate to three significant figure')

Scilab code Exa 2.16 calculating the voltage drop with appropriate number of significant figure

```
// calculating the voltage drop with appropriate
    number of significant figure

clc;
R=31.27;
I=4.37;

E=I*R;
disp(E,'voltage drop(V) =');

disp('the voltage drop is 137 V as one of the resistance is accurate to three significant figure')
```

Scilab code Exa 2.17 calculating the sensitivity and deflection factor of wheatstone bridge

```
//calculating the sensitivity and deflection factor
    of wheatstone bridge
clc;
Mo=3;
Mi=7;
Sen=Mo/Mi;
disp(Sen, 'sensitivity (mm per ohm) =');
Df=Mi/Mo;
disp(Df, 'deflection factor (ohm per mm) =');
```

Scilab code Exa 2.18 calculating the volume of the mercury thermometer

```
//calculating the volume of the mercury thermometer
clc;
Ac=(%pi/4)*0.25^2;
disp(Ac, 'Area of mercury thermometer')
Lc=13.8*10^3;
Vc=Ac*Lc;
disp(Vc, 'Volume of mercury thermometer(mm3)')
```

Scilab code Exa 2.19 calculating the maximum position deviation resistance deviation

```
//calculating the maximum position deviation,
    resistance deviation

clc;
Pl=0.001;
FSD=320;
R=10000;
MDD=(P1*FSD);
disp(MDD,'Maximum displacement deviation(degree)=');
MRD=P1*R;
disp(MRD,'Maximum displacement deviation(ohm)=');
```

Scilab code Exa 2.20 calculating the dead zone

```
1 //calculating the dead zone
2 clc;
3 disp('span s=')
```

```
4 s=600;
5 Dz=0.00125*s;
6 disp(Dz, 'Dead zone(degree C)=');
```

### Scilab code Exa 2.22 calculating the Resolution

```
1 // calculating the Resolution
2 clc;
3 Fs=200;
4 D=100;
5 SD=Fs/D;
6 R=SD/10;
7 disp(R, 'resolution (V)=')
```

### Scilab code Exa 2.23 calculating the Resolution

```
1 // calculating the Resolution
2 clc;
3 Fs=9.999;
4 D=9999;
5 SD=Fs/D;
6 R=SD;
7 disp(R, 'resolution (V)=')
```

Scilab code Exa 2.24 calculating the reading of the multimeter and percentage error

```
3 Z1=20000;
4 Zo=10000;
5 Eo=6;
6 E1=Eo/(1+Zo/Z1);
7 disp(E1, 'Reading of the multimeter (V)=')
8 PE=((E1-Eo)/Eo)*100;
9 disp(PE, 'Percentage error=')
```

Scilab code Exa 2.25 calculating the reading of the multimeter and percentage error

```
//calculating the reading of the multimeter and
percentage error

clc;

Zl=20000;

Zo=1000;

Eo=6;

El=Eo/(1+Zo/Zl);

disp(El, 'Reading of the multimeter (V)=')

PE=((El-Eo)/Eo)*100;

disp(PE, 'Percentage error=')
```

Scilab code Exa 2.26 calculating the loading error

```
1 // calculating the loading error
2 clc;
3 Zl=1000;
4 Zo=200*200/400;
5 Eo=100*200/400;
6 El=Eo/(1+Zo/Zl);
7 disp(El, 'Reading of the multimeter (V)=')
8 PE=((El-Eo)/Eo)*100;
9 disp(PE, 'Percentage loading error=')
```

```
10 Ac=100+PE;
11 disp(Ac, 'Accuracy=')
```

Scilab code Exa 2.27 calculating the voltage across the oscilloscope

```
//calculating the voltage across the oscilloscope
clc;
C=50*10^-6;
f=100000;
disp(f,'frequency=')
Kc=1/(2*%pi*f*C);
R=10^6;
Zl=(R*-%i*Xc)/(R-%i*Xc);
Eo=1;
Zo=10*10^3;

El=Eo/(1+Zo/Zl);
disp(El,'Reading of the multimeter (V)=')
```

Scilab code Exa 2.28 calculating the actual value of current measured value of current and percentage error

```
//calculating the actual value of current, measured
    value of current and percentage error
clc;

Eo=10-((10*1000)/(1000+1000));

Zo=((1000*1000)/(1000+1000))+500;

io=Eo/Zo;

disp(Io,'Actual value of current (A)=')

Zl=100;

Il=Eo/(Zo+Zl);

disp(Il,'Measured value of current (A)=')
```

```
11 PE=((I1-Io)/Io)*100;
12 disp(PE, 'Percentage loading error=')
```

Scilab code Exa 2.29 calculating the maximum available power

```
1 // calculating the maximum available power
2 clc;
3
4 Eo=80*10^-3;
5 Il=5*10^-9;
6 Rl=6*10^6;
7 Ro=(Eo/Il)-R1;
8 Pmax=(Eo^2)/(4*Ro);
9
10 disp(Pmax, 'Maximum available Power(W)=')
```

### Chapter 3

# Errors in Measurements and Their Statistical Analysis

Scilab code Exa 3.1 calculating guarantee value of capacitance

```
// calculating guarantee value of capacitance
clc;
As = 1;
Er=0.05;
Aau=As*(1+Er);
disp(Aau, 'Upper limit(micro F)=');
Aal=As*(1-Er);
disp(Aal, 'Lower limit(micro F)=');
```

Scilab code Exa 3.2 calculating percentage limiting error

```
1 // calculating percentage limiting error
2 clc;
3 As = 150;
4 Er=0.01;
5 dA=As*Er;
```

```
6 As1=75;
7 Er=(dA/As1)*100;
8 disp(Er, 'Percentage limiting error =');
```

#### Scilab code Exa 3.3 Calculate the range of readings

```
// Calculate the range of readings
clc;
fsd=1000;
TP=100;
Efsd=(1/100)*1000;
disp(Efsd, 'magnitude of Error when specified in terms of full scale deflection (w)=')
disp('Thus the meter will read between 90W and 110W')

Etv=(1/100)*100;
disp(Etv, 'magnitude of Error when specified in terms of true value (w)=')
disp('Thus the meter will read between 99W and 101W')
)
```

#### Scilab code Exa 3.4 Calculate the limiting error in percent

```
1 // Calculate the limiting error in percent
2 clc;
3 dA=0.05*5*10^-6;
4 As=2.5*10^-6;
5 Er=(dA/As)*100;
6 disp(Er, 'percemtage limiting error =+/-')
```

Scilab code Exa 3.5 Calculate the range of readings specified in terms of fsd and true value

```
1 // Calculate the range of readings specified interms
      of f.s.d. and true value
2 clc:
3 disp('Range when specified interms of f.s.d.')
4 Error_fsd=1*1000/100;
5 Range_lower_value=100-Error_fsd;
6 disp(Range_lower_value, 'Lower value of range (kN/m2)
      ')
7 Range_upper_value=100+Error_fsd;
8 disp(Range_upper_value, 'Upper value of range (kN/m2)
      ')
9 disp('Range when specified interms of True value')
10 Error_true=1*100/100;
11 Range_lower_value=100-Error_true;
12 disp(Range_lower_value, 'Lower value of range (kN/m2)
13 Range_upper_value=100+Error_true;
14 disp(Range\_upper\_value, 'Upper value of range (kN/m2)
      ')
```

Scilab code Exa 3.6 Calculate the magnitude and limiting error in ohm and in percentage of the resistance

```
9 R=R1+R2+R3;
10 disp(R,'Value of resistance (ohm)=')
11 R_le=R1_le+R2_le+R3_le;
12 disp(R_le,'Limiting Value of resistance (ohm)=')
13 Limiting_error_percentage=R_le*100/R;
14 disp(Limiting_error_percentage,'Limiting Value of resistance (percentage)=+/-')
```

Scilab code Exa 3.7 calculate the value of relative limiting error in resistance

```
// calculate the value of relative limiting error
in resistance
clc;
Re_P=1.5;
Re_I=1;
Re_resistance=(Re_P+2*Re_I);
disp(Re_resistance, 'the value of relative limiting error of resistance in percentage(+/-)=')
```

Scilab code Exa 3.8 Calculate the guaranteed values of the resistance

```
1 // Calculate the guaranteed values of the resistance
2 clc;
3 R1=100;
4 R1_le_perunit=0.5; // R1_le_perunit indicates dR1/R1
= 0.5%
5 R2=1000;
6 R2_le_perunit=0.5;
7 R3=842;
8 R3_le_perunit=0.5;
9 Rx=R2*R3/R1;
10 disp(Rx,'Value of resistance (ohm)=')
```

Scilab code Exa 3.9 Calculate the percentage limiting error and range of resistance values

```
1 // Calculate the percentage limiting error and range
       of resistance values
2 clc;
3 disp('decade a is set at 4000 ohm, so, error in
      decade a=')
4 Er_a=4000*0.1/100;
5 disp(Er_a)
6 disp('decade b is set at 600 ohm, so, error in decade
      b='
7 Er_b=600*0.1/100;
8 disp(Er_b)
9 disp('decade c is set at 30 ohm, so, error in decade
     c=,
10 Er_c=30*0.1/100;
11 disp(Er_c)
12 disp('decade d is set at 9 ohm, so, error in decade d
     = ^{\prime} )
13 Er_d=9*0.1/100;
14 disp(Er_d)
15 Er_total=Er_a+Er_b+Er_c+Er_d;
```

```
16 Re_le_percentage=Er_total*100/4639;
17 disp(Re_le_percentage, 'Percentage Relative limiting error=')
18 Range_lower=4639-Er_total;
19 disp(Range_lower, 'Lower value of range (ohm)=')
20 Range_upper=4639+Er_total;
21 disp(Range_upper, 'upper value of range (ohm)=')
```

Scilab code Exa 3.10 Calculate the magnitude of power and limiting error

```
1 // Calculate the magnitude of power and limiting
      error
2 clc;
3 F=4.58;
4 L=397;
5 R=1202*10^-9;
6 \text{ t=60}:
7 P=(2*\%pi*9.81*F*L*R)/(t*10^6);
8 disp(P, 'Magnitude of power (W)=')
9 dF_pu=0.02/F; // per unit error in force
10 dL_pu=1.3/L; // per unit error in Length
11 dR_pu=1/R; // per unit error in revolution
12 dt_pu=0.5/t; // per unit error in time
13 dP_pu= dF_pu+dL_pu+dR_pu+dt_pu;
14 dP_le=dP_pu*P;
15 disp(dP_le, 'Magnitude of limiting error in power (W)
      ')
```

Scilab code Exa 3.11 Calculate the magnitude of Force and limiting error

```
1 // Calculate the magnitude of Force and limiting
          error
2 clc;
```

```
3 E=200*10^9;
4 L=25*10^-3;
5 b=4.75*10^-3;
6 d=0.9*10^-3;
7 I = (b*d^3)/12;
8 x=2.5*10^-3;
9 F = (3*E*I*x)/(L^3);
10 \operatorname{disp}(F, '\operatorname{Magnitude} \text{ of Force } (N)=')
11 dE_pu=0/E; // per unit error in E
12 	ext{ db_pu=0.0075/b};
13 \, dd_pu=0.0075/d;
14 dx_pu=0.025/x;
15 \text{ dL_pu=0.025/L};
16 dF_pu= (dE_pu+db_pu+3*dd_pu+dx_pu+3*dL_pu)*10^-3;
17
18 disp(dF_pu, 'limiting error in force (N)=+/-')
```

Scilab code Exa 3.12 calculate the power loss and relative error

```
1 // calculate the power loss and relative error
2 clc;
3 I=64*10^-3;
4 R=3200;
5 P=(I^2)*R;
6 disp(P, 'Power(W)=')
7 Re=2*0.75+0.2;
8 disp(Re, 'Relative error (%)=')
```

Scilab code Exa 3.13 Calculate the true power as a percentage of measured power

```
1 // Calculate the true power as a percentage of measured power
```

Scilab code Exa 3.14 calculate the total resistance error of each register and fractional error of total resistance

```
1 //calculate the total resistance, error of each
      register and fractional error of total resistance
2 clc;
3 R1 = 250;
4 R2=500;
5 R3 = 375;
6 R_{true}=1/((1/R1)+(1/R2)+(1/R3));
7 disp(R_true, 'True value of resistance(ohm)=')
8 	 dR1 = 0.025 * R1;
9 dR2 = -0.36 * R2;
10 dR3=0.014*R3;
11 R1_effective=R1+dR1;
12 R2_effective=R2+dR2;
13 R3_effective=R3+dR3;
14 R_{effective} = 1/((1/R1_{effective}) + (1/R2_{effective}) + (1/R2_{effective}) + (1/R2_{effective})
      R3_effective));
15 disp(R_effective, 'Effective value of resistance (ohm
      )=,
16 Fractional_error=(R_true-R_effective)/R_true;
17 disp(Fractional_error, 'Fractional_error')
```

#### Scilab code Exa 3.15 find the error

```
1 //
2 clc;
3 disp('When all the components have 0% error then
      resonant frequency (Hz)')
4 L=160*10^-6;
5 C=160*10^-12;
6 fr=[1/(2*%pi)]*[1/(L*C)]^0.5;
7 disp(fr)
8 disp ('When all the components have +10\% error then
      resonant frequency (Hz)')
9 L_new = (160*10^-6)+0.1*L;
10 C_new = (160*10^-12)+0.1*C;
11 fr_new=[1/(2*%pi)]*[1/(L_new*C_new)]^0.5;
12 disp(fr_new)
13 error = (fr_new-fr)/fr;
14 disp(error, 'error=')
15 disp('When all the components have -10\% error then
      resonant frequency (Hz)')
16 L_new = (160*10^-6) - 0.1*L;
17 C_{new} = (160*10^{-12}) - 0.1*C;
18 fr_new=[1/(2*%pi)]*[1/(L_new*C_new)]^0.5;
19 disp(fr_new)
20 error = (fr_new-fr)/fr;
21 disp(error, 'error=')
```

Scilab code Exa 3.16 calculate the Volume and relative error

```
1 // calculate the Volume and relative error
2 clc;
3 L=250;
```

```
4 d=50;
5 V=((%pi/4)*d^2)*L;
6 disp(V, 'Volume(mm3)=')
7 Re=2*0.2-0.5;
8 disp(Re, 'Relative error (%)=')
```

Scilab code Exa 3.17 calculate the per unit change in the value of spring for different temperature ranges

```
// calculate the per unit change in the value of
    spring for different temperature ranges

clc;

dG_pu=-240*10^-6;

dD_pu=11.8*10^-6;

disp('for temperature change of 20 degree C to 50 degree C (%) =')

d_th=30;

dK_pu=(dG_pu+dD_pu)*d_th*100;

disp(dK_pu)

disp('for temperature change of 20 degree C to -50 degree C (%) =')

d_th=-70;

dK_pu=(dG_pu+dD_pu)*d_th*100;

disp(dK_pu)
```

Scilab code Exa 3.18 Calculate apparent resistance actual resistance and error

```
1 // Calculate apparent resistance, actual resistance
    and error
2 clc;
3 Et=100;
4 It=5*10^-3;
```

```
5 Rt=Et/It;
6 disp(Rt, 'apparent value of resistance (ohm)=')
7 Rv=1000*150;
8 Rx=Rt*Rv/(Rv-Rt);
9 disp(Rx, 'true value of resistance(ohm)')
10 Er_percentage=[(Rt-Rx)/Rx]*100;
11 disp(Er_percentage, 'percentage error=')
```

Scilab code Exa 3.19 Calculate apparent resistance actual resistance and error

```
// Calculate apparent resistance, actual resistance
and error

clc;

Et=40;

It=800*10^-3;

Rt=Et/It;

disp(Rt, 'apparent value of resistance (ohm)=')

Rv=1000*150;

Rx=Rt*Rv/(Rv-Rt);

disp(Rx, 'true value of resistance(ohm)')

Er_percentage=[(Rt-Rx)/Rx]*100;

disp(Er_percentage, 'percentage error=')
```

Scilab code Exa 3.20 Calculate the error and percentage error in the measurement of deflection

```
1 // Calculate the error and percentage error in the
        measurement of deflection
2 clc;
3 l=0.2;
4 E=200*10^9;
5 b=20*10^-3;
```

```
6 d=5*10^-3;
7 D=(4*1^3)/(E*b*d^3);
8 F=1*9.81;
9 x_true= D*F;
10 disp(x_true, 'True value of deflection')
11 x_indicated=D*10.31/(1+.1*D);
12 disp(x_indicated, 'Indicated value of deflection')
13 Er=x_indicated-x_true;
14 disp(Er, 'error=')
15 Er_percentage=Er*100/x_true;
16 disp(Er_percentage, 'Percentage error=')
```

Scilab code Exa 3.21 to find the mean deviations from the mean Average deviation standard deviation and variance

```
1 //to find the mean, deviations from the mean, Average
       deviation, standard deviation and variance
3 clc;
4 x = [532 548 543 535 546 531 543 536];
5 \quad X = sum(x);
6 n=8;
7 a=0;
8 \text{ Mean}=X/n;
9 \operatorname{disp}(X/n, \operatorname{mean}(kHZ));
10 for i=1:n,
11 d(i)=x(i)-Mean
12
       disp(d(i), 'deviations =')
13
     a=a+(abs(d(i)))
14
      end
15
      d_average=a/n;
16 disp(d_average, 'Average deviation (kHz)=')
17 d_2 = sum(d^2);
18 s = sqrt(d_2/(n-1))
19 disp(s, 'standard deviation(kHz)');
```

```
20 V=s^2;
21 disp(V,'varaince (kHZ)2=')
```

Scilab code Exa 3.22 to find the mean standard deviation probable error and range

```
1 //to find the mean, standard deviation, probable
      error and range
2
3 clc;
4 x = [41.7 42 41.8 42 42.1 41.9 42 41.9 42.5 41.8];
5 X = sum(x); disp(X);
6 d=[-.27 .03 -.17 .03 .13 -.07 .03 -.07 .53 -.17];
7 d_2 = sum(d^2);
8 n = 10;
9 disp(X/n, 'mean length(deg C)');
10 disp(sqrt(d_2/n), 'standard deviation(if data is
      infinite)(deg C)');
11 disp(sqrt(d_2/(n-1)), 'standard deviation(deg C)');
12 r1=.6745*sqrt(d_2/(n-1));
13 disp(r1, 'probable error of 1 reading(deg C)');
14 disp(r1/sqrt(n-1), 'probable error of mean(deg C)');
15 \operatorname{disp}(\max(x) - \min(x), \operatorname{range}(\operatorname{deg} C));
```

Scilab code Exa 3.23 to find the arithematic mean maen deviation standard deviation probable error of 1 reading standard deviation and probable error of mean standard deviation of standard deviation

```
3 \text{ clc};
4 T=[397 398 399 400 401 402 403 404 405];
5 f=[1 3 12 23 37 16 4 2 2];
6 Tf = sum(abs(T.*f));
7 disp(Tf/sum(f), 'mean temp(deg C)');
8 d = [-3.78 -2.78 -1.78 -.78 .22 1.22 2.22 3.22 4.22];
9 disp(sum(f.*d)/sum(f), 'mean deviation(deg C)');
10 disp(sqrt(sum(f.*d^2)/sum(f)), 'standard deviation(
     deg C)');
disp(.6745*sqrt(sum(f.*d^2)/sum(f)), 'probable error')
     of 1 reading (deg C)');
12 disp((.6745*sqrt(sum(f.*d^2)/sum(f)))/sqrt(sum(f)), '
     probable error of mean(deg C)');
13 disp((sqrt(sum(f.*d^2)/sum(f)))/sqrt(sum(f)),'
     standard deviation of mean(deg C)');
14 disp((sqrt(sum(f.*d^2)/sum(f)))/sqrt(sum(f)*2),
     standard deviation of standard deviation (deg C)')
```

# Scilab code Exa 3.24 to find probable no of resistors

Scilab code Exa 3.25 to find no of 100 rsding exceed 30mm

Scilab code Exa 3.26 to find no of rods of desired length

```
1 //to find no of rods of desired length
2
3 clc;
               //no of rods
4 n = 25000;
5 n1=12500; //length > 10mm
6 n2=2000; // length > 10.25
               //10 < length < 10.25
7 a=n1-n2;
8 p=a/n;
9 t=1.41;
              //using p
10 t1=t*2;
11 p1 = .4975;
12 b=p1*n;
             //9.5 < length < 10
13 disp(a+floor(b), 'total no of rods');
```

Scilab code Exa 3.27 to find standard deviation and probability of error

```
1 //to find standard deviation and probability of error
```

```
2
3 clc;
4 p=.2;
5 x=.8;
6 t=.5025;
7 sd=x/t;
8 disp(sd,'stndard deviation');
9 x=1.2;
10 t=x/sd;
11 p=2*.2743;
12 disp(p,'probability of error');
```

# Scilab code Exa 3.28 to find no of expected readings

```
1 //to find no of expected readings
2
3 clc;
4 x=20;
5 h=0.04;
6 sd=1/(sqrt(2)*h);
7 t=x/sd;
8
9 P=.3708;
10 disp(ceil(2*P*x), 'no of expected readings');
```

# Scilab code Exa 3.29 to calculate precision index of instrument

```
1 //to calculate precision index of instrument
2
3 clc;
4 t=.675;
5 x=2.4;
6 sd=x/t;
```

```
7 h=1/(sqrt(2)*sd);
8 disp(h, 'precision index');
9 t = (50-44)/sd;
10 p = .45;
11 n=8*30;
              //sept month no of measurements
12 a=((.5-p)*n);
13 disp(a, 'no of false alarms');
14
              //reduced no of false alarms
15 rn=a/2;
16 p1=rn/n;
17 P = .5 - p1;
18 t=1.96;
19 sd = (50-44)/t;
20 h=1/(sqrt(2)*sd);
21 disp(h, 'precision index');
```

Scilab code Exa 3.30 to find confidence interval for given confidence levels

```
1 //to find confidence interval for given confidence
      levels
3 \text{ clc};
4 cl=[.5 .9 .95 .99];
5 s = .22;
6 d = [.7 1.83 2.26 3.25];
7 function [a]=ci(b)
       a=s*b;
9 endfunction
10
11 CI(1)=ci(d(1));
12 CI(2) = ci(d(2));
13 CI(3) = ci(d(3));
14 CI(4) = ci(d(4));
15
16 disp(CI, 'confidence interval');
```

Scilab code Exa 3.31 to point out the reading that can be rejected by chavenets criterion

```
1 //to point out the reading that can be rejected by
       chavenets criterion
3 clc;
4 \quad x = [5.3 \quad 5.73 \quad 6.77 \quad 5.26 \quad 4.33 \quad 5.45 \quad 6.09 \quad 5.64 \quad 5.81
       5.75]*10^-3;
5 d=[-.313 .117 1.157 -.353 -1.283 -.163 .477 .027
       .197 .137]*10^-3;
6 n = 10;
7 X = sum(x)/n;
8 \text{ s=sqrt}(sum(d^2)/(n-1));
9 a=abs(d)/s;disp(a);
10
11
12 \text{ for } i=1:10,
13
14 if a(i)>1.96 then
        disp(x(i), 'rejected value');
15
16 \text{ end}
17
      end
```

Scilab code Exa 3.32 calculate standard deviation

```
1 // calculate standard deviation
2
3 clc;
4 x=[.9 2.3 3.3 4.5 5.7 6.7];
5 y=[1.1 1.6 2.6 3.2 4 5];
```

Scilab code Exa 3.34 determine value of total current considering errors as limiting errors and as standard deviations

```
1 //determine value of total current considering
      errors as limiting errors ans as standrd
      deviations
3 clc;
4 I1=200;
5 I2=100;
6 dI1=2;
7 \text{ dI2=5};
8 I = I1 + I2;
9 dI = ((I1/I)*(dI1/I1)+(I2/I)*(dI2/I2));
10 disp('error considered as limiting errors');
11 disp(I, 'I');
12 disp(dI*I, 'dI');
13 sdI=sqrt(dI1^2+dI2^2);
14 disp('error considered as standard deviations');
15 disp(I, 'I');
16 disp(sdI, 'sdI');
```

Scilab code Exa 3.35 determine probable error in the computed value of resistnce

```
//determine probable error in the computed value of
    resistnce

clc;
    r_V=12;
    I=10;
    r_Rv=r_V/I;
    V=100;
    r1=2;
    r_Ri=V*r1/I^2;
    r_R=sqrt(r_Rv^2+r_Ri^2);
disp(r_R, 'r_R');
```

Scilab code Exa 3.37 to find Cq and its possible errors

```
1 //to find Cq and its possible errors
2
3 clc;
4 d=12.5;
5 A=(%pi/4)*d^2*10^-6;
6 W=392;
7 t=600;
8 p=1000;
9 g=9.81;
10 h=3.66;
11 Cq=W/(t*p*A*sqrt(2*g*h));
12 disp(Cq, 'Cq');
13 dW=.23/W;
```

```
14 dt=2/t;
15 dp=.1/100;
16 dA=2*.002;
17 dg=.1/100;
18 dh=.003/h;
19 dd=.002;
20 dCq=Cq*(dW+dt+dp+dA+dg/2+dh/2);
21 disp(dCq*100/Cq,'%age absolute error');
22
23 sdCq=Cq*sqrt(dW^2+dt^2+dp^2+4*dd^2+.25*(dg^2+dh^2));
24 disp(sdCq*100/Cq,'%age standard deviation error');
```

Scilab code Exa 3.38 calculate power disipated and uncertaainity in power

```
//calculate power disipated and uncertaainity in
    power

clc;
    V=110.2;
    I=5.3;
    P=V*I; disp(P, 'power(W) dissipated');
    w_v=.2;
    w_i=0.06;
    dp=sqrt((w_v*I)^2+(w_i*V)^2);
    disp(dp*100/P, 'uncertainity in power(%)');
```

Scilab code Exa 3.39 to find uncertainty in combined resistance in both series and in parrallel

```
1 //to find uncertainity in combined resistance in
        both series and in parrallel
2
3 clc;
```

```
4 R1 = 100;
5 R2 = 50;
6 \text{ wR1} = .1;
7 \text{ wR2} = 0.03;
8 disp('series conn');
9 R=R1+R2; disp(R, 'resistance(ohm)');
10 dR1=1;
11 dR2=1;
12 wR=sqrt((dR1*wR1)^2+(dR2*wR2)^2);disp(wR, '
      uncertainity in resistance (ohm)');
13
14 disp('parrallel conn');
15 R=R1*R2*(R1+R2)^-1; disp(R, 'resistance(ohm)');
16 dR1 = (R2/(R1+R2)) - ((R1*R2)/(R1+R2)^2);
17 dR2=(R1/(R1+R2))-((R1*R2)/(R1+R2)^2);
18 WR = sqrt((dR1*WR1)^2+(dR2*WR2)^2); disp(WR,')
      uncertainity in resistance (ohm)');
```

#### Scilab code Exa 3.40 to calculate uncertainty in measurement

```
//to calculate uncertainity in measurement

clc;
l=150;
l=150;
l=0.01;
l=50;
wA=1*dl;
disp('when no uncertainity in measurement of length');
disp(wA, 'uncertainity in measurement of area(m*m)');
disp('when no certainity in measurement of length');
wA=1.5*1.5;
wB=0.01;
wL=sqrt((wA^2-(1*wB)^2)/b^2);
```

```
15 disp(wL, 'uncertainity in measurement of length(m)');
```

# Scilab code Exa 3.41 to calculate uncertainity in power

# Chapter 4

# Dynamic Characteristics of Instruments and Measurement systems

Scilab code Exa 4.1 calculating the temperature

```
1 // calculating the temperature after 1.5 s
2 clc;
3 th0=100;
4 t=1.5;
5 tc=3.5;
6 th=th0*[1-exp(-t/tc)];
7 disp(th, 'temperature after 1.5 s (degree C)')
```

Scilab code Exa 4.2 calculate time to read half of the temperature difference

```
1 // calculate time to read half of the temperature
          difference
2 clc;
```

```
3 tc=10/5;
4 th=1;
5 th0=2;
6 t=-tc*log(1-(th/th0));
7 disp(t,'Time to read half of the temperature difference (s)')
```

Scilab code Exa 4.4 Calculate the temperature after 10s

```
1 // Calculate the temperature after 10s
2 clc;
3 th0=25;
4 thi=150;
5 t=10;
6 tc=6;
7 th=th0+(thi-th0)*[exp(-t/tc)];
8 disp(th,'the temperature after 10s (degree C)')
```

Scilab code Exa 4.5 Calculate the value of resistance after 15s

```
1 // Calculate the value of resistance after 15s
2 clc;
3 R0=29.44;
4 Rs=100;
5 t=15;
6 tc=5.5;
7 R_15=Rs+R0*[1-exp(-t/tc)];
8 disp(R_15, 'value of resistance after 15s(ohm)')
```

Scilab code Exa 4.6 Calculate the depth after one hour

```
1 // Calculate the depth after one hour
2 clc;
3 Qm=0.16*10^-3;
4 Hin=1.2;
5 K1=Qm/(Hin)^0.5;
6 Qo=0.2*10^-3;
7 Ho=(Qo/K1)^2;
8 R=Hin/Qm;
9 C=0.1;
10 tc=R*C;
11 t=3600;
12 H=Ho+(Hin-Ho)*exp(-t/tc);
13 disp(H, 'the depth after one hour(m)')
```

#### Scilab code Exa 4.8 Calculate time constant

```
//Calculate time constant
clc;
S=3.5;
Ac=(%pi/4)*(0.25)^2;
alpha=0.18*10^-3;
Vb=S*Ac/alpha;
disp(Vb,'volume of bulb(mm2)')

Rb=[(Vb/%pi)*(3/4)]^(1/3);
Ab=4*%pi*Rb^2;
D=13.56*10^3;
s=139;
H=12;
tc=(D*s*Vb*10^-9)/(H*Ab*10^-6);
disp(tc,'time constant (s)')
```

Scilab code Exa 4.9 Calculate the temperature after 10s

```
1 // Calculate the time constant
2 ess=5;
3 A=0.1;
4 tc=ess/A;
5 disp(tc, 'time constant(s)')
```

Scilab code Exa 4.10 Calculate the temperature at a depth of 1000 m

```
1 // Calculate the temperature at a depth of 1000 m
2 clc;
3 th0=20;
4 t=2000;
5 thr=th0-0.005*(t-50)-0.25*exp(-t/50);
6 disp(thr, 'temperature at a depth of 1000 m (degree C)')
```

Scilab code Exa 4.11 Calculate the value of resistance at different values of time

```
// Calculate the value of resistance at different
values of time

clc;
Gain=0.3925;
T=75;
p_duration=Gain*T;
tc=5.5;
Rin=100;
t=1;
Rt=p_duration*(1-exp(-t/tc))+Rin;
disp(Rt,'Value of resistance after 1s(ohm)=')
t=2;
Rt=p_duration*(1-exp(-t/tc))+Rin;
disp(Rt,'Value of resistance after 2s(ohm)=')
```

```
14 t=3;
15 Rt=p_duration*(1-exp(-t/tc))+Rin;
16 disp(Rt, 'Value of resistance after 3s(ohm)=')
17 R_inc=Rt-Rin;
18 t=5;
19 Rt=(R_inc)*[\exp(-(t-3)/(5.5))]+Rin;
20 disp(Rt, 'Value of resistance after 5s(ohm)=')
21 t = 10;
22 Rt=(R_inc)*[\exp(-(t-3)/(5.5))]+Rin;
23 disp(Rt, 'Value of resistance after 10 \text{ s} (\text{ohm}) = ')
24 t = 20;
25 Rt=(R_inc)*[\exp(-(t-3)/(5.5))]+Rin;
26 disp(Rt, 'Value of resistance after 20 \,\mathrm{s} \,\mathrm{(ohm)} =')
27 t = 30;
28 Rt=(R_inc)*[\exp(-(t-3)/(5.5))]+Rin;
29 disp(Rt, 'Value of resistance after 30 \, \mathrm{s} \, (\mathrm{ohm}) = ')
```

 ${\bf Scilab\ code\ Exa\ 4.12}$  calculate the value of damping constant and frequency of damped oscillations

```
// calculate the value of damping constant and
    frequency of damped oscillations

clc;

M=8*10^-3;

K=1000;

wn=(K/M)^0.5;

disp('for critically damped system eta=1')

B=2*(K*M);

disp(B, 'Damping constant for critically damped system (N/ms-1)=')

eta=0.6;

wd=wn*(1-eta^2)^0.5;

disp(wd, 'frequency of damped oscillations (rad/s)=')
```

Scilab code Exa 4.13 Calculate damping ratio natural frequency frequency of damped oscillations time constant and steady state error for ramp signal

```
1 // Calculate damping ratio, natural frequency,
      frequency of damped oscillations, time constant
2 // and steady state error for ramp signal of 5V/s
3 clc;
4 K = (40*10^-6)/(\%pi/2);
5 J=0.5*10^-6;
6 B=5*10^-6;
7 eta=B/(2*(K*J)^0.5);
8 disp(eta, 'damping ratio=')
9 \text{ wn} = (K/J)^0.5;
10 disp(wn, 'natural frequency (rad/sec)')
11 wd=wn*(1-(eta)^2)^0.5;
12 disp(wd, 'frequency of damped oscillations (rad/s)')
13 tc=1/wn;
14 disp(tc, 'time constant (s)')
15 \text{ ess}=2*\text{eta/wn};
16 disp('for a ramp input of 5V, steady state error (V)
      = ')
17 ess=5*2*eta/wn;
18 disp(ess, '')
19 T_lag=2*eta*tc;
20 disp(T_lag, 'Time lag (s)')
```

Scilab code Exa 4.14 Calculate the natural frequency

```
1 // Calculate the natural frequency
2 clc;
3 wn=2*%pi*30;
```

Scilab code Exa 4.15 Calculate natural frequency and settleing time

```
// Calculate natural frequency and setteling time
clc;
K=60*10^3;
M=30;
wn=(K/M)^0.5;
disp(wn, 'natural frequency (rad/sec)')
eta=0.7;
ts=4/(eta*wn);
disp(ts, 'setteling time (s)')
```

Scilab code Exa 4.16 Calculate time lag and ratio of output and input

```
1 // Calculate time lag and ratio of output and input
2 clc;
3 disp('when time period is 600s')
4 w=2*%pi/600;
5 tc=60;
```

```
6 T_lag=(1/w)*atan(w*tc);
7 disp(T_lag, 'time lag (s)=')
8 M=1/((1+(w*tc)^2)^0.5);
9 disp(M, 'ratio of output and input=')
10 disp('when time period is 120s')
11 w=2*%pi/120;
12 tc=60;
13 T_lag=(1/w)*atan(w*tc);
14 disp(T_lag, 'time lag (s)=')
15 M=1/((1+(w*tc)^2)^0.5);
16 disp(M, 'ratio of output and input=')
```

Scilab code Exa 4.17 Calculate the maximum allowable time constant and phase shift

```
// Calculate the maximum allowable time constant and
phase shift

clc;

M=1-0.05;

w=2*%pi*100;

tc={[(1/M^2)-1]/(w^2)}^0.5;

disp(tc, 'maximum allowable time constant (s)')

disp('phase shift at 50 Hz (degree)=')

ph=[-atan(2*%pi*50*tc)]*(180/%pi);

disp(ph,'')

disp('phase shift at 100 Hz (degree)=')

ph=[-atan(2*%pi*100*tc)]*(180/%pi);

disp(ph,)
```

Scilab code Exa 4.18 Calculate maximum value of indicated temperature and delay time

# Scilab code Exa 4.19 Find the output

```
1 // Find the output
2 clc;
3 disp('when tc=0.2);
4 disp('output=1/(1+(2*0.2)^2)^0.5]sin[2t-atan(2*0.2)]+3/(1+(2*0.2)^2)^0.5]sin[20t-atan(20*0.2)]')
5 disp('on solving output=0.93 sin(2t-21.8)+0.073 sin(20t-76)')
6 disp('when tc=0.002);
7 disp('output=1/(1+(2*0.002)^2)^0.5]sin[2t-atan(2*0.002)]+3/(1+(2*0.002)^2)^0.5]sin[20t-atan(2*0.002)]')
8 disp('on solving output= 1 sin(2t-0.23)+0.3 sin(20t-2.3)')
```

Scilab code Exa 4.20 Calculate maximum and minimum value of indicated temperature phase shift time lag

```
1 // Calculate maximum and minimum value of indicated
      temperature, phase shift, time lag
2 clc;
3 T_{max} = 640;
4 T_min=600;
5 T_mean = (T_max + T_min)/2;
6 Ai = T_mean - T_min;
7 w=2*\%pi/80;
8 \text{ tc=10};
9 Ao=Ai/{(1+(w*tc)^2)}^0.5;
10 T_max_indicated=T_mean+Ao;
11 disp(T_max_indicated, 'Maximum value of indicated
      temperature (degree C)=')
12 T_min_indicated=T_mean-Ao;
13 disp(T_min_indicated, 'Minimum value of indicated
      temperature (degree C)=')
14 ph=-atan(w*tc);
15 Time_lag=-ph/w;
16 disp(Time_lag, 'Time lag (s)')
```

## Scilab code Exa 4.21 determine damping ratio

```
1 // determine damping ratio
2 clc;
3 w=2;
4 K=1.5;
5 J=200*10^-3;
6 wn=(K/J)^0.5;
7 u=w/wn;
8 M=1.1;
9 eta=[{[1/(M^2)]-[(1-u^2)^2]}/(2*u)^2]^0.5;
10 disp(eta, 'damping ratio=')
```

## Scilab code Exa 4.22 Calculate the frequency range

```
1 // Calculate the frequency range
2 clc;
3 \text{ eta=0.6};
4 fn=1000;
5 M = 1.1;
6 disp('M=1/[[(1-u^2)^2]+(2*u*eta)^2]^0.5; .....(
      i ) ')
7 disp('on solving u^4-0.5u^2+0.173=0')
8 disp('the above equation gives imaginary values for
      frequency so for eta=0.6 the output is not 1.1')
9 disp('Now let M=0.9, on solving equation (i) we have
      ')
10 \operatorname{disp}('u^4-0.56u^2-0.234=0')
11 disp('on solving u=0.916')
12 u=0.916;
13 f=u*fn;
14 disp(f, 'maximum value of range (Hz)=')
15 disp('So, the range of the frequency is from 0 to
      916 Hz')
```

## Scilab code Exa 4.23 determine the error

```
1 // determine the error
2 clc;
3 w=6;
4 wn=4;
5 u=w/wn;
6 eta=0.66;
7 M=1/{[(1-u^2)^2]+(2*eta*u)^2}^0.5;
8 Error=(M-1)*100;
9 disp(Error, 'error (%)=')
```

# Chapter 5

# Primary Sensing Elements and Transducers

Scilab code Exa 5.1 Calculate the deflection at center

```
1 // Calculate the deflection at center
2 clc;
3 D=15*10^-3;
4 P=300*10^3;
5 sm=300*10^6;
6 t=[3*D^2*P/(16*sm)]^0.5;
7 disp(t,' thickness(m)=')
8 P=150*10^3;
9 v=0.28;
10 E=200*10^9;
11 dm=3*(1-v^2)*D^4*P/(256*E*t^3);
12 disp(dm,' deflection at center for Pressure of 150 kN/m2(m)=')
```

Scilab code Exa 5.2 Calculate the angle of twist

```
1 // Calculate the angle of twist
2 clc;
3 T=100;
4 G=80*10^9;
5 d=2*15*10^-3;
6 th=16*T/(%pi*G*d^3)
7 disp(th,' angle of twist(rad)=')
```

# Scilab code Exa 5.3 Calculate the Torque

```
1 // Calculate the Torque
2 clc;
3
4 E=110*10^9;
5 t=0.073*10^-3;
6 b=0.51*10^-3;
7 l=370*10^-3;
8 th=%pi/2;
9 T=(E*b*t^3)*th/(12*1);
10 disp(T,' Controlling torque(Nm)=')
```

Scilab code Exa 5.4 Calculating the displacement and resolution of the potentiometer

```
// Calculating the displacement and resolution of the
    potentiometer

clc;
Rnormal=10000/2;
Rpl=10000/50;
Rc1=Rnormal-3850;
Dnormal=Rc1/Rpl;
disp(Dnormal, 'Displacement(mm)=')
Rc2=Rnormal-7560;
```

```
9 Dnormal=Rc2/Rpl;
10 disp(Dnormal, 'Displacement (mm)=')
11 disp('since one displacement is positive and other
      is negative so two displacements are in the
      opposite direction')
12 Re=10*1/200;
13 disp(Re, 'Resolution (mm)=')
```

Scilab code Exa 5.5 plot the graph of error versus K

```
1 // plot the graph of error versus K
2 clc;
3 K=[0    0.25    0.5    0.75    1];
4 V=[0    -0.174    -0.454    -0.524    0];
5 plot(K,V)
```

Scilab code Exa 5.6 Calculating the output voltage

```
1 // Calculating the output voltage
2 clc;
3 RAB=125;
4 Rtotal=5000;
5 R2=75/125*Rtotal;
6 R4=2500;
7 ei=5;
8 eo=[(R2/Rtotal)-(R4/Rtotal)]*ei;
9 disp(eo, 'output voltage (V)=')
```

Scilab code Exa 5.7 Calculating the maximum excitation voltage and the sensitivity

```
// Calculating the maximum excitation voltage and
the sensitivity

clc;
Rm=10000;
Rp=Rm/15;
R=600;
P=5;
ei= (P*R)^0.5;
disp(ei, 'Maximum excitation voltage (V)=')
S=ei/360;
disp(S, 'Sensitivity (V/degree)=')
```

Scilab code Exa 5.8 Calculating the resolution of the potentiometer

```
1 // Calculating the resolution of the potentiometer
2 clc;
3 Rwga=1/400;
4 Re=Rwga/5;
5 disp(Re, 'Resolution (mm)=')
```

Scilab code Exa 5.9 Checking the suitability of the potentiometer

```
1 // Checking the suitability of the potentiometer
2 clc;
3 mo=0.8;
4 sr=250;
5 sm=sr/mo;
6 R=sm*1;
7 disp(R, 'resolution of 1mm movement')
8 Rq=300/1000;
9 disp(Rq, 'resolution required=')
```

10 disp('since the resolution of potentiometer is higher than the resolution required so it is suitable for the application')

Scilab code Exa 5.10 Checking the suitability of the potentiometer

```
// Checking the suitability of the potentiometer
clc;
Pd=(10^2)/150;
disp(Pd, 'Power dissipation (W)=')
th_pot=80+Pd*30*10^-3;
PDa=1-(10*10^-3)*(th_pot-35);
disp(PDa, 'Power dissipation allowed (W)=')
disp('Since power dissipation is higher than the dissipation allowed so potentiometer is not suitable')
```

Scilab code Exa 5.11 Calculating the possion ratio

```
1 // Calculating the possion's ratio
2 clc;
3 Gf=4.2;
4 v=(Gf-1)/2;
5 disp(v, 'Possion s ratio=')
```

Scilab code Exa 5.12 Calculating the value of the resistance of the gauges

```
1 // Calculating the value of the resistance of the
     gauges
2 clc;
```

Scilab code Exa 5.13 calculate the percentage change in value of the gauge resistance

Scilab code Exa 5.14 Calculating the Gauge factor

```
1 // Calculating the Gauge factor
2 clc;
3 b=0.02;
4 d=0.003;
5 I=(b*d^3)/12;
6 E=200*10^9;
```

```
7 x=12.7*10^-3;
8 l=0.25;
9 F=3*E*I*x/1^3;
10 x=0.15;
11 M=F*x;
12 t=0.003;
13 s=(M*t)/(I*2);
14 strain=s/E;
15 dR=0.152;
16 R=120;
17 Gf=(dR/R)/strain;
18 disp(Gf, 'Gauge factor=')
```

Scilab code Exa 5.15 Calculating the change in length and the force applied

Scilab code Exa 5.16 Calculate the linear approximation

```
1 // Calculate the linear approximation
2 clc;
3 th1=30;
4 th2=60;
5 th0=th1+th2/2;
6 Rth1=4.8;
7 Rth2=6.2;
8 Rth0=5.5;
9 ath0=(1/Rth0)*(Rth2-Rth1)/(th2-th1);
10 disp(ath0, 'alpha at o degree(/degree C)=')
11 disp('5.5[1+0.0085(th-45)]')
```

#### Scilab code Exa 5.17 Calculate the linear approximation

#### Scilab code Exa 5.18 Calculate the resistance and the temperature

```
1 // Calculate the resistance and the temperature
2 clc;
3 Rth0=100;
4 ath0=0.00392;
```

```
5 dth=65-25;
6 R65=Rth0*[1+ath0*dth];
7 disp(R65, 'resistance at 65 degree C(ohm)=')
8
9 th={[(150/100)-1]/ath0}+25;
10 disp(th, 'Temperature (degree C)')
```

## Scilab code Exa 5.19 Calculate the resistance

```
1 // Calculate the resistance
2 clc;
3 Rth0=10;
4 ath0=0.00393;
5 dth=150-20;
6 R150=Rth0*[1+ath0*dth];
7 disp(R150, 'resistance at 150 degree C(ohm)=')
```

## Scilab code Exa 5.20 Calculate the time

```
1 // Calculate the time
2 clc;
3 th=30;
4 th0=50;
5 tc=120;
6 t=-120*[log(1-(th/th0))];
7 disp(t, 'time(s)=')
```

# Scilab code Exa 5.21 Calculate the resistance

```
1 // Calculate the resistance
```

```
2 clc;
3 R25=100;
4 ath=-0.05;
5 dth=35-25;
6 R35=R25*[1+ath*dth];
7 disp(R35,'resistance at 35 degree C(ohm)=')
```

## Scilab code Exa 5.22 find resistance

```
1 //
2 clc;
3 Ro=3980;
4 Ta=273;
5 disp('3980= a*3980*exp(b/273)')
6 Rt50=794;
7 Ta50=273+50;
8 disp('794= a*3980*exp(b/323)')
9 disp('on solving')
10 disp('a=30*10^-6', 'b=2843')
11 Ta40=273+40;
12 Rt40=(30*10^-6)*3980*exp(2843/313);
13 disp(Rt40, 'Resistance at 40 degree C (ohm)')
14 Rt100=(30*10^-6)*3980*exp(2843/373);
15 disp(Rt100, 'Resistance at 100 degree C (ohm)')
```

# Scilab code Exa 5.23 calculating the change in temperature

```
1 // calculating the change in temperature
2 clc;
3 th=((1-1800/2000)/0.05)+70;
4 dth=th-70;
5 disp(dth, 'change in temperature (degree C)')
```

## Scilab code Exa 5.24 calculating the frequencies of oscillation

```
1 // calculating the frequencies of oscillation
2 clc;
3 C=500*10^-12;
4 R20=10000*(1-0.05*(20-25));
5 f20=1/(2*%pi*R20*C);
6 disp(f20, 'Frequency of oscillation at 20 degree C (Hz)')
7 R25=10000*(1-0.05*(25-25));
8 f25=1/(2*%pi*R25*C);
9 disp(f25, 'Frequency of oscillation at 25 degree C (Hz)')
10 R30=10000*(1-0.05*(30-25));
11 f30=1/(2*%pi*R30*C);
12 disp(f30, 'Frequency of oscillation at 30 degree C (Hz)')
```

Scilab code Exa 5.25 Calculating the sensitivity and maximum output voltage

```
// Calculating the sensitivity and maximum output
    voltage

clc;
Se_thermocouple=500-(-72);
disp(Se_thermocouple, 'Sensitivity of thermocouple (
    micro V/degree C)=')
Vo=Se_thermocouple*100*10^-6;
disp(Vo, 'maximum output voltage(V)=')
```

#### Scilab code Exa 5.26 Calculating the temperature

```
1 // Calculating the temperature
2 clc;
3 ET=27.07+0.8;
4 Disp(ET, 'Required e.m.f.(mV)')
5 disp('temperature corresponding to 27.87 mV is 620 degree C')
```

Scilab code Exa 5.27 Calcating the series resistance and approximate error

```
1 // Calcating the series resistance and approximate
     error
2 clc;
3 \text{ Rm} = 50;
4 Re=12;
5 E=33.3*10^-3;
6 i=0.1*10^-3;
7 Rs=(E/i)-Rm-Re;
8 disp(Rs, 'series resistance (ohm)=')
9 Re=13;
10 i1=E/(Rs+Re+Rm);
11 AE = [(i1-i)/i]*800;
12 disp(AE, 'approximate error due to rise in resistance
       of 1 ohm in Re (degree C)=')
13 R_change=50*0.00426*10;
14 i1=E/(Rs+Re+Rm+R_change);
15 AE = [(i1-i)/i]*800;
16 disp(AE, 'approximate error due to rise in Temp. of
     10 (degree C)=')
```

Scilab code Exa 5.28 Calculate the values of resistance R1 and R2

```
1 // Calculate the values of resistance R1 and R2
2 clc;
3 E_20=0.112*10^-3; // emf at 20 degree C
4 E_900=8.446*10^-3;
5 E_1200=11.946*10^-3;
6 E1=E_900-E_20;
7 E2=E_1200-E_20;
8 disp('E1=1.08*R1/(R1+2.5+R2); (i)')
9 disp('E2=1.08*(R1+2.5)/(R1+2.5+R2); (ii)')
10 disp('on solving (i) and (ii)')
11 R1=5.95;
12 R2=762.6;
13 disp(R1,'value of resistance R1 (ohm)=')
14 disp(R2,'value of resistance R2 (ohm)=')
```

# Scilab code Exa 5.29 Calculate the percentage linearity

```
1 // Calculate the percentage linearity
2 clc;
3 linearity_percentage=(0.003/1.5)*100;
4 disp(linearity_percentage, 'percentage linearity=')
```

#### Scilab code Exa 5.30 Calculate sensitivity of the LVDT

```
// Calculate senstivity of the LVDT, Instrument and
resolution of instrument in mm

clc;
displacement=0.5;
Vo=2*10^-3;
Se_LVDT=Vo/displacement;
disp(Se_LVDT, 'senstivity of the LVDT (V/mm)')
Af=250;
Se_instrument=Se_LVDT*Af;
```

```
9 disp(Se_instrument, 'senstivity of instrument (V/mm)'
    )
10 sd=5/100;
11 Vo_min=50/5;
12 Re_instrument=1*1/1000;
13 disp(Re_instrument, 'resolution of instrument in mm')
```

Scilab code Exa 5.31 calculate the deflection maximum and minimum force

```
1 // calculate the deflection, maximum and minimum
     force
2 clc;
3 b=0.02;
4 t=0.004;
5 I = (1/12) *b*t^3;
6 F = 25;
71=0.25;
8 E=200*10^9;
9 x=(F*1^3)/(3*E*I);
10 disp(x, 'deflection (m)')
11 DpF=x/F;
12 Se=DpF*0.5*1000;
13 Re=(10/1000)*(2/10);
14 F_min=Re/Se;
15 F_max=10/Se;
16 disp(F_min, 'minimum force (N)')
17 disp(F_max, 'maximum force (N)')
18 disp(Se, '')
```

Scilab code Exa 5.32 calculating the sensitivity of the transducer

```
1 // calculating the sensitivity of the transducer
2 clc;
```

```
3 disp('permittivity of the air e0=8.85*10^-12')
4 e0=8.85*10^-12;
5 w=25*10^-3;
6 d=0.25*10^-3;
7 Se=-4*e0*w/d;
8 disp(Se, 'sensitivity of the transducer (F/m)=')
```

Scilab code Exa 5.33 Calculate the value of the capacitance afte the application of pressure

```
// Calculate the value of the capacitance afte the
    application of pressure

clc;
C1=370*10^-12;
d1=3.5*10^-3;
d2=2.9*10^-3;
C2=C1*d1/d2;
disp(C2, 'the value of the capacitance afte the
    application of pressure (F)=')
```

Scilab code Exa 5.34 Calculate the change in frequency of the oscillator

```
// Calculate the change in frequency of the
    oscillator

clc;
fo1=100*10^3;

d1=4;
d2=3.7;
fo2=[(d2/d1)^0.5]*fo1;
dfo=fo1-fo2;
disp(dfo,'change in frequency of the oscillator (Hz)
')
```

Scilab code Exa 5.35 Calculate the dielectric stress change in value of capacitance

```
// Calculate the dielectric stress, change in value
    of capacitance

clc;
L_air=(3.1-3)/2;
D_stress=100/L_air;
e0=8.85*10^-12;
l=20*10^-3;
D2=3.1;
D1=3;
C=(2*%pi)*e0*1/(log(D2/D1));
disp(C, 'Capacitance(F)=')
l=(20*10^-3)-(2*10^-3);
C_new=(2*%pi)*e0*1/(log(D2/D1));
C_change=C-C_new;
disp(C_change, 'change in Capacitance(F)=')
```

Scilab code Exa 5.36 Calculate the value of time constant phase shift series resistance amplitude ratio and voltage sensitivity

```
// Calculate the value of time constant, phase shift,
    series resistance, amplitude ratio and voltage
    sensitivity

clc;
M=0.95;
w=2*%pi*20;
tc=(1/w)*[(M^2)/(1-M^2)]^0.5;
disp(tc, 'time constant (s)')
ph={(%pi/2)-[atan(w*tc)]}*(180/%pi);
disp(ph, 'phase shift(deg)')
```

```
9  C=(8.85*10^-12*300*10^-6)/(0.125*10^-3);
10  R=tc/C;
11  disp(R, 'series resistance (ohm)')
12  M=1/(1+(1/(2*%pi*5*tc)^2))^0.5;
13  disp(M, 'amplitude ratio=')
14  Eb=100;
15  x=0.125*10^-3;
16  Vs=Eb/x;
17  disp(Vs, 'voltage sensitivity (V/m)')
```

Scilab code Exa 5.37 Calculate the change in capacitance and ratio

```
1 // Calculate the change in capacitance and ratio
2 clc;
3 \text{ e0=8.85*10}^{-12};
4 A=500*10^-6;
5 d=0.2*10^{-3};
6 C=e0*A/d;
7 d1=0.18*10^-3;
8 C_new=e0*A/d1;
9 C_change=C_new-C;
10 Ratio=(C_change/C)/(0.02/0.2);
11 disp(Ratio, 'ratio of per unit change of capacitance
      to per unit change of diaplacement')
12 d1 = 0.19 * 10^{-3};
13 e1=1;
14 d2=0.01*10^-3;
15 e2=8:
16 C=(e0*A)/((d1/e1)+(d2/e2));
17 d1_new=0.17*10^-3;
18 C_{new}=(e0*A)/((d1_{new}/e1)+(d2/e2));
19 C_change=C_new-C;
20 Ratio=(C_change/C)/(0.02/0.2);
21 disp(Ratio, 'ratio of per unit change of capacitance
      to per unit change of diaplacement')
```

Scilab code Exa 5.40 Calculate the output voltage and charge sensitivity

### Scilab code Exa 5.41 Calculate the force

```
1 // Calculate the force
2 clc;
3 g=0.055;
4 t=1.5*10^-3;
5 Eo=100;
6 P= Eo/(g*t);
7 A=25*10^-6;
8 F=P*A;
9 disp(F, 'Force(N)=')
```

Scilab code Exa 5.42 Calculate the strain charge and capacitance clc

```
1 // Calculate the strain, charge and capacitance
```

```
2 clc;
3 A=25*10^-6;
4 F=5;
5 P=F/A;
6 d=150*10^-12;
7 e=12.5*10^-9;
8 g=d/(e);
9 t=1.25*10^-3;
10 Eo=(g*t*P);
11 strain=P/(12*10^6);
12 Q=d*F;
13 C=Q/Eo;
14 disp(strain, 'strain=')
15 disp(Q, 'charge(C)=')
16 disp(C, 'Capacitance(F)=')
```

Scilab code Exa 5.43 calculate peak to peak voltage swing under open and loaded conditions calculate maximum change in crystal thickness

```
1 // calculate peak to peak voltage swing under open
      and loaded conditions
2 // calculate maximum change in crystal thickness
3 clc;
4 d=2*10^-12;
5 t=1*10^-3;
6 \text{ Fmax} = 0.01;
7 e0=8.85*10^{-12};
8 \text{ er=5}:
9 A=100*10^-6;
10 Eo_peak_to_peak=2*d*t*Fmax/(e0*er*A);
11 disp(Eo_peak_to_peak, 'peak voltage swing under open
      conditions')
12 R1=100*10^6;
13 C1 = 20 * 10^{-12};
14 d1 = 1 * 10^{-3};
```

```
15  Cp=e0*er*A/d1;
16  C=Cp+Cl;
17  w=1000;
18  m=[w*Cp*Rl/[1+(w*C*Rl)^2]^0.5];
19  El_peak_to_peak=[2*d*t*Fmax/(e0*er*A)]*m;
20
21  disp(El_peak_to_peak, 'peak voltage swing under loaded conditions')
22  E=90*10^9;
23  dt=2*Fmax*t/(A*E);
24  disp(dt, 'maximum change in crystal thickness (m)')
```

Scilab code Exa 5.44 Calculate the minimum frequency and phase shift

```
1 // Calculate the minimum frequency and phase shift
2 clc;
3 M=0.95;
4 tc=1.5*10^-3;
5 w=(1/tc)*[(M^2)/(1-M^2)]^0.5;
6 disp(w, 'minimum frequency (rad/s)')
7 ph={(%pi/2)-[atan(w*tc)]}*(180/%pi);
8 disp(ph, 'phase shift(deg)')
```

Scilab code Exa 5.45 calculate sensitivity of the transducer high frequency sensitivity Lowest frequency Calculate external shunt capacitance and high frequency sensitivity after connecting the external shunt capacitance

```
4 Kq = 40 * 10^{-3};
5 Cp=1000*10^-12;
6 \text{ K=Kq/Cp};
7 disp(K, 'sensitivity of the transducer(V/m)')
8 Cc = 300 * 10^{-12};
9 Ca=50*10^-12;
10 C=Cp+Cc+Ca;
11 Hf = Kq/C;
12 disp(Hf, 'high frequency sensitivity (V/m)')
13 R=1*10^6;
14 tc=R*C;
15 \quad M = 0.95;
16 w = (1/tc) * [(M^2)/(1-M^2)]^0.5;
17 f=w/(2*\%pi);
18 disp(w, 'minimum frequency (s)')
19 disp('now f=10Hz')
20 f = 10;
21 w = 2 * \%pi * f;
22 tc=(1/w)*[(M^2)/(1-M^2)]^0.5;
23 C_{new=tc/R};
24 \quad Ce=C_new-C;
25 disp(Ce, 'external shunt capacitance(F)')
26 Hf_new=Kq/C_new;
27 disp(Hf_new, 'new value of high frequency sensitivity
       (V/m)')
```

### Scilab code Exa 5.46 calculate op volatge

```
1 //
2 clc;
3 R=10^6;
4 C=2500*10^-12;
5 tc=R*C;
6 t=2*10^-3;
7 d=100*10^-12;
```

```
8 F=0.1;
9 el=10^3*{d*F*[exp(-t/tc)]/C};
10 disp(el,'voltage just before t=2ms (mV)')
11 el_after=10^3*{d*F*[exp(-t/tc)-1]/C};
12 disp(el_after,'voltage just after t=2ms (mV)')
13 disp('when t=10ms')
14 t=10*10^-3;
15 T=2*10
16 e_10=10^3*{d*F*[exp((-T/tc)-1)]*{exp(-(t-T))/tc}/C}}
17 disp(e_10,'output voltage 10 ms after the application of impulse(mV)')
```

Scilab code Exa 5.47 to prove time constant should be approximately 20T

```
1 // to prove time constant should be approximately 20
    T to keep undershoot within 5%
2 clc;
3 disp('Let T=1');
4 T=1;
5 el=0.95;
6 tc=-T/log(el);
7 disp(tc,'time constant')
8 disp('as T=1 so time constant should be approximately equal to 20T')
```

Scilab code Exa 5.48 calculate op volatge

```
1 //
2 clc;
3 Kh=-1*10^-6;
4 I=3;
5 B=0.5;
6 t=2*10^-3;
```

```
7 Eh=Kh*I*B/t;
8 disp(Eh, 'output voltage (V)')
```

Scilab code Exa 5.49 Calculate the threshold wavelength

```
1 // Calculate the threshold wavelength
2 clc;
3 Th_wavelength=1.24*10^-6/1.8',
4 disp(Th_wavelength, 'Threshold wavelength (m)')
```

Scilab code Exa 5.50 Calculate maximum velocity of emitted photo electrons

```
// Calculate maximum velocity of emitted photo
    electrons

clc;
E_imparted=(1.24*10^-6)/(0.2537*10^-6);
B_energy=E_imparted-4.30;
em_ratio=0.176*10^12;
v=(2*B_energy*em_ratio)^0.5;
disp(v,'maximum velocity of emitted photo electrons
    (m/s)')
```

Scilab code Exa 5.51 Calculate the resistance of the cell

```
1 // Calculate the resistance of the cell
2 clc;
3 Ri=30;
4 Rf=100;
5 t=10;
```

```
6 tc=72;
7 Rt=Ri+(Rf-Ri)*[1-exp(-t/tc)];
8 disp(Rt, 'resistance of the cell (K ohm)')
```

Scilab code Exa 5.52 Calculate incident power and cut off frequency

```
//Calculate incident power and cut off frequency
clc;
I_power=250*0.2*10^-6;
disp(I_power, 'incident power (W)')
Rl=10*10^3;
C=2*10^-12;
fc=1/(2*%pi*Rl*C);
disp(fc, 'cut off frequency (Hz)')
```

Scilab code Exa 5.53 Calculate the internal resistance of cell and open circuit voltage

```
1 // Calculate the internal resistance of cell and
      open circuit voltage
2 clc;
3 I=2.2*10^-3;
4 Eo=0.33;
5 Rl=100;
6 Ri=(Eo/I)-100;
7 disp(Ri, 'internal resistance of cell (ohm)')
8 Vo=0.33*[log(25)/log(10)];
9 disp(Vo, 'open circuit voltage for a radiant
      incidence of 25 W/m2 (V)=')
```

### Scilab code Exa 5.54 Find the value of current

```
1 // Find the value of current
2 clc;
3 A=1935*10^-6;
4 r=0.914;
5 S_angle=A/r^2;
6 I=180;
7 L_flux=I*S_angle;
8 disp(L_flux, 'lumnious flux=')
9 disp('Corresponding to lumnious flux o.417 lm and a load resistance of 800 ohm the current is 120 micro Ampere')
```

### Chapter 6

# Signal Conditioning

Scilab code Exa 6.1 calculating feedback resistance

```
1 // calculating feedback resistance
2 clc;
3 A=100;
4 R1=1*10^3;
5 Rf=-A*R1;
6 disp(Rf, 'feedback resistance (ohm)=');
```

Scilab code Exa 6.2 calculating the closed loop gain

```
1 // calculating the closed loop gain
2 clc;
3 Rf=10;
4 R1=1;
5 Avol=200000;
6 A=-(Rf/R1)*(1/[1+(1/Avol)*((R1+Rf)/R1)]);
7 disp(A, 'closed loop gain=')
```

Scilab code Exa 6.3 calculating the maximum output voltage

```
1 // calculating the maximum output voltage
2 clc;
3 Sa=10;
4 disp(Sa, 'saturation voltage=')
5 Vom=Sa;
6 disp(Vom, 'maximum output voltage')
```

Scilab code Exa 6.4 calculating output voltage due to offset voltage

```
1 // calculating output voltage due to offset voltage
2 clc;
3 Vos=5*10^-3;
4 Rf=10;
5 R1=1;
6 Vo=-Vos*(1+Rf/R1);
7 disp(Vo, 'output voltage due to offset voltage (V)=')
```

Scilab code Exa 6.5 calculating Amplification factor

```
1 // calculating Amplification factor
2 clc;
3
4 Rf=10;
5 R1=1;
6 A=Rf/R1;
7 disp(A, 'Amplification Factor=')
```

Scilab code Exa 6.6 calculating output voltage due to offset voltage

```
1 // calculating output voltage due to offset voltage
2 clc;
3 V1=1;
4 V2=-2;
5 Rf=500;
6 R1=250;
7 R2=100;
8 Vo=-{[(Rf/R1)*V1]+[(Rf/R2)*V2]};
9 disp(Vo, 'output voltage(V)=')
```

Scilab code Exa 6.7 calculating gain and feedback resistance

```
// calculating gain and feedback resistance
clc;

Rf=100*10^3;
R1=1*10^3;
A=Rf/R1;
disp(A, 'Gain=')
disp('If multiplier is 10')
A=10;
Rf=A*R1;
disp(Rf, 'feedback resistance (Ohm)=')
```

Scilab code Exa 6.8 Calculating the values of resistances

```
1 // Calculating the values of resistances
2 clc;
3 g=10;
4 Rf=10;
5 R1=Rf/g;
6 disp(R1, 'resistance R1(Kilo-ohms)=')
7 R2=Rf/(0.5*g);
```

```
8 disp(R2, 'resistance R1(Kilo-ohms)=')
9 R3=Rf/(0.333*g);
10 disp(R3, 'resistance R1(Kilo-ohms)=')
```

Scilab code Exa 6.9 Calculating the value of resistance and capacitance

```
// Calculating the value of resistance and
        capacitance
clc;
Voramp=-10;
disp('if voltage source is 10V then RC= 1 ms and if
        C=1 micro-F')
C=1;
R=1*10^-3*10^6;
disp(R,'value of resistance (ohm)= ')
```

Scilab code Exa 6.10 Calculating Difference mode gain and output voltage

```
// Calculating Difference mode gain and output
    voltage

clc;
    V2=5*10^-3;
    V1=3*10^-3;
    Vo=300*10^-3;
    Vd=V2-V1;
    Ad=Vo/Vd;
    disp(Ad, 'difference mode gain=')
    V2=155*10^-3;
    V1=153*10^-3;
    Vo=Ad*(V2-V1);
    disp(Vo, 'output voltage (V)=')
```

Scilab code Exa 6.11 Calculating Difference mode Common mode gain and CMRR

```
// Calculating Difference mode, Common mode gain and
CMRR

clc;
vo=3;
Vo=3;
Vd=30*10^-3;
Ad=Vo/Vd;
disp(Ad, 'difference mode gain=')
Vo=5*10^-3;
Vc=500*10^-3;
Ac=Vo/Vc;
disp(Ac, 'Common mode gain=')
CMRR=Ad/Ac;
disp(CMRR, 'Common mode rejection ratio=')
```

Scilab code Exa 6.12 Calculating Signal to noise ratio and CMRR

```
1 // Calculating Signal to noise ratio and CMRR
2 clc;
3 V2=30*10^-3;
4 V1=-30*10^-3;
5 Vd=V2-V1;
6 Ad=150;
7 Vos=Ad*Vd;
8 Ac=0.04;
9 Vc=600*10^-3;
10 Von=Ac*Vc;
11 SNR=Vos/Von;
12 CMRR=Ad/Ac;
13 disp(SNR, 'Signal to Noise Ratio=')
```

```
14
15 disp(CMRR, 'CMRR=')
```

Scilab code Exa 6.13 Calculating sensitivity and output voltage

```
// Calculating sensitivity and output voltage
clc;
Ci=10*10^-12;
Vi=10;
Eo=8.85*10^-12;
A=200*10^-6;
K=-Ci*Vi/(Eo*A);
disp(K, 'sensitivity (V/mm)=')
d=1*10^-6;
Vo=K*d;
disp(Vo, 'output voltage (V)=')
```

Scilab code Exa 6.14 calculating minimum maximum time constants and value of frequencies

```
// calculating minimum, maximum time constants and
value of frequencies

clc;

MXtc= 10^10*1000*10^-12;

disp(MXtc, 'Maximum time constant (s)');

MNtc= 10^8*10*10^-12;

disp(MNtc, 'Minimum time constant (s)');

AR=0.95;

fmin=(AR)/[2*%pi*MXtc*(1-AR^2)^0.5];

disp(fmin, 'minimum frequency (Hz)')

fmax=(AR)/[2*%pi*MNtc*(1-AR^2)^0.5];

disp(fmax, 'Maximum frequency (Hz)')
```

Scilab code Exa 6.15 calculating time constant and value of capacitance

 ${f Scilab\ code\ Exa\ 6.16}$  calcuating the passband gain and upper and lower cut off frequencies

### Scilab code Exa 6.17 calcuating the value of C

```
1 // calcuating the value of C
2 clc;
3 R=1*10^6;
4 fo=10*10^3;
5 C=1/(2*%pi*fo*R);
6 disp(C, 'the value of C (F) ')
```

### Scilab code Exa 6.19 calculate the output voltage and sensitivity

```
1 // calculate the output voltage and sensitivity
2 clc;
3 \text{ Rt} = 100;
4 \text{ K} = 1;
5 Rb=K*Rt;
6 \text{ ei} = 10;
7 disp('When K=1')
8 eo=[(K*Rt/Rb)/(1+(K*Rt/Rb))]*ei;
9 disp(eo, 'output voltage (V)= ')
10 Se=(ei*Rb)/[(Rb+K*Rt)^2];
11 disp(Se, 'sensitivity (V/ohm) = ')
12 \quad K=0.95;
13 disp('When K=0.95')
14 eo=[(K*Rt/Rb)/(1+(K*Rt/Rb))]*ei;
15 disp(eo, 'output voltage (V)= ')
16 Se=(ei*Rb)/[(Rb+K*Rt)^2];
17 disp(Se, 'sensitivity (V/ohm) = ')
```

Scilab code Exa 6.20 calculate the output voltage for different values of K

```
1 // calculate the output voltage for different values
       of K
2 clc;
3 \text{ ei} = 100;
4 \text{ K=0.25};
5 disp('When K=0.25')
6 eo=[(K/6)/(1+(K/6))]*ei;
7 disp(eo, 'output voltage (V)= ')
8 \text{ K=0.5};
9 disp('When K=0.5')
10 eo=[(K/6)/(1+(K/6))]*ei;
11 disp(eo, 'output voltage (V)= ')
12 \quad K = 0.6;
13 disp('When K=0.6')
14 eo=[(K/6)/(1+(K/6))]*ei;
15 disp(eo, 'output voltage (V)= ')
16 \text{ K=0.8};
17 disp('When K=0.8')
18 eo=[(K/6)/(1+(K/6))]*ei;
19 disp(eo, 'output voltage (V)= ')
```

Scilab code Exa 6.21 calculating the resistance and output voltage

```
1 // calculating the resistance and output voltage
2 clc;
3 R2=119;
4 R3=119.7;
5 R1=120.4;
6 R4=R2*R3/R1;
7 R4=121.2;
8 ei=12;
9 eo=[(R1*R4-R2*R3)/((R1+R3)*(R2+R4))]*ei;
```

```
10 disp(eo, 'output voltage (V)=')
```

### Scilab code Exa 6.22 Calculating the bridge output

```
1 // Calculating the bridge output
2 clc;
3 ei=6;
4 R=10000;
5 disp('if dR=0.05R')
6 dR=0.05*R;
7 eo=[(dR/R)/(4+2*(dR/R))]*ei;
8 disp(eo, 'output voltage (V)')
9 disp('if dR=-0.05R')
10 dR=-0.05*R;
11 eo=[(dR/R)/(4+2*(dR/R))]*ei;
12 disp(eo, 'output voltage (V)')
```

### Scilab code Exa 6.23 Calculating the resistance of unknown resistance

```
// Calculating the resistance of unknown resistance
clc;
R2=800;
R3=800;
R4=800;
Rm=100;
R=800;
ei=4;
im=0.8*10^-6;
dR=(im*R^2)*(4*(1+Rm/R))/ei;
R1=R+dR;
disp(R1, 'Resistance of unknown resistor (ohm)=')
```

### Scilab code Exa 6.24 calculating the current

```
1 // calculating the current
2 clc;
3 R2=1000;
4 R3=1000;
5 R1=1010;
6 R4=1000;
7 ei=100;
8 eo=[(R1*R4-R2*R3)/((R1+R3)*(R2+R4))]*ei;
9 disp(eo, 'open circuit voltage (V)=')
10 Ro=[R1*R4/(R1+R4)]+[R2*R3/(R2+R3)];
11 Rm=4000;
12 im=eo/(Ro+Rm);
13 disp(im, 'current (A)=')
```

Scilab code Exa 6.25 Calculating maximum permissible current through strain gauge supply voltage and Power dissipation in series resistance

```
// Calculating maximum permissible current through
    strain gauge, supply voltage
// and Power dissipation in series resistance
clc;
R=100;
P=250*10^-3;
i=(P/R)^0.5;
disp(i,'maximum permissible current (A)=')
ei=2*i*R;
disp(ei,'maximum supply voltage (V)=')
Rs=100;
Ps=10^2/Rs;
```

```
12 disp(Ps, 'Power dissipation in series resistance (W)'
```

Scilab code Exa 6.26 Calculating the maximum voltage sensitivity of the bridge

Scilab code Exa 6.27 Calculating the resolution of the instrument quantization error and decesion levels

Scilab code Exa 6.28 Calculating the weight of MSB and LSB

```
// Calculating the weight of MSB and LSB
clc;
Ra=10;
b=5;
Wmsb=Ra/2;
disp(Wmsb,'weight of MSB (V)=')
Wlsb=Ra/2^b;
disp(Wlsb,'weight of LSB (V)=')
```

Scilab code Exa 6.29 Calculating reference voltage and percentage change

```
// Calculating reference voltage and percentage
    change

clc;

E=10;

ER=E*256/255;

disp(ER, 'Reference voltage (V)=')

n=8;

CVlsb=(2^-n)*ER;

PC=CVlsb*100/E;

disp(PC, 'Percentage change =')
```

Scilab code Exa 6.30 Calculating the number of bits Value of LSB Quantization error minimum sampling rate Aperature time and dynamic range

```
1 // Calculating the number of bits, Value of LSB,
      Quantization error, minimum sampling rate
      Aperature time and dynamic range
2 clc;
3 n = 14;
4 disp(n, 'number of bits =')
5 E=10;
6 Q = 10;
7 LSB=E/2^n;
8 disp(LSB, 'Value of LSB (V) =')
9 Eq=Q/(2*(3^0.5));
10 disp(Eq, 'Quantization error (V) =')
11 fh=1000;
12 fs=5*fh;
13 disp(fs, 'minimum sampling rate (Hz) =')
14 a=1/16384;
15 ta=1/(2*\%pi*fh)*a;
16 disp(ta, 'Aperature time (s) =')
17 Dr = 6 * n;
18 disp(Dr, 'dynamic range (db) =')
```

Scilab code Exa 6.31 Calculating the value of resistance and smallest output current

### Scilab code Exa 6.32 Calculating the output voltage

```
1 // Calculating the output voltage
2 clc;
3 n=6;
4 R=10000;
5 Io= (10/10*10^3)
         *{1*1+1*0.5+1*0.25+0*0.125+1*0.0625}*10^-6;
6 Rf=5000;
7 Eo=-Io*Rf;
8 disp(Eo, 'Output voltage (V)=')
```

Scilab code Exa 6.33 Calculate the output of successive approximation A to D

```
1 // Calculate the output of successive approximation
     A/D
2 clc;
3 disp('Set d3=1')
4 Output=5/2<sup>1</sup>;
5 disp('since 3.217 > 2.5 so d3=1')
6 disp('Set d2=1')
7 Output = (5/2^1) + (5/2^2);
8 disp('since 3.217 < 3.75 so d2=0')
9 disp('Set d1=1')
10 Output = (5/2^1) + (5/2^3);
11 disp('since 3.217>3.125 so d1=1')
12 disp('Set d0=1')
13 Output = (5/2^1) + (5/2^3) + (5/2^4);
14 disp('since 3.217 < 3.4375 so d0=0')
15 disp('Output of successive approximation A/D = 1010'
      )
```

### Scilab code Exa $6.34\,$ to calculate op dc voltage

```
1 //to calculate o/p dc voltage
2
3 clc;
4 t=400;
5 T=t/4;
6 C=1*10^-6;
7 v=20;
8 i=C*100*v/(T);
9 R=1*10^3;
10 e_o=i*R;
11 disp(e_o, 'output voltage(V)');
```

### Chapter 7

## Display Devices and recorders

### Scilab code Exa 7.1 calculating resolution

```
// calculating resolution
clc;
N = 4;
R=1/10^N;
disp(R, 'Resolution of the meter=');
VR=1;
R1=VR*R;
disp(R1, 'Resolution of the meter for voltage range 1 V=');
VR1=10;
R2=VR1*R;
disp(R2, 'Resolution of the meter for voltage range 10V=');
```

### Scilab code Exa 7.2 calculating resolution

```
1 // calculating resolution
2 clc;
```

```
3 N = 3;
4 R=1/10^N;
5 disp(R, 'Resolution of the meter=');
6 disp('12.98 will be displayed as 12.980 on 10V scale
      ')
7 VR=1;
8 R1=VR*R;
9 disp(R1, 'Resolution of the meter for voltage range 1
     V='):
10 disp('0.6973 will be displayed as 0.6973 on 1V scale
      ')
11 VR1=10;
12 R2=VR1*R;
13 disp(R2, 'Resolution of the meter for voltage range
      10V = ');
14 \operatorname{disp}('0.6973) will be displayed as 00.697 on 10V
      scale')
```

Scilab code Exa 7.3 calculating Total possible error and percentage error

```
// calculating Total possible error and percentage
error

clc;
R=5;
V=0.005*R;
disp(V,'0.5 percent of the reading')
TPE=V+0.01;
R1=0.10;
V1=0.005*R1;
TPE1=V1+0.01;
disp(TPE1,'Total possible error (V)=')

disp(TPE1,'Total possible error (V)=')

PE=(TPE1/0.1)*100;
disp(PE,'Percentage error=')
```

### Scilab code Exa 7.4 calculating frequency

```
1 // calculating frequency
2 clc;
3 N=034;
4 t=10*10^-3;
5 f=N/t;
6 disp(f, 'frequency(Hz)=')
```

#### Scilab code Exa 7.5 calculating maximum error

```
1 // calculating maximum error
2 clc;
3 R=5*10^6;
4 V=0.00005*R;
5 disp(V,'0.005 percent of the reading(micro sec)=');
6 LSD=1;
7 ME=V+1;
8 disp(ME,'Maximum error (micro sec)=')
9 R=500;
10 V=0.00005*R;
11 disp(V,'0.005 percent of the reading(sec)=');
12 LSD=1;
13 ME=V+1;
14 disp(ME,'Maximum error (sec)=')
```

### Scilab code Exa 7.6 calculating number of turns and current

```
1 // calculating number of turns and current
```

```
2 clc;
3 D=8*10^-3;
4 A=D^2;
5 disp(A, 'A=')
6 J=8*10^-3;
7 K=16*10^-3;
8 B=4*J*K;
9 disp (B, 'B=')
10 disp('since A < B so the instrument is underdanged')
11 th = (100 * \%pi) / 180;
12 i=10*10^-3;
13 F=0.2*10^-6;
14 G = (K*th+F)/i;
15 \ 1=65*10^{-3};
16 d=25*10^{-3};
17 N=G/(B*1*d);
18 disp(N, 'number of turns=')
19 i=F/G;
20 disp(i, 'current required to overcome friction (A)')
```

### Scilab code Exa 7.7 calculating speed of the tape

```
1 // calculating speed of the tape
2 clc;
3 Lam = 2.5 * 6.25;
4 f = 50000;
5 S = Lam * 10^-6 * f;
6 disp(S, 'speed(m/s) = ')
```

Scilab code Exa 7.8 calculating number density of the tape

```
1 // calculating number density of the tape 2 \operatorname{clc};
```

```
3 ND=12000/1.5;
4 disp(ND, 'Number density (numbers/mm)')
```

### Scilab code Exa 7.9 Calculating possible phase angles

```
// Calculating possible phase angles
clc;
Y1=1.25;
Y2=2.5;
PA=asind(Y1/Y2);
disp(PA,'phase angle (degree)')
disp('possible angle are 30 degree and 330 degree')
```

### Scilab code Exa 7.10 Calculating possible phase angles

```
1 // Calculating possible phase angles
2 clc;
3 disp ('if spot generating pattern moves in the
      clockwise direction')
4 Y1=0;
5 \quad Y2=5;
6 PA=asind(Y1/Y2);
7 disp(PA, 'phase angle (degree)')
8 \quad Y1 = 2.5;
9 Y2=5;
10 PA=asind(Y1/Y2);
11 disp(PA, 'phase angle (degree)')
12 \quad Y1 = 3.5;
13 Y2=5;
14 PA=asind(Y1/Y2);
15 disp(PA, 'phase angle (degree)')
16 \quad Y1 = 2.5;
17 \quad Y2=5;
```

```
18 PA=180-[asind(Y1/Y2)];
19 disp(PA, 'phase angle (degree)')
```

# Chapter 8

# Metrology

Scilab code Exa 8.1 calculate the arrangement of slip gauges

```
1 // calculate the arrangement of slip gauges
2 clc;
3 Dd=52.215;
4 disp(Dd, 'desired value=')
5 Pb=4;
6 disp(Pb, 'Protected block=')
7 R = Dd - Pb;
8 disp(R, 'Reminder=')
9 Tp=1.005;
10 disp(Tp, 'thousand block=')
11 R=R-Tp;
12 disp(R, 'Reminder=')
13 Hp=1.010;
14 disp(Hp, 'Hunderths block=')
15 R=R-Hp;
16 disp(R, 'Reminder=')
17 Ttp=2.20;
18 disp(Ttp, 'tenths block=')
19 R=R-Ttp;
20 disp(R, 'Reminder=')
21 \text{ Up=4};
```

```
disp(Up, 'unit block=')
R=R-Up;
disp(R, 'Reminder=')
Tp=40;
disp(Tp, 'Tens block=')
R=R-Tp;
disp(R, 'Reminder=')
```

### Scilab code Exa 8.2 calculate the sensitivity

```
1 // calculate the sensitivity
2 clc;
3 \text{ Ps} = 200 * 10^3;
4 r=0.6;
5 d2=0.5;
6 d1=0.5;
7 a=(d2/d1^2);
8 x1=(1.1-r)/(2*a);
9 \text{ disp}(x1, 'x1=')
10 r = 0.8;
11 d2=0.5;
12 d1=0.5;
13 a=(d2/d1^2);
14 x2=(1.1-r)/(2*a);
15 disp(x2, 'x2=')
16 x=x1-x2;
17 disp(x, 'so the range is x (mm)')
18 hS = \%pi * d2 * 10^{-3};
19 A2 = \%pi*d2*10^-6*(x1+x2)/2;
20 pS = -0.4*Ps/A2;
21 \text{ pgS} = 25*10^{-3}/1000;
22 S=hS*pS*pgS;
23 disp(S, 'sensitivity=')
```

Scilab code Exa 8.3 calculate uncertainty in displacement

```
1 // calculate uncertainity in displacement
2 \text{ Pi} = 70 * 10^3;
3 r=0.4;
4 d2=1.6;
5 d1=0.75;
6 a = (d2/d1^2);
7 x1=(1.1-r)/(2*a);
8 \text{ disp}(x1, 'x1=')
9 r = 0.9;
10 x2=(1.1-r)/(2*a);
11 disp(x2, 'x2=')
12 x = x1 - x2;
13 disp(x, 'so the range is x (mm)')
14 d=-2*a;
15 Wr = 12.5/Pi;
16 Wx = Wr/d;
17 disp(Wx, 'uncertainity in displacement (mm)')
```

Scilab code Exa 8.4 calculate difference between height of workpieces and pile of slip gauges

```
// calculate difference between height of workpieces
and pile of slip gauges

clc;
N=12;
lem=0.644;
d=N*lem/2;
disp(d,'difference between height of workpieces and pile of slip gauges (micro-meter)')
```

Scilab code Exa 8.5 calculate seperation distance between two surfaces and angle of tilt

```
// calculate seperation distance between two
    surfaces and angle of tilt

clc;
  N=5;
  lem=546*10^-9;
  d=[(2*N-1)*lem*10^6]/4;
  disp(d, 'seperation distance between two surfaces(
        micro-meter)')
  x=75;
  th=atan(d/x);
  disp(th, 'angle of tilt')
```

Scilab code Exa 8.6 Calculate the difference in two diameters

```
1 // Calculate the difference in two diameters
2 clc;
3 x=20/12;
4 L=50-10;
5 lem=0.6;
6 d=(L*lem)/(2*x);
7 disp(d,'difference in diameters of the rollers(micro-meter)')
```

Scilab code Exa 8.7 Calculate the change in thickness along its length

```
1 // Calculate the change in thickness along its
    length
2 clc;
3 d=4.5-2.5;
4 Tg=2*(0.5)*0.509;
5 disp(Tg, 'change in thickness along its length(micro-meter)')
```

# Chapter 9

# Pressure Measurements

Scilab code Exa 9.1 calculating the length of mean free path

```
1 // calculating the length of mean free path
2 clc;
3 T = 273 + 20;
4 P=101.3*10^3;
5 mfp=22.7*10^-6*T/P;
6 disp(mfp, 'length of mean free path when pressure is
      one atmospheric pressure (m)')
7 P = 133;
8 mfp=22.7*10^-6*T/P;
9 disp(mfp, 'length of mean free path when pressure is
      one torr (m)')
10 P=133*10^-3;
11 mfp=22.7*10^-6*T/P;
12 disp(mfp, 'length of mean free path when pressure is
      one micrometer of Hg(m)')
13 P = 249.1;
14 mfp=22.7*10^-6*T/P;
15 disp(mfp, 'length of mean free path when pressure is
      one inch of water (m)')
16 P = 133 * 10^{-6};
17 mfp=22.7*10^-6*T/P;
```

```
18 disp(mfp, 'length of mean free path when pressure is 10^-3 micrometer of Hg(m)')
```

#### Scilab code Exa 9.2 Calculate Pressure of air source

```
1 //Calculate Pressure of air source
2 clc;
3 T=273+25;
4 P=99.22*10^3;
5 R=288;
6 df=P/(R*T);
7 dm=0.82*996;
8 g=9.81;
9 h=200*10^-6;
10 P1=g*h*(dm-df)*10^3;
11 Pa=P+P1;
12 disp(Pa, 'Pressure of air source(N/m2)')
```

#### Scilab code Exa 9.3 Calculate Pressure head

```
1 // Calculate Pressure head
2 clc;
3 df=1*10^3;
4 dm=13.56*10^3;
5 g=9.81;
6 h=130*10^-3;
7 P=g*h*(dm-df);
8 Ph=P/9.81;
9 disp(Ph, 'Pressure head(mm of water)')
```

#### Scilab code Exa 9.4 calculate height

```
1 // calculate hight
2 clc;
3 hn =250;
4 d=5;
5 D=25;
6 h=hn*(1+(d/D)^2);
7 disp(h, 'height')
```

#### Scilab code Exa 9.6 calculate error in terms of pressure

```
1 // calculate error interms of pressure
2 clc;
3 P=8*133;
4 h=P/(800*9.81);
5 d=2;
6 D=50;
7 hn=h/(1+(d/D)^2);
8 e=(hn-h)/h*100;
9 eP=0.8*1000*9.81*(hn-h);
10 disp(eP, 'error interms of pressure(N/m2)')
```

#### Scilab code Exa 9.7 calculate angle to which tube is incliend to vertical

```
8 D=20;
9 th=asind(P/(g*dm*R*(1+(d/D)^2)));
10 thV=90-th;
11 disp(thV, 'angle to which tube is incliend to vertical(degree)')
```

Scilab code Exa 9.8 calculate angle to which tube is incliend to horizontal

```
// calculate angle to which tube is incliend to
    horizontal

clc;
P=9.81;
g=9.81;
dm=0.864*10^3;
R=4*10^-3;
d=2;
D=20;
th=asind(P/(g*dm*R*(1+(d/D)^2)));
disp(th, 'angle to which tube is incliend to
    horizontal(degree)')
```

Scilab code Exa 9.9 calculate Length of scale angle to which tube is incliend to horizontal

```
1 // calculate Length of scale angle to which tube is
    incliend to horizontal
2 clc;
3 P=500*9.81;
4 g=9.81;
5 d=8;
6 a= (%pi/4)*d^2;
7 A=1200;
8 dm=0.8*10^3;
```

```
9 hn=P/(g*dm*(1+(a/A)));
10 disp(hn, 'Length of scale(m)')
11 R=0.6;
12 P1=50*9.81;
13 th=asind(P1/(g*dm*R*[1+(a/A)]));
14 disp(th, 'angle to which tube is incliend to horizontal(degree)')
```

Scilab code Exa 9.10 calculate diameter of the tube

```
1 // calculate diameter of the tube
2 clc;
3 P=100*10^3;
4 g=9.81;
5 di=10*10^-3;
6 D=40*10^-3;
7 A= (%pi/4)*D^2;
8 dm=13.6*10^3;
9 a=A/[P/(dm*g*di)-1];
10 d=(4*a/%pi)^0.5*10^3;
11 disp(d,'diameter of the tube(mm)')
```

Scilab code Exa 9.11 calculate amplification ratio and percentage error

```
9 PR=(a/A)*100;
10 disp(PR, 'percentage error')
```

Scilab code Exa 9.12 calculate value of counter weight required

```
1 // calculate value of counter weight required
2 clc;
3 P=981;
4 g=9.81;
5 d=500*10^-3;
6 A= (%pi/4)*(10*10^-3)^2;
7 R=275*10^-3;
8 th=30;
9 W=A*d*P/(2*g*R*sind(th));
10 disp(W,'value of counter weight required(kg)')
```

Scilab code Exa 9.13 calculate damping factor time constant error and time lag calculate damping factor natural frequency time constant error and time lag

```
// calculate damping factor, time constant, error
and time lag
// calculate damping factor, natural frequency, time
constant, error and time lag

clc;
Mp1=20/40;
Mp2=10/40;
Mp3=5/40;
Eta=0.225;
disp(Eta, 'damping factor')
Td=1.2;
wd=2*%pi/Td;
mn=wd/[(1-Eta^2)^0.5];
```

```
12 tc=1/wn;
13 disp(tc, 'time constant(s)')
14 ess=2*Eta/wn;
15 \text{ ess5=5*ess};
16 disp(ess5, 'error for 5mm/s ramp(mm)')
17 Tlag=2*Eta*tc;
18 disp(Tlag, 'time lag(s)')
19 Eta1=Eta*(0.5)^0.5;
20 disp(Eta1, 'New damping factor')
21 Td=1.2;
22 \text{ wn1} = \text{wn}*(0.5)^0.5;
23 disp(wn1, 'New natural frequency(rad/s)')
24 \text{ tc1=1/wn};
25 disp(tc1, 'New time constant(s)')
26 \text{ ess51=ess5};
27 disp(ess51, 'new error for 5mm/s ramp(mm)')
28 Tlag1=Tlag;
29 disp(Tlag1, 'new time lag(s)');
```

Scilab code Exa 9.14 calculate thickness of diaphram and natural frequency

```
// calculate thickness of diaphram and natural
    frequency

clc;
P=7*10^6;
R=6.25*10^-3;
v=0.28;
E=200*10^9;
t={[9*P*R^4*(1-v^2)/(16*E)]^0.25}*10^3;
disp(t, 'thickness of diaphram(mm)')
ds=7800;
fn=[2.5*t/(%pi*R^2)]*[E/(3*ds*(1-v^2))]^0.5;
disp(fn, 'natural frequency(Hz)')
```

Scilab code Exa 9.15 calculate the natural length of the spring and dispacement

Scilab code Exa 9.16 calculate the open circuit voltage

```
1 // calculate the open circuit voltage
2 clc;
3 P=200*10^3;
4 R=70*10^-3;
5 v=0.25;
6 t=1*10^-3;
7 r=60*10^-3;
8 E=200*10^9;
9 Sr=[3*P*R^2*v/(8*t^2)]*{(1/v+1)-(3/v+1)*(r/R)^2};
10 St=[3*P*R^2*v/(8*t^2)]*{(1/v+1)-(1/v+3)*(r/R)^2};
11 Sta2=(Sr-v*St)/E;
12 Sta3=(Sr-v*St)/E;
```

```
13 r0=10*10^-3;

14 Sr1=[3*P*R^2*v/(8*t^2)]*{(1/v+1)-(3/v+1)*(r0/R)^2};

15 St1=[3*P*R^2*v/(8*t^2)]*{(1/v+1)-(1/v+3)*(r0/R)^2};

16 Sta1=(Sr1-v*St1)/E;

17 Sta4=(Sr1-v*St1)/E;

18 Gf=1.8;

19 ei=12;

20 eo=(Sta1+Sta4-Sta2-Sta3)*Gf*ei/4;

21 disp(eo,'output voltage (V)')
```

## Scilab code Exa 9.17 calculate the optimum setting

```
1 // calculate the optimum setting
2 clc;
3 \text{ Aou} = 700 * 25 * 1/100;
4 Aol=100*25*1/100;
5 AouPtP= 2*Aou;
6 AolPtP= 2*Aol;
7 Se1=1;
8 D1=AouPtP/Se1;
9 disp(D1, 'deflection of screen corresponding to
     maximum pressure for sensitivity of 1mV/mm (mm)')
10 disp('sinch the length of the screen is 100mm so
      waveform is out of range and hence sensitivity
      setting of 1mV/mm should not be used')
11 Se2=5;
12 D2=AouPtP/Se2;
13 disp(D2, 'deflection of screen corresponding to
     maximum pressure for sensitivity of 5mV/mm (mm)')
14 disp('delection is within the range')
15 \text{ Se3}=20;
16 D3=AouPtP/Se3;
17 disp(D3, 'deflection of screen corresponding to
     maximum pressure for sensitivity of 20mV/mm (mm);
     )
```

```
disp('delection is within the range')
Se4=100;
D4=AouPtP/Se4;
disp(D4, 'deflection of screen corresponding to maximum pressure for sensitivity of 100mV/mm (mm)')
disp('delection is within the range')
Se5=500;
D5=AouPtP/Se5;
disp(D5, 'deflection of screen corresponding to maximum pressure for sensitivity of 500mV/mm (mm)')
disp('delection is within the range')
disp('delection is within the range')
figure deflection so it is the optimum sensitivity')
```

## Scilab code Exa 9.18 calculate the output voltage of bridge

```
1 // calculate the output voltage of bridge
2 clc;
3 dP=(7000*10^3)-(100*10^3);
4 b=25*10^-12;
5 R1=100;
6 dR=R1*b*dP;
7 ei=5;
8 deo=dR*ei/(4*R1)
9 disp(deo,'output voltage of bridge(V)')
```

#### Scilab code Exa 9.19 calculate attenuation

```
1 // calculate attenuation
2 clc;
3 T=273+20;
```

```
4 P=101.3*10^3;
5 R = 287;
6 de=P/(R*T);
7 C=20.04*T^0.5;
8 r=6.25*10^{-3};
9 L=0.6;
10 V = \%pi * [(12.5*10^-3)^2] * (12.5*10^-3);
11 wn=C*r*(\%pi/(V*(L+0.5*\%pi*r)))^0.5;
12 fn=wn/(2*%pi);
13 f=1000;
14 \text{ u=f/fn};
15 mu = 19.1*10^-6;
16 eta=[2*mu/(de*C*r^3)]*[3*L*V/%pi]^0.5;
17 M=1/\{[(1-u^2)^2]+[(2*eta*u)^2]\}^0.5;
18 \text{ %M=M*100};
19 disp(%M, 'attenuation=')
```

#### Scilab code Exa 9.20 calculate error

```
1 // calculate error
2 clc;
3 d=1;
4 At=(%pi*d^2)*10^-6/4;
5 V=100*10^-6;
6 h=30*10^-3;
7 P1=(At*h^2)/V;
8 P2=(At*h^2)/(V-At*h);
9 e=P2-P1;
10 disp(e,'error=')
```