This is for the long chassis configuration. The size of the board is  $15" \times 32" \times 1/2"$  and is made of plywood. Please note that 3/4" plywood will not work as it won't fit. Attachment holes can be drilled once the board is installed on the chassis to make it easier. To do this a 3/16" drill bit is needed. Attachment can be completed with 4,  $10-32 \times 1"$  machine screws with accompanying nuts. The completed board should be installed before attaching all four sides of the chassis together.

