Pcb\_9

new

element\_begin
element\_output

element\_add\_line

element\_add\_arc

element\_add\_pin

element\_add\_pad

element\_add\_pad\_rectangle

element\_add\_pin\_oval

element\_add\_mark

element\_add\_lines

element\_add\_rectangle

element\_set\_text\_xy

element\_set

 ${\tt element\_get}$ 

 ${\tt element\_dump}$ 

References

Change Log

Element Flags

Text Flags

Pin Flags

Pad Flags

Examples



# Creating PCB Elements with Perl

John C. Luciani Jr.

June 24, 2007

#### Pcb\_9

element\_begin

element\_output

element\_add\_line

element\_add\_arc

element\_add\_pin

element\_add\_pad

element\_add\_pad\_rectangle

element\_add\_pin\_oval

element\_add\_mark

element\_add\_lines

element\_add\_rectangle

element\_set\_text\_xy

element\_set

element\_get

get

element\_dump

References

Change Log

Element Flags

Text Flags

Pin Flags

Pad Flags

Examples



### $1 \text{ Pcb}_{-9}$

This document describes a set of Perl routines that can be used to create component footprints for the circuit board layout program PCB. These routines reside in a file called  $Pcb_{\langle n \rangle}$  pm where  $\langle n \rangle$  is the current revision number of the package. Only the new format of PCB elements is output. The differences (that I am aware of) between the old and new formats are:

- Dimensions are in hundreths of a mil.
- The argument delimiters are square brackets []
- The element command adds the mark\_x and mark\_y parameters
- The pin and pad command add clearance and mask parameters.

### Requirements

These routines should run with a standard Perl distribution. The only packages used are POSIX and Carp.

#### Usage

These routines are object oriented. A PCB object is created using new and all subsequent method calls use this object. element\_begin starts a new element. element\_output outputs the element file. element\_add\_mark sets the component centroid. element\_set\_text\_xy sets the text position for the reference designator. The names of the methods used to draw elements all start with the string element\_add. Arguments for the method calls are key-value pairs. The keys are parameter strings defined in pcb.html.

To use these routines in a Perl script to create a PCB element:

- 1. Include the PCB routines use  $Pcb_{\langle n \rangle}$ ;
- 2. Create a PCB object using new
- 3. Begin an element using element\_begin
- 4. Add copper to the element using element\_add\_pin or element\_add\_pad
- 5. Add silkcreen elements using element\_add\_line, element\_add\_arc,
- 6. Mark the centroid using element\_add\_mark. The mark can also be set using parameters of the element\_begin method.
- 7. Add the text location for the reference designator using element\_set\_text\_xy The text location can also be set using parameters of the element\_begin method.
- 8. Output the element to a file using element\_output

The simple example in Listing 1 creates a quarter watt through-hole resistor. The example in Listing 3 creates a variety of two terminal SMD footprints ranging in size from 0402 to 2512. The example in Listing 5 creates Molex 8624 series header connector footprints. The example in Listing 6 creates TQFN footprints for a variety of Maxim parts. These examples place files in the directory ./tmp. This can be easily changed by changing the element\_begin call.

#### Listing 1: 1/4 Watt Resistor Example

#### Contents

Pcb\_9

element\_begin

element\_output

element\_add\_line

 $element\_add\_arc$ 

element\_add\_pin

element\_add\_pad

element\_add\_pad\_rectangle

element\_add\_pin\_oval

element\_add\_mark

 $element\_add\_lines$ 

element\_add\_rectangle

element\_set\_text\_xy

 ${\tt element\_set}$ 

element\_get

element\_dump

\_

References


Change Log

Element Flags

Text Flags

Pin Flags

Pad Flags



```
1 #!/usr/bin/perl
   # Copyright (C) 2005 John C. Luciani Jr.
   # This program may be distributed or modified under the terms of
   # version 0.2 of the No-Fee Software License published by
   # John C. Luciani Jr.
   # Creates a 1/4 Watt resistor
10
11
   use strict;
   use warnings;
12
13
   use Pcb_8;
14
15
   my Pcb = Pcb_8 \rightarrow new(debug => 1);
17
   $Pcb -> element_begin(description => 'resistor',
18
19
                           output_file => '025W',
                           dim => 'mils'):
20
21
22
   # the resistor centroid is at (0,0) and the pins are placed 400 mils
23
   # apart
24
25
   my Body_width = 70;
                                   # y direction
   my $Body_length = 240;
                                   # x direction
26
   my @Pins = (-200, 0, 200, 0); # x, y pin centers
   my $Pin_num = 1;
28
29
   while (@Pins) {
30
31
       my (\$x, \$y) = \text{splice @Pins}, 0, 2;
        $Pcb -> element_add_pin(x => $x, y => $y,
32
33
                                 thickness => 55,
                                 drill_hole => 35,
34
                                 mask => 10,
35
36
                                 clearance => 10,
                                 pin_number => $Pin_num++);
37
38
39
40
   $Pcb -> element_add_rectangle(width => $Body_width,
                                   length => $Body_length,
41
42
                                   thickness => 10,
                                   x => 0,
43
44
                                   y => 0);
45
   foreach my $sign (-1, 1) {
46
        $Pcb -> element_add_line(x1 => $sign * $Body_length / 2,
47
48
                                  y1 => 0,
                                  x2 => \$sign * (\$Body_length / 2 + 30),
49
50
                                  y2 => 0,
                                  thickness => 10);
51
52
53
54
   $Pcb -> element_set_text_xy(x => -$Body_length/2,
55
                                 y = -\$Body_width/2 - 20);
56
57
58
   $Pcb -> element_output();
```

Pcb\_9

new

element\_begin

element\_output

 ${\tt element\_add\_line}$ 

element\_add\_arc

element\_add\_pin

element\_add\_pad

element\_add\_pad\_rectangle

 ${\tt element\_add\_pin\_oval}$ 

 ${\tt element\_add\_mark}$ 

element\_add\_lines

element\_add\_rectangle

element\_set\_text\_xy

 ${\tt element\_set}$ 

 ${\tt element\_get}$ 

500

element\_dump

References

Change Log

Element Flags

Text Flags

Pin Flags

Pad Flags

Examples



#### 2 new

# Usage

Pcb\_9->new(  $\langle parameter\ list \rangle$  )

### Description

Creates an object that is used to make PCB element files. Default parameters for the various element drawing commands can be initialized using a key-value parameter list. The valid keys and default values are in Table 1

Parameter Name	Default Value	Notes
line_thickness	10	thickness used in drawing silkscreen lines
arc_thickness	10	thickness used in drawing silkscreen arcs
thickness	10	thickness used in drawing any silkscreen line
pin_flags	0	flags used in creating element pins (See Table 16)
pad_flags	PAD_SQUARE	flags used in creating pads
font_size	50	size in ??? of the silkscreen found
clearance	10	separation of pad from other conductors on the layer .
mask	10	distance between the edge of the solder mask and the copper pad.
		This definition differs from the <b>PCB</b> definition of mask.
debug	0	debug messages. no messages (0). object methods (1). object
		methods + internal subroutines (2)

Table 1: Keys for Method new

### Example

To create a new object that will display object method debugging messages:

```
my Pcb = Pcb_9 \rightarrow new(debug => 1);
```

Pcb\_9

new

#### ${\tt element\_begin}$

 ${\tt element\_output}$ 

element\_add\_line

element\_add\_arc

element\_add\_pin

element\_add\_pad

 ${\tt element\_add\_pad\_rectangle}$ 

 ${\tt element\_add\_pin\_oval}$ 

 ${\tt element\_add\_mark}$ 

element\_add\_lines

element\_add\_rectangle

element\_set\_text\_xy

element\_set

element\_get

element\_dump

References

Change Log

Element Flags

Text Flags

rext riags

Pin Flags

Pad Flags

Examples



# 3 element\_begin

# Usage

Pcb->element\_begin( \langle parameter list \rangle )

# Description

Initializes a new Pcb element. If an element was previously created but not output a call to element\_begin will remove it. The valid keys and default values are in Table 2

Parameter Name	Default Value	Notes
flags	0	Element flags. See Table 13
description	, ,	Text description of the footprint
layout_name	, ,	Reference designator used on the PCB.
value	, ,	Value of component in the PCB. Leave blank.
mark_x	0	X location of the footprint mark (in mils)
mark_y	0	Y location of the footprint mark (in mils)
text_x	0	X location of the refdes text (in mils)
text_y	0	Y location of the refdes text (in mils)
direction	0	Text direction flags. See Table 14
scale	100	Text scale.
text_flags	0	See Table 15
output_file	'PCB_ELEMENT.TMP'	Element filename
pin_one_square	0	Sets a default value that is used when creating a pin.
dim	'mils'	units default to mils

Table 2: Keys for Method element\_begin

# Example

To begin a 1/4 Watt resistor element with dimension values in mils:

Pcb\_9

new

 ${\tt element\_begin}$ 

#### element\_output

element\_add\_line

element\_add\_arc

element\_add\_pin

element\_add\_pad

element\_add\_pad\_rectangle

element\_add\_pin\_oval

element\_add\_mark

element\_add\_lines

 ${\tt element\_add\_rectangle}$ 

element\_set\_text\_xy

 ${\tt element\_set}$ 

 ${\tt element\_get}$ 

get

element\_dump

References

Change Log


Element Flags

Text Flags

Pin Flags

Pad Flags

Examples



# 4 element\_output

# Usage

Pcb->element\_output(  $\langle parameter\ list \rangle$  )

# Description

element\_output outputs the element drawing commands to a file. At this time there are no parameters that are valid for the \(\lambda parameter \ list \rangle \).

Pcb\_9

element\_begin

element\_output

#### element\_add\_line

element\_add\_arc

element\_add\_pin

element\_add\_pad

element\_add\_pad\_rectangle

element\_add\_pin\_oval

element\_add\_mark

 $element\_add\_lines$ 

 ${\tt element\_add\_rectangle}$ 

element\_set\_text\_xy

 ${\tt element\_set}$ 

 ${\tt element\_get}$ 

element\_dump

get

References

Change Log

Element Flags

Text Flags

rext riago

Pin Flags Pad Flags

Examples



### f 5 element\_add\_line

# Usage

Pcb->element\_add\_line( \langle parameter list \rangle )

### Description

Creates a silkscreen line of a specified thickness (thickness) between two points (x1, y1) and (x2, y2).

Parameter Name	Default Value	Notes
x1		X coordinate of the first point.
y1		Y coordinate of the first point.
x2		X coordinate of the second point.
y2		Y coordinate of the second point.
thickness		Width of the line.

Table 3: Keys for Method element\_add\_line

# Example

To create a 200mil long silkscreen line that is centered at (0,0) that is 10 mils thick

```
Pcb \rightarrow element_add_line(x1 => -100, y1 => 0, x2 => 100, y2 => 0, thickness => 10);
```

Pcb\_9

Hew

element\_begin

 $element\_output$ 

element\_add\_line

#### element\_add\_arc

element\_add\_pin

 ${\tt element\_add\_pad}$ 

 ${\tt element\_add\_pad\_rectangle}$ 

element\_add\_pin\_oval

element\_add\_mark

 $element\_add\_lines$ 

 ${\tt element\_add\_rectangle}$ 

element\_set\_text\_xy

element\_set

 ${\tt element\_get}$ 

get

 ${\tt element\_dump}$ 

References

Change Log

Element Flags

Text Flags

Pin Flags

Pad Flags

Examples



### 6 element\_add\_arc

# Usage

Pcb->element\_add\_arc( \langle parameter list \rangle )

### Description

Creates a silkscreen arc with a specified width and length centered at a point (x1, y1).

Default Value	Notes
	X coordinate of the point.
	Y coordinate of the point.
	horizontal width of the arc
	vertical length of the arc
	Starting angle of the arc (degrees)
	Angle swept by the arc (degrees)
	line thickness
	Default Value

Table 4: Keys for Method element\_add\_arc

# Example

To create a silkscreen circular arc centered at (0,0) with a line thickness of 10 mils, radius of 200 mils that starts at 45° and sweeps for 135°:

For an ellipse set the width and height to unequal values.

Pcb\_9

Hew

element\_begin

 $element\_output$ 

element\_add\_line

element\_add\_arc

#### element\_add\_pin

element\_add\_pad

element\_add\_pad\_rectangle

element\_add\_pin\_oval

element\_add\_mark

 ${\tt element\_add\_lines}$ 

element\_add\_rectangle

element\_set\_text\_xy

 ${\tt element\_set}$ 

 ${\tt element\_get}$ 

get

element\_dump

References

Change Log

Element Flags

Text Flags

Pin Flags

Pad Flags

Examples



# 7 element\_add\_pin

# Usage

Pcb->element\_add\_pin(  $\langle parameter \ list \rangle$  )

### Description

Adds a pin to an element

Parameter Name	Default Value	Notes
X		X coordinate of the point.
у		Y coordinate of the point.
thickness		width of the copper pad
clearance		separation of pad from other conductors on the layer .
mask		distance between the edge of the solder mask and the copper pad.
		This definition differs from the <b>PCB</b> definition of mask.
drill_hole		diameter of the hole that is drilled at the center of the pad
name		string
pin_number		The pin number of the component pin that will inserted at this
		position.
flags		See Table 16

Table 5: Keys for Method element\_add\_pin

# Example

To place a pin with a round pad at (-100,0) with a pad diameter of 55 mils, a drill hole diameter of 35 mils, soldermask clearance of 10 mils, a copper clearance of 9 mils, and a pin number of one:

Pcb\_9

new

 ${\tt element\_begin}$ 

 ${\tt element\_output}$ 

 $element\_add\_line$ 

element\_add\_arc

 ${\tt element\_add\_pin}$ 

#### element\_add\_pad

element\_add\_pad\_rectangle

 ${\tt element\_add\_pin\_oval}$ 

 $element\_add\_mark$ 

 $element\_add\_lines$ 

 ${\tt element\_add\_rectangle}$ 

element\_set\_text\_xy

element\_set

 ${\tt element\_get}$ 

\_\_\_

element\_dump

References

Change Log

Element Flags

Text Flags

Pin Flags

Pad Flags

Examples



# 8 element\_add\_pad

# Usage

Pcb->element\_add\_pad( \langle parameter list \rangle )

### Description

Pads are created by drawing a line, with a specified thickness, between two points. The line is drawn with a square nib and extends beyond each end point by a distance of  $\frac{\text{thickess}}{2}$ .

Parameter Name	Default Value	Notes
x1		X coordinate of the first point.
y1		Y coordinate of the first point.
x2		X coordinate of the second point.
y2		Y coordinate of the second point.
thickness		Width of the line.
clearance		separation of pad from other conductors on the layer.
mask		distance between the edge of the solder mask and the copper pad.
		This definition differs from the <b>PCB</b> definition of mask.
name		Identification string for the pad
pad_number		The pin number of the component that will reside on the pad.
flags		See Table 17

Table 6: Keys for Method element\_add\_line

# Example

To create a pad that is centered at (0,0) that is 100 mils long and 50 mils thick has a soldermask clearance of 10 mils, a copper clearance of 9 mils and is numbered one:

Pcb\_9

element\_begin

 ${\tt element\_output}$ 

element\_add\_line

element\_add\_arc

element\_add\_pin

element\_add\_pad

#### element\_add\_pad\_rectangle

element\_add\_pin\_oval

element\_add\_mark

element\_add\_lines

element\_add\_rectangle

element\_set\_text\_xy

element\_set

 ${\tt element\_get}$ 

element\_dump

References

Change Log

Element Flags

Text Flags

Pin Flags

Pad Flags

Examples



# element\_add\_pad\_rectangle

### Usage

Pcb->element\_add\_pad\_rectangle( \langle parameter list \rangle )

# Description

Create a pad with a specified width and length that is centered at a point (x,y). The length is in x-direction and the width is in the y-direction.

Default Value	Notes
	X coordinate of the point.
	Y coordinate of the point.
	The pad width (y direction)
	The pad length (x direction)
	separation of pad from other conductors on the layer .
	distance between the edge of the solder mask and the copper pad.
	This definition differs from the <b>PCB</b> definition of mask.
	Identification string for the pad
	The pin number of the component pin that will inserted at this
	position.
	Default Value

Table 7: Keys for Method element\_add\_pad\_rectangle

Pcb\_9

new

 ${\tt element\_begin}$ 

 $element\_output$ 

element\_add\_line

element\_add\_arc

element\_add\_pin

element\_add\_pad

element\_add\_pad\_rectangle

#### element\_add\_pin\_oval

 ${\tt element\_add\_mark}$ 

element\_add\_lines

element\_add\_rectangle

element\_set\_text\_xy

element\_set

 ${\tt element\_get}$ 

element\_dump

\_

References

Change Log

Element Flags

Text Flags

Pin Flags

Pad Flags

Examples



# 10 element\_add\_pin\_oval

# Usage

Pcb->element\_add\_pin\_oval( \langle parameter list \rangle )

### Description

Create a pad with a specified width and length that is centered at a point (x,y). The length is in x-direction and the width is in the y-direction. The corners of the pad are rounded.

This is actually a hybrid object consisting of a component side pad, a solder side pad and a pin placed at the same center point.

Parameter Name	Default Value	Notes
X		X coordinate of the point.
у		Y coordinate of the point.
width		The pad width (y direction)
length		The pad length (x direction)
drill_hole		diameter of the hole that is drilled at the center of the pad
name		Identification string for the pad
pin_number		The pin number of the component pin that will inserted at this
		position.

Table 8: Keys for Method element\_add\_pin\_oval

### Example

To place a pin with an oval pad at (-100,0) with a pad diameter of 55 mils, a drill hole diameter of 35 mils, soldermask clearance of 10 mils, a copper clearance of 9 mils, and a pin number of one:

Pcb\_9

Hew

element\_begin

 ${\tt element\_output}$ 

element\_add\_line

element\_add\_arc

element\_add\_pin

element\_add\_pad

element\_add\_pad\_rectangle

element\_add\_pin\_oval

#### element\_add\_mark

element\_add\_lines

element\_add\_rectangle

element\_set\_text\_xy

element\_set

 ${\tt element\_get}$ 

\_\_\_

element\_dump

References

Change Log

Element Flags

Text Flags

Pin Flags

Pad Flags

Examples



# 11 element\_add\_mark

# Usage

Pcb->element\_add\_mark(  $\langle parameter \ list \rangle$  )

### Description

The mark is a positioning hint. element\_add\_mark places the mark at at a point (x1, y1).

Parameter Name	Default Value	Notes
X		X coordinate of the point.
У		Y coordinate of the point.

Table 9: Keys for Method element\_add\_mark

Pcb\_9

IIew

element\_begin

 ${\tt element\_output}$ 

element\_add\_line

element\_add\_arc

element\_add\_pin

element\_add\_pad

element\_add\_pad\_rectangle

element\_add\_pin\_oval

element\_add\_mark

#### element\_add\_lines

element\_add\_rectangle

element\_set\_text\_xy

element\_set

 ${\tt element\_get}$ 

get

element\_dump

References

Change Log

Element Flags

Text Flags

Pin Flags

Pad Flags

Examples



# 12 element\_add\_lines

### Usage

Pcb->element\_add\_lines(  $\langle parameter\ list \rangle$ )

### Description

Draws silkscreen lines using the specified line end points. Lines are drawn from point to point until all the points are connected.

Parameter Name	Default Value	Notes
points		reference to a list containing x,y coordinates for line end points.
thickness		Width of the line.

Table 10: Keys for Method element\_add\_lines

Pcb\_9

element\_begin

 ${\tt element\_output}$ 

element\_add\_line

element\_add\_arc

element\_add\_pin

element\_add\_pad

element\_add\_pad\_rectangle

element\_add\_pin\_oval

element\_add\_mark

element\_add\_lines

#### element\_add\_rectangle

element\_set\_text\_xy

element\_set

 ${\tt element\_get}$ 

element\_dump

References

Change Log

Element Flags

Text Flags

Pin Flags

Pad Flags

Examples



# 13 element\_add\_rectangle

# Usage

Pcb->element\_add\_rectangle(  $\langle parameter \ list \rangle$  )

# Description

Draws a silkscreen rectangle with a specified width and length at a point (x1, y1).

Parameter Name	Default Value	Notes
X		X coordinate of the point.
у		Y coordinate of the point.
width		rectangle width (y direction)
length		rectangle length (x direction
thickness		Width of the line.

Table 11: Keys for Method element\_add\_rectangle

Pcb\_9

new

element\_begin

 ${\tt element\_output}$ 

 ${\tt element\_add\_line}$ 

element\_add\_arc

element\_add\_pin

element\_add\_pad

element\_add\_pad\_rectangle

element\_add\_pin\_oval

element\_add\_mark

element\_add\_lines

element\_add\_rectangle

#### element\_set\_text\_xy

element\_set

 ${\tt element\_get}$ 

element\_dump

References

Change Log

Element Flags

Text Flags

Pin Flags

Pad Flags

Examples



# 14 element\_set\_text\_xy

# Usage

Pcb->element\_set\_text\_xy(  $\langle parameter\ list \rangle$  )

# Description

Sets the position of the reference designator text.

Parameter Name	Default Value	Notes
X		X coordinate of the point.
у		Y coordinate of the point.
$font\_size$		

Table 12: Keys for Method element\_add\_mark

Pcb\_9

new

element\_begin
element\_output

element\_add\_line

 ${\tt element\_add\_arc}$ 

element\_add\_pin

element\_add\_pad

element\_add\_pad\_rectangle

element\_add\_pin\_oval

element\_add\_mark

element\_add\_lines

element\_add\_rectangle

element\_set\_text\_xy

#### element\_set

 ${\tt element\_get}$ 

get

element\_dump

References

Change Log

Element Flags

Text Flags

Pin Flags

Pad Flags

Examples



# 15 element\_set

# Usage

Pcb->element\_set(  $\langle parameter\ list \rangle$  )

# Description

Sets values in the element hash table. This should be the only method used to set values in the element hash.  $\langle parameter\ list \rangle$  contains key-value pairs.

Pcb\_9

new

element\_begin

 ${\tt element\_output}$ 

element\_add\_line

element\_add\_arc

element\_add\_pin

element\_add\_pad

element\_add\_pad\_rectangle

 ${\tt element\_add\_pin\_oval}$ 

 $element\_add\_mark$ 

element\_add\_lines

element\_add\_rectangle

element\_set\_text\_xy

element\_set

#### ${\tt element\_get}$

get

 ${\tt element\_dump}$ 

References

Change Log

Element Flags

Text Flags

Pin Flags

Pad Flags

Examples



# 6 element\_get

# Usage

Pcb->element\_get( \langle parameter list \rangle )

# Description

Returns a value, from the element hash, for each key specified in  $\langle parameter\ list \rangle$ . If the value is undefined in the element hash then a value from the Pcb object hash is returned. A value of undef is returned if neither hash contains a defined value for the key.

This should be the only method used to retrieve values from the element hash.  $\langle parameter\ list \rangle$  contains a list of keys.

Pcb\_9

Hew

element\_begin

element\_output

element\_add\_line

 ${\tt element\_add\_arc}$ 

 ${\tt element\_add\_pin}$ 

element\_add\_pad

element\_add\_pad\_rectangle

element\_add\_pin\_oval

element\_add\_mark

element\_add\_lines

element\_add\_rectangle

element\_set\_text\_xy

 ${\tt element\_set}$ 

 ${\tt element\_get}$ 

#### get

 ${\tt element\_dump}$ 

References

Change Log

Element Flags

Text Flags

Pin Flags

Pad Flags

Examples



# 17 get

### Usage

Pcb->get(  $\langle parameter\ list \rangle$  )

### Description

Retrieves values from the PCB object hash. This should be the only method used to retrieve values from the PCB object hash.  $\langle parameter\ list \rangle$  contains a list of keys.

Pcb\_9

Hew

element\_begin

 ${\tt element\_output}$ 

element\_add\_line

element\_add\_arc

element\_add\_pin

element\_add\_pad

element\_add\_pad\_rectangle

element\_add\_pin\_oval

element\_add\_mark

element\_add\_lines

element\_add\_rectangle

element\_set\_text\_xy

element\_set

 ${\tt element\_get}$ 

#### element\_dump

References

Change Log

Element Flags

Text Flags

Pin Flags

Pad Flags

Examples



# 18 element\_dump

# Usage

Pcb->element\_dump(  $\langle parameter\ list \rangle$ )

### Description

A debugging procedure that Prints out the element command drawing commands to STDOUT.

Pcb\_9

nau

element\_begin

 $element\_output$ 

element\_add\_line

element\_add\_arc

element\_add\_pin

element\_add\_pad

element\_add\_pad\_rectangle

element\_add\_pin\_oval

element\_add\_mark

element\_add\_lines

 ${\tt element\_add\_rectangle}$ 

element\_set\_text\_xy

element\_set

 ${\tt element\_get}$ 

element\_dump

#### References

Change Log


Element Flags

Text Flags

Pin Flags

Pad Flags

Examples



# References

Brorson, S. D., & Meier, S. (2005, January). Footprint creation for the open-source layout program PCB. (Retrieved February 6, 2005, from http://www.brorson.com/gEDA/land\_patterns\_20050129.pdf)

Eaton, H., & Nau, T. (2002). Pcb [Computer software and manual]. (Retrieved February 7, 2007 from http://pcb.sourceforge.net/pcb-cvs/pcb.html)

Pcb\_9

new

 ${\tt element\_begin}$ 

element\_output

element\_add\_line

element\_add\_arc

element\_add\_pin

element\_add\_pad

element\_add\_pad\_rectangle

element\_add\_pin\_oval

element\_add\_mark

element\_add\_lines

element\_add\_rectangle

element\_set\_text\_xy

element\_set

element\_get

element\_dump

References

#### Change Log


Element Flags

Text Flags

Pin Flags

Pad Flags

Examples



# 19 Change Log

Pcb_9	???	jcl	<ol> <li>Fixed a dimension scaling bug in element_add_lines. The scaling routine now scales an array of points. This bug was reported by Ben Jackson.</li> <li>The scaling routines now accept a dimension suffix which will</li> </ol>
Pcb_8	19-Mar-2007	jcl	override the default dimension.  1. Removed the export of element_add_arc. Not necessary (OO).  2. Corrected the mask and clearance parameters in the pin, pad and pin_oval procedures.  3. Removed the Mark command since the mark data is now in the Element header.  4. Exported element_str and added a scale_factor parameter (default value of 100)  5. the key to specify dimensional units (input_dim) was changed
			to dim 6. Fixed the dimension scaling problem in add_element_lines 7. Corrected the documentation for element_add_pin_oval
Pcb_7	25 March 2005	jcl	<ol> <li>changed the definition of the mask and clearance.</li> <li>Fixed the mask and clearance parameters in the pin, pad and</li> </ol>
Pcb_6	22 March 2005	jcl	pin_oval procedures.  1. The element_add_rectangle command now uses the x and y parameters. The center of the rectangle was always placed at (0,0)  2. The pin_one_square key-value pair was not getting properly tested in the element_add_pin procedure.
Pcb_5	6 March 2005	jcl	3. Added the clearance and the mask parameters to element_add_pad_rectangle.  1. Added the element_add_lines command.  2. added the element_add_pin_oval command.  3. Modified the debug print messages.  4. Fixed constant for octagonal pads.  5. Fixed errors in the EXPORT_OK and EXPORT_TAGS decla-
Pcb_4	27 February 2005	jcl	rations. 6. Added element_get_names. 1. Modified the debug strings to output mm and mils. 2. Fixed the scale_factor subroutine. scale_factor did not correctly convert from mils to mm. I did not test (or use) the
Pcb_3	7 February 2005	jcl	conversion to mm until I modified the debug strings Initial Release

Pcb\_9

....

element\_begin
element\_output

•

 ${\tt element\_add\_line}$ 

 ${\tt element\_add\_arc}$ 

element\_add\_pin

 ${\tt element\_add\_pad}$ 

element\_add\_pad\_rectangle

 ${\tt element\_add\_pin\_oval}$ 

element\_add\_mark

element\_add\_lines

element\_add\_rectangle

element\_set\_text\_xy

element\_set

 ${\tt element\_get}$ 

 ${\tt element\_dump}$ 

References

Change Log

#### Element Flags

Text Flags

Pin Flags

Pad Flags

Examples



# 20 Element Flags

The element flag field determines the state of an element. The bit values are:

Parameter Name	Default Value	Notes
ELEMENT_NAME_HIDDEN	0x10	bit 4: the element name is hidden
ELEMENT_SELECTED	0x40	bit 6: element has been selected
ELEMENT_SOLDER_SIDE	0x80	bit 7: element is located on the solder side

Table 13: Element Flags

Pcb\_9

IIew

element\_begin

element\_output

element\_add\_line

element\_add\_arc

element\_add\_pin

 ${\tt element\_add\_pad}$ 

element\_add\_pad\_rectangle

 ${\tt element\_add\_pin\_oval}$ 

element\_add\_mark

element\_add\_lines

element\_add\_rectangle

element\_set\_text\_xy

element\_set

element\_get

\_\_\_

element\_dump

References

Change Log

Element Flags

#### Text Flags

Pin Flags

Pad Flags

Examples



# 21 Text Flags

Parameter Name	Default Value	Notes
TEXT_DIRECTION_O	0	Horizontal
TEXT_DIRECTION_90	1	90 degrees counter-clockwise
TEXT_DIRECTION_180	2	180 degrees counter-clockwise
TEXT_DIRECTION_270	3	270 degrees counter-clockwise

Table 14: Text Direction Flags

Parameter Name	Default Value	Notes
TEXT_SELECTED	0x40	bit 6: the text has been selected
TEXT_ON_SOLDER_SIDE	08x0	bit 7: the text is on the solder (back) side of the board
TEXT_ON_SILKSCREEN	0x400	bit 10: the text is on the silkscreen layer

Table 15: Text Flags

Pcb\_9

пем

 ${\tt element\_begin}$ 

 ${\tt element\_output}$ 

element\_add\_line

element\_add\_arc

element\_add\_pin

 $element\_add\_pad$ 

element\_add\_pad\_rectangle

 ${\tt element\_add\_pin\_oval}$ 

element\_add\_mark

element\_add\_lines

element\_add\_rectangle

element\_set\_text\_xy

element\_set

element\_get

get

 ${\tt element\_dump}$ 

References

Change Log


Element Flags

Text Flags

#### Pin Flags

Pad Flags





# 22 Pin Flags

Parameter Name	Default Value	Notes
PIN_ALWAYS_SET	0x0001	bit 0: always set
		bit 1: always clear
PIN_CONNECTED	0x0004	bit 2: set if pin was found during a connection search
PIN_MOUNTING_HOLE	0x0008	bit 3: set if pin is only a mounting hole (no copper annulus)
PIN_DISPLAY_NAME	0x0020	bit 5: display the pins name
PIN_SELECTED	0x0040	bit 6: pin has been selected
PIN_SQUARE	0x0100	bit 8: pin is drawn as a square
PIN_OCTAGONAL	0080x0	bit 12: set if pin is drawn with an octagonal shape
PIN_ROUND	0x0000	
PIN_SHAPE_MASK	OxEEFF	

Table 16: Pin Flags

Pcb\_9

element\_begin

element\_output

•

element\_add\_line

 ${\tt element\_add\_arc}$ 

 ${\tt element\_add\_pin}$ 

 ${\tt element\_add\_pad}$ 

element\_add\_pad\_rectangle

 ${\tt element\_add\_pin\_oval}$ 

element\_add\_mark

element\_add\_lines

element\_add\_rectangle

element\_set\_text\_xy

element\_set

element\_get

 ${\tt element\_dump}$ 

References

Change Log

Element Flags

Text Flags

Pin Flags

Pad Flags

Examples



# 23 Pad Flags

Parameter Name	Default Value	Notes
PAD_CONNECTED	0x0004	bit 2: set if pad was found during a connection search
PAD_DISPLAY_NAME	0x0020	bit 5: display the pads name
PAD_SELECTED	0x0040	bit 6: pad has been selected
PAD_SOLDER_SIDE	0x0080	bit 7: pad is located on the solder side
PAD_SQUARE	0x0100	
PAD_ROUNDED	0x080x0	bit 11: pad has rounded corners

Table 17: Pad Flags

```
Pcb_9
element_begin
element_output
element_add_line
element_add_arc
element_add_pin
element_add_pad
element_add_pad_rectangle
element_add_pin_oval
element_add_mark
element_add_lines
element_add_rectangle
element_set_text_xy
element_set
element_get
element_dump
```

Change Log Element Flags

Text Flags

References

Pin Flags

Pad Flags

Examples



Listing 2: TO220 Pads

```
#!/usr/bin/perl
   # Copyright (C) 2007 John C. Luciani Jr.
   # This program may be distributed or modified under the terms of
  # version 0.2 of the No-Fee Software License published by
  # John C. Luciani Jr.
   # Places three rounded pads with holes spaced 100 mils.
10
11
   use strict;
12
   use warnings;
13
14
   use Pcb_8;
15
   my Pcb = Pcb_8 \rightarrow new(debug => 1);
17
18
   $Pcb -> element_begin(description => 'TO220-pads',
19
                           output_file =>
                              "tmp/" . 'T0220-pads',
20
                           dim => 'mils');
21
22
   my pin_num = 1;
   my @pos = (-100, 0, 0, 0, 100, 0);
25
   while (@pos) {
26
       my (\$x, \$y) = \text{splice @pos}, 0, 2;
27
28
        $Pcb -> element_add_pin_oval(x => $x,
                                      y => $y,
29
                                       width => 80,
30
31
                                      length => 66,
32
                                      name => '',
                                       pin_number => $pin_num++,
33
34
                                      clearance => 10,
                                      drill_hole => 46,
35
                                      mask => 10);
36
37
38
39
   $Pcb -> element_output();
```

#### Listing 3: SMD Element Creation Example

```
Contents
Pcb 9
element_begin
element_output
element_add_line
element_add_arc
element_add_pin
element_add_pad
element_add_pad_rectangle
element_add_pin_oval
element_add_mark
element_add_lines
element_add_rectangle
element_set_text_xy
element_set
element_get
element_dump
References
Change Log
```

Change Log
Element Flags

Text Flags

Pin Flags

Pad Flags

Examples



62

```
1 #!/usr/bin/perl
   # Copyright (C) 2005 John C. Luciani Jr.
   # This program may be distributed or modified under the terms of
   # version 0.2 of the No-Fee Software License published by
   # John C. Luciani Jr.
   # Creates the PCB elements specified in the DATA section. The
   # footprints are for the SMD packages 0402, 0603, 0805, 1206, 1210,
   # 2010, 2512, 0402, 0504, 0603, 0805, 1206, 1210, 1812, 1825
12
13
   use strict:
   use warnings;
14
15
   use Pcb_9;
16
   my Pcb = Pcb_9 \rightarrow new(debug => 1);
19
   my @Fields = qw(land_pattern_length land_row_distance
20
21
                    land width
                                          land_length
22
                    land_row_centers
                                          grid);
23
   while (<DATA>) {
24
25
       s/\#.*//; # Remove comments
       s/^\s*//; # Remove leading spaces
26
27
       s/\s*$//; # Revove trailing spaces
       next unless length; # Skip empty lines
28
29
       my (\$type, @values) = split /\s*\\s*/;
30
       # hash for each footprint
31
32
33
       my %f = map { $_ => shift(@values) } @Fields;
34
       $Pcb -> element_begin(description => 'SMD',
35
                              output_file => "tmp/$type",
36
                              dim => 'mm');
37
38
       my $x = -$f{land_row_centers} / 2;
39
       foreach my $pin_num (1..2) {
40
41
            $Pcb -> element_add_pad_rectangle(width => $f{land_width},
42
                                               length=> $f{land_length},
43
                                               x => x
                                               y => 0,
44
                                               name => 'input',
45
46
                                               mask => 0.254,
47
                                               clearance => 0.254,
48
                                               pin_number => $pin_num);
            $x += $f{land_row_centers};
49
50
51
       # Draw a silkscreen rectangle around the component. A silkscreen
52
       # specification that all PCB vendors should be able to meet is
53
       # 10mil line width and 10mil spacing. The silkscreen line width
54
       # defaults to 10mils. To achieve the proper spacing we add
55
       # 30 mils (0.762 mm) to the maximum extents of the copper pads
56
57
       # (10 mils on either side of the copper and 2*5 mils for the
       # silkscreen line).
58
59
60
       my $length = $f{land_pattern_length} + 0.762;
61
       my width = f{land\_width} + 0.762;
```

```
Contents
```

Pcb\_9

element\_begin

element\_output

element\_add\_line

element\_add\_arc

element\_add\_pin

element\_add\_pad

\_

element\_add\_pad\_rectangle

element\_add\_pin\_oval

 ${\tt element\_add\_mark}$ 

 ${\tt element\_add\_lines}$ 

element\_add\_rectangle

element\_set\_text\_xy

 ${\tt element\_set}$ 

 ${\tt element\_get}$ 

ger

element\_dump

References

Change Log

Element Flags

Text Flags

Pin Flags

Pad Flags



```
63
        $Pcb -> element_add_rectangle(width => $width,
64
                                        length => $length,
65
                                        x = > 0,
66
                                        v => 0);
67
        # Place the refdes slightly (0.5mm) above the upper left corner of
68
        # the outline rectangle.
70
71
        $Pcb -> element_set_text_xy(x => -$length/2,
72
                                      y =  -\$width/2 - 0.5);
73
74
        $Pcb -> element_output();
75
76
77
78
    __DATA__
79
80
   # type
             package name
82
   #
              overall length of land pattern
   #
       G
              distance between land rows
83
    # X
84
              land width
85
    #
      Y
              land length
86
    #
       C
              center-to-center spacing between land rows
       Grid number of 0.5mm by 0.5mm elements
87
                         G
                                  Χ
                                                      C
                                                             Grid
    # type
                Z
90
     0402
               2.20
                                  0.70
                                           0.90
91
                        0.40
                                                     1.30
                                                             2x6
92
     0504
               2.40
                        0.40
                                  1.30
                                           1.00
                                                     1.40
                                                             4x6
93
     0603
              2.80
                        0.60
                                  1.00
                                           1.10
                                                     1.70
                                                             4x6
     0805
              3.20
                        0.60
                                           1.30
                                                     1.90
                                                            4x8
94
                                  1.50
              4.40
                        1.20
95
     1206
                                  1.80
                                           1.60
                                                     2.80
                                                            4x10
     1210
              4.40
                        1.20
                                  2.70
                                           1.60
                                                     2.80
                                                            6x10
97
     1812
               5.80
                        2.00
                                  3.40
                                           1.90
                                                     3.90
                                                            8x12
98
     1825
              5.80
                        2.00
                                  6.80
                                           1.90
                                                     3.90
                                                            14x12
99
     2010
              6.20
                        2.60
                                  2.70
                                           1.80
                                                     4.40
                                                            6x14
     2512
              7.40
                        3.80
100
                                  3.20
                                           1.80
                                                     5.60
                                                            8x16
```

Pcb\_9

 ${\tt element\_begin}$ 

 ${\tt element\_output}$ 

element\_add\_line

element\_add\_arc

element\_add\_pin

element\_add\_pad

element\_add\_pad\_rectangle

element\_add\_pin\_oval

element\_add\_mark

element\_add\_lines

element\_add\_rectangle

element\_set\_text\_xy

 $element\_set$ 

element\_get

get

element\_dump

References

Change Log

Element Flags

Text Flags

Pin Flags

Pad Flags



```
1 #!/usr/bin/perl
   # Copyright (C) 2005 John C. Luciani Jr.
   # This program may be distributed or modified under the terms of
   # version 0.2 of the No-Fee Software License published by
   # John C. Luciani Jr.
   # Creates the PCB elements for Molex 8624 header connectors
10
   use strict:
11
   use warnings;
12
13
   use Pcb 8:
14
15
   my Pcb = Pcb_8 \rightarrow new(debug \Rightarrow 1);
17
   my @Fields = qw(circuits body_length pin_row_length);
18
19
   my @Def; # definitions that are common to all components
20
21
   while (<DATA>) {
22
       s/\#.*//; # Remove comments
23
24
       s/^s*//; # Remove leading spaces
25
       s/\s*$//; # Revove trailing spaces
       next unless length; # Skip empty lines
26
27
       # Lines that contain an '=' are global definitions.
28
29
       push(@Def, $1, $2), next if /(\S+)\s*=\s*(\S.*)/;
30
31
       my @values = split /\s*\\s*/;
32
33
       # hash for each footprint
34
35
36
       mv \%f = (ODef,
                  map { $_ => shift(@values) } @Fields);
37
38
       $Pcb -> element_begin(description => 'TH',
39
40
                               output_file =>
41
                                  "tmp/" . &package_name($f{circuits}, $f{pin_rows}),
                               dim => 'mils',
42
43
                               pin_one_square => 1);
44
       my $pin_num = 1;
45
       my $pins_per_row = $f{circuits} / 2;
46
47
48
       # lower left corner is pin one
49
50
       my x = -f\{pin\_spacing\} * (pins\_per\_row - 1) / 2;
       my \$y = \$f\{row\_spacing\} / 2;
51
52
53
       # These header connectors consist of two rows of pins. With pin
54
       # one in the lower left corner we will place pins from left to
       # right until half the pins are placed. At the halfway point we
55
56
       # will shift to the top row and place pins from right to left.
57
       while ($pin num <= $f{circuits}) {
58
            $Pcb -> element_add_pin(x => $x, y => $y,
59
60
                                     thickness => 66,
                                     drill_hole => 46,
61
                                                 => 10,
62
                                     mask
```

```
Contents
```

Pcb\_9

element\_begin

element\_output

 ${\tt element\_add\_line}$ 

 ${\tt element\_add\_arc}$ 

element\_add\_pin

element\_add\_pad

element\_add\_pad\_rectangle

element\_add\_pin\_oval

element\_add\_mark

element\_add\_lines

element\_add\_rectangle

element\_set\_text\_xy

element\_set

element\_get

get

element\_dump

References

Change Log

Element Flags

\_ \_.

Text Flags

Pin Flags

Pad Flags



```
63
                                        clearance => 10,
64
                                       pin_number => $pin_num);
65
66
             # If this is the last pin in the row then
             # update the y value otherwise update the x
67
68
             # value. If we are past the halfway point move
69
             # left (-) instead of right (+).
70
71
             x += f\{pin\_spacing\} if y > 0;
72
73
             $pin_num++;
74
75
76
         $Pcb -> element_add_rectangle(width => $f{body_width},
77
                                         length=> $f{body_length},
                                         x => 0,
78
79
                                         y => 0);
80
81
         $Pcb -> element_set_text_xy(x => -$f{body_length}/2,
82
83
                                       y = - f\{body_width\}/2 - 20\};
84
85
86
         $Pcb -> element_output();
    }
87
88
89
    sub package_name ($$) {
         my ($circuits, $rows) = @_;
90
         sprintf("CON_HDR-254P-%iC-%iR-%iN__Molex_8624-Series",
91
92
                 $circuits/$rows,
93
                 $rows,
94
                 $circuits);
95
97
    __DATA__
98
    body_width = 200
99
100
    pin_spacing = 100
    row_spacing = 100
    pin_diameter = 35
103
    pin_rows = 2
104
105
    # circuits
                  body_length pin_row_length
106
107
    4
          190
                100
108
    6
          290
                200
    8
          390
109
                300
110
    10
          490
                400
111
    12
          590
                500
112
    14
          690
                600
          790
                700
113
    16
114
    18
          890
                800
    20
          990
                900
115
116
    22
          1090
                 1000
                1100
117
    24
          1190
    26
          1290
                1200
118
          1390
119
    28
               1300
120
                 1400
    30
          1490
121
    32
          1590
                 1500
122
123
    34
          1690
                 1600
124
          1790
                 1700
125
    38
          1890
                 1800
```

Pcb\_9

element\_begin

element\_output

element\_add\_line

element\_add\_arc

element\_add\_pin

element\_add\_pad

 ${\tt element\_add\_pad\_rectangle}$ 

 ${\tt element\_add\_pin\_oval}$ 

 ${\tt element\_add\_mark}$ 

element\_add\_lines

 ${\tt element\_add\_rectangle}$ 

element\_set\_text\_xy

 ${\tt element\_set}$ 

 ${\tt element\_get}$ 

element\_dump

get

References

Change Log

Element Flags

Text Flags

Pin Flags

Pad Flags



126 40 127 42 128 44 129 46 130 48 131 50 132 52 133 54 134 135 56 136 58 137 60 138 62 139 64 140 66 141 68 142 70 143 72 144 74 145 76			
127         42           128         44           129         46           130         48           131         50           132         52           133         54           135         56           136         58           137         60           138         62           139         64           140         66           141         68           142         70           143         72           144         74           145         76	26 40	1990	1900
128         44           129         46           130         48           131         50           132         52           133         54           134		2090	2000
129         46           130         48           131         50           132         52           133         54           134         135           136         58           137         60           138         62           139         64           141         68           141         68           142         70           143         72           144         74           145         76		2190	2100
130         48           131         50           132         52           133         54           134         56           135         56           136         58           137         60           138         62           139         64           141         68           141         68           142         70           143         72           144         74           145         76			
131         50           132         52           133         54           134         135         56           136         58         137         60           138         62         139         64           140         66         141         68           142         70         143         72           144         74         145         76		2290	2200
132         52           133         54           134         56           136         58           137         60           138         62           139         64           141         66           141         68           142         70           143         72           144         74           145         76		2390	2300
133         54           134         56           136         58           137         60           138         62           139         64           140         66           141         68           142         70           143         72           144         74           145         76	31 50	2490	2400
133 54 134 56 136 58 137 60 138 62 139 64 140 66 141 68 142 70 143 72 144 74 145 76	32 52	2590	2500
134 135 56 136 58 137 60 138 62 139 64 140 66 141 68 142 70 143 72 144 74 145 76		2690	2600
135         56           136         58           137         60           138         62           139         64           140         66           141         68           142         70           143         72           144         74           145         76			
136 58 137 60 138 62 139 64 140 66 141 68 142 70 143 72 144 74 145 76		2790	2700
137     60       138     62       139     64       140     66       141     68       142     70       143     72       144     74       145     76			
138 62 139 64 140 66 141 68 142 70 143 72 144 74 145 76		2890	2800
139 64 140 66 141 68 142 70 143 72 144 74 145 76	37 60	2990	2900
140 66 141 68 142 70 143 72 144 74 145 76	38 62	3090	3000
140 66 141 68 142 70 143 72 144 74 145 76	39 64	3190	3100
141 68 142 70 143 72 144 74 145 76		3290	3200
142 70 143 72 144 74 145 76		3390	3300
143 72 144 74 145 76			
144 74 145 76		3490	3400
145 76		3590	3500
	44 74	3690	3600
146 78	45 76	3790	3700
	46 78	3890	3800
147 80		3990	3900
141 00			

```
Contents
Pcb 9
element_begin
element_output
element_add_line
element_add_arc
element_add_pin
element_add_pad
element_add_pad_rectangle
element_add_pin_oval
element_add_mark
element_add_lines
element_add_rectangle
element_set_text_xy
element_set
element_get
```

element\_dump
References

get

Change Log

Element Flags

Text Flags

Pin Flags

Pad Flags



```
1 #!/usr/bin/perl
   # Copyright (C) 2005 John C. Luciani Jr.
   # This program may be distributed or modified under the terms of
  # version 0.2 of the No-Fee Software License published by
   # John C. Luciani Jr.
   # Creates the PCB elements for Molex 8624 header connectors
10
   use strict:
11
   use warnings;
12
13
   use Pcb 8:
14
15
   my Pcb = Pcb_8 \rightarrow new(debug => 0);
17
   my @Fields = qw(circuits body_length pin_row_length);
18
19
   my @Def; # definitions that are common to all components
20
21
   while (<DATA>) {
22
       s/\#.*//; # Remove comments
23
24
       s/^s*//; # Remove leading spaces
25
       s/\s*$//; # Revove trailing spaces
       next unless length; # Skip empty lines
26
27
       # Lines that contain an '=' are global definitions.
28
29
       push(@Def, $1, $2), next if /(\S+)\s*=\s*(\S.*)/;
30
31
       my @values = split /\s*\\s*/;
32
33
       # hash for each footprint
34
35
       my %f = ( ODef,
36
                  map { $_ => shift(@values) } @Fields);
37
38
       $Pcb -> element_begin(description => 'TH',
39
40
                               output_file =>
                                 "tmp/" . &package_name($f{circuits}, $f{pin_rows}),
41
42
                              dim => 'mils',
43
                              pin_one_square => 1);
44
       my $pin_num = 1;
45
       my $pins_per_row = $f{circuits} / 2;
46
47
       # lower left corner is pin one
48
49
50
       my x0 = -f\{pin\_spacing\} * (pins\_per\_row - 1) / 2;
       my $y0 = $f\{row\_spacing\} / 2;
51
52
53
       my x = x0;
       my \$y = \$y0;
54
55
56
       # These header connectors consist of two rows of pins. With pin
57
       # one in the lower left corner we will place pins from left to
       # right until half the pins are placed. At the halfway point we
58
       # will shift to the top row and place pins from right to left.
59
60
61
       while ($pin_num <= $f{circuits}) {</pre>
            $Pcb -> element_add_pin(x => $x, y => $y,
62
```

```
Contents
```

Pcb\_9

element\_begin

element\_output

element\_add\_line

erement\_add\_rine

 ${\tt element\_add\_arc}$ 

 ${\tt element\_add\_pin}$ 

element\_add\_pad

element\_add\_pad\_rectangle

 ${\tt element\_add\_pin\_oval}$ 

element\_add\_mark

element\_add\_lines

element\_add\_rectangle

element\_set\_text\_xy

element\_set

element\_get

get

element dump

References

Change Log

Element Flags

Element riags

Text Flags

Pin Flags

Pad Flags



```
63
                                      thickness => $f{pad_thickness},
                                      drill hole => $f{drill hole}.
64
                                      mask
                                                 => 10.
65
66
                                      clearance => 10,
                                      pin_number => $pin_num);
67
68
69
             # Header connectors usually have pins numbered from left to
             # right with odd numbers on the bottom and even numbers on the
70
             # top. Since this example program could be used for connectors
71
             # other than headers three pin-numbering options are provided.
72
73
             # header - two rows of pins. numbers increase from left to right.
74
75
                        odd numbered pins on the bottom, even on the top.
76
77
                      - two rows of pins. starting in the lower left corner
                        numbers increase left to right along the bottom row
78
79
                        and right to left along the top row.
80
81
             # power - two rows of pins. numbers increase from left to right
                        starting on the bottom row and then continue left to right
82
                        along the top row.
83
84
85
            if ($f{pin_numbering_scheme} eq 'header') {
                 y = -1;
86
                 x += f{pin\_spacing} if y > 0;
87
            } elsif ($f{pin_numbering_scheme} eq 'dip') {
88
89
                 if ($pin_num == $pins_per_row) {
                     $y -= $f{row_spacing};
90
91
                 } else {
                     $x += $pin_num > $pins_per_row
92
93
                         ? -$f{pin_spacing}
                         : $f{pin_spacing};
94
95
            } elsif ($f{pin_numbering_scheme} eq 'power') {
97
                 if ($pin_num == $pins_per_row) {
                     $y -= $f{row_spacing};
98
                     x = x0;
99
100
                 } else {
                     $x += $f{pin_spacing}
101
102
103
            } else {
104
                 die "unknown pin numbering scheme $f{pin_numbering_scheme} ";
105
106
             $pin_num++;
107
108
        $Pcb -> element_add_rectangle(width => $f{body_width},
109
110
                                        length=> $f{body_length},
111
                                        x => 0,
                                        v => 0);
112
113
114
        $Pcb -> element_set_text_xy(x => -$f{body_length}/2,
115
116
                                      y = - f\{body_width\}/2 - 20\};
117
118
        $Pcb -> element_output();
119
120
121
    sub package_name ($$) {
122
123
        my ($circuits, $rows) = @_;
124
        sprintf("CON_HDR-254P-%iC-%iR-%iN__Molex_8624-Series",
125
                 $circuits/$rows,
```

Pcb\_9

element\_begin

element\_output

element\_add\_line

element\_add\_arc

erement\_add\_arc

element\_add\_pin

 ${\tt element\_add\_pad}$ 

element\_add\_pad\_rectangle

 ${\tt element\_add\_pin\_oval}$ 

element\_add\_mark

element\_add\_lines

 ${\tt element\_add\_rectangle}$ 

element\_set\_text\_xy

 ${\tt element\_set}$ 

 ${\tt element\_get}$ 

\_\_\_

 ${\tt element\_dump}$ 

References

Change Log

Element Flags

Text Flags

Pin Flags

Pad Flags



```
126
                   $rows,
127
                   $circuits);
128
129
    __DATA__
130
131
132
    pad_thickness = 66
133
    drill_hole = 46
    pin_numbering_scheme = header
134
    body_width = 200
135
    pin_spacing = 100
136
    row_spacing = 100
137
     pin_diameter = 35
138
139
    pin_rows = 2
140
141
    # circuits
                    body_length
                                    pin_row_length
142
143
    4
          190
                 100
    6
          290
                 200
144
145
    8
          390
                 300
    10
146
          490
                 400
147
    12
          590
                 500
148
    14
          690
                 600
149
    16
          790
                 700
          890
                 800
150
    18
     20
          990
                 900
151
     22
152
          1090
                  1000
     24
                 1100
153
          1190
154
     26
          1290
                 1200
155
    28
          1390
                 1300
156
    30
          1490
                  1400
157
    32
          1590
                   1500
158
    34
          1690
                   1600
159
160
     36
          1790
                   1700
161
     38
          1890
                   1800
162
    40
          1990
                   1900
     42
          2090
                  2000
163
164
     44
          2190
                  2100
                  2200
     46
          2290
165
                  2300
     48
          2390
166
167
     50
          2490
                   2400
168
     52
          2590
                   2500
     54
          2690
                   2600
169
170
          2790
                  2700
171
    56
    58
          2890
                  2800
172
     60
          2990
                  2900
173
174
     62
          3090
                   3000
     64
          3190
                  3100
175
176
    66
          3290
                  3200
     68
          3390
                   3300
177
     70
          3490
                  3400
178
     72
179
          3590
                  3500
     74
          3690
                  3600
180
    76
          3790
                  3700
181
    78
          3890
                   3800
182
          3990
183
    80
                   3900
```

#### Listing 6: TQFN Element Creation Example

```
Contents
Pcb 9
element_begin
element_output
element_add_line
element_add_arc
element_add_pin
element_add_pad
element_add_pad_rectangle
element_add_pin_oval
element_add_mark
element_add_lines
element_add_rectangle
element_set_text_xy
element_set
element_get
element dump
References
Change Log
```

Change Log
Element Flags

Text Flags

Pin Flags

Pad Flags



```
#!/usr/bin/perl
   # Copyright (C) 2005 John C. Luciani Jr.
   # This program may be distributed or modified under the terms of
   # version 0.2 of the No-Fee Software License published by
   # John C. Luciani Jr.
   # Creates Maxim TQFN style packages.
10
   # Data is from the Maxim 21-0140 Rev G and Maxim 21-10159 Rev A
11
12
   # specifications.
13
  # The TQFN (thin quad flat no-lead) packages have solder terminations
14
   # on four sides and a thermal pad in the center. The two denser
   # packages (T3255-2 and T4055-1) require smaller pads on the corner
  # terminations.
18
19
   use strict;
   use warnings;
20
21
   use Carp;
22
   use Pcb_8; # routines to create PCB elements (packages)
23
24
25
   mv \ Pcb = Pcb_8 \rightarrow new(debug => 0);
26
  # The specifications to generate these symbols is in the __DATA__
27
  # section of this file. Each line can be either blank, contain a global
   # definition or contain a package data record.
29
30
31
   # Global definitions are saved in @Def.
32
   # The field names for the package data record are in @Fields.
33
   my @Def; # Global definitions saved as key-value pairs.
34
   my @Fields = qw(package_code
35
36
                    pin_count
37
                    pad_spacing
                    pad_width
38
                    pad_length
39
40
                    corner_pad_length
                    thermal_pad_width
41
                    thermal_pad_length);
42
43
44
   # Read the __DATA__ section and output a PCB footprint everytime a
   # package data record is read.
45
46
   while (<DATA>) {
47
       last if /^__END__$/;
48
       s/\#.*//; # Remove comments
49
50
       s/^\s*//; # Remove leading spaces
       s/\s*$//; # Revove trailing spaces
51
52
       next unless length; # Skip empty lines
53
54
       # Lines that contain an '=' are global definitions. The key (lhs)
       # and value (rhs) are pushed onto @Def.
55
56
57
       push (@Def, $1, $2), next if /(\S+)\s*=\S*(\S.*)/;
58
       # A line with non-zero length that is not a global definition is a
59
60
       # package data record. We split the package record and create a
       # hash %p that contains key-value pairs for all of the global
61
62
       # definitions and the current record.
```

Pcb\_9

element\_begin

element\_output

element\_add\_line

element\_add\_arc

 ${\tt element\_add\_pin}$ 

element\_add\_pad

 ${\tt element\_add\_pad\_rectangle}$ 

63

64

65

66 67

68

69 70

71

72

73

74

75 76

77

78

79

80 81

82

83

84

85

86

87

88

89

90

91 92

93

94

95

96

97

98

99

100

101

102

 $103\\104$ 

 $105 \\ 106$ 

 $107\\108$ 

109

110 111

112 113

114 115 116

117

118

119

120

121

122

 $\frac{123}{124}$ 

125

element\_add\_pin\_oval

element\_add\_mark

element\_add\_lines

element\_add\_rectangle

element\_set\_text\_xy

element\_set

element\_get

~~+

element\_dump

References

Change Log

Element Flags

Text Flags

Pin Flags

Pad Flags



```
mv @values = split /\s*\\s*/:
my \%p = (@Def,
          map { $_ => shift(@values) } @Fields);
# Create a simple id using the package name, package code and pin
# count and then start a new element.
$p{id} = join('-', map { $p{$_}} } qw(package_name package_code pin_count));
$Pcb -> element_begin(description => $p{id},
                      output_file => "tmp/$p{id}",
                      dim => 'mm'):
print "$p{id}\n";
# Create a few convenient specifications from data in the package
# data record hash. The convenetions for these packages is part
# centroid at (0,0) and pin one is in the lower left corner.
# Corner pads on some of the parts are shorter. This condition is
# handled by creating a new pad length and some pad center
# offsets.
$p{num_pads_per_side} = $p{pin_count} / 4; # leads on four sides
$p{corner_pad_length} = $p{pad_length} if $p{corner_pad_length} eq '';
my $row_center = ($p{body_width_max} - $p{pad_length}) / 2;
my $row_end = ($p{num_pads_per_side} - 1) * $p{pad_spacing} / 2;
my $corner_offset = ($p{pad_length} - $p{corner_pad_length}) / 2;
# @xy contains the staring locations for a row of pads.
# Cinc contains increment values for x and y and offsets for the
# the corner pads. for each row of pads either x or y is incremented.
mv @xv = (x \Rightarrow -\$row center, v \Rightarrow -\$row end.
          x => -$row_end, y => $row_center,
         x => $row_center, y => $row_end,
         x \Rightarrow $row end.
                           v => -$row center):
my @inc= (yinc => $p{pad_spacing}, xoffset => -$corner_offset,
          xinc => $p{pad_spacing}, yoffset => $corner_offset,
          yinc => -$p{pad_spacing}, xoffset => $corner_offset,
         xinc => -$p{pad_spacing}, yoffset => -$corner_offset);
# create the rows of pads
&set_pin_num(1);
while (@xy) {
    mv \%xv = (splice(@inc, 0, 4),
              map { $_ => $p{$_}} } qw(pad_spacing pad_width pad_length));
   &draw_row_of_pads(splice(@xy, 0, 4),
                      pad_length => $p{corner_pad_length},
                      num_pads => 1);
    # no offsets for pads that aren't on the corners
   &draw_row_of_pads(%xy,
                      xoffset => 0,
                      yoffset => 0.
                      num_pads => $p{num_pads_per_side} - 2);
```

```
Contents
```

Pcb\_9

element\_begin

element\_output

element\_add\_line

element\_add\_arc

element\_add\_pin

element\_add\_pad

element\_add\_pad\_rectangle

element\_add\_pin\_oval

element\_add\_mark

element\_add\_lines

element\_add\_rectangle

element\_set\_text\_xy

element\_set

element\_get

element\_dump

References

Change Log

Element Flags

Text Flags

Pin Flags

Pad Flags



```
126
             &draw_row_of_pads(%xv,
127
                                 pad_length => $p{corner_pad_length},
                                num_pads => 1);
128
129
130
         # Add the thermal pad
131
132
133
         $Pcb -> element_add_pad_rectangle(x => 0,
134
                                             length => $p{thermal_pad_length},
135
                                             width => $p{thermal_pad_width},
136
                                             name => '',
137
138
                                             pin_number => $p{pin_count} + 1);
139
140
         # add the pin one dot
141
142
         my dot_pos = row_center + 0.254; \#p\{pad_length\} / 2;
143
144
         $Pcb -> element_add_arc(x => -$dot_pos,
                                   y = > -\$dot_pos,
145
                                   width => $p{pad_width} / 2,
146
                                   height=> $p{pad_width} / 2,
147
148
                                   start_angle => 0,
149
                                   delta_angle => 360,
                                   thickness => 0.254); # 10 mil lines
150
151
152
         # draw a silksreen rectangle around the package body.
153
154
         $Pcb -> element_add_rectangle(x => 0,
                                         y => 0.
155
156
                                         width => $p{body_width_max} + 1,
157
                                         length=> $p{body_length_max} + 1);
158
         # Set the position of the reference designator to the upper left corner
159
160
161
         $Pcb -> element_set_text_xy(x => -$p{body_length_max} / 2 - 1,
162
                                       y => -$p{body_width_max} / 2 - 1);
163
         # Set the centroid mark and output the element
164
165
         $Pcb -> element_output;
166
167
168
169
    \# v\{x\}
                   current x location
170
                   current y location
    # $v{pin_num} current pin number
173
174
    my %v; # values for draw_row_of_pads
175
    sub set_pin_num ($) {
176
177
         $v{pin_num} = shift;
    }
178
179
180
    sub draw_row_of_pads {
181
         my %p = (xoffset => 0,
                  yoffset => 0,
182
183
                  @_);
184
         foreach (qw(pin_num x y)) {
185
186
             v\{_\} = p\{_\} \text{ if defined } p\{_\};
187
188
```

```
Contents
```

Pcb\_9

element\_begin

element\_output

•

 $element\_add\_line$ 

element\_add\_arc

element\_add\_pin

element\_add\_pad

element\_add\_pad\_rectangle

 ${\tt element\_add\_pin\_oval}$ 

element\_add\_mark

element\_add\_lines

element\_add\_rectangle

element\_set\_text\_xy

element\_set

element\_get

get

element\_dump

References

Change Log

Element Flags

Text Flags

Pin Flags

Pad Flags



```
189
        # swap pad length and width for horizontal rows
190
         ($p{pad_width}, $p{pad_length}) = ($p{pad_length}, $p{pad_width})
191
192
             if defined $p{xinc};
193
        foreach (1..$p{num_pads}) {
194
195
             $Pcb -> element_add_pad_rectangle(x
                                                         \Rightarrow $v{x} + $p{xoffset},
196
                                                         => $v{y} + $p{yoffset},
                                                  width => $p{pad_width},
197
                                                 length => $p{pad_length},
198
                                                  name => ',
199
                                                  pin_number => $v{pin_num}++);
200
             $v{x} += $p{xinc} if defined $p{xinc};
201
202
             $v{y} += $p{yinc} if defined $p{yinc};
203
204
205
206
207
208
209
    1;
210
211
212
213
    __DATA__
    body_width_min = 4.9
214
    body_width
                     = 5.0
    body_width_max = 5.1
216
217
    body_length_min = 4.9
    body_length
                     = 5.0 \# D
218
    body_length_max = 5.1 # D
219
220
221
    component_type
                         = ic
                         = TQFN-Maxim-5x5
222
    package_name
223
224
    \# Final pad_length = pad_lenth + body_width_max - body_width_min
225
226
    # T1655-1
                 e (nom) b, L, E2, D2 (max)
    # T2055-2
                 e (nom)
                           b (max) L, E2, D2 (nom)
227
    # T2055-5
                          b (max) L (min) E2, D2 (nom)
228
                 e (nom)
229
230
    # T2855-1
                 e (nom)
                           b (max) L (min) E2, D2 (nom)
231
    # T2855-2
                 e (nom)
                           b (max) L (min) E2, D2 (max)
232
233
    # T3255-2
                 e (nom) b (max) L (max) E2, D2 (max)
234
    # T4055-1
                 e (nom) b (min) L (nom) E2, D2 (min)
235
236
237
                               Ъ
                                       L
                                             L1
                                                      E2
                                                              D2
                       e
                              0.35
                                                     3.2
                                                             3.2
238
     T1655-1
                 16
                      0.8
                                      0.5
     T2055-2
                 20
                              0.35
                                      0.55
                                                     3.10
                                                            3.10
239
                      0.65
     T2055-5
                 20
                      0.65
                              0.35
                                      0.45
                                                     3.25
                                                            3.25
240
241
242
     T2855-1
                 28
                       0.50
                              0.30
                                      0.45
                                                     3.25
                                                            3.25
243
     T2855-2
                 28
                       0.50
                              0.30
                                      0.45
                                                     2.8
                                                             2.8
244
245
246
     T3255-2
                 32
                      0.50
                              0.30
                                      0.5
                                             0.25
                                                     3.2
                                                             3.2
     T4055-1
                 40
                      0.40
                              0.2
                                      0.5
                                             0.25
                                                     3.2
                                                             3.2
247
248
249
    # Style (adapted from the Perl Cookbook, First Edition, Recipe 12.4)
250
    # 1. Names of functions and local variables are all lowercase.
```

Pcb\_9

new

element\_begin

 ${\tt element\_output}$ 

element\_add\_line

element\_add\_arc

element\_add\_pin

element\_add\_pad

element\_add\_pad\_rectangle

 ${\tt element\_add\_pin\_oval}$ 

element\_add\_mark

element\_add\_lines

element\_add\_rectangle

element\_set\_text\_xy

 ${\tt element\_set}$ 

 ${\tt element\_get}$ 

element\_dump

References

Change Log

Element Flags

Text Flags

Pin Flags

Pad Flags



```
# 2. The program's persistent variables (either file lexicals or package globals) are capitalized.
254 # 3. Identifiers with multiple words have each of these
255 # separated by an underscore to make it easier to read.
256 # 4. Constants are all uppercase.
257 # 5. If the arrow operator (->) is followed by either a
258 # method name or a variable containing a method name then
259 # there is a space before and after the operator.
```