Procedure

1. Orient yourself to the labeling on the power cable connection.

Figure 10-6   Labeling on the power connector

2. Orient yourself to the red marking on the coding element.

3. The coding element has 3 red markings. Turn the coding element in such a way that one of the 3 red markings corresponds to the voltage indicated on the connector.

4. Insert the coding element into the back side of the power cable connector, until you hear it click into place. The figure below shows you how to insert a coding element into a power cable connector for 24 VDC.


Figure 10-7   Inserting a coding element into a power connector