TRUST Generic Guide V1.9.2

 $Support\ team:\ trust@cea.fr$

Link to: Project Reference Manual

June 13, 2023

Contents

1	Intr	roduction
	1.1	Before TRUST: a modular software named Trio_U
	1.2	Short history
	1.3	Data file
		1.3.1 Data file example: base blocks
		1.3.2 Basic rules
		1.3.3 Objects notion
		1.3.4 Interpretor notion
		1.3.5 Example
		1.3.6 Important remarks
	1.4	Running a data file
		1.4.1 Sequential calculation
		1.4.2 Parallel calculation
	1.5	Visualization
2	Imp	portant references 12
3	Dat	a setting 13
	3.1	Problems
	3.2	Domain definition
	3.3	Mesh
		3.3.1 Allowed meshes
		3.3.2 Import a mesh file
		3.3.3 Quickly create a mesh
		3.3.4 Transform mesh within the data file
		3.3.5 Test your mesh
	3.4	Discretization
	3.5	Time schemes
		3.5.1 Some available time schemes
		3.5.2 Calculation stopping condition
	3.6	Medium/Type of fluide
	3.7	Add gravity
	3.8	Objects association and discretization
		3.8.1 Association
		3.8.2 Discretization
4	Pro	blem definition 21
_	4.1	Set of equations
		4.1.1 Incompressible problems
		4.1.2 Quasi-compressible problem
		4.1.3 Conduction problem
		4.1.4 Coupled problems
		4.1.5 Other problems
		

	4.2	Pressure solvers	26
	4.3	Convection	26
	4.4	Diffusion	27
	4.5	Initial conditions	27
	4.6	Boundary conditions	28
	4.7	Turbulence models (in TrioCFD)	28
	4.8	Source terms	28
	4.9	Post-processing	29
		4.9.1 Field names	29
		4.9.2 Post-processing blocks	32
		4.9.3 Post-process location	34
5	End	l of the data file	35
	5.1	Solve	35
	5.2	Stop a running calculation	35
	5.3	Save	35
	5.4	Resume	36
6	Pos	t-processing	37
U	6.1	Output files	37
	6.2	Tools	38
	0.2	10018	90
7	Par	allel calculation	39
	7.1	Basic notions	39
	7.2	Performances	36
	7.3	Partitioning	39
		7.3.1 The different blocks	40
		7.3.2 Partitionning: "Assisted" method	40
		7.3.3 TRUST available partitioning tools	41
		7.3.4 Overlapping width value	42
	7.4	Running a parallel calculation	43
		7.4.1 On a PC	43
		7.4.2 On a cluster	43
	7.5	Visualization	43
	7.6	Useful information	44
		7.6.1 Modify the mesh	44
		7.6.2 Modify calculation parameters	44

Chapter 1

Introduction

This document constitutes the generic guide for TRUST software and its Baltik projects.

TRUST is a thermohydraulic software package for CFD simulations for incompressible monophasic flow.

You can create new project based on **TRUST** plateform. Theses projects are named "**BALTIK**" projects.

The currently available modules include a VDF calculation module "Finite Difference Volume", a VEF calculation module "Finite Element Volume" and a PolyMAC module "series of Marker-and-Cell (MAC) schemes that can handle any type of mesh (non-conform, non-orthogonal, poly-hedral types, ...)". For further details, you can see https://cea-trust-platform.github.io/classes/discretizations/

The VDF and VEF validated modules are designed to process the 2D or 3D flow of Newtonian, incompressible, weakly expandable fluids the density of which is a function of a local temperature and concentration values (Boussinesq approximation).

1.1 Before TRUST: a modular software named Trio_U

TRUST was born from the cutting in two pieces of **Trio_U** software. **Trio_U** was a software brick based on the **Kernel** brick (which contains the equations, space discretizations, numerical schemes, parallelism...) and used by other CEA applications (cf Figure 1.1).




Figure 1.1: Trio U: brick software

We could create new projects based on Kernel brick or **Trio_U** brick. Theses projects were named "BALTIK" projects: "Build an Application Linked to TrIo_U Kernel".

In 2015, **Trio** U was divided in two parts: **TRUST** and **TrioCFD**.

• TRUST is a new platform, its name means: "TRio_U Software for Thermohydraulics",

• **TrioCFD** is a BALTIK project based on **TRUST**, which contains the following models: FT, Radiation, LES, zoom...

Here is the structure of **TRUST** platform (cf Figure 1.2):




Figure 1.2: TRUST platform & its BALTIKs

1.2 Short history

 ${\bf TRUST}$ is now developed at the CEA/DES/ISAS/DM2S/SGLS service. The project starts in 1994 and improved versions were built ever since:

- 1994: start of the project Trio U
- 01/1997: v1.0 VDF only
- 06/1998: v1.1 VEF version
- 04/2000: v1.2 parallel version
- 07/2001: v1.3 radiation model, in TrioCFD since v1.7
- 11/2002: v1.4 new LES turbulence models, in TrioCFD since v1.8
- 02/2006: v1.5 VDF/VEF Front Tracking, in TrioCFD since v1.7
- 10/2009: v1.6 data structure revamped
- 06/2015: v1.7 cut into **TRUST** and **TrioCFD** + switch to open source
- \bullet 11/2019: v1.8 Turbulence features are moved from **TRUST** to **TrioCFD** + PolyMAC discretization
- 06/2022: v1.9 Pb_Multiphase in **TRUST** + PolyMAC V2 discretization + Pb_HEM in **TrioCFD**

1.3 Data file

To launch a calculation with **TRUST**, you need to write a "data file" which is an input file for **TRUST** and will contain all the information about your simulation. Data files are written following some rules as shown below. But their language is not a programming language, users can't make loops or switch...

Note that:

- lines between # ... # and /* ... */ are comments,
- in that document, words in **bold** are **TRUST** keywords, you can highlight them in your file editor with the command line (details in section 1.4):
 - > trust -config gedit|vim|emacs

- braces "{ }" are elements that **TRUST** reads and interprets, so don't forget them and <u>put space</u> <u>before and after them,</u>
- \bullet elements between bracket "[]" are optional.

1.3.1 Data file example: base blocks

Discretization of the problem

Discretize my_problem my_discretization

Here is the template of a basic sequential data file:

```
# Dimension 2D or 3D #
Dimension 2
# Problem definition #
Pb hydraulique my_problem
# Domain definition #
Domaine my_domain
# Mesh #
Read file my_mesh.geo ;
# For parallel calculation only! #
# For the first run: partitioning step #
# Partition my_domain
      Partition tool partitioner_name { option1 option2 ... }
      Larg joint 2
      zones_name DOM
End #
# For parallel calculation only! #
# For the second run: read of the sub-domains #
# Scatter DOM.Zones my_domain #
# Discretization on hexa or tetra mesh #
\mathbf{VDF} my_discretization
# Time scheme explicit or implicit #
Scheme euler explicit my_scheme
Read my_scheme
      # Initial time #
      # Time step #
      # Output criteria #
      # Stop Criteria #
}
# Association between the different objects #
Associate my_problem my_domain
Associate my_problem my_scheme
```

```
# New domains for post-treatment #
# By default each boundary condition of the domain is already extracted
  with names such as "my_dom"_boundaries_"my_BC" #

Domaine plane
  extraire_surface
{
    domaine plane
    probleme my_probleme
    condition_elements (x>0.5)
    condition_faces (1)
}
```

```
# Problem description # Read my_problem {
```

```
# hydraulic problem #
Navier\_Stokes\_standard
     # Physical characteristics of medium #
     Fluide Incompressible
     {
          # Gravity vector definition #
          gravity Uniform field 2 0 -9.81
     }
     # Choice of the pressure matrix solver #
     Solveur Pression solver { ... }
     # Diffusion operator #
     Diffusion { ... }
     # Convection operator #
     Convection { ... }
     # Sources #
     Sources { ... }
     # Initial conditions #
     Initial conditions { ... }
     # Boundary conditions #
     Boundary conditions { ... }
}
```

```
# Post_processing description #
      /* To know domains that can be treated directly, search in .err
         output file: "Creating a surface domain named" */
      /* To know fields that can be treated directly, search in .err
         output file: "Reading of fields to be postprocessed" */
      Post processing
           # Definition of new fields #
           Definition Champs { ... }
           # Probes #
           Probes { ... }
           # Fields #
           # format default value: lml #
           # select 'lata' for VisIt tool or 'MED' for Salomé #
           format lata
           fields dt post 1. { ... }
           # Statistical fields #
           Statistiques dt post 1. { ... }
      }
# Saving and restarting process #
[sauvegarde binaire datafile.sauv]
[resume last time binaire datafile.sauv]
```

```
# End of the problem description block #
}
```

```
# The problem is solved with #
Solve my_problem
```

```
# Not necessary keyword to finish #
End
```

Basic rules 1.3.2

There is no line concept in **TRUST**.

Data files uses <u>blocks</u>. They may be defined using the braces:

```
a block
```

Objects notion 1.3.3

Objects are created in the data set as follows:

```
Type identificateur
```

• Type: must be a type of object recognised by TRUST, correspond to the C++ classes. The list of recognised types is given in the file hierarchie.dump.

• *identificateur*: the identifier of the object type *Type* created, correspond to an instancy of the C++ class *Type*. **TRUST** exits in error if the identifier has already been used.

There are several object types. Physical objects, for example:

- A Fluide_incompressible (incompressible_Fluid) object. This type of object is defined by its physical characteristics (its dynamic viscosity μ (keyword mu), its density ρ (keyword rho), etc...),
- A Domaine.

More abstract object types also exist:

- A VDF, VEF or PolyMAC according to the discretization type,
- A Scheme_euler_explicit to indicate the time scheme type, here it's a first-order explicit Euler scheme.
- A Solveur pression to denote the pressure system solver type,
- A Uniform field to define, for example, the gravity field.

1.3.4 Interpretor notion

Interprete (interpretor) type objects are then used to handle the created objects with the following syntax:

```
Type\_interprete argument
```

- Type_interprete: any type derived from the Interprete (Interpretor) type recognised by TRUST. In this manual, they are written in **bold**. You can highlight them in your file editor with the command (details in section 1.4):
 - > trust -config nedit|vim|emacs
- argument: an argument may comprise one or several object identifiers and/or one or several data blocks.

Interpretors allow some operations to be carried out on objects.

Currently available general interpretors include **Read**, **Read_file**, **Ecrire** (Write), **Ecrire_fichier** (Write_file), **Associate**.

1.3.5 Example

A data set to write Ok on screen:

```
Nom a_name  # Creation of an object type. Name identifier a_name #
Read a_name Ok # Allocates the string "Ok" to a_name #
Ecrire a_name  # Write a_name on screen #
```

1.3.6 Important remarks

- 1. To insert <u>comments</u> in the data set, use # .. # (or /* ... */), the character # must always be enclosed by blanks.
- 2. The comma separates items in a list (a comma must be enclosed with spaces or a new line).
- 3. Interpretor keywords are recognised indiscriminately whether they are written in lower and/or upper case.
- 4. On the contrary, object names (identifiers) are recognised differently if they are written in upper or lower case.
- 5. In the following description, items (keywords or values) enclosed by [and] are optional.

1.4 Running a data file

```
To use TRUST, your shell must be "bash". So ensure you are in the right shell:
```

> echo \$0
/bin/bash

To run your data file, you must initialize the TRUST environment using the following command:

> source \$my_path_to_TRUST_installation/env_TRUST.sh
TRUST vX.Y.Z support : trust@cea.fr

Loading personal configuration /\spath_to_my_home_directory/.perso_TRUST.env

1.4.1 Sequential calculation

You can run your sequential calculation:

```
> cd $my_test_directory
> trust [-evol] my_data_file
```

where "trust" command call the "trust" script. You can have the list of its options with:

> trust -help

or

> trust -h

Here is a panel of available options:

Usage: trust [option] datafile [nb_cpus] [1>file.out] [2>file.err]

Where option may be:

-help|-h : List options.

-baltik [baltik_name] : Instanciate an empty Baltik project.
-index : Access to the TRUST ressource index.

-doc : Access to the TRUST manual (Generic Guide).

-html : Access to the doxygen documentation.

-config nedit|vim|emacs|gedit : Configure nedit or vim or emacs or gedit with TRUST keywords.

-edit : Edit datafile.

-xcheck : Check the datafile's keywords with xdata.

-xdata : Check and run the datafile's keywords with xdata.

-partition : Partition the mesh to prepare a parallel calculation (Creation of

-mesh : Visualize the mesh(es) contained in the data file.

-eclipse-trust : Generate Eclipse configuration files to import TRUST sources.
-eclipse-baltik : Generate Eclipse configuration files to import BALTIK sources (7)

-probes : Monitor the TRUST calculation only.
-evol : Monitor the TRUST calculation (GUI).

-prm : Write a prm file (deprecated).
-jupyter : Create basic jupyter notebook file.

-clean : Clean the current directory from all the generated files by TRUS -search keywords : Know the list of test cases from the data bases which contain key-copy : Copy the test case datafile from the TRUST database under the pro-

-check|-ctest all|testcase|list : Check|ctest the non regression of all the test case | -check|-ctest function|class|class::method : Check|ctest the non regression of a list of tests of tests | -check|-ctest function|class|class::method : Check|ctest the non regression of a list of tests | -check|-ctest function|class|class::method : Check|ctest the non regression of a list of tests | -check|-ctest function|class|-check|-ctest function|class|-check|-ctest function|class|-check|-ctest function|class|-check|-ctest function|check|-ctest function|class|-check|-ctest function|check|-ctest fun

-gdb : Run under gdb debugger. -valgrind : Run under valgrind.

-valgrind_strict : Run under valgrind with no suppressions.
-callgrind : Run callgrind tool (profiling) from valgrind.

: Run massif tool (heap profile) from valgrind. -massif : Run heaptrack (heap profile). Better than massif. -heaptrack

: Run advisor tool (vectorization). -advisor

-vtune : Run vtune tool (profiling). : Run perf tool (profiling). -perf

-trace : Run traceanalyzer tool (MPI profiling).

-create_sub_file : Create a submission file only.

: Create a submission file and submit the job on the main product: -prod -bigmem : Create a submission file and submit the job on the big memory pr : Create a submission file with the specified queue and submit the -queue queue : Use ncpus CPUs allocated per task for a parallel calculation. -c ncpus datafile -help_trust : Print options of TRUST_EXECUTABLE [CASE[.data]] [options]. -convert_data datafile : Convert a data file to the new 1.9.1 syntax (milieu, interfaces)

1.4.2 Parallel calculation

To run a parallel calculation, you must do two runs:

- the first one, to partition and create your 'n' sub-domains (two methods: "By hand" method below and "Assisted" method cf parts 7.3.1 & 7.3.2),
- the second one, to read your 'n' sub-domains and run the calculation on 'n' processors.

We will explain here how to do such work:

• Partitioning: "By hand" method

You have to make two data files:

- BuildMeshes.data and
- Calculation.data.

The BuildMeshes.data file only contains the same information as the beginning of the sequential data file and partitioning information. This file will create the sub-domains (cf. Zones files).

```
Dimension 2
Domaine my_domain

# BEGIN MESH #
Read_file my_mesh.geo ;
# END MESH #

# BEGIN PARTITION #
Partition my_domain
{
    Partition_tool partitioner_name { option1 option2 ... }
    Larg_joint 2
    zones_name DOM
    ...
}
End
# END PARTITION #
```

Run the BuildMeshes.data with TRUST:

> trust BuildMeshes

You may have obtained files named DOM_000n .**Zones** which contains the 'n' sub-domains.

• Read the sub-domains

The *Calculation.data* file contains the domain definition, the block which will read the subdomains and the problem definition (as in sequential calculation).

Calculation.data Dimension 2 Domaine my_domain Pb Hydraulique my_problem # BEGIN SCATTER # Scatter DOM. Zones my_domain # END SCATTER # \mathbf{VDF} my_discretization Scheme euler explicit my_scheme Read my_scheme { ... } Associate my_problem my_domain Associate my_problem my_scheme Discretize my_problem my_discretization Read my_problem { Fluide Incompressible { ... } } Solve my_problem End

Run the Calculation.data file with **TRUST**:

```
> trust Calculation procs_number
```

This will read your DOM_000n .Zones files. You can see the documentation of the "scatter" keyword in this part of the Project Reference Manual.

For more information, you can see this exercise in the TRUST tutorial.

1.5 Visualization

To learn how to use the "-evol" option, you can see the first exercise of the TRUST tutorial: Flow around an obstacle.

Chapter 2

Important references

For details and practices, see:

- the TRUST tutorial,
- The TRUST & TrioCFD user slides,
- The TRUST & TrioCFD development slides,
- the Project Reference Manual.

Other references:

- Methodology for incompressible single phase flow (Models_Equations_TRUST.pdf),
- Trio_U code validation data base & best practice guidelines (Best_Practice_TRUST.pdf),
- Organisation of TrioCFD validation data base (HowTo_Validation.pdf),
- To access **TRUST** test case list and most documentation:
 - > trust -index
- To access **TrioCFD** documentation (See how to load TrioCFD environment in the User tutorial):
 - > triocfd -index

For further information, you can see the TRUST/TrioCFD website: https://triocfd.cea.fr.

Remember that you can attend to:


- a user training session (2 days),
- a developper training session (2 days)

provided by the support team. To request session, send an email to trust@cea.fr.

Chapter 3

Data setting

We will now explain how to fill a data file. First you must specify some basic information like the dimension of your domain, its name, the problem type... To define the problem dimension, we use the following keyword:



3.1 Problems

or

You have to define the problem type that you wish to solve.

Here are some of the available problem types:

- for incompressible flow: Pb [Thermo]hydraulique[Concentration] Turbulent],
- for quasi-compressible flow: Pb Thermohydraulique Turbulent QC,
- for weakly compressible flow: Pb Thermohydraulique Turbulent WC,
- for solid: **Pb** Conduction,
- you can find all problem types in the Reference Manual.

where:

- hydraulique: means that we will solve Navier-Stokes equations without energy equation,
- Thermo: means that we will solve Navier-Stokes equations with energy equation,
- Concentration: that we will solve multiple constituent transportation equations,
- Turbulent: that we will simulate a turbulent flow and specify a turbulent model (RANS or LES). (Since version v1.8.0, Turbulence models are in TrioCFD and not anymore in TRUST).
- Conduction: resolution of the heat equation,
- QC: Navier Stokes equations with energy equation for quasi-compressible fluid under low Mach approach,
- WC: Navier Stokes equations with energy equation for weakly compressible fluid under low Mach approach.

3.2 Domain definition

To define the domain, you must name it. This is done thanks to the following block:

```
Domaine my_domain
```

Then you must add your mesh to your simulation.

3.3 Mesh

Notice the presence of the tags:

```
# BEGIN MESH #
...
# END MESH #
```

in the data file of section 1.3.1. This is useful for parallel calculation (see section 7) if well placed in datafile.

3.3.1 Allowed meshes

TRUST allows:

• quadrangular or triangular undeformed meshing for 2D cases (Figure 3.1),







Figure 3.1: 2D allowed elements

• hexahedral or tetrahedral undeformed meshing for 3D cases (Figure 3.2).






Figure 3.2: 3D allowed elements

Non-standard and hybrid meshing are (partially, since not all physical models in TrioCFD are yet available with this discretization) supported thanks to PolyMAC discretization! (cf Figure 3.3)

3.3.2 Import a mesh file

If your mesh was generated with an external tool like Salomé (open source software), ICEM (commercial software), Gmsh (open source software, included in **TRUST** package) or Cast3M (CEA software), then you must use one of the following keywords into your data file:

- Read MED for a MED file from Salomé, Gmsh,...,
- Read File for a binary mesh file from ICEM,




Figure 3.3: Partially supported meshes

• for another format, see the Project Reference Manual.

If you want to learn how to build a mesh with Salomé or Gmsh and read it with **TRUST**, you can look at the exercises of the **TRUST** tutorial: here for Salomé and here for Gmsh.

3.3.3 Quickly create a mesh

Here is an example of a simple geometry (of non complex channel type) using the internal tool of **TRUST**:

```
Mailler my_domain
      /* Define the domain with one cavity */
      /* cavity 1m*2m with 5*22 cells */
      Pave box
           Origine 0. 0.
           Longueurs 1 2
           /* Cartesian grid */
           Nombre de Noeuds 6 23
           /* Uniform mesh */
           Facteurs 1. 1.
      }
      {
           /* Definition and names of boundary conditions */
           bord Inlet
                         X = 0. 0. <= Y <= 2.
           bord Outlet X = 1. O. <= Y <= 2.
           bord Upper
                         Y = 2. 0. <= X <= 1.
           bord Lower
                         Y = 0. 0. <= X <= 1.
      }
```

To use this mesh in your data file, you just have to add the previous block in your data file or save it in a file named for example " $my_mesh.geo$ " and add the line:

```
Read_file my_mesh.geo;
```

Do not forget the semicolon at the end of the line!

3.3.4 Transform mesh within the data file

You can also make transformations on your mesh after the "Mailler" or "Read_*" command, using the following keywords:

- Trianguler to triangulate your 2D cells and create an unstructured mesh.
- Tetraedriser to tetrahedralise 3D cells and create an unstructured mesh.
- Raffiner _ anisotrope/Raffiner _ isotrope to triangulate/tetrahedralise elements of an untructured mesh.
- ExtrudeBord to generate an extruded mesh from a boundary of a tetrahedral or an hexahedral mesh. Note that ExtrudeBord in VEF generates 3 or 14 tetrahedra from extruded prisms.
- RegroupeBord to build a new boundary with several boundaries of the domain.
- Transformer to transform the coordinates of the geometry.
- for other commands, see the section interprete of the Project Reference Manual.

Note that theses mesh modifications work on all mesh types (i.e. also for *.geo or *.bin or *.med files).

3.3.5 Test your mesh

The keyword **Discretiser_domaine** is useful to discretize the domain (faces will be created) without defining a problem. Indeed, you can create a minimal data file, post-process your mesh in lata format (for example) and visualize it with VisIt.

Note that you must name all the boundaries!

Here is an example of this kind of data file:

```
my data file.data
dimension 3
Domaine my_domain
Mailler my_domain
      Pave box
      {
           Origine 0. 0. 0.
           Longueurs 1 2 1
           Nombre de Noeuds 6 23 6
           Facteurs 1. 1. 1.
      }
      {
           bord Inlet
                         X = 0. 0.  <= Y <= 2. 0.  <= Z <= 1.
           bord Outlet X = 1. O. <= Y <= 2. O. <= Z <= 1.
                         Y = 2. 0. \le X \le 1. 0. \le Z \le 1.
           bord Upper
           bord Lower
                         Y = 0. 0.  <= X <= 1. 0.  <= Z <= 1.
           bord Front
                         Z = 0. 0.  <= X <= 1. 0.  <= Y <= 2.
           bord Back
                         Z = 1. 0. \le X \le 1. 0. \le Y \le 2.
      }
discretiser domaine my_domain
postraiter domaine { domaine my_domain fichier file format lata }
End
```

To use it, launch in a bash terminal:

```
# if not already done
> source $my_path_to_TRUST_installation/env_TRUST.sh
# then
> trust my_data_file
> visit -o file.lata &
```

To see how to use VisIt, look at the first TRUST tutorial exercise: Flow around an obstacle.

If you want to learn how to make a mesh with Salomé or Gmsh and read it with **TRUST**, you can look at the exercises of the **TRUST** tutorial: here for Salomé and here for Gmsh.

3.4 Discretization

You have to specify the discretization type which can be VDF, EF or VEFPreP1B or PolyMAC.

In **VDF** discretization, the locations of the unknowns are drawn in the Figure 3.4.




Figure 3.4: VDF unknown locations

For **VEFPreP1B**, the locations of the unknowns are drawn in the Figure 3.5.




Figure 3.5: VEF unknown locations in 2D

In 3D for the pressure, we can also use the P0+P1+Pa discretization for flow with a strong source term and a low velocity field. In this case P0+P1 pressure gradient has trouble to match the source term so we use P0+P1+Pa discretization (cf Figure 3.6).

To specify the wanted discretization, you have to add the following block to your data file:




Figure 3.6: VEF pressure location in 3D

```
Discretization_type my_discretization
[Read my_discretization { ... }]
```

You can add parameters to your discretization with the optional keyword **Read** (see **VEFPreP1B** discretization).

On the TRUST website and TrioCFD website, you can find information about:

- VDF discretization in the PhD thesis of A. Chatelain,
- **VEFPreP1B** discretization (Crouzet-Raviart elements) in the PhD thesis of T. Fortin and PhD thesis of S. Heib.
- PolyMAC discretization in the TRUST website.

3.5 Time schemes

Now you can choose your time scheme to solve your problem. For this you must specify the time scheme type wanted and give it a name. then you have to specify its parameters by filling the associated "Read" block.

```
Scheme\_type my_time_scheme Read my_time_scheme { ... }
```

3.5.1 Some available time schemes

Here are some available types of explicit schemes:

- Scheme Euler explicit,
- Schema Adams Bashforth order 2,
- Runge Kutta ordre 3,

And also some available types of implicit schemes:

- Scheme Euler implicit,
- Schema_Adams_Moulton_order_3.

For other schemes, see this section of the Reference Manual.

Note that you can implicit diffusion term by activating the **diffusion_implicite** keyword in your explicit time scheme.

3.5.2 Calculation stopping condition

You must specify at least one stopping condition for you simulation. It can be:

- the final time: tmax
- the maximal allowed cpu time: tcpumax
- the number of time step: nb pas dt max
- the convergency treshold: seuil statio

Note that if the time step reaches the minimal time step dt min, TRUST will stop the calculation.

If you want to stop properly your running calculation (i.e. with all saves), you may use the my_data_file .stop file (cf section 5.2). When the simulation is running, you can see the "0" value in that file.

To stop it, put a "1" instead of the " $\mathbf{0}$ ", save the file and at the next iteration the calculation will stop properly.

When you don't change anything in that file, at the end of the calculation, you can see that it is writen "Finished correctly".

3.6 Medium/Type of fluide

To specify the medium or fluid, you must add the following block.

$$Fluid_type \{ \dots \}$$

Fluid type can be one of the following:

- Fluide incompressible
- Fluide quasi compressible
- Fluide_Weakly_Compressible
- Solide
- for other types and more information see Project Reference Manual.

Since TRUST v1.9.1, the medium should be read in the beginning of the problem definition (before equations). If you want to solve a coupled problem, each medium should be read in the corresponding problem.

3.7 Add gravity

If needed, you can add a gravity term to your simulation. This is done by adding a uniform field, in the medium block since V1.9.1. For example in 2D:

gravity Uniform_field
$$2~\theta$$
 -9.81

3.8 Objects association and discretization

3.8.1 Association

Until now, we have created some objects, now we must associate them together. For this, we must use the **Associate** interpretor:

```
# Association between the different objects #
Associate my_problem my_domain
Associate my_problem my_time_scheme
```

3.8.2 Discretization

Then you must discretize your domain using the **Discretize** interpretor:

```
Discretize my_problem my_discretization
```

The problem my problem is discretized according to the my discretization discretization.

IMPORTANT: A number of objects must be already associated (a domain, time scheme, ...) prior to invoking the **Discretize** keyword.

Note that when the discretization step succeeds, the mesh is validated by the code.

Chapter 4

Problem definition

4.1 Set of equations

Depending on your choosed problem type, you will have a different set of equations.

4.1.1 Incompressible problems

TRUST solves Navier-Stokes equations with/without the heat equation for an incompressible fluid:

$$\begin{cases} \nabla \cdot \vec{u} = 0 \\ \frac{\partial \vec{u}}{\partial t} + \nabla \cdot (\vec{u} \otimes \vec{u}) = \nabla \cdot (\nu \nabla \vec{u}) - \nabla P^* \\ \frac{\partial T}{\partial t} + \vec{u} \nabla T = \nabla \cdot (\alpha \nabla T) + \frac{Q}{\rho C_p} \end{cases}$$

where: $P^* = \frac{P}{\rho} + gz$, Q is the heat source term, and:

- ρ : density,
- μ : dynamic viscosity,
- $\nu = \frac{\mu}{\rho}$: kinematic viscosity,
- $\vec{g} = gz$: gravity vector in cartesian coordinates,
- $\alpha = \frac{\lambda}{\rho C_p}$: thermal diffusivity.
- C_p : specific heat capacity at constant pressure,
- λ : thermal conductivity,

Note that red terms are convective terms and blue terms are diffusive terms.

```
Pb_Thermohydraulique_Concentration_Turbulent my_problem
Read my_problem
      # Define medium and its properties + gravity if any #
      Fluide incompressible { ... }
      \# Navier Stokes equations with/without turbulent model \#
                      Turbulent
     Navier_Stokes _ Standard
           Solveur_Pression my\_solver \{ \dots \}
           Diffusion { ... }
           Convection { ... }
           Initial_conditions { ... }
           Boundary conditions { ... }
           {\bf Modele\_turbulence}\ modele\ \{\ \dots\ \}
           Sources { ... }
      }
      # Energy equation with/without turbulent model #
      Convection Diffusion Temperature Turbulent
           Diffusion { ... }
           Convection { ... }
           Initial conditions { ... }
           Boundary_conditions { ... }
           Modele turbulence Prandtl { ... }
           Sources { ... }
      \# Constituent transportation equations with/without turbulent model \#
      Convection Diffusion Concentration Turbulent
           Diffusion { ... }
           Convection { ... }
           Initial conditions { ... }
           Boundary conditions { ... }
           Modele_turbulence Schmidt { ... }
           Sources { ... }
      }
}
```

For documentation, see:

Thermo	hydraulique	Concentration	Turbulent	Reference Manual
	Pb_hydraulique			doc
	Pb_hydraulique	_Concentration		doc
	Pb_hydraulique		$_{ m Turbulent}$	TrioCFD Reference Manual
	Pb_hydraulique	_Concentration	$_{ m Turbulent}$	TrioCFD Reference Manual
Pb_Thermo	hydraulique			doc
Pb_Thermo	hydraulique	$_$ Concentration		doc

Pb_Thermo	hydraulique		$_{ m Turbulent}$	TrioCFD Reference Manual
Pb Thermo	hydraulique	Concentration	Turbulent	TrioCFD Reference Manual

4.1.2 Quasi-compressible problem

TRUST solves Navier-Stokes equations with/without heat equation for quasi-compressible fluid:

$$\begin{cases} \frac{\partial \rho}{\partial t} + \nabla \cdot (\rho \vec{u}) = 0 \\ \frac{\partial \rho \vec{u}}{\partial t} + \nabla \cdot (\rho \vec{u} \vec{u}) = \nabla \cdot (\mu \nabla \vec{u}) - \nabla P - \rho \vec{g} \\ \rho C_p \left(\frac{\partial T}{\partial t} + \vec{u} \nabla T \right) = \nabla \cdot (\lambda \nabla T) + \frac{dP_0}{dt} + Q \end{cases}$$

where: $P_0 = \rho RT$, Q is a heat source term, and:

- ρ : density,
- μ : dynamic viscosity,
- $\vec{g} = gz$: gravity vector in cartesian coordinates,
- \bullet $C_p:$ specific heat capacity at constant pressure,
- λ : thermal conductivity.

Note that red terms are convective terms and blue terms are diffusive terms.

```
Pb Thermohydraulique Turbulent QC my_problem
Read my_problem
      # Define medium and its properties + gravity if any #
      Fluide Quasi compressible { ... }
      # Navier Stokes equations for quasi-compressible fluid under #
      \# low Mach numbers with/without turbulent model \#
      Navier Stokes Turbulent QC
           Solveur Pression my solver \{ \dots \}
           Diffusion { ... }
           Convection { ... }
           Initial conditions { ... }
           Boundary conditions { ... }
           {\bf Modele\_turbulence}\ modele\ \{\ \dots\ \}
           Sources { ... }
      }
      \# Energy equation for quasi-compressible fluid under low Mach \#
      # numbers with/without turbulent model #
      {f Convection\_Diffusion\_Chaleur\_Turbulent\_QC}
           Diffusion { ... }
           Convection { ... }
           Initial conditions { ... }
           Boundary_conditions { ... }
           Modele turbulence Prandtl { ... }
           Sources { ... }
      }
}
```

For more information on QC problem, go there and for turbulent QC problem see TrioCFD Reference Manual.

4.1.3 Conduction problem

For this kind of problems, TRUST solves the heat equation:

$$\rho C_p \frac{\partial T}{\partial t} = \nabla \cdot (\lambda \nabla T) + Q$$

where:

- ρ : density,
- C_p : specific heat capacity at constant pressure,
- λ : thermal conductivity,
- Q is a heat source term.

Note that term in blue is the diffusive term.

In your data file, you will have:

For more information, see the Project Reference Manual.

4.1.4 Coupled problems

With **TRUST**, we can couple problems. We will explain here the method for two problems but you can couple as many problems as you want.

To couple two problems, we define two problems $my_problem_1$ and $my_problem_2$ each one associated to a separate domain my_domain_1 and my_domain_2 , and to a separate medium my_medium_1 and my_medium_2 (associated or not to the gravity).

```
Dimension 2

Pb_ThermoHydraulique_Turbulent my_problem_1
Pb_ThermoHydraulique_Turbulent my_problem_2

Domaine my_domain_1
Read_file my_mesh_1.geo;

Domaine my_domain_2
Read_file my_mesh_2.geo;
Associate my_problem_1 my_domain_1

Associate my_problem_2 my_domain_2
```

Then we define a coupled problem associated to a single time scheme like for example:

```
Probleme_Couple my_coupled_problem

VEFPreP1B my_discretization

Scheme_euler_explicit my_scheme
Read my_scheme { ... }

Associate my_coupled_problem my_problem_1
Associate my_coupled_problem my_problem_2
Associate my_coupled_problem my_scheme
```

Then we discretize and solve everything:

You can see the documentation of this kind of problem in the Project Reference Manual.

4.1.5 Other problems

TRUST & TrioCFD can also solve the following types of problems (Turbulence models in TrioCFD):

• Resolution of NAVIER STOKES/energy/multiple constituent transportation equations, with the additional passive scalar equations.

4.2 Pressure solvers

Then you may indicate the choice of pressure solver (cf Project Reference Manual) using the following syntax:

```
Solveur_pression my_solver { ... }
```

The my_solver may be:

- **GCP**,
- Petsc Petsc solver name,
- Cholesky,
- Gmres,
- Gen,
- Optimal.

Reminder: in CFD, a separate solver is used to solve the pressure. For more details, you can have a look at the section "Time and space schemes" of the **TRUST** & **TrioCFD** user slides.

4.3 Convection

There is no default convective scheme so you must choose one convection scheme:

```
convection { convective_scheme }
```

You can use the following convective scheme, following the recommendations of the user training session (cf section "Time and space schemes" of the **TRUST** & **TrioCFD** user slides and the section "Recommendations for schemes") following your discretization type:

- Amont
- Muscl
- EF stab
- for more, see the Project Reference Manual.

Note that there is no default convective scheme and if you don't want convection in your problem, you may use:

4.4 Diffusion

The diffusion term is more or less a Laplacien operator and is thus always discretized by a second order centered difference scheme. So you just need to do this:

Note If you don't want diffusion in your problem, you may use:

4.5 Initial conditions

For each equation, you must set initial conditions:

```
initial_conditions { ... }
```

To see the syntax of each available initial condition: cf Project Reference Manual. Here are the most used initial conditions:

- Vitesse field type bloc lecture champ
- Temperature field type bloc lecture champ
- K eps field type bloc lecture champ

We list here some "field_type":

- Uniform Field: for a uniform field,
- Champ Fonc Med: to read a data field in a MED-format file .med at a specified time,
- Champ_Fonc_txyz: for a field which depends on time and space,
- Champ_Fonc_Fonction_txyz: for a field which is a function of another field and time and/or space coordinates,
- Champ Fonc Reprise: to read a data field in a saved file (.xyz or .sauv) at a specified time.
- refer to the Project Reference Manual.

4.6 Boundary conditions

Then you may specify your boundary conditions like:

```
boundary_conditions { ... }
```

It is important to specify here that TRUST will not accept any boundary conditions by default.

You can find help for boundary conditions in the Project Reference Manual. Here is a list of the most used boundary conditions:

- Bord Frontiere ouverte vitesse imposee boundary field type bloc lecture champ
- Bord Frontiere_ouverte_pression_imposee boundary_field_type bloc_lecture_champ
- Bord Paroi fixe
- Bord Symetrie
- Bord Periodique
- Bord Frontiere_ouverte_temperature_imposee boundary_field_type bloc_lecture_champ
- Bord Frontiere ouverte T_ext boundary_field_type bloc_lecture_champ
- Bord Paroi adiabatique
- Bord Paroi flux impose boundary field type bloc lecture champ
- for more, see the Project Reference Manual.

To choose your "boundary field type" parameters, refer to the Project Reference Manual.

4.7 Turbulence models (in TrioCFD)

User can add a turbulence model to his simulation using the keyword:

```
Modele_turbulence my_model { ... }
```

where $my \mod el$ can be:

- Longueur Melange: RANS model based on mixing length modelling,
- Sous maille: LES model which uses a structure sub-grid function model,
- K epsilon: for RANS turbulence model $(k-\varepsilon)$,
- for more, see the Project Reference Manual.

4.8 Source terms

To introduce a source term into an equation, add the following line into the block defining the equation. The list of source keyword is described below.

```
Sources { source_keyword }
```

To introduce several source terms into the same equation, the blocks corresponding to the various terms need to be separated by a comma:

```
Sources { source_keyword1 , source_keyword2 , ...}
```

- Perte Charge Reguliere type perte charge bloc definition pertes charges
- Perte Charge Singuliere KX | KY | KZ coefficient value { ... }

- Canal perio { ... }
- Boussinesq temperature $\{ \dots \}$: $\rho(T) = \rho(T_0)(1 \beta_{th}(T T_0))$
- Boussinesq concentration { ... }
- Puissance thermique field type bloc lecture champ
- documentation for hydraulic source terms and for scalar source terms.

4.9 Post-processing

Before post-processing fields, during a run, **TRUST** creates several files which contain information about the calculation, the convergence, fluxes, balances... (see part 6.1 for more information).

Several keywords can be used to create a post-processing block, into a problem. First, you can create a single post-processing task (Post_processing keyword). Generally, in this block, results will be printed with a specified format at a specified time period.

But you can also create a list of post-processings with **Post_processings** keyword (named with Post_name1, Post_name2, etc...), in order to print results into several formats or with different time periods, or into different results files:

```
Post_processings
{
         Post_name1 { Postraitement_definition }
         Post_name2 { Postraitement_definition }
         ...
}
```

4.9.1 Field names

• Existing & predefined fields

You can post-process predefined fields and already existing fields. Here is a list of post-processable fields, but it is not the only ones.

Physical values	Keyword for field_name	Unit	
Velocity	Vitesse or Velocity	$m.s^{-1}$	
Velocity residual	Vitesse_residu	$m.s^{-2}$	
Kinetic energy per elements			
$(0.5\rho u_i ^2)$	${f Energie_cinetique_elem}$	$kg.m^{-1}.s^{-2}$	
Total kinetic energy			
$\left(\frac{\sum_{i=1}^{nb} e^{lem} 0.5\rho u_i ^2 vol_i}{\sum_{i=1}^{nb} e^{lem} vol_i}\right)$	${f Energie_cinetique_totale}$	$kg.m^{-1}.s^{-2}$	
Vorticity	Vorticite	s^{-1}	
Pressure in incompressible flow			
$(P/\rho + gz)$	$ m Pression^{\ 1}$	$Pa.m^3.kg^{-1}$	
For Front Tracking probleme		or	
$(P + \rho gz)$		Pa	
continued on next page			

¹The post-processed pressure is the pressure divided by the fluid's density $(P/\rho + gz)$ on incompressible laminar calculation. For turbulent, pressure is $P/\rho + gz + 2/3 * k$ cause the turbulent kinetic energy is in the pressure gradient.

Physical values	Keyword for field name	Unit
Pressure in incompressible flow	Keyword for field_fiame	Unit
$(P+\rho gz)$	Pression pa or Pressure	Pa
Pressure in compressible flow	Pression	Pa
Hydrostatic pressure (ρgz)	Pression hydrostatique	Pa
Totale pressure (when	1 ression_ny drostatique	1 4
quasi compressible model		
is used)=Pth+P	Pression tot	Pa
Pressure gradient	1 Tession_tot	1 4
$(\nabla(P/\rho+gz))$	Gradient pression	$m e^{-2}$
(V(1/p+gz)) Velocity gradient	gradient vitesse	$\frac{m.s^{-2}}{s^{-1}}$
Temperature	Temperature	°C or K
Temperature residual	Temperature residu	${}^{o}\text{C.}s^{-1} \text{ or K.}s^{-1}$
Phase temperature of	Temperature_residu	0.5 01 13.5
a two phases flow	Tomporature EquationName	°C or K
Mass transfer rate	Temperature_EquationName	Cork
	T	121
between two phases	Temperature_mpoint	$\frac{kg.m^{-2}.s^{-1}}{K^2}$
Temperature variance	Variance_Temperature	
Temperature dissipation rate	Taux_Dissipation_Temperature	$K^2.s^{-1}$
Temperature gradient	Gradient_temperature	$K.m^{-1}$
Heat exchange coefficient	H_echange_Tref ²	$W.m^{-2}.K^{-1}$
Turbulent heat flux	Flux_Chaleur_Turbulente	$m.K.s^{-1}$
Turbulent viscosity	Viscosite_turbulente	$m^2.s^{-1}$
Turbulent dynamic viscosity		
(when quasi compressible	Viscosite_dynamique_turbulente	$kg.m.s^{-1}$
model is used)		
Turbulent kinetic energy	K	$m^2.s^{-2}$
Turbulent dissipation rate	Eps	$m^3.s^{-1}$
Turbulent quantities		
K and Epsilon	$ m K_Eps$	$(m^2.s^{-2}, m^3.s^{-1})$
Residuals of turbulent quantities		
K and Epsilon residuals	${f K_Eps_residu}$	$(m^2.s^{-3}, m^3.s^{-2})$
Constituent concentration	Concentration	
Constituent concentration residual	Concentration_residu	
Component velocity along X	VitesseX	$m.s^{-1}$
Component velocity along Y	VitesseY	$m.s^{-1}$
Component velocity along Z	VitesseZ	$m.s^{-1}$
Mass balance on each cell	Divergence U	$m^3.s^{-1}$
Irradiancy	Irradiance	$W.m^{-2}$
Q-criteria	Critere Q	s^{-1}
Distance to the wall $Y^+ = yU/\nu$	_ •	
(only computed on	Y plus	dimensionless
boundaries of wall type)		
Friction velocity	U star	$m.s^{-1}$
Void fraction	alpha	dimensionless
Cell volumes	Volume maille	m^3
Chemical potential	Potentiel Chimique Generalise	
Source term in non		
Galinean referential	Acceleration terme source	$m.s^{-2}$
Stability time steps	Pas de temps	S
Listing of boundary fluxes	Flux bords	cf each *.out file
Volumetric porosity	Porosite_volumique	dimensionless
Distance to the wall	Distance Paroi ³	
	_	$\frac{m}{W.m^{-3}}$
Volumic thermal power	Puissance_volumique	vv.m °
Local shear strain rate defined as		
I	continued on next page	

²Tref indicates the value of a reference temperature and must be specified by the user. For example, H_echange_293 is the keyword to use for Tref=293K.

³distance_paroi is a field which can be used only if the mixing length model (see 2.15.1.2) is used in the data file.

Physical values	Keyword for field_name	Unit
$\sqrt{(2SijSij)}$	${ m Taux_cisaillement}$	s^{-1}
Cell Courant number (VDF only)	Courant_maille	dimensionless
Cell Reynolds number (VDF only)	Reynolds_maille	dimensionless
Viscous force	viscous_force	$kg.m^2.s^{-1}$
Pressure force	${ m pressure_force}$	$kg.m^2.s^{-1}$
Total force	${ m total_force}$	$kg.m^2.s^{-1}$
Viscous force along X	viscous_force_x	$kg.m^2.s^{-1}$
Viscous force along Y	viscous_force_y	$kg.m^2.s^{-1}$
Viscous force along Z	${ m viscous_force_z}$	$kg.m^2.s^{-1}$
Pressure force along X	pressure_force_x	$kg.m^2.s^{-1}$
Pressure force along Y	$pressure_force_y$	$kg.m^2.s^{-1}$
Pressure force along Z	$pressure_force_z$	$kg.m^2.s^{-1}$
Total force along X	total_force_x	$kg.m^2.s^{-1}$
Total force along Y	total_force_y	$kg.m^2.s^{-1}$
Total force along Z	${ m total_force_z}$	$kg.m^2.s^{-1}$

<u>Remark:</u> Physical properties (conductivity, diffusivity,...) can also be post-processed.

The name of the fields and components available for post-processing is displayed in the error file after the following message: "Reading of fields to be postprocessed". Of course, this list depends of the problem being solved.

For more information, you can see the Project Reference Manual.

• Creating new fields

The **Definition_champs** keyword is used to create new or more complex fields for advanced post-processing.

field_name_post is the name of the new created field and field_type is one of the following possible type:

- refChamp
- Reduction 0D using for example the min, max or somme methods.
- Transformation
- for details and other keywords, see the Project Reference Manual.

Note that you can combine several *field_type* keywords to create your field and then use your new fields to create other ones.

Here is an example of new field named max temperature:

You can find other examples in the **TRUST** & **TrioCFD** user slides in the section "Post processing description".

4.9.2 Post-processing blocks

There are three methods to post-process in **TRUST**: using probes, fields or making statistics.

• Probes

Probes refer to sensors that allow a value or several points of the domain to be monitored over time. The probes are a set of points defined:

- one by one: **Points** keyword or
- by a set of points evenly distributed over a straight segment: **Segment** keyword or
- arranged according to a layout: Plan keyword or
- arranged according to a parallelepiped: **Volume** keyword.

Here is an example of 2D **Probes** block:

```
Probes {
   pressure_probe [loc] pressure Periode 0.5 Points 3 1. 0. 1. 1. 1. 2.
   velocity_probe [loc] velocity Periode 0.5 Segment 10 1. 0. 1. 4.
}
```

where the use of "loc" option allow to specify the wanted location of the probes. The available values are "grav" for gravity center of the element, "nodes" for faces and "som" for vertices. There is not default location. If the point does not coincide with a calculation node, the value is extrapolated linearly according to neighbouring node values.

For complete syntax, see the Project Reference Manual, also for all options.

• Fields

This keyword allows to post-process fields on the whole domain, specifying the name of the backup file, its format, the post-processing time step and the name (and location) of the post-processed fields.

Here is an example of **Fields** block:

```
Fichier results
Format lata
Fields dt_post 1. {
    velocity [faces] [som] [elem]
    pressure [elem] [som]
    temperature [elem] [som]
}
```

where "faces", "elem" and "som" are keywords allowed to specify the location of the field.

Note that when you don't specify the location of the field, the default value is "som" for values at the vertices. So fields are post-processed at the vertices of the mesh.

To visualize your post-processed fields, you can use open source softwares like: VisIt (included in **TRUST** package) for lata and med files, or for med files: Salomé or Paraview.

You can see the complete syntax and all options in the Project Reference Manual.

• Statistics

Using this keyword, you will compute statistics on your unknows. You must specify the begining and ending time for the statistics, the post-processing time step, the statistic method, the name (and location) of your post-processed field.

Here is an example of **Statistiques** block:

```
Statistiques dt_post 0.1 {
    t_deb 1. t_fin 5.
    moyenne velocity [faces] [elem] [som]
    ecart_type pressure [elem] [som]
    correlation pressure velocity [elem] [som]
}
```

This block will write at every dt **post** the average of the velocity $\overline{V(t)}$:

$$\overline{V(t)} = \left\{ \begin{array}{ll} 0 & \text{, for } t \leq t_deb \\ \frac{1}{t-t_deb} \int_{t_deb}^t V(t) dt & \text{, for } t_deb < t \leq t_fin \\ \frac{1}{t_fin-t_deb} \int_{t_deb}^{t_fin} V(t) dt & \text{, for } t > t_fin \end{array} \right.$$

the standard deviation of the pressure $\langle P(t) \rangle$:

$$\langle P(t) \rangle = \left\{ \begin{array}{ll} 0 & \text{, for } t \leq t_deb \\ \frac{1}{t-t_deb} \sqrt{\int_{t_deb}^t \left[P(t) - \overline{P(t)}\right]^2 dt} & \text{, for } t_deb < t \leq t_fin \\ \frac{1}{t_fin-t_deb} \sqrt{\int_{t_deb}^{t_fin} \left[P(t) - \overline{P(t)}\right]^2 dt} & \text{, for } t > t_fin \end{array} \right.$$

and correlation between the pressure and the velocity $\langle P(t), V(t) \rangle$ like:

$$\langle P(t).V(t) \rangle = \left\{ \begin{array}{ll} 0 & \text{, for } t \leq t_deb \\ \frac{1}{t-t_deb} \int_{t_deb}^t \left[P(t) - \overline{P(t)} \right] \cdot \left[V(t) - \overline{V(t)} \right] dt & \text{, for } t_deb < t \leq t_fin \\ \frac{1}{t_fin - t_deb} \int_{t_deb}^{t_fin} \left[P(t) - \overline{P(t)} \right] \cdot \left[V(t) - \overline{V(t)} \right] dt & \text{, for } t > t_fin \end{array} \right.$$

<u>Remark:</u> Statistical fields can be plotted with probes with the keyword "operator_field_name" like for example: Moyenne_Vitesse or Ecart_Type_Pression or Correlation_Vitesse_Vitesse. For that, it is mandatory to have the statistical calculation of this fields defined with the keyword **Statistiques**.

For the complete syntax, see the Project Reference Manual here, and for all options see the Project Reference Manual.

4.9.3 Post-process location

You can use location keywords to specify where you want to post-process your fields in order to avoid interpolations on your post-processed fields.

For the **VDF** discretization, you can see the Figure 3.4 and here is a table with a reminder of the computation location of the fields in the **VDF** discretization:

Names	Keyword	Location
Pressure	pressure	element gravity center
Velocity	velocity	faces center
Temperature	temperature	element gravity center
Density ρ	masse_volumique	element gravity center
Kinematic viscosity ν	viscosite_cinematique	element gravity center
Dynamic viscosity μ	viscosite_dynamique	element gravity center
K	k	element gravity center
eps	eps	element gravity center
y^+	$y_{ m plus}$	element gravity center
u^*	${f u_star}$	faces center
Turbulent viscosity	${f viscosite_turbulente}$	element gravity center

For the **VEFPreP1B** discretization, you can see the Figure 3.5 and 3.6. Here is a table with a reminder of the computation location of the fields in **VEFPreP1B** discretization:

Names	Keyword	Location
		element gravity center
Pressure	${\bf pressure}$	vertices
Velocity	velocity	faces center
Temperature	${f temperature}$	faces center
Density ρ	${ m masse_volumique}$	element gravity center
Kinematic viscosity ν	${f viscosite_cinematique}$	element gravity center
Dynamic viscosity μ	${ m viscosite_dynamique}$	element gravity center
K	k	faces center
eps	${ m eps}$	faces center
y^+	$\mathbf{y}_{\mathbf{plus}}$	element gravity center
u^*	${f u_star}$	faces center
Turbulent viscosity	viscosite_turbulente	element gravity center

Be careful, if you are in P0+P1 discretization (default option) and you post-process the pressure field at the element (or at the vertices), you will have an **interpolation** because the field is computed at the element **and** at the vertices.

Chapter 5

End of the data file

5.1 Solve

Now that you have finished to specify all your computation parameters, you may add the "Solve" keyword at the end of your data file, in order to solve your problem. You may also add the "End" keyword to specify the end of your data file.

```
Solve my_problem
[End]
```

For more details, see the Project Reference Manual.

You can see methods to run your data file in section 1.4.

5.2 Stop a running calculation

Your calculation will automatically stop if it has reached:

- the end of the calculation time,
- the maximal allowed cpu time,
- the maximal number of iterations or
- the threshold of convergence.

You may use the $my_data_file.stop$ file, if you want to stop properly your running calculation (i.e. with all saves).

When the simulation is running, you can see the "0" value in that file. To stop it, put a "1" instead of the "0" and at the next iteration the calculation will stop properly. When you don't change anything to that file, at the end of the calculation, you can see that it is writen "Finished correctly".

5.3 Save

TRUST makes automatic backups during the calculation. The unknowns (velocity, temperature,...) are saved in:

- one .xyz file, happening:
 - at the end of the calculation,
 - but, user may disable it with the specific keyword "EcritureLectureSpecial 0" added just before the "Solve" keyword.

- one (or several in case of parallel calculation) .sauv files, happening:
 - at the start of the calculation,
 - at the end of the calculation,
 - each 23 hours of CPU, to change it, uses "periode_sauvegarde_securite_en_heure" keyword (default value 23 hours),
 - user may also specify a time physical period with "dt sauv" keyword,
 - periodically using "tcpumax" keyword for which calculation stops after the specified time (default value 10³⁰), use it for calculation on CCRT/TGCC and CINES clusters for example.

By default, the name for the .sauv files is "filename_problemname.sauv" for sequential calculation, "filename_problemname_000n.sauv" for parallel calculation (one per process). The format of theses files is binary and the files are completed during successive saves.

You can change the behaviour using the following keywords just before the **solve** instruction:

```
egin{array}{lll} 	ext{sauvegarde} & 	ext{binaire} | 	ext{xyz} & 	ext{filename.sauv} | 	ext{filename.xyz} \end{array}
```

with "xyz": the .xyz file is written instead of the .sauv files.

Note that, you can use "sauvegarde_simple" instead of "sauvegarde" where the .sauv or .xyz file is deleted before saves, in order to keep disk space:

```
{f sauvegarde\_simple} {f binaire}|{f xyz} {f filename.sauv}|{f filename.xyz}
```

For more details, see the Project Reference Manual.

5.4 Resume

To resume your calculation, you may:

- change your initial time, the new initial time will be the real final calculation time of the previous calculation (cf. err file),
- change your final calculation time to the new wanted value and
- add the following block just before the "Solve" keyword:

reprise binaire xyz	fil ename . \mathbf{sauv} fil ename . \mathbf{xyz}
-----------------------	--

You can resume your calculation:

- from .sauv file(s) (one file per process): you can only resume the calculation with the same number of equations on the same number of processes,
- or from a .xyz file: here you can resume your calculation by **changing the number of equations** solved and/or with a different number of processes.

Instead of "reprise" keyword, you can use "resume_last_time" where tinit is automatically set to the last time of saved files (but you may change tmax):

```
resume_last_time binaire|xyz filename.sauv|filename.xyz
```

For examples, see the TRUST tutorial and the Project Reference Manual.

Note that you can run a calculation with initial condition read into a save file (.xyz or .sauv) from a previous calculation using Champ_Fonc_reprise or read a into a MED file with Champ_Fonc_MED.

Chapter 6

Post-processing

6.1 Output files

After running, you will find different files in your directory. Here is a short explaination of what you will find in each type of file depending on its extension.

Even if you don't post-process anything, you will have output files which are listed here:

File	Contents
$my_data_file.\mathbf{dt}_\mathbf{ev}$	Time steps, facsec, equation residuals
$my_data_file.\mathbf{stop}$	Stop file ('0', '1' or 'Finished correctly')
$my_data_file.\mathbf{log}$	Journal logging
$my_data_file.\mathbf{TU}$	CPU performances
$my_data_file_\mathbf{detail.TU}$	Statistics of execution
$my_data_file_problem_name.\mathbf{sauv} \text{ or } .\mathbf{xyz}$	Saving $2D/3D$ results for resume
or $specified_name.\mathbf{sauv}$ or $.\mathbf{xyz}$	(binary files)

and the listing of boundary fluxes where:

- $my_data_file_$ Contrainte_visqueuse.out correspond to the friction drag exerted by the fluid,
- my data file Convection qdm.out contains the momentum flow rate,
- my data file **Debit.out** is the volumetric flow rate,
- my_data_file Force pression.out correspond to the pressure drag exerted by the fluid.

If you add post-processings in your data files, you will find:

File	Contents
$my_data_file.\mathbf{sons}$	1D probes list
$my_data_file_probe_name.\mathbf{son}$	1D results with probes
$my_data_file_probe_name.\mathbf{plan}$	3D results with probes
$my_data_file.lml (default format)$	
my_data_file.lata (with all *.lata.* files)	
$my_data_file.\mathbf{med}$	$2\mathrm{D}/3\mathrm{D}\ \mathrm{results}$
or $specified_name.lml$ or $.lata$ or $.med$	

The sceen outputs are automatically redirected in $my_data_file.out$ and $my_data_file.err$ files if you run a parallel calculation or if you use the "-evol" option of the "trust" script. Else you can redirect them with the following command:

```
# if not already done
> source $my_path_to_TRUST_installation/env_TRUST.sh
# then
> trust my_data_file 1>file_out.out 2>file_err.err
```

In the .out file, you will find the listing of physical infos with mass balance and in the .err file, the listing of warnings, errors and domain infos.

6.2 Tools

To open your 3D results in **lata** format, you can use VisIt which is an open source software included in **TRUST** package. For that you may "source" **TRUST** environment and launch VisIt:

```
# if not already done
> source $my_path_to_TRUST_installation/env_TRUST.sh
# then
> visit -o my_data_file.lata &
```

To learn how to use it, you can do the TRUST tutorial exercise Flow around an obstacle.

To open your 3D results in **med** format, you can also use VisIt or Salomé or Paraview.

Here are some actions that you can perform when your simulation is finished:

- To visualize the positions of your probes in function of the 2D/3D mesh, you can open your .son files at the same time of the .lata file in VisIt.
- If you need more probes, you can create them with VisIt (if you have post-processed the good fields) or with MEDCoupling.
- You can use the option "-evol" of the trust script, like:

```
trust -evol my_data_file
```

and access to the probes or open VisIt for 2D/3D visualizations via this tool.

Chapter 7

Parallel calculation

TRUST is a plateform which allows to make parallel calculation following some basic rules:

- Single Program, Multiple Data model: tasks are split up and run simultaneously on multiple processors with different input in order to obtain results faster,
- messages exchange by Message Passing Interface,
- from a PC to a massively parallel computer, with shared or distributed memory.

7.1 Basic notions

To make a parallel calculation, you have to partition your domain. Each sub-domain will be treated by one processor. In order to have good performances, ensure you that:

- sub-domains have almost the same number of cells,
- joint lengths (boundaries between sub-domains) are minimal,

7.2 Performances

You have to choose a number of processors which is in agreement with the number of cells. So, you can evaluate your speed-up (sequential time/parallel time which must be as close as possible of the number of processors) or efficiency (=1/SpeedUp) to choose the right number of processors.

From our experience, for good performance with **TRUST**, each processor has to treat between 20000 and 30000 cells.

7.3 Partitioning

To run a parallel calculation, you must:

- make some modifications on your my data file.data file,
- do two runs:
 - the first one, to partitioning and create your 'n' sub-domains (two methods will by presented),
 - the second one, to read your 'n' sub-domains and run the calculation on 'n' processors.

7.3.1 The different blocks

Different blocks appear in the data file.

• Modifications on the mesh block

First you may add the tags "# BEGIN MESH #" and "# END MESH #" before and after your mesh block, for example:

```
# BEGIN MESH #
Read_file my_mesh.geo ;
[Trianguler_h my_domain]
# END MESH #
```

You can refer to section 3.3 to have more information.

• Adding a partitioning block

You may now add the partitioning block which contains the cutting instruction, after your mesh block:

```
# BEGIN PARTITION
Partition my_domain
{
     Partition_tool partitioner_name { option1 option2 ... }
     Larg_joint 2
     zones_name DOM
     ...
}
End
END PARTITION #
```

Where partitioner_name is the name of the chosen partitioner, one of METIS, Tranche, Sous_Zones, Partition or Fichier_Decoupage (cf section 7.3.3).

The "Larg_joint" keyword allows to specify the overlapping width value. You can see the documentation of this part in the Project Reference Manual.

Note the "End" before the last line. It will be useful for the cutting step.

This block will make the partitioning of your domain into the specified number of sub-domains during the partitioning run.

• Adding a block to read the sub-domains

At last, you will add a block which will be activated during the parallel calculation and will allow to read the sub-domains:

```
# BEGIN SCATTER
Scatter DOM.Zones my_domain
END SCATTER #
```

7.3.2 Partitionning: "Assisted" method

Here we will use the "trust-partition datafile" command line to make the partitioning step. We consider that you have correctly add the "#" in your $my_data_file.data$ file with the partitioning block and cutting block.

Be careful with the hashtags "#", they are interpreted by the script!

To automatically perform the partitioning step and obtain the parallel data file, you have to run:

> trust -partition my_data_file [parts_number]

Note that here parts_number is the number of sub-domains created but it is also the number of processors which will be used.

This command creates:

- a $SEQ_my_data_file.data$ file which is a backup file of $my_data_file.data$ the sequential data file.
- a $DEC_my_data_file.data$ file which is the first data file to be run to make the partitioning. It is immediately run by the command line **trust-partition datafile** to create a partition, located in the DOM_000n .**Zones** files.

Note that the code stops reading this file at the **"End"** keyword just before the **"# END PARTITION #"** block.

• a PAR_my_data_file.data file which is the data file for the parallel calculation. It reads the DOM_000n.Zones files through the instruction "Scatter".

Note that the meshing and cut of the mesh are commented here.

To see your sub-domains, you can run:

```
> trust -mesh PAR_my_data_file
```

For more information, you can go to see this exercise in the TRUST tutorial.

7.3.3 TRUST available partitioning tools

In TRUST, you can make partitioning with:

• the external partitionning library "METIS" (open source). It is a general algorithm that will generate a partition of the domain (cf Project Reference Manual),

```
partition_tool Metis {
    nb_parts N
    [use_weights]
    [pmetis | kmetis]
    [nb_essais N]
}
```

• internal **TRUST** partitioning tool: **Tranche** which makes parts by cutting the domain following x, y and/or z directions.

```
partition_tool Tranche {
     tranches nx ny [nz]
}
```

• other internal partitioning tools.

The Figure 7.1 is an example of what you can obtain by cutting a 1m x 1m square, divided in three parts using **METIS** and the same square divided in three slices following the x direction with **Tranche**.




Figure 7.1: Partitioning tools

You can see the documentation of this part in the Project Reference Manual.

7.3.4 Overlapping width value

To make the partitioning, you will have to specify the <u>overlapping width value</u>. This value corresponds to the thickness of the virtual ghost zone (data known by one processor though not owned by it) i.e. the number of vertices or elements on the remote sub-domain known by the local sub-domain (cf Figure 7.2).




Figure 7.2: Overlapping width

This value depends on the space discretization scheme orders:

- 1 if 1st or 2nd order,
- 2 if 3rd or 4th order.

Note that in general, you will use "2"!

7.4 Running a parallel calculation

7.4.1 On a PC

To launch the calculation, you have to run the calculation by the usual command completed by the number of processors needed:

```
> trust my_parallel_data_file procs_number
```

and *procs_number* is the number of processors used. In fact it is the same as the number of subdomains.

You can see the **TRUST** & **TrioCFD** user slides in the "Parallel calculation" section for more information and those two exercises of the **TRUST** tutorial: exercise 1 and exercise 2.

7.4.2 On a cluster

You must submit your job in a queue system. For this, you must have a submission file. **TRUST** can create a submission file for you **on clusters on which the support team has done installations**. To create this file, run:

```
> trust -create_sub_file my_parallel_data_file
```

You obtain a file named "sub_file", you can open it and verify/change values(for example the name of the job, the name of the exe, ...).

Then you must submit you calculation with:

```
> sbatch sub_file
```

or

> ccc_msub sub_file

following the queue system of the cluster.

You can see the **TRUST** & **TrioCFD** user slides in the "Parallel calculation" section for more information and this exercise of the **TRUST** tutorial.

7.5 Visualization

To visualize your probes, you can use the CurvePlot tool, with the command line:

```
> trust -evol my_parallel_data_file
```

or use Gnuplot or any software which reads values in columns in a file.

There are three ways to visualize your parallel results with VisIt:

- HPCDrive or Nice DCV on CCRT/TGCC clusters: opens a deported graphic session on dedicated nodes with more memory (on TGCC cluster: HPCDrive),
- local mode: copy your results from the cluster to your local computer and open it with a local parallel version of VisIt with:

```
> visit -np 4 &
```

You can have a look at the **TRUST** & **TrioCFD** user slides in the "Parallel calculation description" section.

7.6 Useful information

7.6.1 Modify the mesh

If you want to modify your mesh, you have two possibilities:

- modify the my data file.data file and run:
 - > trust -partition my_data_file [parts_number]

Be carefull it will erase the $SEQ_my_data_file.data$, $DEC_my_data_file.data$ and $PAR_my_data_file.data$ files and creates new ones.

Then it will run the new $DEC_my_data_file.data$ file which gives your new $DOM_000n.$ Zones files.

- modify the meshing part of file $DEC_my_data_file.data$ and run it with:
 - > trust DEC_my_data_file

Then run the parallel calculation normally, on the new DOM = 000n. Zones files.

> trust PAR_my_data_file procs_number

7.6.2 Modify calculation parameters

If you want to modify the calculation parameters, you can modify:

- the file my data file.data and run:
 - > trust -partition data_file_name [parts_number]

But it will erase the $SEQ_my_data_file.data$, $DEC_my_data_file.data$ and $PAR_my_data_file.data$ files and create new ones.

Then it will run the new $DEC_my_data_file.data$ file which gives your new $DOM_000n.$ Zones files

Note that in that case, you don't need to re-create the mesh so you can use the second point below:

• modify the PAR_my_data_file.data file without running "trust -partition datafile" command line.

Then run the PAR my data file.data file with:

> trust PAR_my_data_file procs_number

Note that if after a certain time, you want to reopen an old case and understand want you did in it without any doubts, you may create two files by hands:

- one "BuildMeshes.data" file only for the mesh and the cut of the mesh, and
- one "calculation.data" file for the parallel calculation.

You will run it like:

- > trust BuildMeshes
- > trust calculation processors_number

For this point, you can have a look at this exercise of the TRUST tutorial.