COMS31700 Design Verification:

Assertion-based Verification

Kerstin Eder

(Acknowledgement: Avi Ziv from the IBM Research Labs in Haifa has kindly permitted the re-use of some of his slides.)





What is an assertion?

- An assertion is a statement that a particular property is required to be true.
 - A property is a Boolean-valued expression, e.g. in SystemVerilog.
- An assertion is a directive to a verification tool.
 - Assertions can be checked either during simulation or using a formal property checker.
- Assertions have been used in SW design for a long time.
 - assert() function is part of C #include <assert.h>
 - Used to detect **NULL** pointers, out-of-range data, ensure loop invariants, etc.
- Revolution through Foster & Bening's OVL for Verilog.
 - Clever way of encoding re-usable assertion library in Verilog. ©
 - Assertions have become very popular for Design Verification in recent years: Assertion-Based Verification (also Assertion-Based Design).

HW Assertions


HW assertions:

- combinatorial (i.e. "zero-time") conditions that ensure functional correctness
 - must be valid at all times
 - "This buffer never overflows."
 - "This register always holds a single-digit value."
 - "The state machine is one hot."
 - "There are no x's on the bus when the data is valid."

and

- temporal conditions
 - to verify sequential functional behaviour over a period of time
 - "The grant signal must be asserted for a single clock cycle."
 - "A request must always be followed by a grant or an abort within 5 clock cycles."
 - Temporal assertion specification language facilitate specification.
 - System Verilog Assertions
 - PSL/Sugar

Who writes the assertions?



Types of Assertions

Types of Assertions: Implementation Assertions

- Also called "design" assertions.
- Specified by the designer.
- Encode designer's assumptions.
 - Interface assertions
 - Catch different interpretations between different designers.
- Formulate conditions of design misuse or design faults:
 - detect buffer over/under flow
 - signal read & write at the same time
- Implementation assertions can detect discrepancies between design assumptions and implementation.
- But implementation assertions won't detect discrepancies between functional intent and design!

(Remember: Verification Independence!)

Types of Assertions: Specification Assertions

- Also called "intent" assertions
 - Often high-level properties.
- Specified by architects, verification engineers, IP providers, standards.
- Encode expectations of the design based on understanding of functional intent.
- Provide a "functional error detection" mechanism.
- Supplement error detection performed by self-checking testbenches.
 - Instead of using (implementing) a monitor and checker, in some cases writing a block-level assertion can be much simpler.

Safety Properties

- Safety: Something bad does not happen
 - The FIFO does not overflow.
 - The system does not allow more than one process to use a shared device simultaneously.
 - Requests are answered within 5 cycles.
- More formally: A safety property is a property for which any path violating the property has a finite prefix such that every extension of the prefix violates the property. [Accellera PSL-1.1 2004]

Safety properties can be falsified by a finite simulation run.

Liveness Properties

- Liveness: Something good eventually happens
 - The system eventually terminates.
 - Every request is eventually acknowledged.
- More formally: A liveness property is a property for which any finite path can be extended to a path satisfying the property. [Foster etal.: Assertion-Based Design. 2nd Edition, Kluwer, 2010.]
 - In theory, liveness properties can only be falsified by an infinite simulation run.
 - Practically, we Often assume that the "graceful end-oftest" represents infinite time.
 - If the good thing did not happen after this period, we assume that it will never happen, and thus the property is falsified.


Use of Assertions

- Properties describe facts about a design.
- Properties can be used to write
 - Statements about the expected behaviour of the design and its interfaces
 - Combinatorial and sequential
 - (Can be used for simulation-based or for formal verification.)
 - Checkers that are active during simulation
 - e.g. protocol checkers
 - Constraints that define legal stimulus for simulation
 - Assumptions made for formal verification
 - Functional coverage points
- Remember to re-use existing assertions, property libraries or checks embedded in VIP.

How Assertions work during Simulation

- Temporal properties can be in one of 4 states during simulation:
 - inactive (no match), active, pass or fail

```
property req_followed_by_ack;
  @(posedge clk) { $rose (req) |=> ##[0:1] ack }
end property
p_req_ack: assert property req_followed_by_ack;
```



Overcoming the Observability Problem



If a design property is violated during simulation, then the DUV fails to operate according to the original design intent.

BUT:


- Symptoms of low-level bugs are often not easy to observe/detect.
- Activation of a faulty statement may not be enough for the bug to propagate to an observable output.

Assertion-Based Verification:

- During simulation assertions are continuously monitored.
- The assertion immediately fires when it is violated and in the area of the design where it occurs.
- Debugging and fixing an assertion failure is much more efficient than tracing back the cause of a bug.

Example FIFO DUV


Example DUV Specification - Inputs



Inputs:

- wr indicates valid data is driven on the data_in bus
- data_in is the data to be pushed into the DUV
- rd pops the next data item from the DUV in the next cycle
- clear resets the DUV

Example DUV Specification - Outputs



Outputs:

- data_out_valid indicates that valid data is driven on the data_out bus
- data_out is the data item requested from the DUV
- empty indicates that the DUV is empty
- full indicates that the DUV is full

DUV Specification

- High-Level functional specification of DUV
 - The design is a FIFO.
 - Reading and writing can be done in the same cycle.
 - Data becomes valid for reading one cycle after it is written.
 - No data is returned for a read when the DUV is empty.
 - Clearing takes one cycle.
 - During clearing read and write are disabled.
 - Inputs arriving during a clear are ignored.
 - The FIFO is 8 entries deep.

Identifying Properties for the FIFO block

An invariant property.

Black box view:

- Empty and full are never asserted together.
- After clear the FIFO is empty.
- After writing 8 data items the FIFO is full.
- Data items are moving through the FIFO unchanged in terms of data content and in terms of data order.
- No data is duplicated.
- No data is lost.
- data_out_valid only for valid data, i.e. no x's in data.

Identifying Properties for the FIFO block

White box view:

- The value range of the read and write pointers is between 0 and 7.
- The data_counter ranges from 0 to 8.
- The data in the FIFO is not changed during a clear.
- For each valid read the read pointer is incremented.
- For each valid write the write pointer is incremented.
- Data is written only to the slot indicated by nxt_wr.
- Data is read only from the slot indicated by nxt_rd.
- When reading and writing the data_counter remains unchanged.
 - What about a RW from an empty/full FIFO?

Property Formalization

- Property Formalization Languages
 - Most commonly used languages:
 - SVA and
 - PSL [IEEE 1850]
 - Assertions can be combinatorial

```
property mutex;
{ !(empty & full) }
end property
```

Boolean expression

Temporal expression in form of an implication

- or temporal

```
property req_followed_by_ack;
  @(posedge clk) { $rose (req) |=> ##[0:1] ack }
end property
```

pre-condition (antecedent)

main condition (consequent)

Introduction to Writing Properties using SVA

To formalize basic properties using SVA we need to learn about:

- Sequences
 - Cycle delay and repetition
- Implications
- \$rose, \$fell, \$past, \$stable

Sequences

- Useful to specify complex temporal relationships.
- Constructing sequences:
 - A Boolean expression is the simplest sequence.
 - ## concatenates two sequences.
 - ##N cycle delay operator advances time by N clock cycles.
 - a ##3 b b is true 3 clock cycles after a
 - ##[N:M] specifies a range.
 - a ##[0:3] b b is true 0,1,2 or 3 clock cycles after a
 - [*N] consecutive repetition operator
 - A sequence or expression that is consecutively repeated with one cycle delay between each repetition.
 - a [*2] exactly two repetitions of a in consecutive clock cycles
 - [*N:M] consecutive repetition with a specified range
 - a[*1:3] **covers** a, a ##1 a **or** a ##1 a ##1 a

Implications

- Properties typically take the form of an implication.
- SVA has two implication operators:
- | => represents logical implication

rea ant

true

- A = B is equivalent to (not A) or B,

non-overlapping implication

where B is sampled one cycle after A.

```
req_gnt: assert property ( req |=> gnt );

clk req gnt fail
```

Implications

- SVA has another implication operator:
- | -> represents logical implication
 - A | ->B is equivalent to (not A) or B,
 where B is sampled in the same cycle as A.

```
req_gnt_v1: assert property ( req |=> gnt );
req_gnt_v2: assert property ( req |-> ##1 gnt );
```

The overlapping implication operator |-> specifies behaviour in the same clock cycle as the one in which the LHS is evaluated.

Delay operator ##N delays by N cycles, where N is a positive integer including 0.

Both properties above are specifying the same functional behaviour.

Useful SystemVerilog Functions for Property Specification

- \$rose and \$fell
 - Compares value of its operand in the current cycle with the value this operand had in the previous cycle.
- \$rose
 - Detects a transition to 1 (true)
- \$fell
 - Detects a transition to 0 (false)
- Example:

```
assert property ( $rose(req) |=> $rose(gnt) );
```

Useful SystemVerilog Functions for Property Specification

- \$past(expr)
 - Returns the value of expr in the previous cycle.
 - Example:

```
assert property ( gnt |-> $past(req) );
```

- \$past(expr, N)
 - Returns the value of expr N cycles ago.
- \$stable(expr)
 - Returns true when the previous value of expr is the same as the current value of expr.
 - Represents: \$past(expr) == expr

Property Formalization

- System Verilog Assertion for:
 - Empty and full are never asserted together.

Is this a safety or a liveness property? Why?

```
property not_empty_and_full;
@(posedge clk) !(empty && full);
endproperty
mutex : assert property (not_empty_and_full);
```

This label is useful for debug.

- System Verilog Assertion for:
 - Empty and full are never asserted together.

This is a safety property!

```
property not_empty_and_full;
@(posedge clk) $onehotO({empty,full});
endproperty
mutex : assert property (not_empty_and_full);
```

Alternative encoding: **\$onehot0** returns true when zero or one bit of a multi-bit expression is high.

- System Verilog Assertion for:
 - After clear the FIFO is empty.

```
property empty_after_clear;
@ (posedge clk) (clear |-> empty);
endproperty
a_empty_after_clear : assert property (empty_after_clear);
```

Beware of property bugs! Know your operators:

```
seq1 | -> seq2, seq2 starts in last cycle of seq1 (overlap)
```

■ seq1 |=> seq2, seq2 starts in first cycle after seq1

```
We need: @ (posedge clk) (clear |=> empty);
```

- System Verilog Assertion for:
 - On empty after one write the FIFO is no longer empty.

```
property not_empty_after_write_on_empty;
@ (posedge clk) (empty && wr |=> !empty);
endproperty
a_not_empty_after_write_on_empty : assert property
    (not_empty_after_write_on_empty);
```

Assertions can be monitored during simulation.

Assertions can also be used for formal property checking.

Challenge:

There are many more interesting assertions.

Corner Case Properties

• FIFO empty: When the FIFO is empty and there is a write at the same time as a read (from empty), then the read should be ignored.

• FIFO full: When the FIFO is full and there is a read at the same time as a write, then the write (to full) should be ignored.

All my assertions pass – what does this mean?

- Remember, simulation can only show the presence of bugs, but never prove their absence!
- An assertion has never "fired" what does this mean?
 - Does not necessarily mean that it can't be violated!
 - Unless simulation is exhaustive..., which in practice it never will be.
 - It might not have fired because it was never active.
 - Most assertions have the form of implications.
 - Implications are satisfied when the antecedent is false!
 - These are vacuous passes.
 - We need to know how often the property passes non-vacuously!
- How do you know your assertions are correctly expressing what you intended?

32

Assertion Coverage

- Measures how often an assertion condition has been evaluated.
 - Many simulators count only non-vacuous passes.
 - Option to add assertion coverage points using:

```
assert property ( (sel1 || sel2) |=> ack );
cover property ( sel1 || sel2 );
```

– Coverage can also be collected on subexpressions:

```
cover property ( sel1 );
cover property ( sel2 );
```

Costs and benefits of ABV

Costs include:

- Simulation speed
- Writing the assertions
- Maintaining the assertions

Benefits include:

- Explicit expression of designer intent and specification requirements
 - Specification errors can be identified earlier
 - Design intent is captured more formally
- Enables finding more bugs faster
- Improved localisation of errors for debug
- Promote measurement of functional coverage
- Improved qualification of test suite based on assertion coverage
- Facilitate uptake of formal verification tools
- Re-use of formal properties throughout design life cycle

Intellectual step of property capture forces you to think earlier!

Do assertions really work?

- Assertions are able to detect a significant percentage of design failures:
 [Foster etal.: Assertion-Based Design. 2nd Edition, Kluwer, 2010.]
 - 34% of all bugs were found by assertions on DEC Alpha
 21164 project [Kantrowitz and Noack 1996]
 - 17% of all bugs were found by assertions on Cyrix M3(p1) project [Krolnik 1998]
 - 25% of all bugs were found by assertions on DEC Alpha 21264 project - The DEC 21264 Microprocessor [Taylor et al. 1998]
 - 25% of all bugs were found by assertions on Cyrix M3(p2) project [Krolnik 1999]
 - 85% of all bugs were found using OVL assertions on HP [Foster and Coelho 2001]
- Assertions should be an integral part of a verification methodology.

ABV Methodology

- Use assertions as a method of documenting the exact intent of the specification, high-level design, and implementation
- Include assertions as part of the design review to ensure that the intent is correctly understood and implemented
- Write assertions when writing the RTL code
 - The benefits of adding assertions at later stage are much lower
- Assertions should be added whenever new functionality is added to the design to assert correctness
- Keep properties and sequences simple
 - Build complex assertions out of simple, short assertions/sequences

Summary

In ABV we have covered:

- What is an assertion?
- Use and types of assertions
- Safety and Liveness properties
- Introduction to basics of SVA as a property formalization language
- Importance of Assertion Coverage
- Costs vs benefits of using assertions