Module Interface Specification for 2D-RAPP

Ziyang(Ryan) Fang

 $April\ 18,\ 2025$

1 Revision History

Date	Version	Notes
March 19 2025	1.0	Notes
April 05 2025	2.0	Notes

2 Symbols, Abbreviations and Acronyms

See SRS Documentation at https://github.com/FangZiyang/CAS741-Ryan/blob/main/docs/SRS/SRS.pdf.

Contents

1	Rev	vision 1	History	
2	Symbols, Abbreviations and Acronyms			
3	Introduction			
4	Not	ation		
5	Mo	dule D	Decomposition	
6	MIS	S of Pa	ath-Planning Module	
	6.1		le	
	6.2	Uses		
	6.3	Syntax	X	
		6.3.1	Exported Types	
		6.3.2	Exported Constants	
		6.3.3	Exported Access Programs	
	6.4	Semar	ntics	
		6.4.1	State Variables	
		6.4.2	Assumptions	
		6.4.3	Access Routine Semantics	
		6.4.4	Local Functions	
7	MIS		ollision-Detection Module	
	7.1	Modu	le	
	7.2			
	7.3	Syntax	X	
		7.3.1	Exported Types	
		7.3.2	Exported Access Programs	
	7.4	Semar	ntics	
		7.4.1	State Variables	
		7.4.2	Assumptions	
		7.4.3	Access Routine Semantics	
		7.4.4	Local Functions	
3	MIS	s of In	verse-Kinematics Solver Module	
	8.1	Modu	le	
	8.2	Uses		
	8.3	Syntax	x	
		8.3.1	Exported Access Programs	
	8.4	Semar	ntics	
		8 4 1	State Variables	

		8.4.2	Assumptions	. 7
		8.4.3	Access-Routine Semantics	. 7
		8.4.4	Local Functions	. 7
9	MIS	of Ou	ıtput-Verification Module	8
	9.1	Module	le	. 8
	9.2	Uses .		. 8
	9.3		ζ	
		9.3.1	Exported Constant	. 8
		9.3.2	Exported Access Programs	
	9.4	Seman	atics	. 8
		9.4.1	State Variables	. 8
		9.4.2	Assumptions	
		9.4.3	Access-Routine Semantics	. 8
10	MIS	of Plo	otting Module	10
	10.1	Module	e	. 10
	10.3		、	
		10.3.1	Exported Access Programs	. 10
	10.4	Seman	atics	. 10
		10.4.1	State Variables	. 10
		10.4.2	Environment Variables	. 10
		10.4.3	Assumptions	. 10
		10.4.4	Access-Routine Semantics	. 10
11			ontrol Module	12
	11.1	Module	e	. 12
	11.2	Uses .		. 12
	11.3	Syntax	C	. 12
		11.3.1	Exported Access Programs	. 12
	11.4	Seman	atics	. 12
		11.4.1	State Variables	. 12
		11.4.2	Assumptions	. 12
		11.4.3	Access-Routine Semantics	. 12
12	MIS	of Da	ata-Types Module	13
	12.1	Module	e	. 13
	12.2	Uses .		. 13
	12.3	Syntax	、	. 13
			Exported Types	
			Exported Constants	
		12.3.3	Exported Access Programs	. 13

12.4	Semantics	13
	12.4.1 State Variables	13
	12.4.2 Assumptions	14
	12.4.3 Access-Routine Semantics	14
	12.4.4. Local Functions	1/

3 Introduction

The following document details the Module Interface Specifications for **2D Robot Arm Path Planning**

Complementary documents include the System Requirement Specifications and Module Guide. The full documentation and implementation can be found at https://github.com/FangZiyang/CAS741-Ryan.

4 Notation

The structure of the MIS for modules comes from Hoffman and Strooper (1995), with the addition that template modules have been adapted from Ghezzi et al. (2003). The mathematical notation comes from Chapter 3 of Hoffman and Strooper (1995). For instance, the symbol := is used for a multiple assignment statement and conditional rules follow the form $(c_1 \Rightarrow r_1|c_2 \Rightarrow r_2|...|c_n \Rightarrow r_n)$.

The following table summarizes the primitive data types used by 2D-RAPP.

Data Type	Notation	Description
character	char	a single symbol or digit
integer	\mathbb{Z}	a number without a fractional component in $(-\infty, \infty)$
natural number	N	a number without a fractional component in $[1, \infty)$
real	\mathbb{R}	any number in $(-\infty, \infty)$

The specification of 2D-RAPP uses some derived data types: sequences, strings, and tuples. Sequences are lists filled with elements of the same data type. Strings are sequences of characters. Tuples contain a list of values, potentially of different types. In addition, 2D-RAPP uses functions, which are defined by the data types of their inputs and outputs. Local functions are described by giving their type signature followed by their specification.

5 Module Decomposition

The following table is taken directly from the Module Guide document for this project.

Level 1	Level 2
Hardware Hiding	
	Input Parameters Module
	Output Format Module
Deberieum Hiding	Output Verification Module
Behaviour Hiding	Inverse Kinematics Solver Module
	Configuration Management Module
	Path Planning Module
	Collision Detection Module
	Controll Module
Data Types Module	
Software Decision	Plotting Module
-	

Table 1: Module Hierarchy

6 MIS of Path-Planning Module

6.1 Module

Path-Planning

6.2 Uses

- Input Parameters Module (provides start/goal configurations, obstacles, robot parameters)
- Collision Detection Module (verifies that candidate paths are collision–free)
- Output Format Module (formats the sequence of configurations for visualisation)

6.3 Syntax

6.3.1 Exported Types

 $\texttt{ObstacleT} \equiv \langle c : \mathbb{R}^2, \, r : \mathbb{R} \rangle$

Obstacles \equiv sequence of ObstacleT

RobotParams $\equiv \langle L : \text{sequence of } \mathbb{R}, \ jointLim : \text{sequence of } \langle \ell : \mathbb{R}, \ u : \mathbb{R} \rangle \rangle$

 $Config \equiv \mathbb{R}^n \qquad (vector of joint angles)$

Path \equiv sequence of Config

6.3.2 Exported Constants

 $MAX_ITER : \mathbb{N}$ (default 10 000)

 $HEURISTIC_K : \mathbb{R}$ (default 1.0)

6.3.3 Exported Access Programs

Name	In	Out	Exceptions
planPath	$\begin{array}{ccc} {\tt Config} & \times & {\tt Config} & \times \\ {\tt Obstacles} & \times & {\tt RobotParams} \end{array}$	Path	PathNotFound

6.4 Semantics

6.4.1 State Variables

None.

6.4.2 Assumptions

- The module receives complete and valid *start*, *goal*, *obstacles* and *robot parameters* from the Input-Parameters Module.
- Joint-space is treated as an n-dimensional torus (wrap-around at 360°).

6.4.3 Access Routine Semantics

planPath

• transition: Returns a collision-free feasible path $p = \langle q_0, \dots, q_m \rangle$ s.t.

$$q_0 = start$$

$$q_m = goal$$
 $orall i : \neg \mathtt{checkCollision}(q_i, obstacles, robotParams)$

- \bullet output: p on success.
- exception: PathNotFound raised if no feasible path exists within MAX_ITER.

6.4.4 Local Functions

succ(q) returns the neighbouring configurations of q according to the lattice resolution.

$$\mathtt{gCost}(q_i, q_{i+1}) = \|q_{i+1} - q_i\|_2$$

 $\mathtt{hCost}(q) \ = \ \mathtt{HEURISTIC_K} \ \|q - goal\|_2$

¹The module does not guarantee optimality; any valid path is acceptable.

7 MIS of Collision-Detection Module

7.1 Module

Collision-Detection

7.2 Uses

• Input Parameters Module (provides obstacles and robot parameters)

7.3 Syntax

7.3.1 Exported Types

Config (as defined in §6)

7.3.2 Exported Access Programs

Name	In	Out	Exceptions
checkCollision	$\begin{array}{ll} {\tt Config} & \times & {\tt Obstacles} & \times \\ {\tt RobotParams} & & & \end{array}$	boolean	InvalidConfig
checkPathCollision	$\begin{array}{lll} {\tt Path} & \times & {\tt Obstacles} & \times \\ {\tt RobotParams} & & & \end{array}$	boolean	InvalidPath

7.4 Semantics

7.4.1 State Variables

None.

7.4.2 Assumptions

- Each obstacle is a circle $\langle c, r \rangle$ in \mathbb{R}^2 .
- Links are straight segments between joint positions produced by planar forward kinematics.

7.4.3 Access Routine Semantics

checkCollision

• transition: Let $P = \langle p_0, \dots, p_n \rangle$ be the joint positions obtained from forwardKinematics(config, rowardKinematics(config, rowardKinematics) and $\overline{p_{i-1}p_i}$ collides with obstacle $O = \langle c, r \rangle$ iff

$$d(\overline{p_{i-1}p_i}, c) \le r$$
 where $d = \frac{|(x_2 - x_1)(y_1 - y_c) - (y_2 - y_1)(x_1 - x_c)|}{\sqrt{(x_2 - x_1)^2 + (y_2 - y_1)^2}}$

- output: true iff any link collides with any obstacle.
- exception: InvalidConfig if joint limits are violated.

checkPathCollision

- transition: Returns true iff $\exists q \in path$: checkCollision(q, obstacles, robotParams)
- **output:** boolean as above.
- exception: InvalidPath if path is empty or contains an InvalidConfig.

7.4.4 Local Functions

 $\texttt{forwardKinematics}: \texttt{ConfigtimesRobotParams} \rightarrow \text{sequence of } \mathbb{R}^2$

8 MIS of Inverse-Kinematics Solver Module

8.1 Module

Inverse-Kinematics Solver

8.2 Uses

- Input Parameters Module
- Collision Detection Module

8.3 Syntax

8.3.1 Exported Access Programs

Name	In	Out	Exceptions
solveIK	${\tt Point} \times {\tt RobotParams}$	sequence of Config	NoSolution

8.4 Semantics

8.4.1 State Variables

None.

8.4.2 Assumptions

- The forward-kinematics map FK: Config \rightarrow Point is continuous and differentiable.
- The target point lies inside the reachable workspace.

8.4.3 Access-Routine Semantics

solveIK

- **output:** A finite sequence $S = \langle q_0, \dots, q_k \rangle$ of joint configurations such that $||FK(q_i) target|| \le \varepsilon$ for every $q_i \in S$.
- exception: NoSolution raised if the iterative algorithm exceeds MAX_ITER without satisfying the tolerance.

8.4.4 Local Functions

jacobian(q) returns $J(q) = \partial FK/\partial q$.

9 MIS of Output-Verification Module

9.1 Module

Output-Verification

9.2 Uses

• Collision Detection Module

9.3 Syntax

9.3.1 Exported Constant

 $\mathtt{TOL_ERR} = 10^{-6}$

9.3.2 Exported Access Programs

Name	In	Out	Exceptions
verifyPath	${\tt Path} \times {\tt Obstacles} \times {\tt RobotParams}$	_	PathInvalid, Collision

9.4 Semantics

9.4.1 State Variables

None.

9.4.2 Assumptions

The supplied path has already been discretised into configurations of type Config.

9.4.3 Access-Routine Semantics

verifyPath

• transition:

- 1. Check joint-limit and self-collision constraints for every $q \in path$.
- 2. Call checkPathCollision from the Collision-Detection Module.

• exception:

- PathInvalid if any configuration violates step 1.

- Collision if step 2 reports a collision.

10 MIS of Plotting Module

10.1 Module

Plotting

10.2 Uses

None.

10.3 Syntax

10.3.1 Exported Access Programs

Name	In	Out	Exceptions
plotPath	Path	_	PlotErr
plotMetrics	MetricTable		PlotErr

10.4 Semantics

10.4.1 State Variables

None.

10.4.2 Environment Variables

• win: handle to the active 2-D graphics window.

10.4.3 Assumptions

The graphics back-end supports real-time rendering.

10.4.4 Access-Routine Semantics

plotPath

- transition: Clears win and draws: way-points (circles), continuous trajectory (poly-line), labels for start/goal.
- exception: PlotErr if path is empty.

plotMetrics

- transition: Replaces the contents of win with a bar- or line-chart of the supplied performance metrics.
- exception: PlotErr if the table is ill-formed.

(Local helper routines such as $\mathtt{drawTrajectory}$ are omitted because they are not exported and add no specification value.)

11 MIS of Control Module

11.1 Module

Control

11.2 Uses

• Input-Parameters, Path-Planning, Collision-Detection, Inverse-Kinematics, Output-Verification, Plotting

11.3 Syntax

11.3.1 Exported Access Programs

Name	In	Out	Exceptions
execute	_	Path	CtrlErr

11.4 Semantics

11.4.1 State Variables

None.

11.4.2 Assumptions

All subordinate modules are already initialised.

11.4.3 Access-Routine Semantics

execute

- **output:** Returns the verified, collision-free Path p produced by the following explicit calls:
 - 1. (init, goal, rParam, obs) =**Input-Parameters::**getAll()
 - 2. $p_0 = \text{Path-Planning::planPath}(init, goal, obs, rParam)$
 - 3. Collision-Detection::checkPathCollision(p_0 , obs, rParam)
 - 4. p =Output-Verification::verifyPath $(p_0, obs, rParam)$
 - 5. **Plotting::**plotPath(*p*)
- exception: CtrlErr if any invoked access routine raises an exception.

12 MIS of Data-Types Module

12.1 Module

Data-Types

12.2 Uses

None. This module is imported by other modules to share common abstract data types (ADTs).

12.3 Syntax

12.3.1 Exported Types

```
Point \equiv \mathbb{R}^2 (Cartesian coordinate in the plane)

ObstacleT \equiv \langle c: \text{Point}, \, r: \mathbb{R} \rangle

Obstacles \equiv \text{sequence of ObstacleT}

RobotParams \equiv \langle L: \text{sequence of } \mathbb{R}, \, jointLim: \text{sequence of } \langle \ell: \mathbb{R}, \, u: \mathbb{R} \rangle \rangle

Config \equiv \mathbb{R}^n (vector of joint angles)

Path \equiv \text{sequence of Config}

MetricTable \equiv \text{set of key-value pairs } \langle name: \text{string}, \, value: \mathbb{R} \rangle
```

12.3.2 Exported Constants

None.

12.3.3 Exported Access Programs

None. The module only publishes type definitions.

12.4 Semantics

12.4.1 State Variables

None.

12.4.2 Assumptions

- All numeric quantities are expressed in SI units (metres, radians, seconds) unless stated otherwise.
- The dimension n in Config equals the number of revolute joints in the robot and is fixed at run-time by RobotParams.

12.4.3 Access-Routine Semantics

Not applicable – no routines are exported.

12.4.4 Local Functions

None.

References

Carlo Ghezzi, Mehdi Jazayeri, and Dino Mandrioli. Fundamentals of Software Engineering. Prentice Hall, Upper Saddle River, NJ, USA, 2nd edition, 2003.

Daniel M. Hoffman and Paul A. Strooper. Software Design, Automated Testing, and Maintenance: A Practical Approach. International Thomson Computer Press, New York, NY, USA, 1995. URL http://citeseer.ist.psu.edu/428727.html.