## Semiconductor Engineering

:Semiconductor Physics and Devices

Summary

## Chapter 3. Metal-Semiconductor Contacts

## Equilibrium in electronic systems

Why metal-semiconductor contact is important?

Most of the electronic devices that make up an <u>integrated circuit are connected</u> by means of metal-semiconductor contacts.

the nature of the thermal equilibrium that is established when a metal and a semiconductor are in intimate contact

underlie the basic properties of **semiconductor** *pn* **junctions** as well as the properties of interfaces between **semiconductors** and **insulators** and between **metals** and **insulators**.

Metal-semiconductor contact

Schottky theory

→ **ohmic** and **rectifying behavior** in various metal-semiconductor system

## Equilibrium in electronic systems

Metal-Semiconductor System

Using the concepts developed in Chapter 1, we recognize that these systems of allowed states can be regarded as being almost entirely populated at energies less than the Fermi energy and nearly vacant at higher energies..


When the metal and the semiconductor are remote from one another (do not interact)

both the systems of electronic states and their Fermi levels are <u>independent</u>

Let us designate the metal as <u>state-system number 1</u> the semiconductor as <u>state-system number 2</u>.

Each system has a density of allowed states g(E) per unit energy.

Of these g(E) states, n(E) are full and v(E) are empty.



**FIGURE 3.1** Allowed electronic-energy-state systems for two isolated materials. States marked with an × are filled; those unmarked are empty. System 1 is a qualitative representation of a metal; system 2 qualitatively represents a semiconductor.

### Equilibrium in electronic systems

#### Metal-Semiconductor System

• The Fermi-Dirac distribution functions

• The filled state density 
$$n_{1,2} = g_{1,2} \times f_{D1,2}$$

$$f_{D1.2} = \frac{1}{1 + \exp[(E - E_{f1,2})/kT]}$$

• The vacant state density  $v_{1,2} = g_{1,2} \times (1 - f_{D1,2})$ 

Because of the Pauli exclusion principle, the <u>available state density</u> is not  $g(E_x)$ , the state density, but  $\underline{v(E_x)}$ , the vacant-state density

The proportionality factor relating the transfer probability

is the same for transfer from system 1 to system 2 as it is for transfer from system 2 to system 1 at thermal equilibrium

$$\longrightarrow n_1 \times v_2 = n_2 \times v_1 \qquad \Longrightarrow \qquad f_{D1}g_1g_2 = f_{D2}g_2g_1$$



$$f_{D1}g_1g_2 = f_{D2}g_2g_1$$


We therefore have established the important property of any two systems in thermal equilibrium: they have the <u>same Fermi energy</u>.

Regardless of the detailed nature of these functions, a statement that their <u>Fermi levels</u> are equal is equivalent to stating that the two systems are in thermal equilibrium

At thermal equilibrium, the Fermi level is constant throughout a system.

#### **Band Diagram**

Specific cases of the allowed energy states for gold and for silicon



**FIGURE 3.3** Pertinent energy levels for the metal gold and the semiconductor silicon. Only the work function is given for the metal, whereas the semiconductor is described by the work function  $q\Phi_{\mathcal{S}}$ , the electron affinity  $qX_{\mathcal{S}}$ , and the band gap  $(E_{\varepsilon} - E_{v})$ .

 $E_o$ : the energy that an electron would have if it were just free of the influence of the given material


→ a convenient reference level for energy is taken to be the vacuum or free-electron energy

**Work function**: The difference between  $E_o$  and  $E_f$ 

usually given the symbol  $q\Phi$  in energy units and often listed as  $\Phi$  in volts for particular materials

#### **Band Diagram**

In the case of the semiconductor



**FIGURE 3.3** Pertinent energy levels for the metal gold and the semiconductor silicon. Only the work function is given for the metal, whereas the semiconductor is described by the work function  $q\Phi_S$ , the electron affinity  $qX_S$ , and the band gap  $(E_c - E_p)$ .

because  $E_f$  changes position within the gap separating  $E_v$  and  $E_c$  as the doping is varied, the difference between  $E_o$  and  $E_f$  is a function of the dopant concentration of the semiconductor

The difference between the vacuum level  $(E_0)$  and the conduction-band edge  $(E_c)$  is, however, a constant of the material. This quantity is called the *electron affinity*, and is conventionally denoted by qX in energy units. Tables of X in volts exist for many materials. (The symbol X is a Greek capital letter chi.)

#### Band Diagram

- $\Phi_{\rm M}$  is less than  $\Phi_{\rm S}$  and the materials do not interact an electron in the metal has, on average, a total energy that is higher than the average total energy of an electron in the semiconductor
- $\Phi_{\rm M}$  is greater than  $\Phi_{\rm S}$  and the materials do not interact the average total energy of an electron in the semiconductor is higher than it is in the metal

#### Consider the latter case where $\Phi_{\rm M} > \Phi_{\rm S}$

→ When an intimate contact is established, the <u>disparity in the average energies</u> can be expected to cause the transfer of electrons from the <u>semiconductor into the metal</u>.

#### **Band Diagram**

Looking at the establishment of equilibrium for this case where  $\Phi_{\rm M} > \Phi_{\rm S}$ 

$$f_{D1}g_1g_2 = f_{D2}g_2g_1$$
 (Eq. 3.1.5)

The left-hand side of <u>Equation 3.1.5</u> in that section is proportional to the flow of electrons from state system 1 to state-system 2 while the right-hand side of the same equation is proportional to the inverse flow.

The net flow is easily seen to be in the direction 2 to 1 if  $f_{D2} > f_{DI}$  or, therefore, if  $E_{f2} > E_{fI}$ .

The charge transfer continues until equilibrium is obtained, and a single Fermi level characterizes both the metal and the semiconductor.

At equilibrium, the semiconductor, having lost electrons, is charged positively with respect to the metal

#### **Band Diagram**

How to draw proper band diagram?

1. the vacuum level  $E_o$  must be drawn as a continuous curve

 $E_o$  represents the energy of a "justfree" electron and thus must be a continuous, single-valued function in space

- 2. Electron affinity is a property associated with the crystal lattice like the forbidden-gap energy. Hence, it is a constant in a given material
- 3. Considering these three factors: constancy of  $E_f$ , continuity of  $E_o$ , and constancy of X in the semiconductor

we can sketch the general shape of the band diagram for the metal semiconductor system

Charge, Depletion Region and Capacitance


*n*-type semiconductor–metal

$$\Phi_{\rm M} > \Phi_{\rm S}$$

Schottky contact

#### **Before contact**

#### **After contact**



#### Schottky barrier height

$$\Phi_B = \Phi_M - \chi$$

: Potential barrier for e' moving fr metal to s.c.

#### Contact potential

$$V_0 = \Phi_M - \Phi_S$$

: Potential barrier for e' moving fr s.c. to metal

Electron transfer from semiconductor to metal until the Fermi levels align at equilibrium

- ⇒ positive charge of donor ion in depletion region = the negative charge on metal
- $\Rightarrow$  contact potential  $(V_o)$  prevent electron flow from semiconductor to metal


#### Charge, Depletion Region and Capacitance

#### *p*-type semiconductor–metal


$$\Phi_{\mathrm{M}} < \Phi_{\mathrm{S}}$$

Schottky contact

#### **Before contact**



#### **After contact**



#### Schottky barrier height

$$\Phi_B = \chi + \frac{E_g}{q} - \Phi_M$$

: Potential barrier for h' moving from metal to s.c.

#### Contact potential

$$V_o = \Phi_S - \Phi_M$$


: Potential barrier for h' moving from s.c. to metal

Hole transfer from s.c. to metal until the Fermi levels align at equilibrium

- ⇒ negative charge of acceptor ion in depletion region = the positive charge on metal
- $\Rightarrow$  contact potential (V<sub>o</sub>) prevent hole flow from s.c. to metal

## Idealized Metal-Semiconductor Junction Applied Bias

• Nonequilibrium condition (at applied voltage)



#### At equilibrium condition

Abrupt step in allowed electron energies at the metal-semiconductor interface

This step makes it more difficult to cause a net transfer of free electrons from the metal into the semiconductor than it is to obtain a net flow of electrons in the opposite direction

There is a barrier of  $q\Phi_B$  electron volts between electrons at the Fermi level in the metal and the conduction band states in the semiconductor near its surface

The barrier height is independent of bias

#### **Applied Bias**


• Nonequilibrium condition (at applied voltage)

An applied voltage is similarly dropped entirely within the semiconductor and alters the equilibrium-band diagram by changing the total curvature of the bands, modifying the potential drop from  $\Phi_i$ 

 $\rightarrow$  Electrons in the bulk of the semiconductor at the conduction-band edge are interrupted from transferring to the metal by a barrier that can be changed readily from its equilibrium value  $\Phi_i$  by an applied bias.

### At equilibrium condition

 $(V_a = 0)$ 




#### Under positive Bias $(V_a > 0)$

The barrier is reduced when the metal is biased positively with respect to the semiconductor

#### Under negative Bias $(V_a < 0)$


The barrier is increased when the metal is more negative.





Applied Nanomaterials & Devices LAB.

#### Schottky contact


#### **Rectifying contact under bias**










#### **Forward**





#### Reverse





#### Forward bias


Barrier reduce :  $V_o \rightarrow V_o - V_F$ 

 $\Rightarrow$  Enhance *e* diffusion from s.c. to metal

#### Reverse bias

Barrier increase :  $V_0 \rightarrow V_0 + V_r$ 

 $\Rightarrow$  Reduce *e* diffusion from s.c. to metal



#### Schottky diode

- $\Rightarrow$  short delay time
- ⇒ high-speed rectifier


#### Ohmic contact

#### *n*-type semiconductor–metal $(\Phi_M < \Phi_S)$

#### **Before contact**

## $\Phi_m < \Phi_s$ n-type $q\chi$ $q\Phi_s$ $E_{Fm}$

#### **After contact**




Electron transfer from metal to s.c. until the Fermi levels align at equilibrium

⇒ energy barrier to electron flow between metal and s.c. is much small and easily overcome by small voltage


#### Ohmic contact

*p*-type semiconductor–metal  $(\Phi_M > \Phi_S)$ 

#### **Before contact**



#### **After contact**



hole transfer from metal to s.c. until the Fermi levels align at equilibrium

⇒ barrier to hole flow between metal and s.c. is much small and easily overcome by small voltage

	n-type	p-type
$\Phi_{\rm M} > \Phi_{\rm S}$	rectifying	ohmic
$\Phi_{\rm M} < \Phi_{\rm S}$	ohmic	rectifying

- Most of electronic devices need Ohmic junction for contact between different material, which causes minimal contact resistance
- Rectifying properties of diode need Schottky contact.





FIGURE 3.21 Diagrams for ideal metal-semiconductor Schottky diodes.


Chapter 4. p-n Junction

#### **Device building block**




#### To build a model for the *pn* junction

- Considering initially separated *n* and p-type semiconductor crystals of the same material
- When these are brought into intimate contact as shown in Figure 4.3b, the large difference in electron concentrations between the two materials causes electrons to flow from the n-type semiconductor into the *p-type* semiconductor and holes to flow from the p-type region into the n-type region.
- As these mobile carriers move into the oppositely doped material, they leave behind uncompensated dopant atoms near the junction, causing an electric field
- The field lines extend from the donor ions on the n-type side of the junction to the acceptor ions on the p-type side (Figure 4.3c).
- This field creates a potential barrier between the two types of material.
- When equilibrium is reached, the magnitude of the field is such that the tendency of electrons to diffuse from the *n*-type region into the p-type region is exactly balanced by the tendency of electrons to drift in the opposite direction under the influence of the built-in field.



**FIGURE 4.3** (a) *n*-type and *p*-type semiconductor regions separated and not in thermal equilibrium. (b) The two regions brought into intimate contact allowing diffusion of holes from the *p*-region and electrons from the *n*-region. (c) Transfer of free carriers leaves uncompensated dopant ions, which cause a field that opposes and balances the diffusion tendencies of holes and electrons.


#### Potential barrier



- ① PN junction이 생성되었다고 가정
- ② 전자와 정공의 농도 차이로 인해서 접합을 향해서 확산
- ③ 전자와 정공이 서로 만나 재결합(recombination)으로 사라짐.
- ④ 도펀트 이온만 노출되며 공핍영역에 전기장 형성
- ⑤ 도펀트 이온에 의한 전기장방향과 캐리어(전자 또는 정공)에 의한 확산 전류는 서로 반대
- ⑥ 확산 전류를 막아서 net current = 0이 될 때까지 전기장 증가
- ⑦ 확산과 드리프트 간 전류가 평형이 발생하며 그 때, built-in potential 결정

#### To build a model for the *pn* junction


- Considering initially separated *n* and p-type semiconductor crystals of the same material
- When these are brought into intimate contact as shown in Figure 4.3b, the large difference in electron concentrations between the two materials causes electrons to flow from the n-type semiconductor into the *p-type* semiconductor and holes to flow from the p-type region into the n-type region.
- As these mobile carriers move into the oppositely doped material, they leave behind uncompensated dopant atoms near the junction, causing an electric field
- The field lines extend from the donor ions on the n-type side of the junction to the acceptor ions on the p-type side (Figure 4.3c).
- This field creates a potential barrier between the two types of material.
- When equilibrium is reached, the magnitude of the field is such that the tendency of electrons to diffuse from the *n*-type region into the p-type region is exactly balanced by the tendency of electrons to drift in the opposite direction under the influence of the built-in field.



**FIGURE 4.3** (a) *n*-type and *p*-type semiconductor regions separated and not in thermal equilibrium. (b) The two regions brought into intimate contact allowing diffusion of holes from the *p*-region and electrons from the *n*-region. (c) Transfer of free carriers leaves uncompensated dopant ions, which cause a field that opposes and balances the diffusion tendencies of holes and electrons.

#### Junction formation

#### P-type semiconductor




Semiconductor lattice with acceptor ions and free holes

Acceptor



#### N-type semiconductor




Semiconductor lattice with donor ions and free electrons

Donor




Junction formation : Depletion region




Depletion region: region where free carriers (e, h) are depleted


Junction formation: depletion region (space charge region)



Junction formation: electric field in the space charge region




Junction formation (band diagram)




Applied Nanomaterials & Devices LAB.

## Chapter 5. Currents p-n Junctions

## Junctions under applied bias (voltage)




## Carrier distribution of p-n junction in ideal case



Applied Nanomaterials & Devices LAB.

## Fabrication process of p-n junction



# Chapter 8. Properties of the metal-oxide-silicon system

#### The ideal MOS structure

## Thermal-Equilibrium Energy-Band Diagram


The Fermi levels in the different materials are equalized by the transfer of negative charge from materials with higher Fermi levels (smaller work functions) across the interfaces to materials with lower Fermi levels (higher work functions).

\*The vacuum level is a continuous function of position

When the materials are **separated**, the various energies are indicated on the Figure 8.1

Aluminum (work function = 4.1 V), silicon dioxide (electron affinity ~0.95 V), uniformly doped p-type silicon (electron affinity = 4.05 V) having a work function of 4.9 V are considered.

The vacuum level is designated  $E_o$ ,



**FIGURE 8.1** Energy levels in three separated materials that form an MOS system: aluminum, thermally grown silicon dioxide, and p-type silicon containing  $N_a \approx 1.1 \times 10^{15}$  cm<sup>-3</sup>. (Note that there is considerable variation in tabulated values for work functions and electron affinities. Commonly used values are indicated.)

## The ideal MOS structure

#### Thermal-Equilibrium Energy-Band Diagram


#### As the materials are brought together,

Negative charge (electron) is transferred from the aluminum to the silicon to bring the system to equilibrium

because the work function of the metal is 0.8 eV less than the work function of the silicon

The insulator is incapable of transferring charge because it ideally possesses zero mobile charge, so a voltage drop appears across it because of the charge stored on either side.

There is a thin sheet of positive charge (a plane of charge in the ideal case of a perfect conductor) at the surface of the metal and negatively charged acceptors extending into the semiconductor from its



**FIGURE 8.2** Energy-band diagram at thermal equilibrium for an ideal MOS system composed of the materials indicated in Figure 8.1. The oxide and Si–SiO<sub>2</sub> interface are assumed to be ideal and free of charges.


#### Thermal-Equilibrium Energy-Band Diagram


#### As the materials are brought together,

Negative charge (electron) is transferred from the aluminum to the silicon to bring the system to equilibrium

In fact, if the system being considered were fabricated without any path for charge flow between the metal and the silicon other than through an ideal oxide, the materials could exist in a condition of nonequilibrium (i.e., with unequal Fermi levels) for long periods

However, nearly every MOS system of interest has some alternative path for the transfer of charge that is much more transmissive to charge flow than is the oxide; e.g., the aluminum gate electrode and the silicon substrate may be connected together, or an ohmic conducting path may exist between them.





**FIGURE 8.2** Energy-band diagram at thermal equilibrium for an ideal MOS system composed of the materials indicated in Figure 8.1. The oxide and Si–SiO<sub>2</sub> interface are assumed to be ideal and free of charges.

Polysilicon and Metals as Gate-electrode Materials

Because the surface condition of the silicon can be controlled by the metal electrode, the metal layer is usually called the *gate*, and the voltage on the metal is denoted by  $V_G$ .

Because the silicon is deposited over amorphous silicon dioxide, it is a polycrystalline film typically consisting of sub-micrometer-size crystallites.


A very high concentration of either *n-type* or *p-type* dopant is subsequently introduced into the polysilicon to make it sufficiently conducting to behave electrically like a metal

- One major advantage of polysilicon is its ability to withstand high-temperature thermal treatments
- primary drawback is the <u>high resistance of even heavily doped polysilicon</u> compared to that of a metal


Attempts to find attractive metals to replace polysilicon as the gate electrode are continuing

#### The Flat-Band Voltage

For the idealized MOS system at thermal equilibrium, the metal and the semiconductor form two plates of a capacitor.




The capacitor is charged to a voltage corresponding to the difference between the metal and semiconductor work functions



Negative voltage applied to the metal with respect to the silicon opposes the built-in voltage on the capacitor and tends to reduce the charge stored on the capacitor plates below its equilibrium value.

pulling positive holes toward the surface of the semiconductor to neutralize some of the negatively charged acceptors.



#### The Flat-Band Voltage

For the idealized MOS system at thermal equilibrium, the metal and the semiconductor form two plates of a capacitor.

The capacitor is charged to a voltage corresponding to the difference between the metal and semiconductor work functions




At one particular value, the applied voltage exactly compensates the difference in the work functions of the metal and the semiconductor.

The stored charge on the MOS capacitor is then reduced to zero, and the fields in the oxide and the semiconductor vanish



The voltage that produces flat energy bands in the silicon is called the flatband voltage and usually designated  $V_{FB}$ 



#### The Flat-Band Voltage

For the idealized MOS system at thermal equilibrium, the metal and the semiconductor form two plates of a capacitor.

The capacitor is charged to a voltage corresponding to the difference between the metal and semiconductor work functions

• The flat-band voltage varies with the <u>dopant density</u> in the <u>silicon</u>, as well as with <u>the specific metal(work function)</u> used for the MOS system

#### At the flat-band condition

→ MOS system is *not* at thermal equilibrium


The voltage applied to the ideal MOS system to bring it to the flat-band condition equals the difference in the work functions of the metal and the silicon.


$$V_{FB} = \Phi_M - \Phi_S = \Phi_{MS}$$


TABLE 8.1 Work Functions ( $\Phi_M$  and  $\Phi_s$ ) and Flat-Band Voltages for Commonly Used Gate Materials and p-Type Silicon with  $N_a=1.1\times10^{15}~{\rm cm}^{-3}$ .

Gate material parameter	Aluminum	<i>n</i> ⁺ polysilicon	<i>p</i> ⁺ polysilicon	Tungsten
$\Phi_M(V)$	4.1	4.05	5.17	4.61
$\Phi_s(V)$	4.9	4.9	4.9	4.9
V <sub>FB</sub> (V)	-0.8	-0.85	0.27	-0.29

Qualitative Description (nMOS)










"Accumulation"


# ② No bias $(V_G - V_{FR} = 0)$
















"Depletion"





Qualitative Description (nMOS)

#### "Accumulation"


If the silicon is held at ground and the voltage applied to the metal is negative but increases in magnitude above  $V_{FB}$ 

Additional positively charged holes are attracted toward the silicon surface, and the MOS capacitor begins to store positive charge there.

This positive charge is made up of an increase in the hole population at the surface, so the surface has a greater density of holes than  $N_a$  the acceptor density

Flat band

① Negative  $(V_G - V_{FB} < 0)$ 



Negative voltage applied to the metal plate



Excess positive carriers (holes) induced at the interface



**Energy bands bent upward** 



Increase of  $(E_i-E_F)$ 



**Enhanced hole concentration "Accumulation"** 

#### Qualitative Description (nMOS)


#### "Depletion"

The applied voltage gives rise to negative charge in the semiconductor by repelling holes from the surface to create the depletion region

If this built-in voltage is aided by applying a positive gate voltage between the metal and the silicon

The silicon becomes further depleted as more holes are repelled from its surface and more acceptors are exposed, the positive charge on the metal increases.

Because <u>mobile silicon charge is withdrawn</u> from the surface, this condition is called *surface depletion* 



Small positive voltage applied to the metal plate



**Energy band near the interface bent downward** 



Decrease of  $(E_i-E_F)$ 



The holes are depleted



"Depletion"

#### Qualitative Description (nMOS)

#### "Inversion"

The applied voltage gives rise to negative charge in the semiconductor by inducing electrons to form the inversion layer

If the Fermi level remains constant in the silicon while the energy bands bend as the applied voltage changes, at sufficiently high voltages the intrinsic Fermi level  $E_i$  at the silicon surface crosses the Fermi level corresponding to the silicon bulk.

the Fermi level is closer to the conduction- band edge than to the valence-band edge. In terms of carrier densities, this means that the applied voltage has created an *inversion layer*, so-called because the surface contains more electrons than holes, even though the silicon was doped with acceptor impurities.

Flat band

(V<sub>G</sub> - V<sub>FB</sub> >> 0)

M

O

p-type S

(+)  $E_C$   $E_C$   $E_F$   $E_V$ 

Larger positive voltage applied to the metal plate



**Energy band bent downward even more** 

$$p_{p} = n_{i}e^{\frac{(E_{i}-E_{F})}{kT}} < n_{i}$$

$$n_{p} = n_{i}e^{\frac{(E_{F}-E_{i})}{kT}} > n_{i}$$


Minority carrier  $(n_p)$  is greater than majority carrier  $(p_p)$  at the interface (semiconductor surface)



## Chapter 9. MOS Field-Effect Transistor

#### Operation of MOSFET (Gate voltage)


Flow of current (I<sub>D</sub>) from "Source" to "Drain" is controlled by the "Gate" and "Drain" voltages.



- Gate voltage modulate the conductivity of the semiconductor region just below the gate. → Channel
- Charge carrier in channel is electron  $\Rightarrow$  n-channel MOSFET (NMOS)
- Charge carrier in channel is hole ⇒ p-channel MOSFET (PMOS)

#### Operation of MOSFET (Gate voltage)

#### 1) Accumulation




Only holes are accumulated between the source and drain.


→ No current between source and drain


#### Operation of MOSFET (Gate voltage)

#### 2) Depletion

$$0 < V_G < V_T$$









Holes are depleted between the source and drain.

→ No current between source and drain

#### Operation of MOSFET (Gate voltage)

#### 3) Inversion






Inversion layer is formed between the source and drain.

→ Channel → Current flow between source and drain

#### Operation of MOSFET (Drain voltage)




Applied Nanomaterials & Devices LAB.

Operation of MOSFET (Drain voltage)

#### 1) Zero drain voltage ( $V_D = 0$ )


$$V_D = 0, V_G > V_T \longrightarrow I_D = 0$$



- Mobile electrons pile up at the interface between Si and SiO<sub>2</sub>.
- Higher gate bias : more electrons pile up  $\Rightarrow$  increase channel conductance
- Still, no current (very small) flows because no potential gradient exist

#### Operation of MOSFET (Drain voltage)

#### 2) Linear region ( $V_D > 0$ )




- Depletion width widen due to V<sub>DS</sub>.
- Further increase of  $V_D$   $\Rightarrow$  progressive reduction of the carrier concentration in the channel  $\Rightarrow$  decrease conductance of channel  $\Rightarrow$  slowly increase  $I_D$
- Increase of  $V_G \Rightarrow$  increase conductance of channel  $\Rightarrow$  Increase  $I_D$

Operation of MOSFET (Drain voltage)

3) Saturation region ( $V_D > V_{D, sat}$ )

$$V_D \ge V_{D, sat}$$
,  $V_G > V_T \longrightarrow I_D = saturation$ 



- Depletion width is further widen due to V<sub>DS</sub>.
- Slope of V<sub>D</sub>-I<sub>D</sub> is "zero"
- $V_D \ge V_{D, \text{ sat}}$  → "pinch off"

## Chapter 10. Optoelectronic Devices

### Optoelectronic (Photonic) devices

# Light-Emitting Diode (LED) Laser Diode (LD)

**Electrical energy** 




**Optical energy** 

**Photodetectors** 

Solar cells

#### Photodetector

Principle of photodetector: photoconductor/photodiode




#### Photodetector

#### 1) Photoconductor

Conductivity of semiconductors


$$\sigma = q(\mu_n n + \mu_p p)$$
 Shining light  $n$  and  $p$  increase  $\sigma$  increase




#### Photodetector

#### (2) Photodiode

Reverse biased p-n junction or metal-semiconductor junction





## End of Slide