

# BR500 and BR301BLE Bluetooth CCID Driver Install Manual

Made by: Feitian Technologies

# **Revision Sheet**

Release No.	Date	Revision Description
Rev 1. 0	26/7/16	Install Manual Created
Rev 1.1	20/3/18	Update driver and support new bR301BLE and bR500, which upgrade the Bluetooth module.

### **Software Developer's Agreement**

All Products of Feitian Technologies Co., Ltd. (Feitian) including, but not limited to, evaluation copies, diskettes, CD-ROMs, hardware and documentation, and all future orders, are subject to the terms of this Agreement. If you do not agree with the terms herein, please return the evaluation package to us, postage and insurance prepaid, within seven days of their receipt, and we will reimburse you the cost of the Product, less freight and reasonable handling charges.

- Allowable Use You may merge and link the Software with other programs for the sole purpose of
  protecting those programs in accordance with the usage described in the Developer's Guide. You
  may make archival copies of the Software.
- 2. Prohibited Use The Software or hardware or any other part of the Product may not be copied, reengineered, disassembled, decompiled, revised, enhanced or otherwise modified, except as specifically allowed in item 1. You may not reverse engineer the Software or any part of the product or attempt to discover the Software's source code. You may not use the magnetic or optical media included with the Product for the purposes of transferring or storing data that was not either an original part of the Product, or a Feitian provided enhancement or upgrade to the Product.
- 3. Warranty Feitian warrants that the hardware and Software storage media are substantially free from significant defects of workmanship or materials for a time period of twelve (12) months from the date of delivery of the Product to you.
- 4. Breach of Warranty In the event of breach of this warranty, Feitian's sole obligation is to replace or repair, at the discretion of Feitian, any Product free of charge. Any replaced Product becomes the property of Feitian.

Warranty claims must be made in writing to Feitian during the warranty period and within fourteen (14) days after the observation of the defect. All warranty claims must be accompanied by evidence of the defect that is deemed satisfactory by Feitian. Any Products that you return to Feitian, or a Feitian authorized distributor, must be sent with freight and insurance prepaid.

EXCEPT AS STATED ABOVE, THERE IS NO OTHER WARRANTY OR REPRESENTATION OF THE PRODUCT, EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.


5. Limitation of Feitian's Liability – Feitian's entire liability to you or any other party for any cause whatsoever, whether in contract or in tort, including negligence, shall not exceed the price you paid for the unit of the Product that caused the damages or are the subject of, or indirectly related to the cause of action. In no event shall Feitian be liable for any damages caused by your failure to meet your obligations, nor for any loss of data, profit or savings, or any other consequential and incidental damages, even if Feitian has been advised of the possibility of damages, or for any claim by you based on any third-party claim.



# **BR301BLE AND BR500 DRIVER INSTALL MANUAL**

# TABLE OF CONTENTS

	Page #
1.0 Preparatory work	1-1
1.0.1 Pair	1-1
1.0.2 Choose the right driver	1-2
1.0.2 Install Driver	1-3
1.0.3 Uninstall Driver	1-4



### 1.0 PREPARATORY WORK

The driver using for BR500 AND BR301BLE, they are using Bluetooth BLE 4.2 technology, to be make it work under Windows platform. Feitian made Windows Bluetooth driver for Windows 8 and 10, allow user using wireless connection on Windows platform.


The driver is CCID, PCSC compatible driver, if your application developed by PCSC or WINSCARD API, then you can be using Feitian BR301BLE and BR500 directly.

### 1.0.1 Pair

The BR301BLE and BR500 using Bluetooth 4.0 LE technology to build, the firmware is according with CCID protocol. To improve user experiences, we developed driver for Windows and allow user do communication on Windows wirelessly.

\*Before start using driver on windows, please check your computer/laptop support Bluetooth 4.0 LE technology.

To install driver, firstly, we need pair with on PC, open your Bluetooth or



## 1.0.2 Choose the right driver


After paired device to your Windows, please install below tool to check your reader version, currently, we released two versions, which upgrade the Bluetooth module, the old Bluetooth module stop production by the vendor.

How to check the reader Bluetooth version, follow below steps:

**Step 1:** Download application first:

https://www.microsoft.com/en-us/p/bluetooth-le-explorer/9n0ztkf1qd98

Step 2: Lunch the application, and Filter with "FT", click start




Step 3: check the UUID of your device, you can find the UUID from the below

If the UUID is 46540001-0002-00c6-0000-465453414645, then please choose **bR301LEDriver\_C6.exe**, if the UUID is 46540001-0002-00c4-0000-465453414645, then please choose **bR301LEDriver\_C4.exe** 



### 1.0.2 Install Driver


**Step #1**: Enter to driver folder, and running "BR301BLE\_AND\_BR500\_DRIVER\_RELEASE.exe", After your pair successful, then click YES to start install.



**Step #2**: Once your driver installs successful, you will found the driver list in your device manager, you can find WINSCARD demo or tool to test it. The second screenshot show you after insert card, you can do connect "FT BR301BLE 0" and power on to get card ATR.

### **Notice:**

If the card cannot detect by driver, please make sure your reader has connected to PC correctly and after disable driver and enable again.



### 1.0.3 Uninstall Driver

The step as 1.0.2, choose the uninstall button to uninstall.