

V1.1

Feitian Technologies Co., Ltd Website: www.FTsafe.com

Revision History:

Date	Revision	Description
Dec. 2014	V1.0	First release
Feb. 2016	V1.1	Second release

Software Developer's Agreement

All Products of Feitian Technologies Co., Ltd. (Feitian) including, but not limited to, evaluation copies, diskettes, CD-ROMs, hardware and documentation, and all future orders, are subject to the terms of this Agreement. If you do not agree with the terms herein, please return the evaluation package to us, postage and insurance prepaid, within seven days of their receipt, and we will reimburse you the cost of the Product, less freight and reasonable handling charges.

- 1. Allowable Use You may merge and link the Software with other programs for the sole purpose of protecting those programs in accordance with the usage described in the Developer's Guide. You may make archival copies of the Software.
- 2. Prohibited Use The Software or hardware or any other part of the Product may not be copied, reengineered, disassembled, decompiled, revised, enhanced or otherwise modified, except as specifically allowed in item 1. You may not reverse engineer the Software or any part of the product or attempt to discover the Software's source code. You may not use the magnetic or optical media included with the Product for the purposes of transferring or storing data that was not either an original part of the Product, or a Feitian provided enhancement or upgrade to the Product.
- 3. Warranty Feitian warrants that the hardware and Software storage media are substantially free from significant defects of workmanship or materials for a time period of twelve (12) months from the date of delivery of the Product to you.
- 4. Breach of Warranty In the event of breach of this warranty, Feitian's sole obligation is to replace or repair, at the discretion of Feitian, any Product free of charge. Any replaced Product becomes the property of Feitian.

Warranty claims must be made in writing to Feitian during the warranty period and within fourteen (14) days after the observation of the defect. All warranty claims must be accompanied by evidence of the defect that is deemed satisfactory by Feitian. Any Products that you return to Feitian, or a Feitian authorized distributor, must be sent with freight and insurance prepaid.

EXCEPT AS STATED ABOVE, THERE IS NO OTHER WARRANTY OR REPRESENTATION OF THE PRODUCT, EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

- 5. Limitation of Feitian's Liability Feitian's entire liability to you or any other party for any cause whatsoever, whether in contract or in tort, including negligence, shall not exceed the price you paid for the unit of the Product that caused the damages or are the subject of, or indirectly related to the cause of action. In no event shall Feitian be liable for any damages caused by your failure to meet your obligations, nor for any loss of data, profit or savings, or any other consequential and incidental damages, even if Feitian has been advised of the possibility of damages, or for any claim by you based on any third-party claim.
- 6. Termination This Agreement shall terminate if you fail to comply with the terms herein. Items 2, 3, 4 and 5 shall survive any termination of this Agreement.

1.	OVERVIEW OF ROCKEY301	I
	1.1 Product overview	
	1.2 PRODUCT FEATURE	
	1.3 TECHNIQUE SPECIFICATION	
	1.4 KEYWORDS	
	1.5 APPLICATIONS	
	1.6 SECURITY FEATURE	
	1.7 Extension and maintenance	
	1.8 Reliability	۱۱
	1.9 PRODUCT SHELL	
	1.10 Product Icon	
_		
2.	INTRODUCTION TO ROCKEY301	
	2.1 ROCKEY301 HARDWARE CONFIGURATION	VI
	2.2 USB2.0 Full Speed Communication	VI
	2.3 ROCKEY301 READER	VII
	2.3.1 Hardware Description	vii
	2.3.2 Software Environment	vii
	2.3.3 Precondition of Installation	vii
	2.3.4 Installing CCID Driver on Windows	
_		
	INSTALL/UNINSTALL CCID DRIVER IN LINUX AND MAC OS X	
4.	FREQUENTLY ASKED QUESTIONS AND SOLUTIONS	XIII
	4.1 WHY THERE IS NO "FOUND NEW HARDWARE" POPUP WINDOW WHEN I ATTACH A ROCKEY301 READER?	XIII
	4.2 WHY IT SHOWS "CONNECT READER TO PC!" WHEN I DOUBLE-CLICKED ROCKEY301.UPDATE?	XIII
	4.3 LIGHT IS OFF	XIII
	A A LICHT IS FLASHING WHEN NO CARD IS IN CARD READED.	

ΑP	PENDIX ABBREVIATION	. X\
	4.6 Blue light is flashing when a card is inserted in the card reader	XI\
	4.5 DECE LIGHT IS I EASTHING TREQUERTED WHEN TO CARD IS IN CARD READER.	
	4.5 Blue light is flashing frequently when no card is in card reader	ΧI

1. Overview of ROCKEY301

This chapter introduces the basic concept, technique specification and product features of the ROCKEY301 reader.

1.1 Product overview

ROCKEY301 reader is a kind of high-speed contact smart card reader, which is used for PC environment or relevant smart card environment. It is compliant with standard CCID specification and USB 2.0 interface (also the USB 1.1 interface). The ROCKEY301 reader can operate all CLASS A, CLASS B and CLASS C smart cards which are compliant with ISO 7816-1/2/3. The standard size IC card which is compliant with ISO 7816-3 can be supported stably as well. As the mandatory processing device of smart card integrated systems, ROCKEY301 reader can greatly increase the security of the whole application. It can be widely used in financial, social security, telecom, online banking, e-business, authentication, e-government and other CPU based high level security card application fields.

1.2 Product feature

- Support USB 2.0 interface
- Compiled standard CCID specification
- Read/Write all CLASS A, CLASS B and CLASS C smart cards which are compliant with ISO 7816-1/2/3 T=0
 and T=1
- For contact card, support full parameter PPS protocol. The ICC data transfer Baud rate is 344K (The result is got when the frequency of IC card is 4MHz-12MHz)
- Short circuit protection
- Be compliance with ISO7816, IEC/EN60950, EMV 2000 Level
- Power supply: 1.8V/3V/5V (independent control), LDO provides stable 1.8V/3V power
- Data transfer speed: For T=0 and T=1, Baud rate is 10.753k ~ 344K (The result is got when the frequency of IC card is 4MHz-12MHz) (D=32/F=372)

1.3 Technique specification

Table 1 ROCKEY301 technique specification

Interface type	USB 2.0 interface						
Power supply	USB port 5VDC						
Working current	<50mA without card plugged						
Working	$0^{\circ}\text{C}\sim 60~^{\circ}\text{C}$						
temperature							
Storage	- 20°C ∼ 85°C						
temperature							
Humidity	≤90%(non-condensed)						
Slot	ISO7816-3 standard slot						
5101	>100,000 times plug/unplug						
Protection	Short circuit protection						
	ISO/IEC7816, T=0 and T=1 protocol						
CPU card	Data transfer speed: 10753~344086 bps						
CPO Card	Power supply 1.8V, 3V and 5V						
	Frequency of Card: 4-12(MHz)						
Sizo(mm)	B5: 75.5 *22*8.7	C11: 67 *57.5 *12.5	C41:	C25: 74 *56			
Size(mm)			120*80*76mm	*11			
material	B5: ABS+PC	C11: ABS+PC	C41: ABS+PC+	C25: ABS+PC			
materiai			Metal				
Weight	34g	50g	281.96g	46.7g			
Standard and ISO-7816 Class A, B, C (5V, 3V,1.8V)、CCID、EN 60950/IEC 60950、CE、FCC							
specification Microsoft WHQL 2K\ XP\ RoHS Compliant\ EMV 2000 Level 1							

1.4 Keywords

ROCKEY301 Reader keywords

Contact

Reader

Full speed USB device

ISO7816

CCID

T0

T1

1.5 Applications

ROCKEY301 reader is a kind of high-speed contact smart card reader, which is used for PC environment or relevant smart card environment. It is compliant with standard CCID specification and USB 2.0 interface. The ROCKEY301 reader can operate all type A, type B and type C smart cards which are compliant with ISO 7816-1/2/3. The standard size IC card which is compliant with ISO 7816-3 can be supported stably as well. As the mandatory processing device of smart card integrated systems, ROCKEY301 reader can greatly increase the security of the whole application. It can be widely used in financial, social security, telecom, online banking, e-business, authentication, e-government and other CPU based high level security card application fields.

1.6 Security feature

- 1) firmware cannot be read out. Anti-reverse analysis
- 2) Short circuit protection and overcurrent protection
- 3) Do not contain any users' sensitive data in product, such as password.
- 4) PCB board has a 5mm distance with reader shell.

1.7 Extension and maintenance

- 1) Product can be extended and disassembled.
- 2) Firmware can be extended, customized and updated.

1.8 Reliability

- 1) 100,000 times plug/unplug. The period of hardware usable is at least 5 years.
- 2) Frequently read/write 200 times will not lead the system down or error.
- 3) Continuously using 48 hours will not lead error occurrence rate exceed 3%.

1.9 Product shell

Rockey301 reader is a kind of high-speed contact smart card reader, which is used for PC environment or relevant smart card environment. Product shell is using C25 by default. It contains a big slot so that can also be used with C41 and B6 shell.

The casing picture see below:

C11, with full size card slot and SIM card slot:



C25 with full size card slot only:



B5 with SIM Card slot only:



C41 with full size card slot only:



1.10 Product Icon

Operating System: Windows 2000 (SP4)、2003Server、XP (SP2、SP3)、2008 Server、Windows®Vista, Windows 7 , Windows CE, Linux®。

Product certifications: CE 、 FCC



2. Introduction to ROCKEY301

ROCKEY301 is a professional reader for contact IC card. It is used for various IC card applications.

This chapter introduces ROCKEY301 comprehensively.

2.1 ROCKEY301 Hardware Configuration

ROCKEY301 provides the following hardware configuration for users.

Card slot interface: USB2.0, Full speed is up to 12MHz Card slot support one full size IC card

ROCKEY301 uses operating system's CCID driver which can be got from OS provider. This manual takes Windows XP for example to introduce how to install CCID driver.

2.2 USB2.0 Full Speed Communication

ROCKEY301 is USB2.0 full speed device. Before installing the driver, you need to connect the reader to the computer according to the figure below.




Figure 1 USB Connection

After connection, we can start to install the driver for ROCKEY301.

2.3 ROCKEY301 Reader

2.3.1 Hardware Description

- Support 1 big size card
- PC/SC device
- 1.5m USB cable
- Red/Blue LED

2.3.2 Software Environment

- 1). CCID driver
- 2). Supported systems:
- Windows 2000(SP4)
- Windows 2003 Server
- Windows XP(SP2、SP3)
- Windows 2008 server
- Windows Vista
- Windows 7
- Windows 8
- Windows 81
- Windows 10
- Windows 2012server
- Linux® (FC7、ubuntu7.1、AS4 and more)
- MacOS® (Mac 10.4 or above)

2.3.3 Precondition of Installation

Before installation the driver for ROCKEY301, please confirm to meet the following requirements:

- The OS is supported by ROCKEY301
- The setting of BIOS supports USB device
- 1.5m USB cable
- ROCKEY301 reader

2.3.4 Installing CCID Driver on Windows

^{*}CCID driver for XP -> http://download.ftsafe.com/files/reader/CCID driver on Windows2000+.zip

^{*}Below just describe install driver on Windows, for Vista+, customer don't need install driver, the driver already

integrated into Windows system.

1. Connect ROCKEY301 according to figure 1. The system will find the new hardware and the following interface appears. Select "Install from a list or specific location (Advanced)" and click "Next" button.



Figure 2 Found New Hardware Wizard

2. The following interface appears as Figure 3 shown below. Click "Browse" button.



Figure 3 Searching Driver

3. After clicking "Browse" button, the following interface appears. Please select the folder that the CCID driver is in and click "OK" button.



Figure 4 Chose CCID Driver

4. Click "Next" button as shown in Figure 3 and then the system starts to install the driver.



Figure 5 Installing

5. Installation is finished.



Figure 6 The End of Installation

6. After installation, ROCKEY301 can be found in "Device Manager" as shown below.



Figure 7 ROCKEY301 in Device List

3. Install/Uninstall CCID driver in Linux and Mac OS X

*Please confirm your computer has installed the latest CCID and PCSC Lite.

For Linux, the default CCID driver will be install on linux, if your system has installed CCID driver, then can using R301 directly, because R301 has add support in CCID support list.

For MAC, after MAC OS 10.4.X, the mac system can using Feitian R301 directly.

If your computer hasn't install CCID driver, then you will follow CCID official website to do install, more information, please check http://pcsclite.alioth.debian.org/ccid.html

4. Frequently asked questions and solutions

4.1 Why there is no "found new hardware" popup window when I attach a ROCKEY301 reader?

Symptom: After attached ROCKEY301 reader, there is no "found new hardware" popup window.

Solution: Right click "My Computer" -> "Device Manager" -> "Smart card readers", right click "update driver", use "hardware update wizard" to update hardware.

4.2 Why it shows "Connect Reader to PC!" when I double-clicked ROCKEY301.Update?

Symptom: Double-click "ROCKEY301.Update.exe" and shows "Connect Reader to PC!".

Solution: Please remove the ROCKEY301 reader and re-attach it again.

4.3 Light is off

Symptom: The device light is off. The device may not be correctly connected.

Solution:

Re-attach the device;

Check the USB connection line.

4.4 Light is flashing when no card is in card reader

Symptom: The device is broken.

Solution: Return this device to manufacturer for repairing.

4.5 Blue light is flashing frequently when no card is in card reader

Symptom: Blue light is flashing with frequent 4Hz. This means the checksum of the firmware is wrong.

Solution: Please update the firmware or return the device to manufacturer.

4.6 Blue light is flashing when a card is inserted in the card reader

Symptom: Blue light is flashing when a card is inserted in the card reader. The card is unusable.

Solution:

Insert the card again with another side;

The card is not compatible with the ISO-7816 (e.g., timeout, byte intervals);

The card is not compatible with the power supply.

The output current of the card is too weak to be recognized by the card reader.

The card is damaged.

The device is damaged and need to be return to manufacturer.

Appendix Abbreviation

CE Attestation of Conformity



The equipment complies with the principal protection requirement of the EMC Directive (Directive 89/336/EEC relating to electromagnetic compatibility) based on a voluntary test.

This attestation applies only to the particular sample of the product and its technical documentation provided for testing and certification.

After preparation of the necessary technical documentation as well as the conformitydeclaration the CE marking as shown below can be affixed on the equipment as stipulated Article 10.1 of the Directive. Other relevant Directives have to be observed.

FCC certificate of approval



This Device is conformance with Part 15 of the FCC Rules and Regulations for Information Technology Equipment.

WEEE



Dispose in separate collection.

RoHS

