EECE 2322: Fundamentals of Digital Design and Computer Organization Lecture 6_3: MIPS ISA

Xiaolin Xu Department of ECE Northeastern University

Operands: Registers

- Registers:
 - \$ before name
 - Example: \$0, "register zero", "dollar zero"
- Registers used for specific purposes:
 - \$0 always holds the constant value 0.
 - the *saved registers*, \$s0-\$s7, used to hold variables
 - the *temporary registers*, \$t0 \$t9, used to hold intermediate values during a larger computation
 - Discuss others later

MIPS Register Set

Name	Register Number	Usage					
\$0	0	the constant value 0					
\$at	1	assembler temporary					
\$v0-\$v1	2-3	Function return values					
\$a0-\$a3	4-7	Function arguments					
\$t0-\$t7	8-15	temporaries					
\$s0-\$s7	16-23	saved variables					
\$t8-\$t9	24-25	more temporaries					
\$k0-\$k1	26-27	OS temporaries					
\$gp	28	global pointer					
\$sp	29	stack pointer					
\$fp	30	frame pointer					
\$ra	31	Function return address					

Instructions with Registers

* Revisit add instruction

C Code

$$a = b + c$$

MIPS assembly code

Instructions with Registers

* Revisit add instruction

C Code

$$a = b + c$$

MIPS assembly code

$$\#$$
 \$s0 = a, \$s1 = b, \$s2 = c add \$s0, \$s1, \$s2

From High-level Code to Assembly Language

C Code

$$a = b + c;$$

 $f = (g + h) - (i + j)$

MIPS assembly code

assuming that a-to-c are stored in \$s0to-\$s2, f-to-j are stored in \$s3-to-\$s7

$$\#$$
 \$s0 = a, \$s1 = b, \$s2 = c, \$s3 = f, \$s4 = g, \$s5 = h $\#$ \$s6 = i, \$s7 = j

How to convert the C code to assembly code?

#a=b-c #\$t0=g+h #\$t1=i+j #f=(g+h)-(i+j)

From High-level Code to Assembly Language

C Code

$$a = b + c;$$

 $f = (g + h) - (i + j)$

MIPS assembly code

assuming that a-to-c are stored in \$s0to-\$s2, f-to-j are stored in \$s3-to-\$s7

$$\#$$
 \$s0 = a, \$s1 = b, \$s2 = c, \$s3 = f, \$s4 = g, \$s5 = h $\#$ \$s6 = i, \$s7 = j

How to convert the C code to assembly code?

MIPS Instructions: Arithmetic

Instruction	Example	Meaning	Comments
add	add \$1,\$2,\$3	\$1=\$2+\$3	
subtract	sub \$1,\$2,\$3	\$1=\$2-\$3	
add immediate	addi \$1,\$2,100	\$1=\$2+100	"Immediate" means a constant number
add unsigned	addu \$1,\$2,\$3	\$1=\$2+\$3	Values are treated as unsigned integers, not two's complement integers
subtract unsigned	subu \$1,\$2,\$3	\$1=\$2-\$3	Values are treated as unsigned integers, not two's complement integers

EECE2322 Xiaolin Xu

MIPS Instructions: Arithmetic

add immediate unsigned	addiu \$1,\$2,100	\$1=\$2+100	Values are treated as unsigned integers, not two's complement integers
Multiply (without overflow)	mul \$1,\$2,\$3	\$1=\$2*\$3	Result is only 32 bits!
Multiply	mult \$2,\$3	\$hi,\$low=\$2*\$3	Upper 32 bits stored in special register hi Lower 32 bits stored in special register 10
Divide	div \$2,\$3	\$hi,\$low=\$2/\$3	Remainder stored in special register hi Quotient stored in special registerlo

MIPS Instructions: Logical

Instruction	Example	Meaning	Comments
and	and \$1,\$2,\$3	\$1=\$2&\$3	Bitwise AND
or	or \$1,\$2,\$3	\$1=\$2 \$3	Bitwise OR
and immediate	andi \$1,\$2,100	\$1=\$2&100	Bitwise AND with immediate value
or immediate	or \$1,\$2,100	\$1=\$2 100	Bitwise OR with immediate value
shift left logical	sll \$1,\$2,10	\$1=\$2<<10	Shift left by constant number of bits

shift right logical

\$1=\$2>>10

srl \$1,\$2,10

Shift right by constant number of bits

MIPS Instructions: Data Transfer

Instruction	Example	Meaning	Comments
load word	lw \$1,100(\$2)	\$1=Memory[\$2+100]	Copy from memory to register
store word	sw \$1,100(\$2)	Memory[\$2+100]=\$1	Copy from register to memory
load upper immediate	lui \$1,100	\$1=100x2 ^1 6	Load constant into upper 16 bits. Lower 16 bits are set to zero.
load address	la \$1,label	\$1=Address of label	Pseudo-instruction (provided by assembler, not processor!) Loads computed address of label (not its contents) into register
load immediate	li \$1,100	\$1=100	Pseudo-instruction (provided by assembler, not processor!) Loads immediate value into register
(H / S / /			X T/A/AITA

EECE2322 Alaoin Xu

MIPS Instructions: Data Transfer

move from hi	mfhi \$2	\$2=hi	Copy from special register hi to general register
move from lo	mflo \$2	\$2=lo	Copy from special register 10 to general register
move	move \$1,\$2	\$1=\$2	Pseudo-instruction (provided by assembler, not processor!) Copy from register to register.

MIPS Instructions: Others

- * See reference: https://www.dsi.unive.it/~gasparetto/ materials/MIPS_Instruction_Set.pdf
- Un/Conditional Branch: enabling if-else, etc.
- System call: print/read/exit, etc.

Operands: Memory

- * Too much data to fit in only 32 registers
- * Store more data in memory
 - * However, Memory is large, but slow
- Commonly used variables kept in registers

Word-Addressable Memory

• Each 32-bit data word has a unique address

Word Address	Data								
•	•						•		
•	•						•		
•				•					•
0000003	4	0	F	3	0	7	8	8	Word 3
0000002	0	1	Ε	Ε	2	8	4	2	Word 2
0000001	F	2	F	1	Α	С	0	7	Word 1
0000000	Α	В	С	D	Ε	F	7	8	Word 0
0000001	F	2	F	1	A	С	0	7	Word

Reading Word-Addressable Memory

- Memory read called *load*
- Mnemonic: load word (lw)
- Format:

```
lw $s0, 5($t1)
```

- Address calculation:
 - add base address (\$t1) to the offset (5)
 - address = (\$t1 + 5)
- Result:
 - \$s0 holds the value at address (\$t1 + 5)

Any register may be used as base address

Reading Word-Addressable Memory

- Example: read a word of data at memory address 1 into \$s3
 - address = (\$0 + 1) = 1
 - -\$s3 = 0xF2F1AC07 after load

Assembly code

lw \$s3, 1(\$0) # read memory word 1 into \$s3

Word Address				Da	ta				
•	•						•		
•		•						•	
•									•
0000003	4	0	F	3	0	7	8	8	Word 3
00000002	0	1	Ε	Ε	2	8	4	2	Word 2
0000001	F	2	F	1	Α	С	0	7	Word 1
00000000	Α	В	С	D	Ε	F	7	8	Word 0

Writing Word-Addressable Memory

- Memory write are called store
- Mnemonic: store word (sw)

Writing Word-Addressable Memory


- Example: Write (store) the value in \$t4 into memory address 7
 - add the base address (\$0) to the offset (0x7)
 - address: (\$0 + 0x7) = 7

Offset can be written in decimal (default) or hexadecimal


Assembly code

Byte-Addressable Memory

- Each data byte has unique address
- Load/store words or single bytes: load byte (1b) and store byte (sb)
- 32-bit word = 4 bytes, so word address increments by 4



Word/Byte-Addressable Memory



Reading Byte-Addressable Memory


- The address of a memory word must now be multiplied by 4. For example,
 - the address of memory word 2 is $2 \times 4 = 8$
 - the address of memory word 10 is $10 \times 4 = 40$ (0x28)
- MIPS is byte-addressed, not word-addressed

Reading Byte-Addressable Memory

- Example: Load a word of data at memory address 4 into \$s3.
- \$s3 holds the value ___? after load

MIPS assembly code

lw \$s3, 4(\$0) # read word at address 4 into \$s3




Reading Byte-Addressable Memory

- Example: Load a word of data at memory address 4 into \$s3.
- \$s3 holds the value 0xF2F1AC07 after load

MIPS assembly code

lw \$s3, 4(\$0) # read word at address 4 into \$s3




Writing Byte-Addressable Memory

• Example: stores the value held in \$\pm 7\$ into memory address 0x2C (44)

MIPS assembly code

sw \$t7, 44(\$0) # write \$t7 into address 44




Writing Byte-Addressable Memory

• Example: stores the value held in \$\pm 7\$ into memory address 0x2C (44)


MIPS assembly code

sw \$t7, 44(\$0) # write \$t7 into address 44

where is address 44?



Practice: Reading/Writing Byte-addressable Memory




MIPS assembly code

```
lw $s0, 0($0)
lw $s1, 8($0)
lw $s2, OxC($0)
sw $s3, 4($0)
sw $s4, 0x20($0)
sw $s5, 400($0)
```

MIPS assembly code

```
# read data word ______ into $s0
# read data word _____ into $s1
# read data word _____ into $s2
# write $s3 to data word ____?
# write $s4 to data word ____?
# write $s5 to data word ____?
```

Practice: Reading/Writing Byte-addressable Memory



MIPS assembly code

```
lw $s0, 0($0)
lw $s1, 8($0)
lw $s2, OxC($0)
sw $s3, 4($0)
sw $s4, Ox20($0)
sw $s5, 400($0)
```

MIPS assembly code

```
# read data word 0 (0xABCDEF78) into $s0
# read data word 2 (0x01EE2842) into $s1
# read data word 3 (0x40F30788) into $s2
# write $s3 to data word 1
# write $s4 to data word 8
# write $s5 to data word 100
```

Problematic/Illegal Usage

* Why?

MIPS assembly code

lw \$s0, 7 (\$0)

Problematic/Illegal Usage

* Why?

MIPS assembly code

lw \$s0, 7 (\$0)

In the MIPS architecture, word addresses for lw and sw must be word aligned. That is, the address must be divisible by 4