

# Keyboard


黄元豪 Yuan-Hao Huang

國立清華大學電機工程學系 Department of Electrical Engineering National Tsing-Hua University

#### USB HID Host (1/3)


THE STATE OF THE S

HID: Human Interface Device




### USB HID Host (2/3)





#### USB HID Host (3/3)





### Microchip PIC24FJ128




- Configuration mode
  - Download a bit-stream to the FPGA.

- Application mode
  - In Basys 3, this is called USB HID Host mode.
  - Only a single mouse or a single keyboard can be used.
  - PS2\_CLK and PS2\_DATA are used to implement a standard PS/2 interface.

#### **HID Controller**






Symbol	Parameter	Min	Max
$T_{CK}$	Clock time	30 us	50 us
$T_{SU}$	Data-to-clock setup time	5 us	25 us
$T_{HLD}$	Clock-to-data hold time	5 us	25us

#### Initialization

- Initially, Basys3 identifies the devices through PS2\_CLK and PS2\_DATA.
- When Basys3 is idled (unconnected), Basys3 reads 0xFA using a Read ID command.
- When a keyboard or mouse is connected to the Basys3, a "self-test passed" command (0xAA) is sent to the Basys3.
  - $-0xFA \rightarrow 0xAA$
- Scancode of keyboard
  - Each key is assigned a code
  - If the key is held down, the scan code will be sent repeatedly about once every 100ms.
  - When a key is released, an F0 key-up code is sent, followed by the scan code of the released key.
  - Some keys (right Ctrl, right Alt, ...), called extended keys, send an E0 ahead of the scan code.

### PS/2 Port





#### Example PC compatible (IBM PS/2) scancodes

kov	set 1 (IBM PC XT)		set 2 (IBM PC AT)		set 3 (IBM 3270 PC)	
key	press	release	press	release	press	release
A (normal letter)	1E	9E	10	F0 1C	1C	FØ 1C
Return / Enter (main keyboard)	1C	9C	5A	F0 5A	5A	FØ 5A
Enter (numeric keypad)	E0 1C	E0 9C	E0 5A	E0 F0 5A	79	F0 79
Left Windows key	EØ 5B	EØ DB	E0 1F	E0 F0 1F	8B	FØ 8B
Right Windows key	E0 5C	EØ DC	E0 27	E0 F0 27	8C	FØ 8C


from Wiki

#### PS/2 Scancode



<b>Extend Code</b>	Break Code	Make code	
E0	F0	XX	

(means "release")



We only use the yellow parts of the keyboard.

# PS/2 Scancode (Example)




L Alt press			11
L Alt release		F0	11
R Alt press	E0		11
R Alt release	E0	F0	11


ESC 76		F5 03 0B F7 0A 0A		E012E07C E11477E1  (Prt Scr L) (Pause Brk)	F014F077
(i) (1) (1) (1) (1) (1) (1) (1) (1) (1) (1	! (2@) (3#) (4\$) (5%) (2E)	6 <sup>^</sup> (7& 8 * 3E (9 ( 0 ) 45 (46 (45 )	- +=  \lambda \\ 4E \big(55) \big(5D) \big(\dagger) \\ 66	Ins E070 Home E06C P Up E07D	Num / * * C
TAB 0D	Q W E R 2D 2	$\begin{array}{cccccccccccccccccccccccccccccccccccc$	P [{ 54 }] 5B	Del End P Dn E069	7 6C 75 7D +
Caps 58	A S D F 23 2B	G H J K L 4B	) (1		4 5 6 74 79
Shift 12	$ \begin{array}{c c} Z & X & C & V \\ 1A & 22 & 21 & 24 \end{array} $		> . ? / Shift 59	↑ E075	1 2 3 7A Enter
Ctrl 14	Alt 11	SPACE 29	Alt Ctrl E0 14	← ↓ → E072 ← E074	0 70 71 E05A

# Verilog Module: KeyboardCtrl(1/2)

- In Keyboard-Controller
  - Ps2Interface.v
  - KeyboardCtrl.v
- KeyboardCtrl.v
  - Input: PS2\_CLK, PS2\_DATA, rst, clk
  - Output: key\_in, is\_extend, is\_break, valid, err




# Verilog Module: KeyboardCtrl(1/2)




# KeyboardCtrl (Output Example 1)

#### LAlt press




# KeyboardCtrl (Output Example 2)

#### L Alt release




# KeyboardCtrl (Output Example 3)

#### R Alt press



# KeyboardCtrl (Output Example 4)


#### R Alt release



# Verilog Module: KeyboardDecoder (1/5)


- In Keyboard Sample Code
  - KeyboardDecoder.v
- I/O for KeyboardDecoder
  - Input: PS2\_CLK, PS2\_DATA, rst, clk
  - Output : key\_down, last\_change, Key\_valid

# Verilog Module: KeyboardDecoder (2/5)



# Verilog Module: KeyboardDecoder (3/5)


- last\_change: 9 bits
  - represent the key which has been pressed or released.



- key\_valid: 1 bit
  - should be active for one clock period (100MHz) when any key is pressed or released.

# Verilog Module: KeyboardDecoder (4/5)

• key\_down [511:0] are status bits. Each bit indicates pressed (1) or released (0) of each button of the keyboard.



- the key indexed by "0\_0100\_0000" is pressed.
- the key indexed by "0\_0100\_0001" is released.

### Verilog Module: KeyboardDecoder (5/5)

- key\_down [511:0]
- key\_down <= key\_down | key\_decode;</li>


	0	1	1	1	1	
or	0	0	0	1	0	
	0	1	1	0	1	

key\_down <= key\_down & (~key\_decode);</li>

	0	1	0	0	1
and	1	1	0	1	1
	0	1	1	0	1


#### How to Use IP (1/3)





#### How to Use IP (2/3)





### How to Use IP (3/3)



