
# Reservoir Inflow Behaviour

November 1, 2021

- 1 Production Engineering
- 2 Reservoir Inflow Behaviour



## 3 Import Python Libraries

```
[1]: import pandas as pd
import numpy as np
import matplotlib.pyplot as plt
import seaborn as sns
```

[2]: %config Completer.use\_jedi = False

## 4 Important Functions

$$q_o = \frac{k_{oh(P_r - Pwf)}}{141.2\beta_o \mu_o \left( \ln \frac{r_e}{r_w} - 0.75 + S \right)}$$

## 4.1 Productivity Index Taking into account Petrophysical and Fluid Properties

$$J = \frac{K_o h}{141.2 B_o u_o (\ln \frac{r_e}{r_w} - 0.75 + s)}$$

#### Where:

*J:* Productivity Index (bpd/psi)

 $K_o$ : Effective permeablity (md)

*h:* Thickness (ft)

 $B_o$ : Oil Formation Volume Factor (rb/stb)

 $u_o$ : Oil Viscosity (cp)

 $r_e$ : Drainage ratio (ft)

 $r_w$ : Well ratio (ft)

s: Skin

```
[3]: # Productivity Index (darcy law)
def J_darcy(ko, h, bo, uo, re, rw, s, flow_regime = 'seudocontinuo'):
    if flow_regime == 'seudocontinuo':
        J = ko * h / (141.2 * bo * uo * (np.log(re / rw) - 0.75 + s))
    elif flow_regime == 'continuo':
        J = ko * h / (141.2 * bo * uo * (np.log(re / rw) + s))
    return J
```

## 4.2 Productivity Index with productivity test data

$$J = \frac{Q_o}{P_r - Pwf}$$

### Where:

J: Productivity Index (bpd/psi)

 $Q_o$ : Oil Flow Rate (bpd)

 $P_r$ : Reservoir Pressure (psia)

*Pwf:* Pressure Well Flowing (psia)

```
[4]: # Productivity Index
def J(q_test, pwf_test, pr, pb):
    if pwf_test > pb:
        J = q_test / (pr - pwf_test)
    else:
        J = q_test / ((pr - pb) + (pb / 1.8) * (1 - 0.2 * (pwf_test / pb) - 0.8
        * (pwf_test / pb)**2))
    return J
```

### 4.3 Oil Flow Rate at Bubble Point

$$Q_b = I(P_r - P_b)$$

#### Where:

*Q<sub>b</sub>*: Oil Flow Rate at Bubble Point (bpd)

*J:* Productivity Index (bpd/psi)

 $P_r$ : Reservoir Pressure (psia)

*P<sub>b</sub>*: Bubble Point Pressue

```
[5]: # Q(bpd) @ Pb

def Qb(q_test, pwf_test, pr, pb):
    qb = J(q_test, pwf_test, pr, pb) * (pr - pb)
    return qb
```

#### 4.4 AOF at different conditions

If  $P_r > P_b$  -> The oil reservoir is **UNDERSATURATED**:

At this case, there are 2 conditions:

- If 
$$Pwf >= P_b$$
:

$$AOF = IP_r$$

Otherwise,

$$AOF = Q_b + \frac{JP_b}{1.8}$$

On the other hand, if  $P_r \ll P_b \gg$  The oil reservoir is **SATURATED:** 

At this situation:

$$AOF = \frac{Qo_{test}}{1 - 0.2(\frac{Pwf_{test}}{P_r}) - 0.8(\frac{Pwf_{test}}{P_r})^2}$$

#### Where:

AOF: Absolute Open Flow (bpd)

*Q<sub>b</sub>*: Oil Flow Rate at Bubble Point (bpd) *J*: Productivity Index (bpd/psi)

 $P_r$ : Reservoir Pressure (psia)

*P<sub>h</sub>*: Bubble Point Pressue

Pwf: Pressure Well Flowing (psia)

Pwftest: Pressure Well Flowing of productity test (psia)

*Qo<sub>test</sub>*: Oil Flow Rate of productivity test (bpd)

## **4.5** $Q_o$ at Different Conditions

Here, it is assumed that FE (Flow Efficiency) = 100% by using Vogel's statements.

If  $P_r > P_b$  -> The oil reservoir is **UNDERSATURATED**:

At this case, there are 2 conditions:

- If 
$$Pwf >= P_b$$
:

$$Q_o = J(P_r - Pwf)$$

Otherwise,

$$Q_o = Q_b + \frac{JP_b}{1.8}(1 - 0.2(\frac{Pwf}{P_b}) - 0.8(\frac{Pwf}{P_b})^2)$$

On the other hand, if  $P_r \ll P_b \gg T$  The oil reservoir is **SATURATED**:

At this situation:

$$Q_o = AOF(1 - 0.2(\frac{Pwf}{P_h}) - 0.8(\frac{Pwf}{P_h})^2)$$

#### Where:

 $Q_o$ : Oil Flow Rate of productivity test (bpd)

*AOF:* Absolute Open Flow (bpd)

*Q<sub>b</sub>*: Oil Flow Rate at Bubble Point (bpd) *J*: Productivity Index (bpd/psi)

 $P_r$ : Reservoir Pressure (psia)

*P<sub>h</sub>*: Bubble Point Pressue

Pwf: Pressure Well Flowing (psia)

```
[7]: #Qo(bpd) @ vogel conditions
def qo_vogel(q_test, pwf_test, pr, pwf, pb):
    if pr > pb: # Yac. subsaturado
```

## 4.6 Ejercicio 1

```
[8]: # Data
ko = 8.2 #md
h = 53 #ft
bo = 1.2 #rb/stb
uo = 1.2 #cp
re = 2978.4 # ft
rw = 0.328 # ft
s = 0
pr = 5651 #psia
```

### 4.6.1 a) J

```
[9]: J_darcy = J_darcy(ko, h, bo, uo, re, rw, s)
print(f"J -> {J_darcy} bpd/psia")
```

J -> 0.25555511281513077 bpd/psia

### 4.6.2 AOF

```
[10]: AOF = J_darcy * pr
print(f"AOF -> {AOF} bpd")
```


AOF -> 1444.141942518304 bpd

### 4.7 Ejercicio 2

```
[11]: # Data
pr = 2400 #psia
pb = 2500 #psia
pwf = 1000 #psia
q_test = 100 #stb/d
pwf_test = 1800 #psia
```

#### 4.7.1 a) AOF

```
[12]: AOF = aof(q_test, pwf_test, pr, pb, pwf)
      print(f"AOF -> {AOF} bpd")
     AOF -> 250.0000000000000 bpd
     4.7.2 b) IPR Curve
[13]: # Creating Dataframe
      df = pd.DataFrame()
      df['Pwf(psia)'] = np.array([2400, 2000, 1500, 1000, 500, 0])
      df['Qo(bpd)'] = df['Pwf(psia)'].apply(lambda x: qo_vogel(q_test, pwf_test, pr,__
       \rightarrowx, pb))
[14]: df
[14]:
         Pwf(psia)
                       Qo(bpd)
              2400
                      0.000000
      0
      1
              2000
                     69.44444
      2
              1500 140.625000
      3
              1000 194.44444
      4
               500 230.902778
                 0 250.000000
[15]: # Plot
      fig, ax = plt.subplots(figsize=(18, 8))
      ax.plot(df['Qo(bpd)'], df['Pwf(psia)'], c='red')
      ax.set_xlabel('Qo(bpd)')
      ax.set_ylabel('Pwf(psia)')
      ax.set_title('IPR')
      ax.set(xlim=(0, df['Qo(bpd)'].max() + 10), ylim=(0, df['Pwf(psia)'][0] + 100))
      ax.grid()
      plt.show()
```



## 4.8 Ejercicio 3

```
[16]: # Data
    pr = 120 #bar
    pb = 65 #bar
    q_test = 400 #m3/d
    pwf_test = 100 #bar
    pwf = 40 #bar
```

## 4.8.1 Qo @ Pwf=40 bar

## 4.9 Ejercicio 4

```
[18]:  # Data

pr = 4000 #psi

pb = 3000 #psi

qo_test = 600 #bpd

pwf_test = 2000 #bpd
```

- 4.9.1 a) Qmax
- 4.9.2 b) Qo @ Pwf = 3500 psi
- 4.9.3 c) Qo @ Pwf = 1000 psi
- 4.9.4 d) pwf @ Q = 1110 bpd
- 4.9.5 e) IPR Curve