Simple Cooperative Scheduler for Arduino® ARM & AVR Aka « SCoop »

https://code.google.com/p/arduino-scoop-cooperative-scheduler-arm-avr/

Introduction

Yet another library ...

This library aims to provide a light and simple environment for creating powerful multi-threaded programs or easy multi-tasking solutions on the Arduino IDE and with the Arduino or Teensy boards using AVR or ARM processors.

There are lots of other alternatives from the best RTOS to the simplest "timer" or interrupt libraries around the World Wide Web. This one fits in between and looks easy to use and powerful enough for the most of us. It is mainly inspired by the java Thread library and use traditional switching context mechanism taken from other RTOS like ChibiOS or freeRTOS.

Let's use it

Here is an example on how to use the SCoop library with a very basic sketch:

The first line just includes the SCoop library definition file in your sketch and creates an instance of the scheduler object with the predefined name **mySCoop** which you can use later in your program to control or monitor the scheduler behavior.

The second section uses a predefine macro called **defineTask** in order to generate a code header which will create your own object inheriting from the library class called **SCoopTask**.

Then the code void Task1::setup() and void Task1::loop() are your own peace of code attached to the Task1 object which will be executed by the scheduler as if the code was in the original Arduino main setup() or loop().

The third section uses a predefine macro called **defineTaskLoop** to declare a Task2 with only a loop() method, forcing the led to blink every 100ms. The **sleep()** function replace the usual delay() and enables the scheduler to control the other task.

In the main sketch setup(), the instruction **mySCoop.start**() prepare the scheduler and launch each individual setup() method for Task2 and then for Task1 (reverse order compared to declaration).

In the main loop() the code is printing any changes to the "count" variable.

You can create as much task objects as you need as long as the microprocessor will have enough resource to hold them in memory and execute them in an acceptable time for you.

Each Task has its own "stack" context in order to hold local variables and to call other functions while remembering return address. By default the **defineTask** macro is creating an array of 150 bytes for each AVR task or 256 bytes for each ARM tasks, but this can be overridden by adding your own value as a second parameter to the **defineTask** macro. Example: defineTask (Task2,200) will provide the task with 200 byte of dedicated local stack.

It is also possible to create a task without using the **defineTask** macro, by just creating an instance of the **SCoopTask** object and calling a method later in the program to initialize your code and stack.

SCoopTask myTask; ... myTask.init(...)

How tasks works in a sketch:

The Cooperative scheduler library is responsible of tasks and events management and is organized around a very simple function called **yield()**.

This *yield* keyword (which sounds a bit weird for non-native English speaker) is part of the Arduino due Scheduler library and has been recently introduced in the standard Arduino libraires as of build >1.5. It is also part of the pirc teensy core. Some function like delay() are using it, and the principal loop() function in the Teensy core is now including a default call to yield() at the end of user code. *yield* is also used in java programing and declared in the java Thread library.

Basically, when your program is in a section of code where you have spare time, just call **yield()** and this will <u>eventually</u> go to the scheduler and switch to the next task registered in your sketch.

The scheduler will come back to the original code as soon as the other tasks also call the **yield()** function. Otherwise the process is stuck in a task and the scheduler cannot take control back again! This is why the word Cooperative is important here, compared to other preemptive RTOS.

The big advantage of Cooperative multi-tasking is that all the existing libraries will be working well in a multi-tasking environment as they will not be interrupted by a preemptive mechanism, as most of the library does not accept reentrant calls (calling a function again, before it is completed).

Task Objects in more details:

Defining a task and providing a stack:

The main idea of this library which is illustrated in the example is to consider a task as an object having its own stack and methods like **setup()** and **loop()**, which are inherited from the **SCoopTask** framework.

To create a task, just use the **defineTask** or **defineTaskRun** macro which will generate the header code for your object.

By default, a stack (an array of bytes) will be created for this object with the number of bytes declared in the second parameter. If you omit the stack-size parameter, then the array is set to a default value (150 for AVR, 256 for ARM), which is very comfortable for doing some basic computing on couple of local variables and also to call some Serial.print functions for example.

If your code needs more local variable, or if it is calling a function which needs more space, then you have to *anticipate* this by allocating more stack-size in the declaration. Unfortunately there is no easy way to calculate the maximum stack size needed, but the library contains a method called **stackLeft()** which will return the amount of memory in the stack that has not yet been used at this moment.

Once the task is declared, an object is created and the Arduino environment will automatically call the object "constructor" at the beginning of the program before entering in the main setup() or loop(). Therefore the object is automatically registered in a list of items that the scheduler will use later to start and launch each task (or events or timers) one by one.

You can declare a task yourself by instantiating the basic object **SCoopTask** and then calling the init(...) method with 3 parameters: address of the stack, size of the stack, address of the function to be called instead of the loop() method, as in the below example. In that case the **defineStack** macro can be used to facilitate the declaration of the stack array with some 8 bytes alignment needed for ARM platform:

```
SCoopTask myTask;
defineStack(mystack,128)
void mycode() { count+++; }
void setup() { myTask.init(&myStack,sizeof(mystack),&mycode); ... }
```

The call to the init() method can also be grouped with the object declaration like this:

```
defineStack(mystack,128)
  Void mycode() { count+++; }
  SCoopTask myTask(&myStack,sizeof(mystack),&mycode); // implicit call to init()
  Void setup() { ... }
```

Starting a task:

Each task defined with the **defineTask** macro is expected to have its own **setup**() method. The scheduler will launch all the setup() of all task registered in the list with the command **mySCoop.start**(). The latest task registered will be launched first (reverse order compared to declaration in your sketch).

This command should be placed inside the main setup(). It will also initializes the Scheduler and reset the variables used for counting time. After this, each task is considered "RUNNABLE" for safely entering in their specific **loop()** method.

Running and leaving the task with yield()

Each task defined with the **defineTask** or **defineTaskLoop** macro is also expected to have its own **loop**() method. The scheduler will launch this method periodically, as part of a whole scheduling process. The task code inside this loop() can be blocking forever if needed, as long as the yield() (or sleep) method is called somewhere, sometime.

The mechanism to enter in and to switch out from a task is organized by the scheduler with its **yield**() function. Calling the method yield() from a task will most likely switch to the next task in the list and return to the Scheduler when reaching the last one. Then the Scheduler will launch all pending timers or event (see later in documentation) and will restart launching the tasks one by one.

Once all the other potential tasks (and timers or events) have been executed, it will give the control back to the original task as if it was a simple return from the call to the yield() method. The execution just continues afterward.

It is recommended to systematically call yield() from the main Arduino sketch loop() by using mySCoop.yield(). This will force the loop to first launch <u>all</u> tasks and pending event/timer before executing its own loop() code. It is possible to change this behavior by setting a predefine variable called SCoopYIELDCYCLE to 0 at the beginning of the SCoop.h file, so that the Scheduler is always in control of the switching mechanisms. With this approach, the main loop() would be considered as a tower of control for all other piece of code and therefore the code inside the main loop() would have a better priority of execution as it would be executed between each task switching or event/timer launch.

Remark:

The SCoop library forces a call to yield() at the end of the user's task loop(). If you implement your own looping mechanisms (e.g. while(1) $\{ ... \}$ inside the task loop()) then the program has to call the yield() method (or sleep) time to time somewhere in the loop.

The SCoop library overrides the original Arduino yield() weak function, with the one declared by the scheduler library called mySCoop.yield(). So you can also use the simple word yield() everywhere in your program or included files. This also provide a mechanism to hook the standard Arduino delay() function, which is now calling the yield() function (only as of Arduino library >1.5) ensuring that the scheduler will be always under control of the whole program.

Ending a taks?

Not really, as the library allocates an amount of static memory for the stack, a task is not supposed to end once started! So it is up to the user to have code for stopping or starting or waiting events within the task loop(), eventually by using pause() and resume(). (see "Android scheduler" for dynamic tasks)

Method available in your task object:

Within the code of a task object, it is possible to call several methods inherited from the **SCoopTask** base object:

sleep(time**)** : same behavior as the standard delay() function, but the spare time is used to give the control back to the scheduler immediately or to execute the other pending tasks.

sleepSync(time**)**: same function as sleep, but the time to sleep is synchronized with the previous call to a sleep() or sleepSync() function, enabling a strict periodic time handling ("no jitter").

sleepUntil(Boolean**)**: just wait the Boolean <u>variable</u> to become true (and then set it to false) and give the control back to the scheduler in the meantime. It is mandatory to use volatile variable for this flag, as the status change will come from another task or from the main loop() program itself.

sleepUntil(Boolean,timeOut): (as of V1.2) same as sleepUntil, but will return anyway after the given timeOut period. It can be used as a function in an expression and return false in case of timeout.

stackLeft(): return a number of byte never used in the task stack since the task was started.

This function can also be called from the main loop() in the Arduino sketch, outside of the task object context, by referencing it with the task object itself or with a global pointer:

Cross task talking and Volatile

Nothing to do with chickens here. Due to compiler optimization, very often a variable is made local or uses a temporary register. In order to pass information across tasks or to use a variable in a multiple thread program (e.g one task is writing, the other one is reading), we have to declare the common variable as **volatile**, which forces the compiler to read and write them into memory at each access.

To simplify variable declaration, the SCoop library predefines some types for int8,16,32 and uint8,16,32 and Boolean, preceding the original Arduino type name with a "v" and removing the "_t" like:

```
vuil6 mycount; // exact same as volatile uint16_t mycount
vbool OneSecond = false; exact same as volatile Boolean OneSecond
```

Remark: the "_t" at the end has been removed voluntary but it is agreed to be a deviation to the traditional type naming convention...

Timers

The library provides a complementary **SCoopTimer** object which can be used to create periodic actions which will be orchestrated by the Scheduler. You can instantiate as many timers as you need and they can even be declared temporarily as a local object in a function or task. A timer doesn't need a stack context as you enter and you leave from a timer in a single atomic yield() operation; they use the normal stack of the main Arduino sketch. Timers have to be fast as they cannot give control back to scheduler in any case (the local yield() method is disabled). Timer looks like an MCU timer interrupt, but with the possibility to call any of your existing function or libraries from them, without risk of system crash...

Defining a Timer:

The specific macro **defineTimerRun** can be used to declare your own timer object, with 1 or 2 parameters. The first parameter is the name of your object; the second optional is the period of the timer:

```
defineTimerRun(myTimer,1000) { ticSecond=true; countSecond++ }
```

The code of this timer is implicitly attached to myTimer::run() method. It must be fast and non-blocking. The timer are registered in the same list as for the tasks and therefore will be triggered by the scheduler during a call to yield(). Once the time elapsed since the last call has reached the defined period, the run() method is executed once.

If a timer needs time to complete (say some milli-seconds), it is suggested to use a Task instead, with the sleepSync() function at the very beginning of the loop() method and some calls to yield() or yield(0) in the blocking or slow section. This code will give the exact same behavior as a timer(1000) definition:

```
defineTaskLoop(myTimer,100) { sleepSync(1000); ticSecond=true; countSecond++ }
```

Remark: In this example, we reduce the default stack size by forcing the value 100 with the second parameter, because the task loop() doesn't need that much as it doesn't call any other function and has no local variables. This is to be experimented case by case.

Starting and monitoring timer:

A call to **mySCoop.start**() will initialize all the timers registered and will enable them if the time period was provided as the second parameter of the **defineTimerRun** macro. If not, then this is up to the program to initialize this later with a call to the method **schedule**(time) (see below).

The following methods provide other means to modify or monitor the timers:

schedule(time): enable the timer and prepare it to be launched every "time" ms

schedule(time, count): same as schedule(time), adding a maximum number of execution.

getPeriod(): return the value registered for the time period of this timer.

setPeriod(): force a value for the time period.

getTimeToRun(): return the time in ms before the next execution of the timer run() method.

Other way of declaring timer with predefined macros:

defineTimer(T1,optional period) gives the possibility to declare both a T1::setup() and a T1::run() method for this object, this is useful if we want to add some setup code inside this object, instead of writing them in the main setup(): this is not backward compatible with V1.1 as the setup() is now mandatory! please rework your program to use defineTimerRun() instead, if you do not need setup().

```
defineTimer(myTimer,1000)
void myTimer::setup() { count=0; }
void myTimer::run() { count++; }
```

By extension 2 other macros can be used for defining timer class: **defineTimerBegin**(event[,period]) and **defineTimerEnd**(event). See example 2 in the library as a showcase.

Events

The library provides a complementary object **SCoopEvent** which can be used to handle code to be executed by the scheduler upon an external event or trigger. As an example, it is possible to trigger an event from an interrupt (isr, signal) but the corresponding run() code will be executed only by the scheduler, outside of the interrupt context. This enables to write complex event handling, calling library function, without the criticality needed for coding hardware interrupts.

Like the **SCoopTimer** object, the **SCoopEvent** has no stack context and is expected to be as fast as possible in order to keep the scheduling fluent. If an event needs lot of time to complete, then it should be declared as a permanent task, waiting for a volatile flag by using the **sleepUntil()** method.

Example of event declaration and usage:

```
defineEventRun(myevent) { Serial.println("trigger received"); }
isr(pin) { myevent.set(); } // or myevent=true;
```

The event object has only one public method to set the trigger flag:

set(): set the trigger flag to true. The event will be launched by the scheduler by calling yield().

set(value): set the trigger value, if false, nothing happen. If true then equivalent to set()

The event trigger flag can also be set directly by an assignment like "myevent=true", as the library overloads the standard "=" operator for this object.

defineEvent(event) can be used to define both event::setup() and event::run(), as for timers. This is not backward compatible with V1.1! please use defineEventRun(event) instead, if you do not need setup().

By extension 2 other macros can be used for defining event class: **defineEventBegin**(event) and **defineEventEnd**(event). See example 2 in the library as a showcase.

Fifo / first in first out new in V1.1

The SCoop library provides a complementary object **SCoopFifo** and a macro called **defineFifo** which will provide nice support to manage first-in first-out buffer, for bytes, integers, long or any type of structure data below 256 bytes. This can be very usefull to exchange data between task, event or timer and another task with a producer-consumer or sender-receiver model, in a synchronous way (no synchronization needed between tasks).

Here is an example on how to declare a fifo buffer of 100 integers and to use it between a timer doing analog sampling and a task using them for monitoring variation.

```
defineFifo(analogBuf,int16_t,100)
int16_t A,B;
defineTimer(anaRead,10) // read analog every 10ms
void anaRead::run() { A=analogRead(1); analogBuf.put(&A); }
defineTaskLoop(task1) {
   while(analogBuf<32) yield(0); // wait for 32 items in the buffer
   int16_t avg=0;
   for (int i=0; i<32; i++) { analogBuf.get(&B); avg += B; }
   avg /= 32; yield();
   Serial.print("average analog value for 32 samples = "); Serial.println(avg);
}</pre>
```

The **SCoopFifo** also provides the following methods:

put(& var): add the value of the <u>variable</u> to the buffer. Return true if the result is successful or false if the buffer was already full.

putChar(val) **putInt**(val) **putLong**(val) can be used to directly add a given value into the buffer, without needing an intermediate variable.

get(& var): take the older value from the buffer and store it in the <u>variable</u> passed. Return true if successful or false if the buffer was empty.

flush(): empty the buffer and return the size of the buffer (number of items) as per declaration.

flushNoAtomic(): same as flush, but doesn't touch interrupts. Should not be used in conjunction with ISR.

count(): return the amount of samples available in the buffer.

It is also possible to use the name of the object inside an integer expression which will return the same value as the method count().

<u>Virtual timer/delay: SCoopDelay and SCoopDelayus new in V1.2</u>

The SCoop library now use and provides a simple object to facilitate delays or timeout measurements, with a class named **SCoopDelay**. This looks a bit like **TimerDown** (see later in the document).

The object can be declared with or without an auto reload value. If not used, the reload storage variable will be hopefully automatically removed by the linker. If used then the timer/delay automatically starts.

Typical usage:

```
SCoopDelay time;

time = 10; while (time) yield(); // this launch yield() during 10ms

SCoopDelay t10seconds(10000);

If (T10seconds.reloaded()) { /* do something every 10 seconds */ }
```

Methods for SCoopDelay objects:

set(time): define the starting time for the delay. The delay will then start counting down to 0;

get(): return the value of the delay. if delay is elapsed, the result is 0.

add(time): add a certain amount of time to the delay

sub(time): subtract a certain amount of time to the delay

These 4 methods can also be transparently used by directly using the SCoopDelay object in an expression like x=delay or delay=x or delay+=x or delay== x. thanks to operator overloading.

elapsed(): return true if the delay is elapsed.

reloaded(): same as elapsed, but automatically restart the delay with the reload value if defined.

setReload(time): predefine and attach a reload value to the object. Same as if provided during object declaration.

getReload(): return the value of the reload parameter attached to the object.

reload(): add the reload value to the SCoopDelay object.

initReload() : set the SCoopDelay object with its reload value.

All the value are defined in int32 as defined by the **SCDelay_t** variable at the beginning of SCoop.h file.

By extension a **SCoopDelayus** object is also provided by the library, which is the same but using parameter in <u>micro seconds</u>. The values are int16 for AVR or int32 for ARM, as defined by the micros_t variable at the beginning of the SCoop.h file.

Time Counters:

The SCoop library provides 2 powerful objects, totally independent of the scheduler to handle time counting up and down. The time base for a tic count can be specified from 1ms up to 30seconds (int16). There are no limitations on the number of timer that can be declared.

TimerUp: will provide an object counting time from 0 to a maximum amount to be defined in the object declaration (can be 0). Once the maximum is reached, the counter go back to 0 and it is possible to monitor the rollover event with the **rollOver()** method in order to start an action. Example:

The object can also be used in an expression or in an assignment directly.

```
TimerUp myTime(1000);
...
void loop() {
   if (skip) && (myTime > 500) { mytime = 800; } // will read and force timer
```

The value set during the declaration for the rollover can be modified later on with the method **setRollOver**(timeMax).

TimerDown provides another type of powerful object counting down from a maximum value to 0. Once the down counting reaches 0, the counter definitely keeps the value 0, until the program force it to another value: example:

In addition, the method below can be used for TimerUp and TimerDown objects:

Init(time, timeBase): initializes the counter with a given timemax and a given time base. As an example counter.init(5,1000) will initialize the counter (up or down) with the value corresponding to 5 seconds. if it is a TimerUp then it will count from 0 to 4. If it is a TimerDown, it will count from 5 to 0.

set(time): forces a new value in the counter. This is equal to assigning a value like counter=100;

reset(): just forces the counter to 0. Also clear the rollover flag for TimerUp objects.

get(): return the value of the timer. A timer can also be read directly within an integer expression like x=counterMs;

pause(time): the timer will keep its actual value until it is resumed.

resume(): if the timer was paused, then it is resumed and start counting again from this value.

Library compilation option:

It is possible to edit the files named **TimerUp.h** and **TimerDown.h** and to change some values in the first lines, inside the #define statement, which will impact the compilation pre-processing

As an example, the time-base handling can be disabled in order to make the library more compact. Then the default time base is the millisecond. It is also possible to change the name of the original object class TimerUp (or TimerDown) by your own object name like for example TimeCounter, if preferred.

It is finally possible to force the method parameter as "int" instead of "long", but the internal timing computation remains in 32bits mode. (remark: for ARM, int is still 32bits!)

Digital Input Output and time filtering

The SCoop library provides a standalone component to define, use and filter digital inputs and outputs in a comprehensive manner by using the power of objects and the possibilities offered by operator overloading. The **IOFilter.h** library is provided mainly in the goal of eliminating bounce or for filtering and/or counting transition on any inputs, with the benefit of using scheduler orchestration and synchronous timers. But like for TimerUp and TimerDown, the library can also be used totally independently of the SCoop scheduler, and then the time filtering becomes asynchronous and depends on the user code.

Example of usage with SCoop

```
#include <IOFilter.h>
#include <SCoop.h>

Output led(13);
Input switch1(1);
InputFilter button2(2,150,100); // 150ms before HIGH, 100ms before LOW

defineTimer(debounce,20) // will check all the inputs registered every 20ms void debounce::setup() { }
void debounce::loop() { IOFilter::checkAll(0); }
...
Void setup() { led = LOW; }
Void loop() { If (button1 || (button2.count==2)) { button2.reset();led=HIGH; }
```

It is possible to use the same example without the SCoop library, just removing "scoop.h" file and the "debounce" timer definition. The filtering and counting sequence will then happen asynchronously each time the button2 inputs is read. The user code can force the filtering to be checked synchronously on a regular basis by calling the method checkAll() at some place in the program (see explanation below).

Method and class available in the IOFilter.h library:

Input myInput(pin) : define myInput as INPUT and prepare for using digitalRead(pin)

get(): read the instant value of the pin using digitalRead(pin)

myInput can be used in an integer expression (x=myInput)

readAll(): this method is a placeholder not implemented yet and still WIP in this version, but will be used to force the library to read all inputs object declared and registered in the list, in order to synchronize input value at a certain time. Then reading the pin with get() or within an integer expression will return the value memorized by the last readAll() method. This is typically useful in an industrial process or when developing a program working as a PLC cycle, enabling a programing style like with Ladder or FBD languages.

Output myOut(pin): define myOut as an OUTPUT and prepare for using digitalWrite(pin)

set(value): basically execute the digitalWrite(pin, value). The value is memorized for further reading.

get(): return the last value wrote on the pin via the set(value) command.

myOut can also be used in an integer expression (x=myOut) or in an assignment (myOut=1)

writeAll(): this method is a placeholder not implemented yet and still WIP in this version, but will be used to force the library to write all outputs object declared and registered in the list, in order to synchronize outputs update at a certain time. Then writing the output with set() or by assigning the object in a expression, will just write the new value in memory, until a user call to writeAll() is made. As for readAll(), this is typically useful in an industrial process or when developing a program working as a PLC cycle where inputs are read at the beginning of the cycle, and output written once at the end.

<u>InputFilter</u> myInputF(pin, timeOn, timeOff): define myInputF as INPUT and prepare for using digitalRead(pin) with time filtering when input raises to high (timeOn) and when input falls to low (timeOff). The value will be set to high or low only if the pin is held to this status during the time define by timeOn or timeOff

get(): return the value of the input, once filtering constrains is applied.

check(): launch a process to verify the input against the time filtering constrains. Also increment the attached counter if the pin value has changed from low to high since the last call to check().

Remark: the check() method is always launched once when the user code call the get() method, or read the input within an integer expression. This guarantees a synchronous handling of time changes and counting event if the scheduler library is not used.

count(): return the number of raising transition on the input, as detected by the check() method.

reset(): reset the counter attached to the input. Des not impact timing check constrains.

checkAll(): launch the check() method for all objects which have been declared and automatically registered (ptrInputFilter). This method will check first if the time spent since its last call is above the default threshold of 10ms, to avoid losing time where not needed. This value can be changed at the beginning of the the IOFilter.h file.

checkAll(time): provide the same behavior than checkAll(), but the time checker at the beginning of the routine will use the time parameter given instead of the default one. Using 0 will force the execution of checkAll() anyway;

remark: checkAll() and checkAll(time) are declared as static and therefore can be called by the user code without referencing a formal object, just by forcing the scope (IOFilter::checkAll()).

readAll(): placeholder not implemented yet. Same beahavior as readAll() for Input objects.

<u>InputMem</u> myBit(addr,bit) define myBit as an input returning a 0 or 1 value (low/high) by extracting the bit from the memory address provided. This is helpful for defining a comprehensive input variable attached to a bit in memory, for example a "coil" returned by a Modbus protocol an stored at a given memory address in the RAM area.

get(): return the value of the bit in memory.

The object can also be used in a integer expression (x=myBit) as the library overload the operator.

<u>OutputMem</u> myBit(addr,bit) define myBit as an output corresponding to the bit from the memory address provided. This is helpful for defining an intermediate output variable, or for defining an output attached to a memory address stored in the RAM area, like the "coil" object used in Modbus protocol.

set(value): force the bit to 0 or 1 according to value passed.


get(): return the value of the bit in memory.

The object can also be used in an integer expression (x=myBit or myBit=y) as the library overload the operator and assignment logic.

Remark: intend is to create the same type of library for Analog inputs and PWM outputs in a later version of the SCoop framework, under the name IOAnalog.h

More technical things

This picture represents the objects classes an some instances and how this works together with the standard setup() and loop() function in the Arduino sketch. This aims to illustrate the explanation given in previous chapters:



Timing measurements:

With the variable **SCoopTIMEREPORT** defined at the beginning of the **SCoop.h** file, the library will provide additional variables to control time spent in and out of a task.

If the value (N) of the predefined variable is set to 0, then none of these variables are available and the code of the library is optimized to reduce scheduler overhead time and size. If the value (N) is set to 1, 2, 3 or 4 (up to 7 for ARM), then the 4 variables below will be available in the SCoop and SCoopTask object:

SCoopTask.yieldMicros: gives the total amount of time spent in the task during the N last cycles of the scheduler.

mySCoop.cycleMicros provides the total time for the whole cycle, including time spent in the main loop(), for the N last cycles. Dividing these 2 numbers just give the ratio of cpu that has been allocated and used for the task.

cycleMicros (once divided by N) represents the average responsiveness of the scheduler. Any timer or event will be launched within this time window (unless a task needs more time at the same moment).

SCoopTask.maxYieldMicros provides the maximum value reached by yieldMicros since the scheduler has started. This can be used to identify if a task is consuming more time than expected, at some point in time. The variable is accessible in R/W and can be reset by the main sketch.

mySCoop.maxCycleMicros provides the maximum value reached by cycleMicros since the scheduler has started.

Calling yield() more often will certainly reduce the risk of having a big difference between cycleMicros and maxCycleMicros.

Remark: It is possible to define the number of cycles used to cumulate time, from 2 (default), 4, 8 or 16 by changing the value of the SCoopTIMEREPORT from 1 to 4, at the beginning of the SCoop.h file. For AVR platform these variables are only 16bits and might overfilling. For ARM it is possible to cumulate up to 128 cycles by extending these values to 5, 6 or 7 without any impact on performances.

Quantum as a way to force time spent per taks or % of CPU ...

Each task object provides a variable named **quantumMicros** for defining the amount of time that the scheduler should spend in this task before switching to another one. This guarantees that the task gets a certain amount of CPU time to proceed, relatively to the whole cycle time. When the object is initialized, this variable is set to a default value (SCoopDefaultQuantum) depending on the platform: 200us for ARM, 400us for AVR. If needed, it is possible to change this value dynamically in the program (example myTask.quantumMicros = 700;) preferably in a task setup() method. This will impact the default time spent in this task but also the length of the whole cycle as a consequence. This is a smart way to force a certain amount of CPU time ("percentage") to a task. But because the model is Cooperative, this is not committed.

Remark: When a task is using sleep() or sleepUntil() or sleepSync(), it switches back almost immediately to the scheduler if the condition is not met. Therefore the time spent in the task is seen as 0 in the yieldMicros variable, which is not entirely true as the task spent at least the time needed to check its condition \odot .

The user program can also force a parameter in micro seconds to SCoopTask::yield(x) that would be used instead of the quantumMicros for this yield(x) call only. As an example, writing "yield(100)" will ask the scheduler to check if we have spent already 100uS in this task. If yes, then the scheduler will switch to next. If not, it will return from the yield(100) immediately. With same behavior, writing "yield(0)" will just force the scheduler to switch to next task immediately, as the minimum time verification will always be true.

mySCoop.start(cycleTime) can also be used (as of V1.2) to override the default task quantumMicros by dividing the cycleTime provided as a parameter by the number of tasks registered (+1 for main loop).

If the task quantumMicros value is 0, then the SCoop library is optimizing the code, in order to systematically switch to the next task, without controlling its time spent. This reduce switching time as the yield() will not call the micros() function to compare with quantumMicros.

This can be achieved by writing mySCoop.Start(0) in the main sketch setup() or by changing the predefined variable SCoopDefaultQuantum at the beginning of the SCoop.h file.

mySCoop.start(cycleTime,mainLoop) gives the possibility to allocate a specific time to the main loop() (even 0). Remark: if mainLoop is not 0, then the scheduler will always adjust the time spent in the main loop (plus or minus) to try to guarantee a constant cycleTime!

Atomic piece of code:

Because the yield() function is now embedded in many function of the Arduino >1.5 library, it might be needed to force a piece of code to be "atomic" and not interrupted by the scheduler. Imagine an example where you setup a chip register with the wire library and you need to wait 3 ms with a delay(3) before sending a new register. In that case the library provide a 8bits global variable called **mysCoop.Atomic** that you just need to increment (mysCoop.Atomic++) at the beginning of the sensitive code and then decrement (mysCoop.Atomic--) at this end of this code portion.

When the mySCoop. Atomic variable contains a non-null value, then the yield function is just returning.

As of V1.2 a predefined macro **SCoopATOMIC** $\{ ... \}$ (same as **yieldATOMIC** $\{ ... \}$ can be used instead. This will insert the proper code at the beginning and at the end of the block code declared within brackets.

Re-entrancy protection:

Another case where we want to protect a piece of code is when a function calls yield() (like some in the Ethernet library) but the function is not re-entrant and must be protected against multiple calls from other tasks. For this a special macro calls **SCoopPROTECT**() has been introduced. same as **yieldPROTECT**(). Just use this macro at the beginning of the function to protect it and this will insert automatically some static volatile flag and some code to check if the flag is already set by a previous call. If so, the code will call yield() until the flag is reset. The flag reset is automatically inserted at the end of the bloc code in bracket, where the SCoopPROTECT() has been used.

It is possible to use **SCoopUNPROTECT**() before the end of the block code to reset the flag earlier.

Performances:

As for a preemptive OS, the performance of the SCoop cooperative scheduler depends on the time spent in the scheduler routines for checking time and switching tasks context.

SCoop is using optimized code and routine, to spend as less time as possible time in the yield() method. If the time spent in the task, since the scheduler launched it, has not reached the "quantumMicros", then yield() will return as quickly as possible in the task. If the time is over (200us AVR 400us ARM by default) then the yield() will take much more time to prepare and then switch to the next task.

SCoop is using the standard Arduino micros() function to evaluate the time spent. To grant better performances on Arduino UNO, a specific 16 bits micros function has been rewritten for AVR, leveraging most ideas used in the Teensy core. See source code for more info and copyrights.

Another key difference in Cooperative scheduling is the fact that the user code must call yield() quite often and as soon as there is spare time or a blocking piece of code. This is the only way to guarantee a smooth switching across tasks, timers and events. Therefore, the relative time spent in the yield() compared to the other activities is more important than with a preemptive OS, where the switch is triggered top-down by a periodic interrupt, say every ms. In some case, if a task is doing very simple things (e.g using sleepUntil()), the yield() might be called very often like every 10us or so, therefore the total time spent in yield() would be 100 times more than with a preemptive OS! BUT that doesn't mean that SCoop is not good. That just means that your task doesn't need this amount of CPU power and then transfer it to yield(), so don't blame SCoop © . The concept of time quantum has been introduced just for that, to make sure we continue executing a task code before switching to another one. That way, the relative time spent in yield() is reduced, and the task is guaranteed to have a certain amount of CPU resources, this is important for applications requiring computation like fft or sampling.

To evaluate the overall performance, the SCoop library is provided with an example called performance1. It shows how much "count" we can do without scheduler, and then with 3 tasks with a big and a zero quantum. Then we can see how much the time spent in the yield() impacts the number of count done during 10 seconds. By diving this difference by the number of calls made to yield() (one every 32 AVR or 128 ARM) we can calculate the avg time spent per yield()...

During 10 seconds	Max number of count in main loop() without	Time spent in SCoop yield() to check	Time spent in SCoop yield() for immediate	For reference: yield in "Android" like Arduino DUE
	scheduler	quantumMicros	switching	Scheduler.h
PanStamp 328p	3925440	5.48us	31.63us	
Arduino Uno 16M	7859200	2.64us	15.64us	
Teensy++2	7866560	2.44us	14.96us	8.42us (4.94%)
Teensy 3 ARM	153239040	1.40us	3.23us	1.57us (16.03%)
overclock 96Mhz				
Teensy 3 ARM 48M	115360320	1.66us	4.12us	_
Arduino DUE ARM	tbd	tbd	tbd	tbd

Object context vs main arduino sketch.

The SCoop library forces user to define a task as an object with its own setup and loop() function which looks cool but this brings some constrains and limitation when the program becomes big. For a better readability the task might be spread in multiple function called from the task loop().

```
void printMyStack() { ... }

defineTaskRun(task1) {
   printMyStack();
   x=x+1; sleep(100); }
```

In this situation, the function which is outside cannot access the methods from the SCoopTask object like sleep() or stackLeft() (they are not declared as static).

Remark: There is an exception with yield() as the library defines a global yield() which can be used from everywhere.

To solve this, it is possible to reference the method with the name of the object itself like task1.sleep(10), but if the function is common to multiple tasks then the code must use a global pointer **mySCoop.Task** which always contains a pointer to the task object under execution. So in this case the function printMyStack() should contain the following type of code:

```
void printMyStack() {
   Serial.println(mySCoop.Task->stackLeft());
   mySCoop.Task->sleep(100); }
```

"Android Scheduler" New in V1.2 -> SchedulerARMAVR.h

The Arduino 1.5 library for Arduino DUE board based on Atmel ARM chip is provided with a Scheduler.h library which is a very basic scheduler with task context switching involved by a global yield() method. The original source code comes from the Android team / project and this is why I simply call this library the "Android Scheduler". So what ?

The SCoop library is provided with a version of this file which is now compatible with both ARM and AVR! I have ported the code to AVR by extending the original Scheduler.h library with AVR stack switching and the result is quite good despite the poor functionalities. Because each user will be questioning which solution to use, I wanted to transparently provide this file as a possible alternative for your project. Documenting it in this user guide would be like delivering a hard copy of this guide with a gold-plated cover, and I will not © considering price of gold nowadays and as I'm working in green-it.

This scheduler is very fast but doesn't check any time quantum or time spent in a task, and this might then give very worst result for your application. Also the library doesn't provide any supporting function for fifo, time measurement or timers and event. But fine, it works. And SCoop can compensate this.

The nice (-and bad-) thing with this Android Scheduler is the possibility to start a dynamic task on the fly within the main sketch, just by calling **startLoop**(myLoop,stackSize) as you could see in the multipleBlink original example. Then the code will use the standard malloc and free function to allocate the task object and its stack from the heap. This approach is often considered as risky for small systems with low memory and very sensitive for non-expert users. The library also gives the possibility for a task to die. Then the memory is free-d on the fly creating holes in the heap.

Because you will try it and will be pleased with this library, it was important to bring SCoop almost at the same level and to make it COMPATIBLE so you can move to it now, or later ©.

When it comes to performance, this is not possible to reach the same result. The best context switch time on AVR with SCoop is 15us and this is down to 9us with the ported "Android Scheduler". BUT, SCoop might be faster at the end, as the basic yield() call will take only 2.5us if the time quantum is not spent. So don't be fooled by rough numbers.

That said, I've decided to add 2 methods in the SCoop library which gives the exact same possibility to define dynamic tasks with the same syntax: it is possible to add a task dynamically to the SCoop scheduler by calling mySCoop.startLoop(myLoop,myStack) or Scheduler.startLoop(myLoop,myStack) and to kill this task later with a call to SCoopTask::kill()!

In order to keep a pointer to this task, the good way of using this would be:

```
SCoopTask* ptrAndroid;
ptrAndroid = Scheduler.startLoop(myLoop,256);
mySCoop.start(); // or Scheduler.start();
...
while (1) {
   yield();
   if (something) ptrAndroid->killMe(); }
```

Technically this works and you can use only this way to add task to SCoop. But my personal choice is done ③. It seems also possible (according to the success with multipleBlink example) to immediately replace the use of the Android Scheduler in an existing project by just replacing the

#include <Scheduler.h> by #include <SCoop.h>, but this is to be further experienced of course.

One prerequisite is to launch a Scheduler.start() at the end of your main setup() otherwise SCoop will not start;). ("Scheduler." is the same as "mySCoop." when SCoopANDROIDMODE >= 1)

Last but not least, the kill() will work only if you change the predefined variable SCoopANDROIDMODE to 2 at the beginning of the SCoop.h header file. The reason is that I didn't want to pollute some piece of critical code in the main "SCoop::yield()" with the constrains brought by the possibility to kill a task...

After this long 20 pages reading, time for you to experience all of this and to report any feebdback or bug in the Arduino forum! . Thanks guys.