Introduction

Chapter 12 introduces Texas Instruments Built-In Operating System ("BIOS") for Digital Signal Processors - "DSP/BIOS". This firmware will allow you to use a range of a Real Time Operating System ("RTOS") features in an embedded control application. It is not the intention of this module to cover the theory of Operating Systems and the specific demands of a real time control applications. To be able to work with all options of DSP/BIOS it will be necessary for you to enrol in additional classes about this topic at your university. When you have completed these classes, it is highly recommended to return to this module after you are familiar with the theory of multi processing and real time control. With this knowledge, you can enhance the examples shown in this chapter to their full extent.

We will now have a brief look into the essentials of DSP/BIOS. We shall start with the introduction of core terms and definitions of a real time system:

- What is a RTOS?
- What is a task?
- What is the task state model?
- What is a scheduler?

Then we will discuss and use the BIOS system configuration tools to simplify the setup of a C28x code project.

Next, we will begin to get a closer look into the basic concepts of DSP/BIOS:

- Scheduler
- Hardware Interrupts (HWI)
- Software Interrupts (SWI)
- Periodic Functions (PRD)

At the end of this module we will return to the laboratory and modify one of our existing programs to use both the DSP/BIOS configuration tool and a periodic function.

Module Topics

C28x DSP/BIOS	12-1
Introduction	12-1
Module Topics	12-2
Real Time Operating System	12-3
A RTOS - Task	12-4
Task State Model	12-5
The RTOS - Scheduler	12-7
Texas Instruments DSP/BIOS	12-8
DSP/BIOS Configuration Tool	12-10
DSP/BIOS Task Groups	12-14
Periodic Functions (PRD)	
DSP/BIOS API	
Lab Exercise 12	12-21
Procedure Open Files, Create Project File	12-21
Project Build Options	
Edit DSP/BIOS Configuration	12-23
Test the code	12-25
Potential Solution for function "led runner":	12-26

Real Time Operating System

You are probably familiar with the basics of the operating system (OS) of your PC. One of the typical features of this OS is the ability to start and work on different processes simultaneously. You can open your word processor to edit a document and at the same time you can browse the web in another application process or you can check your emails. The term for this type of OS is "multi tasking". The more processes you open the more difficult it will become for your OS to respond in time. Sometimes one of your processes will be 'blocked' for a while before it continues. It becomes more difficult for the OS if dedicated hardware interactions are involved, like burning a CD/DVD. In these cases, your application probably gives out a meek recommendation like: "Do not start any other application now..." to assure that its own procedure will be completed in time.

In short, this type of OS does not guarantee any completion time for a process! Sometimes a process is not completed at all; you are no doubt familiar with the keys "CTRL-ALT-DEL".

Now imagine an embedded control application such as an autopilot of an airplane or a car braking system controlled by this type of operating system.

For this type of application, we need another type of OS that will guarantee a time line for all processes involved. We also need to know a "worst case response time" for all interactions and event processing of the control system - a "Real Time Operating System"

Real Time Operating Systems (RTOS)

What is a RTOS?

- Particular class of operating systems for digital processor systems
- ◆ Capable of serving multiple user tasks at one time ("multi-task OS")
- ◆ For all tasks in a running system it is guaranteed, that random external events in the environment of each individual task will be serviced in a given time ("Worst Case Response Time").
- ◆ All tasks must be served simultaneously ("multi-task OS") AND timely ("RTOS")
- ◆ RTOS are very popular in embedded control

12 - 2

A RTOS - Task

One of the basic terms of a RTOS is 'task'. A task is an independent portion of the whole control solution that is driven by its own program code. This owns a predefined set of resources and interacts with other tasks only by means of the RTOS. A task is characterised by its own set of state variables, its own local stack and program counter.

Real Time Operating Systems (RTOS)

What is a Task?

- ♦ A running or executable program object, that:
 - · is controlled by a portion of machine code
 - 'owns' a given set of operating resources to start/resume its course of actions
 - is characterized by a set of state variables (registers, program counter, local stack variables, semaphores, mailboxes)
- **◆** Tasks are programmed and debugged independently from each other
- ◆ Accesses to peripherals or data transfers between tasks are performed by RTOS system functions calls.

12 - 3

Tasks are designed and debugged independently from other activities of the control unit. Each task follows the design rules of the RTOS. To estimate the workload of the computing system, each task is characterized by the following timing information:


- Best case execution time (BCET) in number of CPU-cycles
- Worst case execution time (WCET) in number of CPU-cycles
- Period of task or time interval between two consecutive requests to start the task
- Amount of time for resource usage, block time
- Task "Dead Line" latest time when the task must be finished, measured from the point of requesting the task.

For a "hard"-RTOS, no task must fail to meet its Dead Line under any circumstances, throughout the whole lifetime of the control system. Most embedded systems are of this type.

12 - 4 DSP/BIOS

Task State Model

Each task will be in one of the states given in the task state model (see slide 12-4). The RTOS takes control of the current status and possible transitions for each individual state.



The states are:

- Existent The task is installed in the control system but not yet activated.
- Ready The task is activated and ready for running. It owns all necessary resources but the processor.
- Running The task is currently executing
- Blocked The task is waiting for a resource, a message, a signal or an event, which has not yet occurred.
- Completed The task has terminated and awaits a new activation.
- Not Existent The task has been cancelled permanently.

The transitions between the states of a task are explained at the next slide. It is important to remember that some of the transitions are initiated by the RTOS-Scheduler, whereas others are performed by the task that is currently in state "running".

Real Time Operating Systems (RTOS)

When does the task – state change?

- 1. A task is created by an initialization function
- 2. A task is selected by the scheduler to use the CPU
- 3. The scheduler performs a task change according to the scheduling rules of the RTOS
- 4. The running task is waiting for an external event, a message from another task or for a signal
- 5. The event that was blocking a task has occurred
- 6. The task has completed its program
- 7. The task is re-activated by another task or by an event
- 8. The task will never be used again (as long as the embedded system is not switched off)

All other task state transitions are illegal.

12 - 5

The transitions are:

- (1) A task is activated by another task. This is usually done by an initialization function during startup. Alternately, a running task needs to be supported by a new 'child' task and therefore activates a new one.
- (2) According to the rules of the RTOS, one of the tasks in the "ready" state is selected by the scheduler to use the processor.
- (3) The scheduler decides to swap the task in the "running" state with another task in the "ready" state according to the scheduling rules of the RTOS.
- (4) The "running task" waits for an external signal, for a message or for any other resource that is not available at this time.
- (5) The scheduler administrates all blocked tasks with their blocking events. If one event occurs, the blocked task will be freed and merge back into the "ready" state.
- (6) The running task has terminated.
- (7) The task is re-activated by the running task.
- (8) The task is permanently deleted from the system by the running task.

12 - 6 DSP28 - DSP/BIOS

The RTOS - Scheduler

One of the core modules of a RTOS is the scheduler. As the name implies, it schedules the execution of all tasks in a control system. It uses the task state model and the rules of the RTOS to work out how to handle multiple requests at one time. The main task of a RTOS-Scheduler is to interleave all tasks in state "ready", so that each individual task is able to meet its specified dead line.

Real Time Operating Systems (RTOS)

What is a Task - Scheduler?

- An important part of the RTOS that schedules the sequence of task execution phases and the change of task states
- Two basic operating modes for schedulers:
 - time slice mode computing time is assigned to tasks in a predefined amount of processor time
 - priority mode computing time is assigned to tasks according to the priority of each task in the system. If a task with higher priority gets into status 'ready' the running task will be pre-empted.
 - combined versions between pre-emptive and time slice schedulers are also possible

12 - 6

A scheduler is no magic trick; it follows strict rules that were defined during the system configuration of the embedded system. Depending on the ability of the RTOS, we can choose between different options to tailor the scheduler. In general, there are two basic operating modes for the scheduling rules:

- Time Slice Mode CPU time is granted to the tasks in fixed amounts of time. If the slice was consumed by the task before it could finish its operation the next "ready" task will be selected by the scheduler. The old task is suspended and will be added back at the end of the waiting list in state "ready". It will resume its operation when the next slice is granted by the scheduler.
- Priority Mode
- The scheduler uses the priority of a task to perform task switches. If there is a task in state "ready" with a higher priority than the running task, the scheduler will swap the two tasks. Some RTOS allow dynamic change of the priority depending on the current situation of the control system, others use static priorities. Common rules are "Dead Line Monotonic", "Rate Monotonic", "Earliest Dead Line First" or "Least Laxity".

12 - 7 DSP28 - DSP/BIOS

Texas Instruments DSP/BIOS

For the TMS320 family of Digital Signal Processors Texas Instruments offers a Built-In Operating System (BIOS) to support the setup of embedded control systems and to help designers to build control schemes according to the "philosophy" of Real Time Operating Systems. DSP/BIOS allow the designer to split a control project into independent sub-modules and to control the interaction between the "tasks" by means of the operating system. Instead of writing your own code to initialize and administrate interrupt vector tables, service routines and internal hardware modules, you can use standardized accesses to do so.

DSP/BIOS is available as a scalable real time kernel, it can be tailored in its size to the needs of the developer. It features all the typical functions of a RTOS and is equipped with a pre-emptive priority driven scheduler.

During debug a new real time analysis tool is available to verify the correct functionality of the system solution.

Texas Instruments DSP/BIOS

What is DSP/BIOS?

- **♦** BIOS = "Build In Operating System"
- ◆ Texas Instruments firm ware RTOS kernel for the TMS320 family of DSP's
- **♦** A full-featured, scalable real-time kernel
 - System configuration tools
 - Preemptive multi-threading scheduler
 - · Real-time analysis tools

12 - 7

DSP/BIOS is an integrated part of Code Composer Studio and can be included to any CCS project as simply as adding another source code file to an existing project. Lab12 will prove this.

12 - 8 DSP28 - DSP/BIOS

The next slide summarizes some reasons to take into account when starting a new project. Especially with the C28x and its powerful math units, it is worth considering the use of DSP/BIOS.

For most car manufacturers it is mandatory to have electronic control units equipped with RTOS functionality. If you decide to build your professional career in the automotive industry, you won't be able to skip this point.

Texas Instruments DSP/BIOS

Why use DSP/BIOS?


- ♦ Helps manage complex C28x system resources
- ◆ Allows to develop and test tasks in a multiple task control environment independently
- **♦** Reduces software project development time
- **♦** Eases software maintenance & documentation
- **◆** Integrated with Code Composer Studio IDE
 - · Requires no runtime license fees
 - Fully supported by TI and is a key component of TI's eXpressDSPTM real-time software technology
- ◆ Uses minimal MIPS and memory (2-8K)

12 - 8

DSP/BIOS Configuration Tool

The following slide highlights all major blocks of DSP/BIOS. They are:

- The System Configuration Tool ("System")
- The Real-Time Scheduler ("Scheduling")
- The Real-Time Analysis Tool ("Instrumentation")
- The Task Synchronisation Module ("Synchronisation") and
- The Real-Time Data Exchange Support ("Input/Output")




The first part of DSP/BIOS that will be useful during the set-up of a CCS project is the System Configuration Tool. In general, this tool will replace the handwritten linker command file that we have used so far in our lab exercises. With the help of the Configuration Tool, we can define new sections of physical memory and connect logical software segments to memory locations ("MEM"). Global settings, like defining the stack size, are also done within this tool. In Lab exercise 12, we will use this tool to setup the linker environment.

With the help of the scheduler group, we can configure the different tasks that are part of the project. There are four different groups of tasks available: Hardware – Interrupts ("HWI"), Software Interrupts ("SWI"), Tasks ("TSK") and Periodic Functions ("PRD"). We will use the scheduler part to connect RTOS-function to our software modules.

12 - 10 DSP28 - DSP/BIOS

DSP/BIOS Task Groups


If we look into a typical development cycle of a project that is not driven by an OS, we will face the following design problem:



A new function is to be added to our existing project. A professional embedded system designer would NOT start immediately with the new coding and hope that afterwards everything will work as expected. That would be the 'trial and error' method and is no good at all for safety critical applications. Instead, a serious developer would try to answer the following questions first:

- How much computing power is still available BEFORE we add a new function?
- How much storage capacity will the new function need? Is there enough code memory left?
- What type of resources will be needed by the new function? Are there potential conflicts with other functions in the system?
- Are there any interactions, synchronisations or message transfers between the new function and the existing functions needed?
- What is the deadline of the new function, once it is called? What is the estimated computing time for the new function?
- Do I have to prioritize the new function against others? Are there consequences for the execution of other functions, when I have to modify the priorities of existing functions?

If the new system seems feasible and we do not have an OS-support, we could add the new function as shown at the next slide:



This is a simple solution that might work for a few projects. But with this scheme we can face new problems:

• What if function 1 has to be executed more frequently than function 2? Answer: we could call function 1 more than once before we call function 2:


```
while(1)
{
    function_1();
    function_1();
    ...
    function_1();
    function_2()
}
```

• But what if function2 takes too long to execute? We might reach the next call of function1 too late for its real time interactions! In this case we would have to completely re-write function2, split it into several parts and interleave calls to function1. The resulting code would not look structured at all!

Obviously there must be a more appropriate way for this type of real-time programming!

12 - 12 DSP28 - DSP/BIOS

If you already have some basic experience with microprocessors, you may have suggested using interrupts instead of the function loop in solution1. This principle is shown with the next slide:



We distribute all functions into dedicated Interrupt Service Routines (ISR). The main function will perform basic initialization routines for the project like system setup, memory initialization, peripheral unit setups, enabling of desired interrupts, prepare timer periods etc. At the end of main the code will stay in an idle-loop, in C usually coded as "while(1);" or "for(;;);". When one of the hardware units, for example a timer, calls its ISR, the assigned function will be executed. After finishing this ISR the processor will return to main's idle-loop and await the next interrupt.


Our previous example could use a first timer that is initialized to a period of $50\mu s$ and a second timer with a period of 0.5s. All we would have to do is to connect timer 1 interrupt service to function 1 and timer 2 to function 2.

This principle will work fine for most of the time, but sometimes our control unit will behave unexpectedly. Why is this?

If the processor executes function 2 and at the same time function 1 is requested by timer 1 ISR, the processor will finish function 2 first before it deals with the next request. In this case the execution of function 1 will be delayed. In best cases our system will behave a little bit sluggishly, in worst cases the motor that is controlled by function 1 will change from full forward to full reverse....

Hardware Interrupts (HWI)

The usual back door way out of this dilemma is using interrupts that can be interrupted by other interrupts. This principle is called 'nested' interrupts and is usually the best solution for this type of real-time projects. Nesting interrupts requires the save of the environment (registers, stack pointer, flags etc) and status of the running interrupt before the processor can switch to the next interrupt service. Before the processor can switch back to the interrupt that was paused, the status must be restored. This principle is called 'context save & restore'. If you do not have the support of an OS, you would be responsible to take care of these additional steps. Or, your C-compiler adds context save & restore functions automatically – usually when you mark a function with keyword "interrupt".




In case of DSP/BIOS the OS itself takes care of context switch. The Texas Instruments syntax for nested interrupts is called "Hardware Interrupt (HWI)". For the C28x we can assign one HWI function for each physical interrupt line INT1-INT14.

NOTE: To use DSP/BIOS as background task system, we have to leave the main function after all initialization is done! Make sure that you do not have any endless loop construct still in your main – code.

DSP/BIOS will call its own idle – function if there are no other activities necessary at the moment.

12 - 14 DSP28 - DSP/BIOS

To adapt a non-DSP/BIOS code for interrupt service routines you will have to delete the keyword "interrupt' from an existing service routine.



Next you will have to tell the DSP/BIOS configuration tool to take care of context switches. Open the configuration database file (*.cdb) and click on

→ Scheduling → HWI Hardware Interrupt Service Routine Manager

Expand the '+'-sign in front of HWI, click right on the HWI that you want to modify (e.g. "HWI_INT1") and select "Properties"


Under "General" you can specify the name of the function that you'd like to connect to this HWI, e.g. _MyHwi. The underscore in front of the name of the function is mandatory to indicate a C code function.

Under "Dispatcher" enable the box "Use Dispatcher", this will include the context save and restore functions that are needed to allow nested hardware interrupts.

Software Interrupts (SWI)

The next group of DSP/BIOS functions is called "Software Interrupts (SWI)". As the name says, this group of functions is initiated by software requests. The difference to HWI's is that the user has more flexibility in the system design when using software interrupts. Whilst the priority of all hardware interrupts is given by the C28x and can't be changed at all, the user has full flexibility to assign priorities to software interrupts as static or dynamic priorities. The number of software interrupts is not limited by DSP/BIOS; of course the number of feasible software interrupts depends on the computing time that is consumed by all software interrupt functions.





- Make each algorithm an independent software interrupt
- ♦ SWI scheduling is handled by DSP/BIOS
 - ◆ HWI function triggered by hardware
 - SWI function triggered by software e.g. a call to SWI_post()
- ♦ Why use a SWI?
 - ◆ No limitation on number of SWIs, and priorities for SWIs are user-defined
 - SWI can be scheduled by hardware or software event(s)
 - ♦ Relocate task processing from HWI to SWI


12 - 15

A recommended principle is to limit the length of hardware interrupt service routines to an absolute minimum, just what is necessary to deal with the hardware event. All other activities that must be executed due to the hardware event are relocated into software interrupt services. The HWI schedules all actions that should follow the hardware event. Thus the DSP/BIOS controlled project is most flexible.

12 - 16 DSP28 - DSP/BIOS

Periodic Functions (PRD)

Another group of DSP/BIOS objects are called "Periodic Functions". They are based on multiples of the DSP/BIOS system clock and are usually used to call a function at equally spaced time intervals, e.g. blinking a LED. Recall our previous lab exercises where we used one of the C28x core timers or an event manager timer just to create a period for a next event. We can simplify these exercises by replacing all the timer functions by a periodic DSP/BIOS function!




- ◆ Periodic functions run at a specific rate in your system:
 - e.g. LED blink requires 0.5 Hz
- ◆ Use the CLK Manager to specify the DSP/BIOS CLK rate in microseconds per "tick"
- ◆ Use the PRD Manager to specify the period (for the function) in ticks
- Allows multiple periodic functions with different rates

12 - 16

First we have to specify the DSP/BIOS clock rate ("ticks") in microseconds per tick. This is done with the CLK Manager of the Configuration Tool.


Next we can use the Periodic Function Manager ("PRD") to define the period for a specific function in number of 'ticks'. We also have to connect the PRD-event with a function from our source code.

The procedure for creating a periodic event in DSP/BIOS is shown at the next slide. Later in lab exercise 12 we will use a periodic function to modify the status of our 8 LED output lines periodically.



The two steps to prepare a periodic function are shown at the slide:


Finally, to start DSP/BIOS we have to terminate the main function:



12 - 18 DSP28 - DSP/BIOS

Real-Time Analysis Tool

Important test support tools for RTOS based projects are analysis tools to measure and document the efficiency and the feasibility of the implementation. This includes graphical displays for resource usage, CPU load, the sequence of task changes during test runs and measurement tools for blocking times of resources by individual tasks. At the end of the day the designer must answer all the questions that we have discussed at beginning of this module with solid facts. A widely used tool that is used to support these debug and test phases is a logic analyzer, used in combination with a real time data logging system.



Texas Instruments provides some of these support tools as integrated parts of DSP/BIOS. The Execution Graph shows the flow and interleaving of tasks and interrupts on a time base. The CPU Load Graph gives a graphical view of the C28x computing time that is used by the whole project, excluding the DSP/BIOS idle function.

Another tool is the "Event Log Manager (LOG)". In order to send debug information about the sequence of instructions to a terminal window a designer quite often uses 'printf'- instructions. The disadvantage is the modification of the code by these additional instructions. With DSP/BIOS we can use the LOG – window for this purpose. All logging instructions will be executed by the OS in background, hence not delaying the original flow of program execution.

DSP/BIOS API

The next slide is a summary of all API Modules that are part of DSP/BIOS. In the next lab exercise we will use the Memory Manager (MEM), System Clock Manager (CLK) and Periodic Function Manager (PRD).

Instrumentation/Real-Time Analysis		TSK C	Communication/Synchroniza	
		SEM	Semaphores manager	
LOG	Message log manager	MBX	Mailboxes manager	
STS	Statistics accumulator manager	LCK	Resource lock manager	
TRC RTDX	Trace manager Real-Time Data eXchange manager	Devic	Device-Independent Input/Output	
Thread Types		PIP	Data pipe manager	
		HST	Host input/output manager	
HWI	Hardware interrupt manager	SIO	Stream I/O manager	
SWI	Software interrupt manager	DEV	Device driver interface	
TSK IDL	Multi-tasking manager Idle function & process loop manager	Memo	ry and Low-Level Primitives	
Clock and Periodic Functions		MEM	Memory manager	
		SYS	System services manager	
CLK	System clock manager	QUE	Queue manager	
PRD	Periodic function manager	ATM	Atomic functions	
		GBL	Global setting manager	

12 - 20 DSP28 - DSP/BIOS

Lab Exercise 12

Lab 12: Modify Lab 2 to use BIOS

- Use your solution for Lab2 to begin with
- Modify the project to use DSP/BIOS functionality
- Let DSP/BIOS create the necessary Linker Command Files
- Replace the software delay loop from Lab2 by a periodic function ("PRD") of DSP/BIOS
- Create a new function "led_runner()" that will activate the next state of the LED-line
- Call this function every 500ms with a PRD-function out of DSP/BIOS
- · For a detailed procedure see textbook!

12 - 21

Objective

The objective of this laboratory exercise is to implement the code from Lab2, this time using DSP/BIOS periodic functions rather than a simple software delay loop to generate the time separation.

Instead of using the linker command file from Lab2 we will use the DSP/BIOS Configuration Tool to auto generate the linker information

We will add a periodic function (PRD) to the DSP/BIOS system that will be used to execute the next state of our control sequence.

Procedure

Open Files, Create Project File

- 1. Create a new project, called **Lab12.pjt** in E:\C281x\Labs.
- 2. Open the file Lab2.c from E:\C281x\Labs\Lab2 and save it as Lab12.c in E:\C281x\Labs\Lab12.

- 3. Add the source code file to your project:
 - Lab12.c
- 4. From *C:\tidcs\c28\dsp281x\v100\DSP281x headers\source* add:

DSP281x_GlobalVariableDefs.c

5. This is the first exercise in which we are using the DSP/BIOS. This requires a new linker command file to be added to our project. The new command-file, also provided by Texas Instruments with the peripheral header files, excludes the PieVectorTable structure from the project.

From C:\tidcs\c28\dsp281x\v100\DSP281x headers\cmd add:

F2812_Headers_BIOS.cmd

- 6. The DSP/BIOS itself will include the C environment library files into the project. There is no need to add the file "rts2800 ml.lib" manually.
- 7. Next we have to create a DSP/BIOS Configuration File (*.cdb). Select:

File → New → DSP/BIOS Configuration

From the next window select the template "c28xx.cdb" to begin with. Save the new configuration file as "lab12.cdb".

8. Add the configuration file to your project:

Project → Add Files to Project → lab12.cdb

9. The DSP/BIOS configuration has automatically generated a new linker command file "lab12cfg.cmd", which must be added to our project manually:

Project → Add Files to Project → lab12cfg.cmd

Project Build Options

10. Setup the search path to include the peripheral register header files. Click:

Project → Build Options

Select the Compiler tab. In the preprocessor Category, find the Include Search Path (-i) box and enter:

C:\tidcs\C28\dsp281x\v100\DSP281x_headers\include; ..\include

Close the Build Options Menu by Clicking **<OK>**.

12 - 22 DSP/BIOS

NOTE: Do NOT setup the stack size inside the Build Options! It will be done with the help of the DSP/BIOS configuration tool later.

Modify Source Code

11. Open Lab12.c to edit.

Disable the Watchdog Timer:

In function "InitSystem" make sure to disable the watchdog timer (register WDCR). For the first DSP/BIOS – Test we would like to keep the code as simple as possible. Later, if the code works, we can easily expand our test setup.

Delete function "delay loop":

Recall, in lab2 we used a software delay function for the interval between the LED-output instructions. For lab12, all timing will be done by DSP/BIOS.

Delete the endless "while(1)" construct in "main":

At the end of "main" DSP/BIOS will take care about the background activities and the timing of all active tasks. If we do not return from main, DSP/BIOS will not start.

Add a new function "led_runner()" at the end of your code:

This new function will be called by DSP/BIOS periodically. The code inside this function should copy the next value from array LED[8] to the LED-lines.

Remove variable "i" and "LED[8]" from "main" and add them at the beginning of this new function. Declare them as "static" and initialize "i" to 0.

Increment "i" with each call of function "led_runner" and load the next value out of "LED[8]" into register "GpioDataRegs.GPBDAT.all".

Do not forget to reset i to 0 after the end of the sequence was reached!

Edit DSP/BIOS Configuration

12. Open File "lab12.cdb".

"MEM - Memory Section Manager"


Inspect the "System" Category by expanding the '+' sign in front. Click right on "MEM – Memory Section Manager" and select "Properties". Verify that in the "General"- Folder the Stack Size has already been defined as 0x0200. This is a default value for the stack size that was initialized when we created the configuration file. If necessary for larger project, this size can be adjusted here. For now, just keep the default value.

Next, move to the "Compiler Sections" tab. This table controls the connection of code sections to physical memory in an identical way, to which we used in our handmade linker command files. When we edit the configuration, this table will be used by CCS to auto-generate the linker command file "lab12cfg.cmd", which is already part of our project. For now, just keep the table with its default values.

Close the "MEM" – menu by clicking <OK>.

"CLK" - Clock Manager

Right click on "CLK" and select "Properties". Enable "Use high resolution time for internal timings" and set the number of microseconds per interrupt to 1000.




"PRD - Periodic Function Manager"

Expand the "Scheduling" Category. For lab12 we would like to add a periodic function to our project. Click right on "PRD – Periodic Function Manager" and select "Insert PRD". A function "PRD0" will be created.

Rename "PRD0" to "LED_Line".

Next, click right on "LED_Line", select "Properties" and edit the general properties of this object. Edit the number of ticks from 65535 to 500. This is the period of the function call in milliseconds. In field "function" enter "_led_runner". Do not forget the leading underscore!

12 - 24 DSP/BIOS



Build the project

13. Click the "Rebuild All" button or perform:

Project → **Build**. If build was successful you'll get:

Build Complete, 0 Errors, 0 Warnings, 0 Remarks.

Test the code

- 14. Test the project with the debugger by hitting <F5>. The LED line should show the next value after 500ms. The amazing thing is that our code never calls this function; it is called by the scheduler-task of DSP/BIOS every 500ms.
- 15. Let's have a final look into the source code. The main function consists of only 2 function calls:

```
void main(void)
{
    InitSystem();
    Gpio_select();
}
```

After returning from "Gpio_select()" main itself terminates! For a standard embedded systems program this would be most strange because leaving "main" would definitely cause a system crash.

In case of lab12 with DSP/BIOS supporting a background task, the DSP/BIOS-scheduler, takes care of further activities.

16. You can experiment with different time intervals for the call of function "led_runner" by changing the period property of PRD-function "LED_Line" in the DSP/BIOS configuration file "Lab12.cdb".

Potential Solution for function "led_runner":

12 - 26 DSP28 - DSP/BIOS